



Service Bulletin

W-103

Models 247D523B190 & 247D585C190 LOG SPLITTERS
 Date May 7, 1997
 Subject CYLINDER SERVICE

Hydraulic cylinders on log splitters are designed to be reliable and easy to service. If a cylinder should leak, follow the rebuilding instructions below.

Model 247D585C190 Log Splitters are equipped with one of two manufacturers of cylinders **Fisher or Best**. When working on this particular model, the manufacturer of the cylinder can be determined by referring to the chart at the end of this bulletin.


OBSERVE ALL WARNING AND CAUTIONS WHEN SERVICING LOG SPLITTER

- 1 Remove cylinder and drain all fluid
 - 2 With the body of cylinder held firmly, place a sleeve over rod and tap cap inward. The rod cap must be pushed inward into cylinder body enough to clear retaining ring. **NOTE** To remove rod cap without retaining ring, unscrew threaded cap using a spanner wrench or carefully use a punch and hammer. The *Best* cylinder will utilize a threaded rod cap.
 - 3 Pry retaining ring out of the groove in cylinder body. Discard and order new retaining ring.
 - 4 Grasp end of rod and pull piston and rod assembly from tube.
 - 5 Remove all seals being careful not to scratch any parts.
 - 6 Inspect all components and seals for uneven wear and/or contamination. Small scratches in cylinder tube or on rod may be removed with fine emery cloth. Replace cylinder if components show excessive roughness.
- NOTE Do not re-machine cylinder components because of the safety risks involved. Any alterations are not only dangerous to the cylinder, but to any persons in the vicinity of the log splitter.**
- 7 If the piston needs to be removed from rod, secure rod in a vise using soft brass jaws and remove piston nut turning counterclockwise. Remove piston and O-ring from cylinder rod.
 - 8 Wash all parts with clean solvent and wipe dry with a clean lint-free cloth. **KEEP PARTS CLEAN**. Thoroughly clean inside diameter of the tube assembly and all seal grooves.
 - 9 Remove new O-rings and seals from packaging and place on a clean dry surface. Before installing O-rings and seals, lubricate with clean hydraulic fluid.
 - 10 If piston was removed from rod, install O-ring on the piston rod shank.
 - 11 Slide piston onto shank being careful not to damage O-ring or threads. Insure piston shoulders are fully against rod.

- 12 With rod held firmly in a soft brass jawed vise, tighten piston nut to 60 to 70 ft-lbs Using original punch marks on nut, center punch the inside diameter of the threaded portion of nut to keep nut in position
- 13 Install ring and backup washer in the piston seal groove
- 14 Lubricate inside diameter of the tube assembly and outside diameter of piston assembly with clean hydraulic fluid and slide piston into tube
- 15 Install rod wiper in the rod cap, as shown below, by tapping it in place with soft mallet Next, install rod seal in the center groove in rod cap Then install U-ring in rod cap groove In the outside groove of rod cap, install the O-ring and backup washer NOTE The U-ring and O-ring faces the pressure side of the cap
- 16 Prior to installing rod cap, check rod end for burrs or nicks that would damage the seals and polish smooth
- 17 Lubricate rod cap seals and rod Slide rod cap over rod With a soft mallet, tap rod cap into cylinder body enough to clear the rod cap locking ring groove
- 21 Carefully secure with new locking ring into the groove making sure ring is fully seated in the groove
- 22 Install cylinder on unit
- 23 Upon reassembly, cycle unit to reseal and properly position rod cap in cylinder body This procedure should be done before returning the unit to service

Seal Kit Chart

247B523E19D	753-0564	753-0691
use	FISHER CYLINDER (ID STAMP "F") use	BEST CYLINDER (ID STAMP "B") use
753-0637 Seal Kit	753-0564 Seal Kit	753-0691 Seal Kit



Warranty Allowance Normal warranty terms will apply

Service Manager	Parts Manager	Service Tech	Service Tech	Service Tech

Circulate and Initial