



MODEL }
MODÈLE } **4 0**

OVERSIZED SCREW

In order to repair any broken threads in the composite material, (e.g. in the crankcase), an oversized screw is introduced,

Reference number 503 21 22-01 Screw

Assembly

- Remove parts from the broken thread from the hole.
- Drill up the holes in the parts, where the screw goes through, to size $\varnothing$ 6.0 mm, (e.g. the holes in the starter housing),
- Assemble the screw 503 21 22-01.

VISSURDIMENSIONÉE

Nous tenons à votre disposition une vis surdimensionnée pour les réparations des filetages défectueux clans le matériau composite (par ex. le carter moteur).

Numéro de référence 5032122-01.

Montage

- Enlever le filetage défectueux.
- Aléser à $\varnothing$ 6,0 mm les trous clans les pièces qui sent traverses par la vis (par ex. les trous du lanceur).
- Monter la vis 5032122-01.