

92500 to 92599

SERVICE ENGINE



SALES MANUAL

**MODEL 92500 SERIES ENGINES REPLACED WITH
 STANDARD SERVICE ENGINES**

In most cases, the Original Type numbers shown may be replaced by a Service Type Number without making any changes. Necessary changes of engine parts such as crankshafts, reduction parts, blower housings, etc., are noted. Other differences, such as mufflers, elbows, deflectors, etc., are not listed but are very important for safety and engine performance. Be sure the exhaust system on the replacement engine duplicates the system originally selected by the equipment manufacturer. Parts that are suitable for additional use should be transferred. Before making any conversion, check the data shown in the column labeled "REMOVE, ADD and NOTE." See if the changes, which are shown, are actually necessary on the application in question. Often a standard service engine will be a WORKABLE replacement without converting to such things as a special fuel tank or starter position.

If the crankshaft number does not appear in the "Original Engine" column, consult the Illustrated Parts List for the correct service replacement crankshaft number.

Engine Replacement Notes:

NOTE 25: If the replacement engine supersedes to or is a Model 120000 series engine, refer to the illustrations located after the conversion data for this model series. The overall dimensions that differ, are shown in the illustrations. If after making a visual inspection and it is determined the Model 120000 series engine cannot be used because of equipment interference, the original engine should be repaired with individual parts.

NOTE 73: Transfer Flywheel Assembly to the replacement engine.

Short Block Notes:

The SHORT BLOCK part number shown, is the assembly which can be used to rebuild the Original Type Number. If a letter appears after the short block number, it indicates the short block must be modified. The change denoted by each letter is as follows:

NOTE PP: Change Drive Shaft in Short Block. Remove 230831. Add 231213.

92500 to 92599

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0115	92502	260124	9M902	0015						All	3500			
0116	92502	260096	9M902	0016						All	3500			
0117	92502	260097	No Replacement Repair With Individual Parts.								All	3500		
0118	92502	260098	9M902	0018						All	3500			
0120	92506	260124	9M902	0015					73	All	3500			
0121	92506	260096	9M902	0016						All	3500			
0122	92506	260097	No Replacement Repair With Individual Parts.								All	3500		
0123	92506	260098	9M902	0018						All	3500			
0125	92592	260099	No Replacement Repair With Individual Parts.								All	3500		
0127	92582	260911	No Replacement Repair With Individual Parts.								All	3500		
0128	92582	260912	No Replacement Repair With Individual Parts.								All	3500		
0129	92582	260913	No Replacement Repair With Individual Parts.								All	3500		
0130	92582	260914	No Replacement Repair With Individual Parts.								All	3500		
0131	92586	260911	No Replacement Repair With Individual Parts.								All	3500		
0132	92596	260099	No Replacement Repair With Individual Parts.								All	3500		
0133	92502	260096	9M902	0016						All	3300			
0134	92502	260124	9M902	0015					73	All	3500			
0135	92502	260124	9M902	0015					73	All	3500			
0136	92502	260370	No Replacement Repair With Individual Parts.								All	3300		
0139	92502	260124	9M902	0015					73	All	3500			
0140	92502	260856	No Replacement Repair With Individual Parts.								All	3500		
0141	92502	260097	No Replacement Repair With Individual Parts.								All	3500		
0142	92502	260124	9M902	0015						All	3500			
0143	92502	260124	9M902	0015					73	All	4000			
0144	92502	260124	122K02	0515	1	690319	1	691851	25	All	3500			
0145	92506	260124	9M902	0015					73	All	3500			
0146	92502	260204	No Replacement Repair With Individual Parts.								All	3500		
0147	92502	260096	9M902	0016						All	3300			

92500 to 92599

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0148	92502	260124	9M902	0015							All	3500		
0149	92502	260124	9M902	0015					73		All	4000		
0150	92502	260670	No Replacement Repair With Individual Parts.								All	3500		
0151	92502	260124	9M902	0015					73		All	3300		
0152	92506	260670	No Replacement Repair With Individual Parts.								All	3500		
0153	92502	260098	9M902	0018					73		All	4000		
0154	92502	260124	9M902	0015							All	4000		
0155	92502	260097	No Replacement Repair With Individual Parts.								All	4000		
0156	92502	260124	No Replacement Repair With Individual Parts.								All	4000		
0157	92582	260914	No Replacement Repair With Individual Parts.								All	4000		
0158	92502	260096	9M902	0016							All	3300		
0159	92502	260124	9M902	0015							All	3500		
0160	92502	260124	9M902	0015							All	3500		
0161	92502	260098	No Replacement Repair With Individual Parts.								All	4100		
0162	92502	260096	9M902	0016							All	3500		
0163	92502	260097	No Replacement Repair With Individual Parts.								All	3500		
0164	92501	260097	No Replacement Repair With Individual Parts.								All	3300		
0165	92502	260124	9M902	0015							All	4000		
0166	92592	260224	No Replacement Repair With Individual Parts.								All	4100		
0167	92502	260097	No Replacement Repair With Individual Parts.								All	3500		
0168	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500		
0169	92502	260124	9M902	0015							All	3500		
0170	92502	260096	9M902	0016							All	3500		
0171	92592	260099	No Replacement Repair With Individual Parts.								All	3300		
0172	92502	260098	122K02	0518	1	492177	1	492893	25		All	4100		
						1 690319	1	691290						
0173	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500		
0174	92502	260124	9M902	0015							All	4000		
0175	92502	260319	No Replacement Repair With Individual Parts.								All	3500		
0176	92502	260096	No Replacement Repair With Individual Parts.								All	3500		
0177	92502	260124	9M902	0015					73		All	3500		
0178	92582	260913	No Replacement Repair With Individual Parts.								All	4000		
0179	92502	260670	No Replacement Repair With Individual Parts.								All	3500		
0180	92502	260319	122K02	0516	1	492177	1	492893	25		All	4000		
0181	92506	260096	9M902	0016							All	3300		
0182	92502	260124	9M902	0015							All	3500		
0183	92502	260097	No Replacement Repair With Individual Parts.								All	3500		
0184	92506	260124	9M902	0015							All	3500		
0185	92502	260124	9M902	0015							All	3500		
0186	92501	260098	No Replacement Repair With Individual Parts.								All	3500		
0187	92502	260098	No Replacement Repair With Individual Parts.								All	3500		
0188	92502	260096	9M902	0016							All	3500		
0189	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500		
0190	92502	260098	122K02	0518	1	690319	1	691290	25		All	4000		
0191	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500		
0192	92502	260098	122K02	0518	1	690319	1	691290	25		All	4000		
0193	92502	260670	No Replacement Repair With Individual Parts.								All	3500		
0194	92506	260670	No Replacement Repair With Individual Parts.								All	3500		
0195	92502	260124	122K02	0515	1	690319	1	691290	25		All	4000		
0196	92506	260096	9M902	0016							All	3500		
0197	92502	260124	122K02	0515	1	690319	1	691290	25		All	4000		
0198	92502	260096	9M902	0016							All	3500		
0199	92596	260244	No Replacement Repair With Individual Parts.								All	3500		
0200	92502	260124	9M902	0015					73		All	4000		

92500 to 92599

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
0201	92502	260096	122K02	0516	1	262665	1	262654	25		All	4000			
					1	492177	1	492893							
0202	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500			
0203	92586	260914	No Replacement Repair With Individual Parts.									All	4000		
0204	92592	260224	No Replacement Repair With Individual Parts.									All	3500		
0205	92502	260839	No Replacement Repair With Individual Parts.									All	3500		
0206	92502	260124	122K02	0515	1	690319	1	691290	25		All	4000			
0207	92502	260124	9M902	0015					73		All	3500			
0208	92502	260097	No Replacement Repair With Individual Parts.									All	3500		
0209	92502	260124	122K02	0515	1	690319	1	691851	25		All	3300			
0210	92502	260098	122K02	0518	1	492177	1	492893	25		All	4000			
					1	690319	1	691290							
0211	92502	260096	9M902	0016							All	4000			
0212	92502	260096	9M902	0016							All	4000			
0213	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500			
0214	92502	260097	No Replacement Repair With Individual Parts.									All	3500		
0215	92592	260099	No Replacement Repair With Individual Parts.									All	3500		
0216	92502	260096	9M902	0016							All	3500			
0217	92502	260124	No Replacement Repair With Individual Parts.									All	3500		
0218	92502	260124	No Replacement Repair With Individual Parts.									All	3500		
0219	92592	260224	No Replacement Repair With Individual Parts.									All	3500		
0220	92502	260096	9M902	0016							All	3500			
0221	92501	260098	122K02	0518	1	690319	1	691851	25		All	3500			
0222	92502	260411	No Replacement Repair With Individual Parts.									All	4000		
0223	92502	260096	9M902	0016							All	4000			
0224	92502	260096	9M902	0016							All	3500			
0225	92506	260096	9M902	0016							All	3500			
0226	92502	260370	No Replacement Repair With Individual Parts.									All	4000		
0227	92502	260235	122K02	0515			1	93061	25		All	3300			
0228	92506	260096	9M902	0016							All	3300			
0229	92502	260957	No Replacement Repair With Individual Parts.									All	3500		
0230	92506	260957	No Replacement Repair With Individual Parts.									All	3500		
0231	92502	260957	No Replacement Repair With Individual Parts.									All	3500		
0232	92506	260098	122K02	0518	1	690319	1	691851	25		All	3500			
0233	92502	260096	9M902	0016							All	3500			
0234	92506	260097	No Replacement Repair With Individual Parts.									All	4000		
0235	92506	260098	122K02	0518	1	690319	1	691851	25		All	3500			
0236	92502	260096	122K02	0516					25		All	3300			
0237	92502	260096	122K02	0516					25		All	3300			
0238	92502	260124	9M902	0015							All	3500			
0239	92506	260096	9M902	0016							All	3500			
0240	92506	260124	No Replacement Repair With Individual Parts.									All	3500		
0241	92502	260400	No Replacement Repair With Individual Parts.									All	3300		
0242	92502	260370	No Replacement Repair With Individual Parts.									All	3300		
0243	92582	260912	No Replacement Repair With Individual Parts.									All	3300		
0244	92586	260912	No Replacement Repair With Individual Parts.									All	3300		
0245	92502	260957	No Replacement Repair With Individual Parts.									All	3500		
0246	92506	260957	No Replacement Repair With Individual Parts.									All	3500		
0247	92502	260957	No Replacement Repair With Individual Parts.									All	3500		
0248	92506	260124	9M902	0015					73		All	3500			
0249	92502	260096	9M902	0016							All	3500			
0251	92592	260099	No Replacement Repair With Individual Parts.									All	3500		
0252	92506	260097	No Replacement Repair With Individual Parts.									All	3500		
0253	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500			

92500 to 92599

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0254	92502	260856	No Replacement Repair With Individual Parts.								All	3500		
0255	92502	260124	122K02	0515	1	690319	1	691851	25		All	3300		
0256	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500		
0257	92502	260098	122K02	0518	1	492177	1	492893	25		All	4000		
					1	690319	1	691290						
0258	92502	260098	122K02	0518	1	492177	1	492893	25		All	4000		
					1	690319	1	691290						
0259	92586	260914	No Replacement Repair With Individual Parts.								All	4000		
0260	92506	260204	No Replacement Repair With Individual Parts.								All	3500		
0261	92502	260096	9M902	0016							All	3500		
0262	92502	260098	122K02	0518	1	690319	1	691852	25		All	3300		
0263	92502	260096	9M902	0016							All	3300		
0264	92582	260911	No Replacement Repair With Individual Parts.								All	3500		
0265	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500		
0266	92502	260096	9M902	0016							All	3300		
0267	92502	260096	9M902	0016							All	3300		
0268	92502	260096	9M902	0016							All	3500		
0269	92502	260097	No Replacement Repair With Individual Parts.								All	3300		
0270	92502	260097	No Replacement Repair With Individual Parts.								All	4000		
0271	92502	260096	9M902	0016							All	4000		
0272	92506	260124	9M902	0015					73		All	3300		
0273	92502	260957	No Replacement Repair With Individual Parts.								All	3500		
0274	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500		
0275	92502	260096	122K02	0516					25		All	3300		
0276	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500		
0277	92502	260096	122K02	0516	1	690319	1	691851	25		All	3500		
0278	92502	260957	No Replacement Repair With Individual Parts.								All	3500		
0279	92582	260912	No Replacement Repair With Individual Parts.								All	3300		
0601	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500		
0602	92502	260096	9M902	0016							All	3500		
0603	92502	260097	No Replacement Repair With Individual Parts.								All	3500		
0604	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500		
0605	92502	260124	122K02	0515	1	690319	1	691851	25		All	3300		
0606	92502	260096	122K02	0516					25		All	3300		
0609	92505	261030	No Replacement Repair With Individual Parts.								All	3500		
0610	92505	261012	No Replacement Repair With Individual Parts.								All	3500		
0611	92505	261013	No Replacement Repair With Individual Parts.								All	3500		
0612	92505	261014	No Replacement Repair With Individual Parts.								All	3500		
0613	92506	260124	9M902	0015							All	3500		
0614	92506	260096	9M902	0016							All	3500		
0615	92506	260097	No Replacement Repair With Individual Parts.								All	3500		
0616	92506	260098	122K02	0518	1	690319	1	691851	25		All	3500		
0617	92508	261030	122K02	0515	1	690319	1	691851	25		All	3500		
0618	92508	261012	122K02	0516	1	690319	1	691851	25		All	3500		
0619	92508	261013	No Replacement Repair With Individual Parts.								All	3500		
0620	92508	261014	122K02	0518	1	690319	1	691851	25		All	3500		
0621	92582	260911	No Replacement Repair With Individual Parts.								All	3500		
0622	92582	260912	No Replacement Repair With Individual Parts.								All	3500		
0623	92582	260913	No Replacement Repair With Individual Parts.								All	3500		
0624	92582	260914	No Replacement Repair With Individual Parts.								All	3500		
0625	92502	260124	9M902	0015							All	3100		
0627	92502	260097	No Replacement Repair With Individual Parts.								All	3100		
0628	92502	260098	122K02	0518					25		All	3100		
0629	92585	261021	No Replacement Repair With Individual Parts.								All	3500		

92500 to 92599

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
0630	92585	261022	No Replacement Repair With Individual Parts.									All	3500		
0631	92585	261023	No Replacement Repair With Individual Parts.									All	3500		
0632	92585	261024	No Replacement Repair With Individual Parts.									All	3500		
0633	92586	260911	No Replacement Repair With Individual Parts.									All	3500		
0634	92586	260912	No Replacement Repair With Individual Parts.									All	3500		
0635	92586	260913	No Replacement Repair With Individual Parts.									All	3500		
0636	92586	260914	No Replacement Repair With Individual Parts.									All	3500		
0637	92588	261021	No Replacement Repair With Individual Parts.									All	3500		
0638	92588	261022	No Replacement Repair With Individual Parts.									All	3500		
0639	92588	261023	No Replacement Repair With Individual Parts.									All	3500		
0640	92588	261024	No Replacement Repair With Individual Parts.									All	3500		
0641	92592	260099	No Replacement Repair With Individual Parts.									All	3500		
0642	92592	260224	No Replacement Repair With Individual Parts.									All	3500		
0643	92502	260098	122K02	0518					25		All	3100			
0644	92502	260097	No Replacement Repair With Individual Parts.									All	3100		
0645	92595	261006	No Replacement Repair With Individual Parts.									All	3500		
0646	92595	261007	No Replacement Repair With Individual Parts.									All	3500		
0647	92596	260099	No Replacement Repair With Individual Parts.									All	3500		
0648	92596	260224	No Replacement Repair With Individual Parts.									All	3500		
0649	92598	261006	No Replacement Repair With Individual Parts.									All	3500		
0650	92598	261007	No Replacement Repair With Individual Parts.									All	3500		
0652	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500			
0654	92505	261030	No Replacement Repair With Individual Parts.									All	3500		
0655	92506	260124	9M902	0015							All	3500			
0656	92508	261030	122K02	0515	1	690319	1	691851	25		All	3500			
0657	92582	260911	No Replacement Repair With Individual Parts.									All	3500		
0659	92585	261021	No Replacement Repair With Individual Parts.									All	3500		
0660	92586	260911	No Replacement Repair With Individual Parts.									All	3500		
0661	92588	261021	No Replacement Repair With Individual Parts.									All	3500		
0662	92592	260099	No Replacement Repair With Individual Parts.									All	3500		
0664	92595	261006	No Replacement Repair With Individual Parts.									All	3500		
0665	92596	260099	No Replacement Repair With Individual Parts.									All	3500		
0666	92598	261006	No Replacement Repair With Individual Parts.									All	3500		
0668	92582	260911	No Replacement Repair With Individual Parts.									All	3500		
0670	92502	260957	No Replacement Repair With Individual Parts.									All	3300		
0671	92506	260098	122K02	0518					25		All	3200			
0672	92508	261014	122K02	0518					25		All	3100			
0673	92502	260839	No Replacement Repair With Individual Parts.									All	3500		
0674	92502	260124	122K02	0515	1	690319	1	691851	25		All	3300			
0675	92502	260096	9M902	0016							All	3500			
0676	92508	261030	122K02	0515	1	690319	1	691851	25		All	3500			
0677	92502	260124	9M902	0015					73		All	3500			
0678	92508	261014	122K02	0518					25		All	3300			
0679	92502	260124	9M902	0015							All	4000			
0680	92502	260096	9M902	0016							All	3300			
0681	92502	260124	9M902	0015							All	3300			
0682	92502	260124	9M902	0015							All	3300			
0683	92502	260124	9M902	0015							All	3300			
0684	92502	260098	9M902	0018							All	3300			
0685	92502	260124	9M902	0015							All	3500			
0686	92502	260098	122K02	0518	1	690319	1	690252	25		All	3500			
0687	92508	261030	122K02	0515	1	690319	1	691290	25		All	3700			
0688	92508	261013	No Replacement Repair With Individual Parts.									All	3100		
0689	92502	260096	9M902	0016							All	3300			
0690	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500			

92500 to 92599

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
0691	92502	260097	No Replacement Repair With Individual Parts.									All	3300		
0692	92502	260096	9M902	0016							All	3300			
0693	92502	260097	No Replacement Repair With Individual Parts.									All	3100		
0694	92502	260096	9M902	0016							All	3300			
0695	92502	260957	No Replacement Repair With Individual Parts.									All	3300		
0696	92506	260096	9M902	0016							All	3300			
0697	92582	260912	No Replacement Repair With Individual Parts.									All	3300		
0698	92502	260096	9M902	0016							All	3300			
0699	92502	260124	9M902	0015							All	3500			
0700	92502	260124	9M902	0015					73		All	3500			
0701	92502	260096	9M902	0016							All	3500			
0702	92508	261012	122K02	0516	1	690319	1	691851	25		All	3500			
0703	92502	260096	9M902	0016							All	3500			
0704	92502	260098	122K02	0518					25		All	3000			
0705	92506	260098	122K02	0518					25		All	3000			
0706	92508	261014	122K02	0518					25		All	3200			
0707	92502	260096	9M902	0016							All	3200			
0708	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500			
0709	92502	260319	122K02	0516	1	690319	1	691851	25		All	4000			
0710	92508	261029	122K02	0515	1	690319	1	691851	25		All	3300			
0711	92502	260370	No Replacement Repair With Individual Parts.									All	3300		
0712	92502	260400	No Replacement Repair With Individual Parts.									All	3300		
0713	92505	261050	No Replacement Repair With Individual Parts.									All	3300		
0714	92508	261050	No Replacement Repair With Individual Parts.									All	3300		
0715	92502	260096	9M902	1615							All	3300			
0716	92502	260098	122K02	0518	1	690319	1	691290	25		All	4000			
0717	92502	260124	9M902	0015					73		All	4000			
0718	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500			
0719	92502	260124	9M902	0015							All	3200			
0720	92502	260096	9M902	0016							All	3200			
0721	92502	260096	9M902	0016							All	3500			
0722	92502	260096	9M902	0016							All	3300			
0723	92502	260098	122K02	0518					25		All	3500			
0724	92502	260124	9M902	0015							All	3300			
0725	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500			
0726	92502	260096	9M902	0016							All	3500			
0727	92508	261012	122K02	0516	1	690319	1	691851	25		All	3500			
0728	92502	260096	9M902	0016							All	3300			
0729	92506	260124	9M902	0015					73		All	3300			
0730	92502	260124	122K02	0515					25		All	3000			
0731	92502	260957	No Replacement Repair With Individual Parts.									All	3100		
0732	92508	261013	No Replacement Repair With Individual Parts.									All	3000		
0733	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500			
0734	92502	260124	122K02	0515	1	690319	1	691290	25		All	4000			
0735	92502	260096	9M902	0016							All	3500			
0736	92508	261012	122K02	0516	1	690319	1	691851	25		All	3500			
0737	92502	260400	No Replacement Repair With Individual Parts.									All	3300		
0738	92502	260096	9M902	0016							All	3700			
0739	92508	261013	No Replacement Repair With Individual Parts.									All	3300		
0740	92502	260096	9M902	0016							All	3500			
0741	92506	260204	No Replacement Repair With Individual Parts.									All	3500		
0742	92508	261012	122K02	0516	1	690319	1	691851	25		All	3500			
0743	92502	260957	No Replacement Repair With Individual Parts.									All	3100		
0744	92502	260124	122K02	0515	1	690319	1	691290	25		All	4000			

92500 to 92599

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
0745	92508	261012	122K02	0516					25		All	3000			
0746	92508	261013	No Replacement Repair With Individual Parts.									All	3500		
0747	92502	260124	122K02	0515	1	690319	1	691290	25		All	4000			
0748	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500			
0749	92508	261014	122K02	0518					25		All	3000			
0750	92502	260098	122K02	0518					25		All	3300			
0751	92505	261030	No Replacement Repair With Individual Parts.									All	3300		
0752	92508	261012	122K02	0515					25		All	3300			
0753	92502	260124	122K02	0515					25		All	3200			
0754	92502	260319	No Replacement Repair With Individual Parts.									All	3500		
0755	92505	261013	No Replacement Repair With Individual Parts.									All	3100		
0756	92502	260097	No Replacement Repair With Individual Parts.									All	3500		
0757	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500			
0758	92508	261013	No Replacement Repair With Individual Parts.									All	3500		
0759	92502	260096	9M902	0016							All	3000			
0760	92502	260124	9M902	0015							All	3000			
0761	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500			
0762	92502	260096	9M902	0016							All	3200			
0763	92502	260096	122K02	0516					25		All	3000			
0764	92502	260097	No Replacement Repair With Individual Parts.									All	3300		
0765	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500			
0766	92502	260096	9M902	0016							All	3500			
0767	92508	261030	122K02	0515	1	690319	1	691851	25		All	3300			
0768	92508	261014	122K02	0518					25		All	3000			
0769	92502	260124	9M902	0015							All	3200			
0770	92502	260096	9M902	0016							All	3500			
0771	92502	260098	122K02	0518					25		All	3000			
0772	92502	260096	9M902	0016							All	3500			
0773	92502	260098	9M902	0018							All	3000			
0774	92502	260096	9M902	0016							All	3000			
0775	92502	260096	9M902	0016							All	3100			
0776	92506	260124	9M902	0015					73		All	3000			
0777	92508	261012	122K02	0516	1	690319	1	691851	25		All	3500			
0778	92502	260096	9M902	0016							All	3100			
0779	92508	261012	122K02	0518					25		All	3100			
0780	92502	260124	9M902	0015							All	2900			
0781	92502	260098	9M902	0018							All	3300			
0782	92502	260098	9M902	0018							All	3100			
0783	92502	260124	9M902	0015							All	3200			
0784	92508	261030	9M902	0015							All	3200			
0785	92502	260098	9M902	0018							All	3300			
0786	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500			
0787	92502	260098	9M902	0018							All	3000			
0788	92508	261014	9M902	0018							All	3100			
0789	92502	260098	122K02	0518	1	690319	1	691851	25		All	3300			
0790	92502	260124	9M902	0015							All	3100			
0791	92502	260124	9M902	0015							All	3100			
0792	92502	260096	9M902	0016							All	3100			
0793	92502	260096	9M902	0016							All	3000			
0794	92508	261012	122K02	0516					25		All	3000			
0795	92502	260096	9M902	0016							All	3000			
0796	92502	260096	9M902	0016							All	3100			
0797	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500			
0798	92502	260098	9M902	0018							All	3000			
0799	92502	260098	9M902	0018							All	3100			

92500 to 92599

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0800	92508	261014	122K02	0518					25		All	3100		
0801	92502	260097	No Replacement Repair With Individual Parts.											
0802	92508	261012	122K02	0516					25		All	3100		
0803	92905	260124	No Replacement Repair With Individual Parts.											
0804	92508	261013	No Replacement Repair With Individual Parts.											
0805	92502	260098	9M902	0018							All	3100		
0806	92502	260124	9M902	0015							All	3300		
0807	92502	260124	9M902	0015					73		All	3500		
0808	92502	260096	No Replacement Repair With Individual Parts.											
0809	92505	261012	No Replacement Repair With Individual Parts.											
0810	92508	261012	No Replacement Repair With Individual Parts.											
0811	92502	260096	9M902	0016							All	3500		
0812	92502	260124	122K02	0515	1	690319	1	691290	25		All	3700		
0813	92502	260096	9M902	0016							All	3000		
0814	92508	261014	122K02	0518	1	690319	1	691851	25		All	3500		
0815	92588	261023	No Replacement Repair With Individual Parts.											
0816	92508	261050	No Replacement Repair With Individual Parts.											
0817	92502	260097	No Replacement Repair With Individual Parts.											
0818	92508	261050	No Replacement Repair With Individual Parts.											
0819	92502	260098	122K02	0518	1	690319	1	691290	25		All	3700		
0820	92505	261014	No Replacement Repair With Individual Parts.											
0821	92505	261050	No Replacement Repair With Individual Parts.											
0822	92502	260096	122K02	0516					25		All	3000		
0823	92502	260097	No Replacement Repair With Individual Parts.											
0824	92502	260097	No Replacement Repair With Individual Parts.											
0825	92502	260124	122K02	0515					25		All	3000		
0826	92502	260098	122K02	0518					25		All	3100		
0827	92502	260957	No Replacement Repair With Individual Parts.											
0828	92502	260096	9M902	0016							All	3100		
0829	92502	260096	9M902	0016							All	3200		
0830	92508	261012	122K02	0516					25		All	3200		
0831	92502	260098	9M902	0018							All	3300		
0832	92502	260097	No Replacement Repair With Individual Parts.											
0833	92502	260097	No Replacement Repair With Individual Parts.											
0834	92502	260098	9M902	0018							All	3000		
0835	92502	260097	No Replacement Repair With Individual Parts.											
0836	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500		
0837	92508	261050	No Replacement Repair With Individual Parts.											
0838	92505	261050	No Replacement Repair With Individual Parts.											
0839	92502	260096	9M902	0016							All	3200		
0840	92508	261012	122K02	0516					25		All	3200		
0841	92502	260370	No Replacement Repair With Individual Parts.											
0842	92502	260957	No Replacement Repair With Individual Parts.											
0843	92502	260097	No Replacement Repair With Individual Parts.											
0844	92508	261050	No Replacement Repair With Individual Parts.											
0845	92508	261030	122K02	0515	1	690319	1	691290	25		All	3700		
0846	92502	260098	9M902	0018							All	3200		
0847	92502	260097	No Replacement Repair With Individual Parts.											
0848	92508	261013	No Replacement Repair With Individual Parts.											
0849	92508	261014	122K02	0518					25		All	3200		
0850	92502	260124	122K02	0515	1	690319	1	691290	25		All	3700		
0851	92508	261014	122K02	0518	1	690319	1	691290	25		All	3700		
0852	92502	260098	9M902	0018							All	3300		
0853	92502	260097	No Replacement Repair With Individual Parts.											
0854	92502	260097	No Replacement Repair With Individual Parts.											

92500 to 92599

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block			
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes		
0855	92502	260124	9M902	0015							All	3300				
0856	92502	260097	No Replacement Repair With Individual Parts.										All	3300		
0857	92502	260124	122K02	0515	1	690319	1	691290	25		All	3700				
0858	92502	260124	9M902	0015							All	3000				
0859	92505	261013	No Replacement Repair With Individual Parts.										All	3100		
0860	92502	260096	9M902	0016							All	3100				
0861	92502	260096	122K02	0516	1	492177	1	492893	25		All	3200				
0862	92505	261050	No Replacement Repair With Individual Parts.										All	3300		
0863	92508	261050	No Replacement Repair With Individual Parts.										All	3300		
0864	92508	261050	No Replacement Repair With Individual Parts.										All	3300		
0865	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500				
0866	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500				
0867	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500				
0868	92502	260098	122K02	0518					25		All	3000				
0869	92508	261014	122K02	0518	1	690319	1	691851	25		All	3500				
0870	92508	261050	No Replacement Repair With Individual Parts.										All	3300		
0871	92502	260098	122K02	0518					25		All	3000				
0872	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500				
0873	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500				
0874	92502	260096	9M902	0016							All	3100				
0875	92502	260124	9M902	0015							All	3500				
0876	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500				
0877	92508	261013	No Replacement Repair With Individual Parts.										All	3100		
0878	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500				
0879	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500				
0880	92582	260914	No Replacement Repair With Individual Parts.										All	3200		
0881	92502	260957	No Replacement Repair With Individual Parts.										All	3500		
0882	92502	260098	9M902	0018							All	3100				
0883	92508	261014	122K02	0518					25		All	3100				
0884	92502	260124	9M902	0015							All	3200				
0885	92502	261239	No Replacement Repair With Individual Parts.										All	3100		
0886	92508	261237	No Replacement Repair With Individual Parts.										All	3100		
0887	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500				
0888	92508	261237	No Replacement Repair With Individual Parts.										All	3500		
0889	92502	260097	No Replacement Repair With Individual Parts.										All	3500		
0890	92502	260098	122K02	0518	1	690319	1	691851	25		All	3300				
0891	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500				
0892	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500				
0893	92502	261013	No Replacement Repair With Individual Parts.										All	3300		
0894	92508	261013	No Replacement Repair With Individual Parts.										All	3300		
0895	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500				
0896	92508	261012	No Replacement Repair With Individual Parts.										All	3300		
0897	92502	260124	122K02	0515	1	690319	1	691290	25		All	3700				
0898	92508	261012	122K02	0516					25		All	3200				
0899	92508	261014	122K02	0518	1	690319	1	691851	25		All	3500				
0900	92502	260097	No Replacement Repair With Individual Parts.										All	3500		
0901	92508	261013	No Replacement Repair With Individual Parts.										All	3500		
0902	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500				
0903	92502	260124	9M902	0015							All	3500				
0904	92508	261292	No Replacement Repair With Individual Parts.										All	3100		
0905	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500				
0906	92502	260096	9M902	0016							All	3500				
0907	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500				

92500 to 92599

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
0908	92502	260096	122K02	0516					25		All	3500			
0909	92502	260096	122K02	0516	1	690319	1	691851	25		All	3500			
0910	92502	260124	122K02	0515					25		All	3200			
0911	92508	261012	122K02	0516					25		All	3200			
0912	92502	260096	122K02	0516	1	690319	1	691851	25		All	3500			
0913	92502	260124	122K02	0515					25		All	3500			
0914	92502	260096	122K02	0516					25		All	3200			
0915	92502	260096	122K02	0516					25		All	3500			
0916	92502	260096	122K02	0516					25		All	3500			
0917	92502	260124	122K02	0515					25		All	3200			
0918	92508	261030	122K02	0515					25		All	3200			
0919	92502	260124	122K02	0515					25		All	3300			
0920	92502	260098	122K02	0518	1	690319	1	691851	25		All	3700			
0921	92508	261050	No Replacement Repair With Individual Parts.									All	3300		
0922	92502	260096	122K02	0516					25		All	3000			
0923	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500			
0924	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500			
0925	92508	261014	122K02	0518	1	690319	1	691851	25		All	3500			
0926	92508	261014	122K02	0518	1	690319	1	691851	25		All	3300			
0927	92502	290096	122K02	0516	1	690319	1	691851	25		All	3500			
0928	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500			
0929	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500			
0930	92508	261050	No Replacement Repair With Individual Parts.									All	3200		
0931	92502	260098	122K02	0518	1	690319	1	691290	25		All	3700			
0932	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500			
0933	92502	260098	122K02	0518	1	690319	1	691851	25		All	3300			
0934	92508	261030	122K02	0515					25		All	3200			
0935	92508	261012	122K02	0516	1	690319	1	691851	25		All	3500			
0936	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500			
0937	92508	261030	122K02	0515	1	690319	1	691851	25		All	3500			
0938	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500			
0939	92502	260124	9M902	0015					73		All	3000			
0940	92508	261014	122K02	0518	1	690319	1	691851	25		All	3500			
0941	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500			
0942	92502	260124	9M902	0015					73		All	3200			
0943	92508	261013	No Replacement Repair With Individual Parts.									All	3500		
0944	92508	261030	122K02	0515					25		All	3100			
0945	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500			
0946	92508	261012	122K02	0516	1	690319	1	691851	25		All	3300			
0947	92508	261014	122K02	0518					25		All	3100			
0948	92502	260096	122K02	0516					25		All	3100			
0949	92502	260097	No Replacement Repair With Individual Parts.									All	3100		
0950	92508	261013	No Replacement Repair With Individual Parts.									All	3100		
0951	92508	261415	No Replacement Repair With Individual Parts.									All	2500		
0952	92508	261293	No Replacement Repair With Individual Parts.									All	2500		
0953	92508	261415	No Replacement Repair With Individual Parts.									All	2500		
0954	92508	261415	No Replacement Repair With Individual Parts.									All	2500		
0955	92502	260097	No Replacement Repair With Individual Parts.									All	3300		
0956	92502	260096	9M902	0016							All	3300			
0957	92502	260098	122K02	0518					25		All	3000			
0958	92502	260096	122K02	0516					25		All	3300			
0959	92502	260096	9M902	0016					25		All	3200			
0960	92502	260097	No Replacement Repair With Individual Parts.									All	3100		

92500 to 92599

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block			
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes		
0961	92502	260124	122K02	0515	1	690319	1	691851	25		All	3300				
0962	92502	260096	9M902	0016							All	3500				
0963	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500				
0964	92502	260096	122K02	0516	1	690319	1	691851	25		All	3500				
0965	92502	260098	122K02	0518					25		All	3000				
0966	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500				
0967	92502	260096	9M902	0016							All	3500				
0968	92502	260096	122K02	0516	1	690319	1	691851	25		All	3600				
0969	92502	260098	122K02	0518					25		All	3200				
0970	92502	260124	122K02	0515					25		All	3200				
0971	92502	260096	9M902	0016							All	3200				
0972	92502	260096	122K02	0516					25		All	3200				
0973	92502	260096	122K02	0516	1	690319	1	691851	25		All	3500				
0974	92508	261030	122K02	0515					25		All	3200				
0975	92502	260096	122K02	0516	1	690319	1	690851	25		All	3500				
0976	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500				
0977	92502	260096	122K02	0516					25		All	3100				
0978	92502	260096	122K02	0516	1	690319	1	691851	25		All	3500				
0979	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500				
0980	92502	260096	No Replacement Repair With Individual Parts.										All	3500		
0981	92502	260124	122K02	0515					25		All	3100				
0982	92502	260098	9M902	0015							All	3500				
0983	92502	260124	122K02	0515					25		All	3100				
0984	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500				
0985	92508	261415	No Replacement Repair With Individual Parts.										All	2500		
0986	92508	261415	No Replacement Repair With Individual Parts.										All	2500		
0987	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500				
0988	92502	260098	9M902	0018							All	3100				
0989	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500				
0990	92508	261292	No Replacement Repair With Individual Parts.										All	3000		
0991	92502	260124	9M902	0015							All	3700				
0992	92502	260096	9M902	0016							All	3500				
0993	92502	260096	122K02	0516	1	690319	1	691851	25		All	3500				
0994	92502	260097	No Replacement Repair With Individual Parts.										All	3500		
0995	92502	260096	122K02	0516	1	690319	1	691851	25		All	3500				
0996	92502	260097	No Replacement Repair With Individual Parts.										All	3500		
0997	92502	260124	9M902	0015							All	3500				
0998	92508	261013	No Replacement Repair With Individual Parts.										All	3300		
0999	92502	260096	122K02	0516	1	690319	1	691851	25		All	3700				
1000	92508	261293	No Replacement Repair With Individual Parts.										All	2500		
1001	92508	261293	No Replacement Repair With Individual Parts.										All	2500		
1002	92502	260098	122K02	0518					25		All	3000				
1003	92502	260096	122K02	0516					25		All	2900				
1004	92502	260096	122K02	0516					25		All	3200				
1005	92502	260096	122K02	0516					25		All	3100				
1006	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500				
1007	92508	261030	122K02	0515	1	690319	1	691851	25		All	3500				
1008	92502	260096	9M902	0016							All	3200				
1009	92502	260124	9M902	0015							All	3700				
1010	92502	260124	122K02	0515					25		All	3000				
1011	92502	260124	122K02	0515	1	690319	1	691290	25		All	3700				
1012	92502	260096	9M902	0016							All	3500				
1013	92502	260096	122K02	0516					25		All	3100				
1014	92502	260096	122K02	0516	1	690319	1	691851	25		All	3500				

92500 to 92599

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block			
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes		
1015	92502	260096	9M902	0016							All	3100				
1016	92502	260124	122K02	0515					25		All	3500				
1017	92502	260097	No Replacement Repair With Individual Parts.										All	3300		
1018	92502	260096	122K02	0516					25		All	3100				
1019	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500				
1020	92508	260098	122K02	0518					25		All	3000				
1021	92502	260124	9M902	0015							All	3200				
1022	92502	260124	9M902	0015							All	3500				
1023	92502	260124	122K02	0515					25		All	3300				
1024	92502	260097	No Replacement Repair With Individual Parts.										All	3200		
1025	92502	260096	122K02	0516	1	690319	1	691851	25		All	3500				
1026	92502	260098	122K02	0518					25		All	3300				
1027	92502	260096	9M902	0016					73		All	2900				
1028	92508	260098	No Replacement Repair With Individual Parts.										All	3500		
1029	92502	260095	9M902	0015							All	3500				
1030	92508	260096	122K02	0516					25		All	3100				
1031	92502	260096	9M902	0016							All	3500				
1032	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500				
1033	92508	261293	No Replacement Repair With Individual Parts.										All	2600		
1034	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500				
1035	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500				
1036	92502	260096	9M902	0016							All	3500				
1037	92502	260124	9M902	0015							All	3200				
1038	92508	261030	122K02	0515					25		All	3200				
1039	92502	260097	No Replacement Repair With Individual Parts.										All	3100		
1040	92502	260096	122K02	0516					25		All	3100				
1041	92502	260096	9M902	0016							All	3100				
1042	92502	260096	9M902	0016							All	3200				
1043	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500				
1044	92502	260098	122K02	0518	1	692315	1	691992	25		All	3000				
1045	92502	260096	9M902	0016							All	3500				
1046	92502	260096	122K02	0516					25		All	3300				
1047	92508	260096	122K02	0516					25		All	3300				
1048	92502	260096	9M902	0016							All	3200				
1049	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500				
1050	92502	260096	9M902	0016							All	3700				
1051	92502	260096	9M902	0016							All	3500				
1052	92502	260096	122K02	0516					25		All	2900				
1053	92508	260098	122K02	0518	1	690319	1	691851	25		All	3500				
1054	92502	260098	122K02	0518					25		All	3200				
1055	92502	260096	122K02	0516					25		All	3200				
1056	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500				
1057	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500				
					1	692315	1	691992								
1058	92508	261293	No Replacement Repair With Individual Parts.										All	3500		
1059	92502	260096	122K02	0516	1	690319	1	691851	25		All	3500				
1060	92502	260096	122K02	0516					25		All	3100				
1061	92502	260096	122K02	0516	1	690319	1	691851	25		All	3500				
1062	92502	260096	122K02	0516					25		All	3100				
1063	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500				
1064	92502	260096	122K02	0516					25		All	3000				
1065	92508	260096	122K02	0516					25		All	3200				
1066	92902	260096	122K02	0516					25		All	3200				
1067	92502	260124	9M902	0015							All	3300				

92500 to 92599

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
1068	92502	260096	122K02	0516					25		All	2900			
1069	92502	260096	122K02	0516					25		All	3100			
1070	92502	260096	122K02	0516					25		All	3100			
1071	92508	261293	No Replacement Repair With Individual Parts.									All	3500		
1072	92502	260096	98902	0016							All	3300			
1073	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500			
1074	92502	260096	122K02	0516					25		All	3100			
1075	92502	260097	No Replacement Repair With Individual Parts.									All	3300		
1076	92502	260124	122K02	0515	1	690319	1	691851	25		All	3300			
1077	92502	260839	No Replacement Repair With Individual Parts.									All	3500		
1078	92502	260096	9M902	0016							All	2900			
1079	92502	260124	122K02	0515					25		All	3200			
1080	92508	261293	No Replacement Repair With Individual Parts.									All	3200		
1081	92502	260096	9M902	0016							All	3300			
1082	92502	260124	122K02	0515	1	690319	1	691851	25		All	3500			
1083	92508	260124	122K02	0515					25		All	3200			
1084	92502	260098	122K02	0518	1	690319	1	691851	25		All	3500			
						1	692315	1	691992						
1085	92508	260098	122K02	0518	1	690319	1	691851	25		All	3500			
1086	92502	260096	9M902	0016							All	3500			
1087	92508	260124	122K02	0515					25		All	3200			
1088	92502	260098	122K02	0518					25		All	3200			
1089	92502	260096	9M902	0016							All	3000			
1090	92502	260096	9M902	0016							All	3200			
1091	92502	260096	122K02	0516					25		All	3200			
1092	92502	260096	122K02	0516					25		All	3200			
1093	92502	260096	122K02	0516					25		All	3000			
1094	92502	260124	122K02	0515					25		All	3300			
1095	92502	260096	122K02	0516	1	690319	1	691851	25		All	3500			
1096	92502	260124	122K02	0515					25		All	3300			
3101	92502	492748	122K02	0515					25		All	3100	398210		
3102	92502	492086	122K02	0516					25		All	3100	398211		
3103	92502	493618	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398212	
3104	92502	494034	122K02	0518					25		All	3100	398213		
3105	92502	492086	122K02	0516					25		All	3100	398211		
3106	92502	261987	9M902	0015							All	3100	398210		
3107	92582	492086	No Replacement Repair With Short Block and/or Individual Parts									All	3200	398216	
3108	92502	493618	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398212	
3109	92502	492748	122K02	0515					25		All	3100	398210		
3110	92502	493846	9M902	0018							All	3100			
3133	92502	492086	122K02	0516					25		All	3200	398211		
3134	92502	492086	9M902	0016							All	3000	398211		
3136	92502	494034	122K02	0518	1	690319	1	691851	25		All	3500	398213		
3137	92502	492086	9M902	0016							All	3100	398211		
3138	92502	492086	122K02	0516					25		All	3300	398211		
3139	92502	492086	122K02	0516					25		All	3100	398211		
3140	92502	261987	9M902	0015							All	3100	398210		
3141	92502	493034	9M902	0018							All	3100	398213		
3142	92582	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398214	PP
3143	92502	494034	9M902	0018							All	3100	398213		
3144	92502	492748	9M902	0015							All	3100	398210		
3145	92502	492086	9M902	0016							All	3100	398211		
3146	92582	492086	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398216	
3147	92582	492086	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398216	
3148	92582	492086	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398217	

92500 to 92599

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
3149	92502	492086	9M902	0016							All	3100	398211		
3150	92502	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210		
3151	92502	493618	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398212	
3152	92502	494034	122K02	0518					25		All	3100	398213		
3153	92502	494034	122K02	0518					25		All	3100	398213		
3154	92502	492086	122K02	0515					25		All	3100	398211		
3155	92502	492086	122K02	0515					25		All	3100	398211		
3156	92502	494034	122K02	0518					25		All	3100	398213		
3157	92502	492086	9M902	0016							All	3100	398211		
3158	92502	492086	9M902	0016							All	3100	398211		
3159	92502	492086	122K02	0516					25		All	3100	398211		
3160	92502	492086	9M902	0016							All	3100	398211		
3161	92502	492748	122K02	0515					25		All	3200	398210		
3162	92582	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3200	398214	
3163	92502	492086	9M902	0016							All	3100	398211		
3164	92502	492086	122K02	0516					25		All	3100	398211		
3165	92502	492748	122K02	0515					25		All	3200	398210		
3166	92502	492086	9M902	0016							All	3100	398211		
3167	92502	492086	9M902	0016							All	3100	398211		
3168	92502	494034	9M902	0018							All	3100	398213		
3169	92502	492086	9M902	0016							All	3100	398211		
3170	92502	492086	9M902	0016							All	3100	398211		
3171	92502	492748	122K02	0515					25		All	3300	398210		
3172	92502	493618	9M902	0018							All	3100	398213		
3173	92502	492748	122K02	0515	1	690319	1	691851	25		All	3300	398210		
3174	92502	492086	122K02	0516	1	690319	1	691851	25		All	3500	398211		
3175	92502	492748	122K02	0515	1	690319	1	691851	25		All	3300	398210		
3176	92502	492748	9M902	0015							All	3100	398210		
3177	92502	493618	9M902	0018							All	3100	398213		
3178	92502	492086	9M902	0016							All	3100	398211		
3179	92502	492086	122K02	0516	1	691319	1	691851	25		All	3500	398211		
3180	92502	492748	9M902	0015							All	3100	398210		
3181	92502	492748	9M902	0015							All	3100	398210		
3182	92502	492086	9M902	0016							All	2900	398211		
3183	92502	493618	No Replacement Repair With Short Block and/or Individual Parts									All	3300	398212	
3184	92502	494034	9M902	0018							All	3100	398213		
3185	92502	492748	122K02	0515					25		All	3100	398210		
3186	92502	492086	9M902	0016							All	3100	398211		
3187	92502	492086	9M902	0016							All	3100	398211		
3188	92502	493846	9M902	0018							All	3100			
3189	92502	493846	9M902	0018							All	3100			
3190	92502	492086	9M902	0016							All	3100	398211		
3191	92502	492086	9M902	0016							All	3100	398211		
3192	92502	493552	9M902	0018							All	3100			
3193	92502	492086	122K02	0516	1	690319	1	691851	25		All	3500	398211		
3194	92502	492748	122K02	0515					25		All	3100	398210		
3195	92502	493618	No Replacement Repair With Short Block and/or Individual Parts									All	3300	398212	
3196	92502	492748	122K02	0515	1	690319	1	691851	25		All	3300	398210		
3197	92502	493552	122K02	0518					25		All	3100			
3198	92502	492086	122K02	0516					25		All	3100	398211		
3199	92502	492086	9M902	0016							All	3100	398211		
3200	92502	492086	9M902	0016							All	3100	398211		
3201	92502	492086	9M902	0016							All	3100	398211		
3202	92502	493552	9M902	0018							All	3100			
3203	92502	492086	122K02	0516					25		All	3100	398211		

92500 to 92599

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
3204	92502	493618	No Replacement Repair With Short Block and/or Individual Parts								All	3500	398212	
3205	92502	493552	9M902	0018							All	3100		
3206	92502	494034	9M902	0018							All	3100	398213	
3207	92502	492748	122K02	0515					25		All	3100	398210	
3208	92502	492086	9M902	0016							All	3100	398211	
3209	92502	492086	9M902	0016							All	3100	398211	
3210	92502	492748	122K02	0515					25		All	3200	398210	
3211	92502	492086	9M902	0016							All	3200	398211	
5015	92508	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5101	92502	492748	122K02	0515					25		All	3100	398210	
5102	92502	492086	122K02	0516					25		All	3100	398211	
5103	92502	493618	No Replacement Repair With Short Block and/or Individual Parts								All	3100	398212	
5104	92502	494034	122K02	0518					25		All	3100	398213	
5105	92502	492748	122K02	0515					25		All	3300	398210	
5106	92502	492086	122K02	0516					25		All	3300	398211	
5107	92507	492748	No Replacement Repair With Individual Parts.								All	3500		
5108	92502	492748	122K02	0515					25		All	3100	398210	
5109	92502	492086	122K02	0516					25		All	3200	398211	
5110	92502	492748	122K02	0515					25		All	3200	398210	
5111	92502	492086	122K02	0516					25		All	3200	398211	
5112	92502	492748	122K02	0515					25		All	3000	398210	
5130	92502	492086	No Replacement Repair With Individual Parts.								All	3000		
5131	92502	492086	9M902	0016					73		All	3000	398211	
5132	92502	492086	122K02	0516					25		All	3100	398211	
5133	92507	492086	No Replacement Repair With Individual Parts.								All	3500		
5134	92502	492086	122K02	0516					25		All	3100	398211	
5135	92502	494034	122K02	0518	1	690319	1	691851	25		All	3500	398213	
5136	92502	494034	122K02	0518	1	690319	1	691851	25		All	3500	398213	
5137	92502	492748	122K02	0515					25		All	3300	398210	
5139	92502	492748	122K02	0515					25		All	3100	398210	
5140	92502	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5141	92502	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5142	92502	492748	122K02	0515	1	690319	1	691851	25		All	3300	398210	
5143	92502	493618	No Replacement Repair With Short Block and/or Individual Parts								All	3100	398212	
5144	92502	492748	122K02	0515					25		All	3100	398210	
5145	92502	493618	No Replacement Repair With Short Block and/or Individual Parts								All	3100	398212	
5146	92502	494034	122K02	0518	1	690319	1	691851	25		All	3500	398213	
5147	92502	492086	9M902	0016							All	3200	398211	
5148	92502	494034	122K02	0518					25		All	3100	398213	
5149	92508	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5150	92502	493618	No Replacement Repair With Short Block and/or Individual Parts								All	3100	398212	
5151	92508	492748	122K02	0515	1	690319	1	691290	25		All	3700	398210	
5152	92508	492748	122K02	0515	1	690319	1	691290	25		All	3700	398210	
5153	92508	492748	122K02	0515					25		All	3200	398210	
5154	92508	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5155	92508	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5156	92502	494034	122K02	0518	1	690319	1	691851	25		All	3500	398213	
5157	92508	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5158	92502	492086	122K02	0516					25		All	3200	398211	
5159	92502	492086	122K02	0516					25		All	3100	398211	
5160	92502	492086	122K02	0516					25		All	3100	398211	
5161	92508	492748	122K02	0515					25		All	3100	398210	
5162	92502	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5163	92508	494034	122K02	0518	1	690319	1	691851	25		All	3500	398213	

92500 to 92599

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
5164	92502	492086	9M902	0016							All	3500	398211	
5165	92508	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5166	92508	492086	122K02	0516					25		All	3300	398211	
5167	92502	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5168	92502	492086	9M902	0016							All	3500	398211	
5169	92502	494034	122K02	0518	1	690319	1	691851	25		All	3500	398213	
5170	92502	492748	122K02	0515	1	91084	1	691290	25		All	3700	398210	
5171	92502	494034	122K02	0518	1	690319	1	691851	25		All	3500	398213	
5172	92502	492086	122K02	0516	1	690319	1	691851	25		All	3500	398211	
5173	92502	492086	122K02	0516	1	690319	1	691851	25		All	3500	398211	
5174	92508	492748	122K02	0515					25		All	3300	398210	
5175	92508	492086	9M902	0016					73		All	3500	398211	
5176	92508	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5177	92508	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5178	92508	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5179	92502	492086	122K02	0516					25		All	3300	398211	
5180	92508	492748	122K02	0515	1	690319	1	691851	25		All	3300	398210	
5181	92502	493618	122K02	0518					25		All	3100	398213	
5182	92502	492086	122K02	0516					25		All	3200	398211	
5183	92502	492748	122K02	0515					25		All	3000	398210	
5184	92502	492748	122K02	0515	1	690319	1	691851	25		All	3300	398210	
5185	92502	492748	122K02	0515	1	690319	1	691851	25		All	3400	398210	
5186	92502	494034	122K02	0518	1	690319	1	691851	25		All	3500	398213	
5187	92502	492748	122K02	0515					25		All	3200	398210	
5188	92502	492086	122K02	0516	1	492177	1	492893	25		All	3200	398211	
5189	92502	492086	122K02	0516					25		All	3200	398211	
5190	92508	492086	122K02	0516					25		All	3200	398211	
5191	92502	492086	122K02	0516					25		All	3200	398211	
5192	92502	492748	122K02	0515					25		All	3200	398210	
5193	92502	492748	122K02	0515	1	690319	1	691851	25		All	3300	398210	
5194	92502	492086	9M902	0016							All	3200	398211	
5197	92502	493016	122K02	0515	1	690319	1	691851	25		All	3300	398210	
5198	92502	493552	No Replacement Repair With Individual Parts.								All	3100		
5199	92502	492086	9M902	0016							All	4000	398211	
5200	92507	492086	No Replacement Repair With Individual Parts.								All	4000		
5201	92508	493016	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5202	92508	493016	122K02	0515	1	690319	1	691851	25		All	3300	398210	
5203	92502	492748	122K02	0515	1	690319	1	691851	25		All	3300	398210	
5204	92502	492086	122K02	0516					25		All	3200	398211	
5205	92502	493016	9M902	0015					73		All	3700	398210	
5206	92508	493016	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5500	92502	492748	122K02	0515					25		All	3200	398210	
5501	92502	492086	122K02	0516					25		All	3200	398211	
5502	92502	492748	122K02	0515					25		All	3200	398210	
5503	92502	492086	122K02	0516					25		All	3200	398211	