

92900 to 92999

SERVICE ENGINE



SALES MANUAL

**MODEL 92900 SERIES ENGINES REPLACED WITH
 STANDARD SERVICE ENGINES**

In most cases, the Original Type numbers shown may be replaced by a Service Type Number without making any changes. Necessary changes of engine parts such as crankshafts, reduction parts, blower housings, etc., are noted. Other differences, such as mufflers, elbows, deflectors, etc., are not listed but are very important for safety and engine performance. Be sure the exhaust system on the replacement engine duplicates the system originally selected by the equipment manufacturer. Parts that are suitable for additional use should be transferred. Before making any conversion, check the data shown in the column labeled "REMOVE, ADD and NOTE." See if the changes, which are shown, are actually necessary on the application in question. Often a standard service engine will be a WORKABLE replacement without converting to such things as a special fuel tank or starter position.

If the crankshaft number does not appear in the "Original Engine" column, consult the Illustrated Parts List for the correct service replacement crankshaft number.

Engine Replacement Notes:

- NOTE 14:** Drill Set Screw spot 1-27/32" from end of Crankshaft, if required.
- NOTE 25:** If the replacement engine supersedes to or is a Model 120000 series engine, refer to the illustrations located after the conversion data for this model series. The overall dimensions that differ, are shown in the illustrations. If after making a visual inspection and it is determined the Model 120000 series engine cannot be used because of equipment interference, the original engine should be repaired with individual parts.
- NOTE 73:** Transfer Flywheel Assembly to the replacement engine.

Short Block Notes:

The SHORT BLOCK part number shown, is the assembly which can be used to rebuild the Original Type Number. If a letter appears after the short block number, it indicates the short block must be modified. The change denoted by each letter is as follows:

- NOTE G:** Drill and re-tap end of Crankshaft 7/16"-20 (1-1/8" deep). Use 25/64" tap drill.
- NOTE S:** Add Stellite Exhaust Valve, Spring, Rotator, Retainer and Pin as shown in VALVES, Section 5, Figure 3.
- NOTE T:** Add Stellite Valve as shown in VALVES, Section 5, Figure 2.
- NOTE Y:** Change Drive Shaft in Short Block. Remove 230831. Add 230870.
- NOTE .:**
- NOTE AA:** Change Drive Shaft in Short Block. Remove 230948. Add 230860.
- NOTE BB:** Change Drive Shaft in Short Block. Remove 230831. Add 230860.
- NOTE CC:** Change Drive Shaft in Short Block. Remove 230831. Add 230952.
- NOTE DD:** Change Drive Shaft in Short Block. Remove 230948. Add 230952.
- NOTE FF:** Change Drive Shaft in Short Block. Remove 230948. Add 230831.
- NOTE II:** Change Drive Shaft in Short Block. Remove 230831. Add 230948.
- NOTE PP:** Change Drive Shaft in Short Block. Remove 230831. Add 231213.

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
0015	92902	260124	9M902	0015					73		All	3500			
0016	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
0017	92902	260096	9M902	0016							All	3500			
0018	92902	260096	9M902	0016							All	3500			
0019	92902	260098	122K02	0518	1	492177	1	492893	25		All	3500			
						1	690319	1	691851						
0020	92902	260098	122K02	0518	1	492177	1	492893	25		All	3500			
						1	690319	1	691851						
0021	92902	260670	9M902	0015							All	3500			
0022	92902	260670	No Replacement Repair With Individual Parts.									All	3500		
0023	92902	260097	No Replacement Repair With Individual Parts.									All	3500		
0024	92902	260957	122K02	0515	1	690319	1	691851	25		All	3500			
0028	92902	260411	No Replacement Repair With Individual Parts.									All	4000		
0029	92902	260370	No Replacement Repair With Individual Parts.									All	3500		
0030	92906	260124	9M902	0015					73		All	3500			
0031	92906	260096	9M902	0016							All	3500			

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block			
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes		
0032	92906	260670	No Replacement Repair With Individual Parts.									All	3500			
0033	92906	260400	No Replacement Repair With Individual Parts.									All	3500			
0034	92906	260957	122K02	0515	1	690319	1	691851	25		All	3500				
0040	92992	260099	No Replacement Repair With Individual Parts.									All	3500			
0041	92992	260099	No Replacement Repair With Individual Parts.									All	3500			
0042	92992	260099	No Replacement Repair With Individual Parts.									All	3500			
0043	92992	260224	No Replacement Repair With Individual Parts.									All	3500			
0044	92999	260244	No Replacement Repair With Individual Parts.									All	3500			
0050	92982	260914	No Replacement Repair With Individual Parts.									All	4000			
0060	92986	260911	No Replacement Repair With Individual Parts.									All	3500			
0090	92902	260124	9M902	0015					73		All	3200				
0115	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500				
0116	92902	260096	9M902	0016							All	3500				
0117	92902	260097	No Replacement Repair With Individual Parts.									All	3500			
0118	92902	260098	122K02	0518	1	690319	1	691851	25		All	3500				
0120	92906	260124	9M902	0015					73		All	3500				
0121	92906	260096	122K02	0516	1	690319	1	691851	25		All	3500				
0122	92906	260097	No Replacement Repair With Individual Parts.									All	3500			
0123	92906	260098	122K02	0518	1	690319	1	691851	25		All	3500				
0124	92992	260099	No Replacement Repair With Individual Parts.									All	3500			
0126	92996	260099	No Replacement Repair With Individual Parts.									All	3500			
0127	92982	260911	No Replacement Repair With Individual Parts.									All	3500			
0128	92982	260912	No Replacement Repair With Individual Parts.									73	All	3500		
0129	92982	260913	No Replacement Repair With Individual Parts.									All	3500			
0130	92982	260914	No Replacement Repair With Individual Parts.									All	3500			
0131	92986	260911	No Replacement Repair With Individual Parts.									All	3500			
0132	92902	260098	122K02	0518	1	690319	1	691290	25		All	4100				
0133	92902	260124	9M902	0015					73		All	3500				
0134	92902	260124	9M902	0015					73		All	3300				
0135	92902	260124	9M902	0015							All	3500				
0136	92902	260096	9M902	0015							All	3300				
0137	92902	260235	9M902	0015							All	3300				
0138	92992	260402	No Replacement Repair With Individual Parts.									All	3300			
0139	92902	260124	9M902	0015							All	3500				
0140	92906	260124	9M902	0015							All	3500				
0141	92902	260098	122K02	0518	1	492177	1	492893	25		All	4100				
					1	690319	1	691290								
0142	92902	260124	9M902	0015							All	3300				
0143	92902	260096	122K02	0516					25		All	3500				
0144	92902	260124	9M902	0015							All	3500				
0145	92906	260124	9M902	0015							All	3500				
0146	92992	260856	No Replacement Repair With Individual Parts.									All	3500			
0147	92902	260097	No Replacement Repair With Individual Parts.									All	3500			
0148	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500				
0149	92902	260124	9M902	0015					73		All	3500				
0150	92982	260912	No Replacement Repair With Individual Parts.									All	3500			
0151	92906	260096	9M902	0016							All	3300				
0152	92902	260097	No Replacement Repair With Individual Parts.									All	3500			
0153	92992	260224	No Replacement Repair With Individual Parts.									All	3300			
0154	92996	260224	No Replacement Repair With Individual Parts.									All	3300			
0155	92902	260204	No Replacement Repair With Individual Parts.									All	3500			
0156	92902	260124	9M902	0015							All	3500				
0157	92902	260096	9M902	0016							All	3500				
0158	92902	260124	9M902	0015							All	3500				
0159	92902	260124	9M902	0015							All	3500				

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
0160	92902	260124	9M902	0015							All	3300			
0161	92902	260124	No Replacement Repair With Individual Parts.									All	3500		
0162	92992	260224	No Replacement Repair With Individual Parts.									All	3500		
0163	92902	260124	9M902	0015							All	3500			
0164	92992	260224	No Replacement Repair With Individual Parts.									All	3500		
0165	92902	260124	9M902	0015							All	3300			
0166	92902	260124	9M902	0015							All	3300			
0167	92906	260124	9M902	0015							All	4100			
0168	92902	260124	122K02	0515	1	690319	1	691290	25		All	4100			
0169	92992	260224	No Replacement Repair With Individual Parts.									All	3500		
0170	92902	260098	122K02	0518	1	690319	1	691851	25		All	3500			
0172	92902	260670	No Replacement Repair With Individual Parts.									All	3500		
0173	92902	260319	No Replacement Repair With Individual Parts.									All	4100		
0174	92902	260124	9M902	0015							All	3300			
0175	92906	260670	No Replacement Repair With Individual Parts.									All	3500		
0176	92982	260915	No Replacement Repair With Individual Parts.									All	4000		
0177	92986	260915	No Replacement Repair With Individual Parts.									All	3500		
0178	92902	260098	122K02	0518	1	492177	1	492893	25		All	4000			
						1	690319	1	691290						
0179	92982	260914	No Replacement Repair With Individual Parts.									All	4000		
0180	92992	26022	No Replacement Repair With Individual Parts.												
0181	92902	260124	9M902	0015					73		All	4100			
0182	92902	260098	122K02	0518	1	690319	1	691851	25		All	3500			
0183	92992	260224	No Replacement Repair With Individual Parts.									All	3500		
0184	92906	260124	9M902	0015							All	3300			
0185	92902	260098	122K02	0518	1	492177	1	492893	25		All	4100			
						1	690319	1	691290						
0186	92902	260097	No Replacement Repair With Individual Parts.									All	3500		
0187	92902	260124	9M902	0015							All	4100			
0188	92982	260911	No Replacement Repair With Individual Parts.									All	3500		
0189	92906	260124	9M902	0015							All	3500			
0190	92996	260224	No Replacement Repair With Individual Parts.									All	3500		
0191	92902	260124	122K02	0515	1	492177	1	492893	25		All	3500			
						1	690319	1	691851						
0192	92906	260098	122K02	0518	1	690319	1	691851	25		All	3300			
0193	92902	260098	122K02	0518	1	690319	1	691851	25		All	3300			
0194	92906	260124	9M902	0015							All	3300			
0195	92902	260124	122K02	0515	1	690319	1	691851	25		All	3300			
0196	92902	260124	122K02	0515	1	690319	1	691851	25		All	3300			
0197	92902	260097	No Replacement Repair With Individual Parts.									All	3500		
0198	92902	260124	122K02	0515	1	690319	1	691851	25		All	3300			
						1	91084	1	93418						
0199	92906	260124	9M902	0015	1	91084	1	93418			All	3300			
0200	92902	260411	No Replacement Repair With Individual Parts.									All	4000		
0201	92996	260099	No Replacement Repair With Individual Parts.									All	3300		
0202	92902	260124	122K02	0515	1	690319	1	691851	25		All	3300			
0203	92902	260096	9M902	0016							All	3300			
0204	92902	260096	9M902	0016					73		All	3300			
0205	92902	260124	9M902	0015					73		All	3300			
0206	92902	260098	122K02	0518	1	492177	1	492893	25		All	4000			
						1	690319	1	691290						
0207	92902	260124	9M902	0015							All	4100			
0208	92902	260124	122K02	0515	1	492177	1	492893	25		All	3300			
0209	92982	260914	No Replacement Repair With Individual Parts.									All	4000		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0210	92902	260096	9M902	0016							All	3500		
0211	92906	260124	9M902	0015							All	4000		
0212	92902	260124	9M902	0015					73		All	3500		
0213	92902	260235	122K02	0515	1	690319	1	691290	25		All	4000		
0214	92986	260911	No Replacement Repair With Individual Parts.								All	3500		
0215	92902	260096	9M902	0016							All	3500		
0216	92906	260097	No Replacement Repair With Individual Parts.								All	4000		
0217	92902	260098	No Replacement Repair With Individual Parts.								All	3300		
0218	92902	260096	122K02	0516					25		All	3300		
0219	92902	260124	122K02	0515	1	690319	1	691851	25		All	3300		
0220	92902	260124	9M902	0015							All	3500		
0221	92906	260124	9M902	0015							All	3500		
0222	92902	260124	122K02	0515	1	690319	1	691290	25		All	4000		
0223	92902	260124	122K02	0515	1	690319	1	691851	25		All	3300		
0224	92902	260098	122K02	0516	1	690319	1	691851	25		All	3500		
0225	92902	260096	9M902	0016							All	3300		
0226	92992	260099	No Replacement Repair With Individual Parts.								All	3500		
0227	92992	260856	No Replacement Repair With Individual Parts.								All	3500		
0228	92982	260915	No Replacement Repair With Individual Parts.								All	3500		
0229	92901	260098	No Replacement Repair With Individual Parts.								All	4000		
0230	92902	260670	No Replacement Repair With Individual Parts.								All	3500		
0231	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500		
0232	92992	260099	No Replacement Repair With Individual Parts.								All	3500		
0233	92982	260915	No Replacement Repair With Individual Parts.								All	3500		
0235	92902	260124	122K02	0515	1	690319	1	691290	25		All	4000		
0236	92902	260124	No Replacement Repair With Individual Parts.								All	4000		
0237	92902	260124	No Replacement Repair With Individual Parts.								All	4000		
0238	92902	260124	122K02	0515	1	690319	1	691290	25		All	4000		
0240	92982	260911	No Replacement Repair With Individual Parts.								All	4000		
0241	92992	260099	No Replacement Repair With Individual Parts.								All	3500		
0242	92906	260124	9M902	0015							All	3500		
0243	92986	260911	No Replacement Repair With Individual Parts.								All	3500		
0244	92902	260124	9M902	0015							All	4000		
0245	92902	260098	122K02	0518	1	690319	1	691851	25		All	3500		
0246	92902	260098	No Replacement Repair With Individual Parts.								All	4000		
0247	92902	260124	No Replacement Repair With Individual Parts.								All	3500		
0248	92902	260096	122K02	0516	1	492177	1	492893	25		All	4000		
					1	690319	1	691851						
0249	92902	260098	122K02	0518	1	690319	1	691290	25		All	4000		
0251	92986	260911	No Replacement Repair With Individual Parts.								All	3500		
0252	92992	260224	No Replacement Repair With Individual Parts.								All	3500		
0253	92992	260099	No Replacement Repair With Individual Parts.								All	3300		
0254	92902	260124	9M902	0015							All	3300		
0255	92906	260124	9M902	0015							All	3300		
0256	92992	260099	No Replacement Repair With Individual Parts.								All	3300		
0257	92902	260124	9M902	0015					73		All	3300		
0258	92992	260856	No Replacement Repair With Individual Parts.								All	3500		
0259	92906	260670	9M902	0015							All	3500		
0260	92902	260670	No Replacement Repair With Individual Parts.								All	3500		
0261	92902	260096	9M902	0016					73		All	3300		
0262	92902	260124	9M902	0015					73		All	3300		
0263	92902	260098	No Replacement Repair With Individual Parts.								All	4000		
0264	92902	260124	9M902	0015					73		All	3500		
0265	92901	260096	No Replacement Repair With Individual Parts.								All	3300		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0266	92992	260224	No Replacement Repair With Individual Parts.								All	4000		
0267	92992	260224	No Replacement Repair With Individual Parts.								All	3500		
0268	92902	260124	9M902	0015						All	3500			
0269	92906	260124	9M902	0015						All	3500			
0270	92902	260099	No Replacement Repair With Individual Parts.								All	3500		
0271	92906	260098	122K02	0518	1	690319	1	691851	25	All	3500			
0272	92906	260124	9M902	0015						All	3300			
0273	92902	260098	122K02	0518	1	492177	1	492893	25	All	4000			
					1	690319	1	691290						
0274	92982	260911	No Replacement Repair With Individual Parts.								All	3500		
0275	92902	260096	9M902	0016						All	3500			
0276	92902	260096	122K02	0516	1	690319	1	691851	25	All	3500			
0277	92992	260099	No Replacement Repair With Individual Parts.								All	4000		
0278	92996	260099	No Replacement Repair With Individual Parts.								All	4000		
0279	92902	260096	122K02	0516					25	All	3300			
0280	92906	260096	122K02	0516					25	All	3300			
0281	92902	260124	9M902	0015						All	3500			
0282	92982	260911	No Replacement Repair With Individual Parts.						73		All	3500		
0283	92996	260856	No Replacement Repair With Individual Parts.								All	3500		
0284	92902	260124	122K02	0515	1	690319	1	262656	25	All	3500			
0285	92902	260096	9M902	0016						All	3500			
0286	92902	260098	122K02	0518	1	492177	1	492893	25	All	3300			
					1	690319	1	691851						
0287	92902	260097	No Replacement Repair With Individual Parts.								All	3500		
0288	92992	260099	No Replacement Repair With Individual Parts.								All	3500		
0289	92902	260098	122K02	0518	1	690319	1	691851	25	All	3500			
0290	92902	260098	122K02	0518	1	690319	1	691851	25	All	3300			
0291	92982	260911	No Replacement Repair With Individual Parts.								All	3500		
0292	92906	260097	No Replacement Repair With Individual Parts.								All	3500		
0293	92902	260096	122K02	0516	1	690319	1	691851	25	All	3500			
0294	92902	260096	9M902	0016						All	3500			
0295	92902	260319	No Replacement Repair With Individual Parts.								All	3300		
0296	92902	260124	9M902	0015					73	All	3500			
0297	92996	260099	No Replacement Repair With Individual Parts.								All	3300		
0298	92902	260124	122K02	0515	1	690319	1	691851	25	All	3500			
0299	92902	260096	9M902	0016						All	3500			
0300	92992	260402	No Replacement Repair With Individual Parts.								All	3300		
0301	92902	260235	9M902	0015						All	3300			
0302	92902	260098	No Replacement Repair With Individual Parts.								All	3300		
0303	92902	260124	9M902	0015					73	All	3500			
0304	92902	260096	9M902	0016						All	3500			
0305	92906	260124	9M902	0015						All	4000			
0306	92982	260911	No Replacement Repair With Individual Parts.								All	4000		
0307	92906	260096	9M902	0016						All	4000			
0308	92902	260096	122K02	0516	1	690319	1	691851	25	All	4000			
0309	92902	260098	122K02	0518	1	690319	1	691851	25	All	3500			
0310	92902	260124	122K02	0515	1	690319	1	691851	25	All	3500			
0311	92902	260124	9M902	0015					73	All	4000			
0312	92992	260224	No Replacement Repair With Individual Parts.								All	3500		
0313	92982	260914	No Replacement Repair With Individual Parts.								All	3500		
0314	92906	260096	9M902	0016						All	4000			
0315	92992	260099	No Replacement Repair With Individual Parts.								All	3500		
0316	92986	260911	No Replacement Repair With Individual Parts.								All	3500		
0317	92982	260911	No Replacement Repair With Individual Parts.								All	3500		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
0318	92902	260957	No Replacement Repair With Individual Parts.									All	3500		
0319	92906	260957	No Replacement Repair With Individual Parts.									All	3500		
0320	92986	260957	No Replacement Repair With Individual Parts.									All	3500		
0321	92982	260957	No Replacement Repair With Individual Parts.									All	3500		
0322	92902	260957	No Replacement Repair With Individual Parts.									All	3500		
0323	92902	260957	No Replacement Repair With Individual Parts.									All	3500		
0324	92906	260098	122K02	0518	1	690319	1	691851	25		All	3500			
0325	92906	260124	9M902	0015					73		All	3500			
0326	92982	260957	No Replacement Repair With Individual Parts.									All	3500		
0327	92906	260096	9M902	0016							All	3300			
0328	92902	260096	122K02	0516					25		All	3300			
0329	92902	260124	122K02	0515	1	492177	1	492893	25		All	3500			
					1	690319	1	691851							
0330	92902	260096	9M902	0016					73		All	4000			
0331	92992	260224	No Replacement Repair With Individual Parts.									All	3500		
0332	92992	260224	No Replacement Repair With Individual Parts.									All	3500		
0333	92982	260912	No Replacement Repair With Individual Parts.									All	3500		
0334	92902	260098	122K02	0518	1	492177	1	492893	25		All	4000			
					1	690319	1	691290							
0335	92996	260099	No Replacement Repair With Individual Parts.									All	3500		
0336	92992	260099	No Replacement Repair With Individual Parts.									All	3500		
0337	92902	260096	122K02	0516					25		All	3300			
0338	92906	260097	No Replacement Repair With Individual Parts.									All	3300		
0339	92906	260124	No Replacement Repair With Individual Parts.									All	3500		
0340	92902	260098	122K02	0518	1	690319	1	691290	25		All	4000			
0341	92996	260224	No Replacement Repair With Individual Parts.									All	3500		
0342	92902	260370	No Replacement Repair With Individual Parts.									All	3300		
0343	92902	260124	9M902	0015							All	3300			
0344	92982	260912	No Replacement Repair With Individual Parts.									All	3300		
0345	92986	260912	No Replacement Repair With Individual Parts.									All	3300		
0346	92902	260957	9M902	0015					14		All	3500			
0347	92906	260957	9M902	0015					14		All	3500			
0348	92902	260124	9M902	0015					73		All	3500			
0349	92902	260096	9M902	0016							All	3500			
0350	92902	260096	9M902	0016							All	3500			
0351	92901	260124	9M902	0015							All	3500			
0352	92902	260096	9M902	0016							All	3500			
0353	92906	260096	122K02	0516	1	690319	1	691851	25		All	3500			
0354	92902	260096	No Replacement Repair With Individual Parts.									All	4000		
0355	92902	260124	9M902	0015							All	3300			
0356	92982	260911	No Replacement Repair With Individual Parts.									All	3500		
0357	92902	260235	9M902	0015					73		All	3500			
0358	92902	260124	9M902	0015					73		All	4000			
0359	92902	260096	122K02	0516	1	690319	1	691851	25		All	3500			
0360	92902	260098	122K02	0518	1	492177	1	492893	25		All	3500			
					1	690319	1	691851							
0361	92982	260911	No Replacement Repair With Individual Parts.									All	3500		
0362	92992	260099	No Replacement Repair With Individual Parts.									All	3500		
0363	92992	260099	No Replacement Repair With Individual Parts.									All	3500		
0364	92992	260224	No Replacement Repair With Individual Parts.									All	3500		
0365	92902	260124	9M902	0015							All	3500			
0366	92906	260370	No Replacement Repair With Individual Parts.									All	3500		
0367	92902	260096	9M902	0016							All	3500			
0368	92902	260098	122K02	0518	1	492177	1	492893	25		All	4000			
					1	690319	1	691290							

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
0369	92902	260098	122K02	0518	1	690319	1	691851	25		All	3500			
0370	92902	260124	9M902	0015					73		All	3500			
0371	92906	260096	9M902	0016							All	3500			
0372	92902	260098	122K02	0518	1	492177	1	492893	25		All	3500			
					1	690319	1	691851							
0373	92902	260124	122K02	0515	1	690319	1	691290	25		All	4000			
0374	92902	260124	9M902	0015					73		All	4000			
0375	92982	260911	No Replacement Repair With Individual Parts.									All	3500		
0376	92902	260124	No Replacement Repair With Individual Parts.									All	4000		
0377	92902	260124	122K02	0515	1	690319	1	691851	25		All	3300			
0378	92906	260124	9M902	0015							All	3300			
0379	92992	260856	No Replacement Repair With Individual Parts.									All	3500		
0380	92982	260911	No Replacement Repair With Individual Parts.									All	3300		
0381	92902	260097	No Replacement Repair With Individual Parts.									All	3500		
0382	92902	260096	9M902	0016					73		All	3300			
0383	92902	260098	122K02	0518	1	492177	1	492893	25		All	3500			
					1	690319	1	691851							
0384	92982	260911	No Replacement Repair With Individual Parts.									All	3300		
0385	92982	260914	No Replacement Repair With Individual Parts.									All	4000		
0386	92902	260097	No Replacement Repair With Individual Parts.									All	4000		
0387	92902	260124	122K02	0515	1	690319	1	691290	25		All	4000			
0388	92902	260096	122K02	0516	1	492177	1	492893	25		All	3500			
0389	92906	260097	No Replacement Repair With Individual Parts.									All	3300		
0390	92906	260098	122K02	0518	1	690319	1	691851	25		All	3300			
0391	92902	260098	No Replacement Repair With Individual Parts.									All	4000		
0392	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
0393	92902	260096	122K02	0516					25		All	3300			
0394	92992	260099	No Replacement Repair With Individual Parts.									All	3300		
0395	92902	260098	122K02	0518	1	690319	1	691851	25		All	3300			
0396	92902	260098	122K02	0518	1	690319	1	691851	25		All	3500			
0397	92902	260124	9M902	0015					73		All	4000			
0398	92902	260098	122K02	0518	1	690319	1	691851	25		All	3500			
0399	92982	260914	No Replacement Repair With Individual Parts.									All	3500		
0400	92902	260124	9M902	0015					73		All	3300			
0401	92902	260096	9M902	0016							All	3300			
0403	92982	260911	No Replacement Repair With Individual Parts.									All	4000		
0404	92982	260912	No Replacement Repair With Individual Parts.									All	3300		
0405	92902	260096	122K02	0516	1	492177	1	492893	25		All	3500			
					1	690315	1	691851							
0406	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
0407	92902	260124	9M902	0015							All	4000			
0408	92906	260124	9M902	0015							All	4000			
0409	92902	260098	122K02	0518	1	492177	1	492893	25		All	4000			
					1	690319	1	691851							
0410	92982	260911	No Replacement Repair With Individual Parts.									All	3500		
0411	92902	260124	9M902	0015							All	3500			
0412	92992	260099	No Replacement Repair With Individual Parts.									All	3300		
0413	92992	260099	No Replacement Repair With Individual Parts.									All	3300		
0414	92986	260911	No Replacement Repair With Individual Parts.									All	3300		
0415	92982	260914	No Replacement Repair With Individual Parts.									All	3500		
0416	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
0417	92982	260914	No Replacement Repair With Individual Parts.									All	3500		
0418	92986	260912	No Replacement Repair With Individual Parts.									All	3300		
0419	92901	260097	No Replacement Repair With Individual Parts.									All	3300		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
0420	92982	260911	No Replacement Repair With Individual Parts.									All	3500		
0421	92902	260096	9M902	0016							All	3300			
0422	92992	260856	No Replacement Repair With Individual Parts.									All	3500		
0424	92902	260098	122K02	0518	1	690319	1	691851	25		All	3500			
0425	92902	260096	9M902	0016					73		All	3500			
0426	92902	260124	9M902	0015					73		All	3500			
0427	92982	260911	No Replacement Repair With Individual Parts.									All	3500		
0428	92902	260096	122K02	0515	1	690319	1	691851	25		All	3300			
0429	92982	260911	No Replacement Repair With Individual Parts.									All	4000		
0430	92906	260096	122K02	0516	1	690319	1	691851	25		All	3500			
0431	92902	260124	122K02	0515	1	690319	1	691290	25		All	4000			
0432	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
0433	92902	260096	122K02	0516					25		All	3300			
0434	92986	260911	No Replacement Repair With Individual Parts.									All	3500		
0435	92902	260097	No Replacement Repair With Individual Parts.									All	4000		
0436	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
0437	92902	260124	122K02	0515	1	690319	1	691290	25		All	4000			
0438	92982	260911	No Replacement Repair With Individual Parts.									All	3300		
0439	92982	260912	No Replacement Repair With Individual Parts.									All	3500		
0440	92902	260096	9M902	0016							All	3500			
0441	92902	260124	122K02	0515	1	690319	1	691851	25		All	3300			
0442	92902	260124	122K02	0515	1	690319	1	691290	25		All	4000			
0443	92906	260124	122K02	0515	1	690319	1	691290	25		All	4000			
0444	92902	260096	122K02	0516					25		All	3300			
0445	92902	260124	9M902	0015							All	3500			
0446	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
0447	92902	260098	No Replacement Repair With Individual Parts.									All	3500		
0448	92902	260098	No Replacement Repair With Individual Parts.									All	2900		
0449	92902	260098	No Replacement Repair With Individual Parts.									All	2900		
0450	92982	260911	No Replacement Repair With Individual Parts.									All	3300		
0451	92902	260098	122K02	0518	1	492177	1	492893	25		All	3700			
						1	690319	1	691290						
0452	92902	260097	No Replacement Repair With Individual Parts.									All	3200		
0515	92902	260124	9M902	0015					73		All	3200			
0516	92902	260124	9M902	0015							All	3200			
0517	92902	260096	9M902	0016							All	3200			
0519	92902	260098	9M902	0018					73		All	3200			
0521	92902	260670	9M902	0015							All	3200			
0523	92902	260097	No Replacement Repair With Individual Parts.									All	3200		
0524	92902	260957	No Replacement Repair With Individual Parts.									All	3200		
0526	92902	260400	No Replacement Repair With Individual Parts.									All	3300		
0528	92902	260411	No Replacement Repair With Individual Parts.									All	4000		
0529	92902	260370	No Replacement Repair With Individual Parts.									All	3200		
0530	92906	260124	9M902	0015							All	3200			
0532	92906	260670	No Replacement Repair With Individual Parts.									All	3500		
0533	92906	260400	No Replacement Repair With Individual Parts.									All	3300		
0534	92906	260957	No Replacement Repair With Individual Parts.									All	3200		
0535	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
0536	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
0540	92992	260099	No Replacement Repair With Individual Parts.									All	3500		
0542	92992	260099	No Replacement Repair With Individual Parts.									All	3200		
0543	92992	260224	No Replacement Repair With Individual Parts.									All	3200		
0544	92992	260224	No Replacement Repair With Individual Parts.									All	3200		
0545	92998	261007	No Replacement Repair With Individual Parts.									All	3200		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0550	92982	260914	No Replacement Repair With Individual Parts.								All	3200		
0551	92982	260911	No Replacement Repair With Individual Parts.								All	3200		
0560	92986	260911	No Replacement Repair With Individual Parts.								All	3200		
0565	92988	261021	No Replacement Repair With Individual Parts.								All	3200		
0566	92988	261021	No Replacement Repair With Individual Parts.								All	3300		
0567	92988	261052	No Replacement Repair With Individual Parts.								All	3200		
0571	92908	261030	122K02	0515					25		All	3200		
0572	92908	261012	122K02	0516					25		All	3200		
0573	92908	261013	No Replacement Repair With Individual Parts.								All	3200		
0574	92908	261014	122K02	0518					25		All	3200		
0575	92908	261050	No Replacement Repair With Individual Parts.								All	3300		
0576	92908	261050	No Replacement Repair With Individual Parts.								All	3100		
0577	92908	261133	No Replacement Repair With Individual Parts.								All	3300		
0578	92908	261050	No Replacement Repair With Individual Parts.								All	3100		
0579	92908	261133	No Replacement Repair With Individual Parts.								All	3300		
0580	92908	261293	No Replacement Repair With Individual Parts.								All	3000		
0601	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500		
0602	92902	260096	9M902	0016							All	3500		
0603	92902	260097	No Replacement Repair With Individual Parts.								All	3500		
0604	92902	260098	122K02	0518	1	492177	1	492893	25		All	3500		
						1	690319	1	691851					
0605	92902	260124	No Replacement Repair With Individual Parts.								All	3500		
0609	92905	261030	No Replacement Repair With Individual Parts.								All	3500		
0610	92905	261012	No Replacement Repair With Individual Parts.								All	3500		
0611	92905	261013	No Replacement Repair With Individual Parts.								All	3500		
0612	92905	261014	No Replacement Repair With Individual Parts.								All	3500		
0613	92906	260124	9M902	0015							All	3500		
0614	92906	260096	9M902	0016							All	3500		
0615	92906	260097	No Replacement Repair With Individual Parts.								All	3500		
0616	92906	260098	122K02	0518	1	690319	1	691851	25		All	3500		
0617	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500		
0618	92908	261012	122K02	0516					25		All	3500		
0619	92908	261013	No Replacement Repair With Individual Parts.								All	3500		
0620	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500		
0621	92982	260911	No Replacement Repair With Individual Parts.								All	3500		
0622	92982	260912	No Replacement Repair With Individual Parts.								All	3500		
0623	92982	260913	No Replacement Repair With Individual Parts.								All	3500		
0624	92982	260914	No Replacement Repair With Individual Parts.								All	3500		
0629	92985	261021	No Replacement Repair With Individual Parts.								All	3500		
0630	92985	261022	No Replacement Repair With Individual Parts.								All	3500		
0631	92985	261023	No Replacement Repair With Individual Parts.								All	3500		
0632	92985	261024	No Replacement Repair With Individual Parts.								All	3500		
0633	92986	260911	No Replacement Repair With Individual Parts.								All	3500		
0634	92986	260912	No Replacement Repair With Individual Parts.								All	3500		
0635	92986	260913	No Replacement Repair With Individual Parts.								All	3500		
0636	92986	260914	No Replacement Repair With Individual Parts.								All	3500		
0637	92988	261021	No Replacement Repair With Individual Parts.								All	3500		
0638	92988	261022	No Replacement Repair With Individual Parts.								All	3500		
0639	92988	261023	No Replacement Repair With Individual Parts.								All	3500		
0640	92988	261024	No Replacement Repair With Individual Parts.								All	3500		
0641	92992	260099	No Replacement Repair With Individual Parts.								All	3500		
0642	92992	260224	No Replacement Repair With Individual Parts.								All	3500		
0645	92995	261006	No Replacement Repair With Individual Parts.								All	3500		
0646	92995	261007	No Replacement Repair With Individual Parts.								All	3500		
0647	92996	260099	No Replacement Repair With Individual Parts.								All	3500		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0648	92996	260224	No Replacement Repair With Individual Parts.								All	3500		
0649	92998	261006	No Replacement Repair With Individual Parts.								All	3500		
0650	92998	261007	No Replacement Repair With Individual Parts.								All	3500		
0652	92902	260124	9M902	0015							All	3500		
0654	92905	261030	No Replacement Repair With Individual Parts.								All	3500		
0655	92906	260124	9M902	0015							All	3500		
0656	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500		
0657	92982	260911	No Replacement Repair With Individual Parts.								All	3500		
0659	92985	261021	No Replacement Repair With Individual Parts.								All	3500		
0660	92986	260911	No Replacement Repair With Individual Parts.								All	3500		
0661	92988	261021	No Replacement Repair With Individual Parts.								All	3500		
0662	92992	260099	No Replacement Repair With Individual Parts.								All	3500		
0664	92995	261006	No Replacement Repair With Individual Parts.								All	3500		
0665	92996	260099	No Replacement Repair With Individual Parts.								All	3500		
0666	92998	261006	No Replacement Repair With Individual Parts.								All	3500		
0668	92982	260911	No Replacement Repair With Individual Parts.								All	3500		
0670	92902	260124	9M902	0015					73		All	4000		
0671	92902	260096	9M902	0016							All	3500		
0672	92908	261012	122K02	0516					25		All	3000		
0673	92902	260124	9M902	0015							All	3100		
0674	92906	260098	122K02	0518					25		All	3100		
0675	92982	260914	No Replacement Repair With Individual Parts.								All	3100		
0676	92982	260957	No Replacement Repair With Individual Parts.								All	3100		
0677	92902	260124	122K02	0515	1	492177	1	492893	25		All	3200		
0678	92902	260096	122K02	0516	1	492177	1	492893	25		All	3500		
0679	92906	260124	9M902	0015							All	4000		
0680	92902	260124	9M902	0015							All	3300		
0681	92908	261030	122K02	0515	1	690319	1	691851	25		All	3300		
0682	92902	260124	9M902	0015					73		All	3500		
0683	92902	260098	122K02	0518	1	262665	1	492893	25		All	3500		
					1	492177	1	691851						
0684	92908	261030	122K02	0515					25		All	3100		
0685	92902	260124	122K02	0515	1	690319	1	691851	25		All	3300		
0686	92902	260098	122K02	0518	1	690319	1	691851	25		All	3500		
0687	92902	260124	9M902	0015					73		All	3300		
0688	92902	260096	9M902	0016							All	3500		
0689	92902	260319	No Replacement Repair With Individual Parts.								All	3300		
0690	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500		
0691	92902	260124	122K02	0515	1	690319	1	691290	25		All	4000		
0692	92902	260124	122K02	0515	1	690319	1	691290	25		All	4000		
0693	92902	260098	122K02	0518					25		All	3200		
0694	92908	261030	122K02	0515					25		All	3000		
0695	92982	260911	No Replacement Repair With Individual Parts.								All	3000		
0696	92982	260912	No Replacement Repair With Individual Parts.								All	3000		
0697	92982	260911	No Replacement Repair With Individual Parts.								All	3000		
0698	92985	261021	No Replacement Repair With Individual Parts.								All	3000		
0699	92908	261014	122K02	0518	1	690319	1	691851	25		All	3300		
0700	92902	260098	122K02	0518	1	690319	1	691851	25		All	3300		
0701	92988	261021	No Replacement Repair With Individual Parts.								All	3300		
0702	92902	260124	122K02	0515	1	690319	1	691851	25		All	3300		
0703	92908	261030	122K02	0515	1	690319	1	691851	25		All	3300		
0704	92902	260097	No Replacement Repair With Individual Parts.								All	3500		
0705	92902	260124	122K02	0515					25		All	3300		
0706	92908	261030	122K02	0515					25		All	3300		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0707	92902	260319	122K02	0516	1	492177	1	492893	25					
0708	92906	260124	9M902	0015							All	3300		
0709	92902	260124	122K02	0515					25		All	3100		
0710	92908	261030	122K02	0515					25		All	3100		
0711	92902	260124	122K02	0515	1	690319	1	691851	25		All	3300		
0712	92908	261030	122K02	0515	1	690319	1	691851	25		All	3300		
0713	92982	260911	No Replacement Repair With Individual Parts.								All	3300		
0714	92992	260224	No Replacement Repair With Individual Parts.								All	3300		
0715	92902	260097	No Replacement Repair With Individual Parts.								All	3500		
0716	92902	260124	9M902	0015					73		All	3300		
0717	92982	260914	No Replacement Repair With Individual Parts.								All	3500		
0718	92902	260098	122K02	0518	1	492177	1	492893	25		All	3700		
						1	690319	1	691862					
0719	92908	261013	No Replacement Repair With Individual Parts.								All	3100		
0720	92908	261012	122K02	0516					25		All	3300		
0721	92988	261024	No Replacement Repair With Individual Parts.								All	3100		
0722	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500		
0723	92998	261007	No Replacement Repair With Individual Parts.								All	3300		
0724	92998	261007	No Replacement Repair With Individual Parts.								All	3300		
0725	92902	260097	No Replacement Repair With Individual Parts.								All	3100		
0726	92908	261013	No Replacement Repair With Individual Parts.								All	3100		
0727	92902	260096	122K02	0516					25		All	3300		
0728	92906	260096	9M902	0016							All	3300		
0729	92992	260099	No Replacement Repair With Individual Parts.								All	3300		
0730	92996	260099	No Replacement Repair With Individual Parts.								All	3300		
0731	92902	260098	122K02	0518	1	690319	1	691851	25		All	3500		
0732	92902	260098	122K02	0518	1	492177	1	492893	25		All	3500		
						1	690319	1	691851					
0733	92908	261012	122K02	0516					25		All	3300		
0734	92988	261021	No Replacement Repair With Individual Parts.								All	3300		
0735	92908	261012	122K02	0516					25		All	3300		
0736	92998	261028	No Replacement Repair With Individual Parts.								All	3300		
0737	92995	261028	No Replacement Repair With Individual Parts.								All	3300		
0738	92902	260098	122K02	0518	1	690319	1	691851	25		All	4000		
0739	92902	260411	No Replacement Repair With Individual Parts.								All	4000		
0740	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500		
0741	92902	260096	122K02	0516					25		All	3300		
0742	92988	261022	No Replacement Repair With Individual Parts.								All	3300		
0743	92905	261032	No Replacement Repair With Individual Parts.								All	3300		
0744	92908	261032	122K02	0515					25		All	3300		
0745	92908	261033	122K02	0516					25		All	3000		
0746	92995	261051	No Replacement Repair With Individual Parts.								All	3300		
0747	92998	261051	No Replacement Repair With Individual Parts.								All	3300		
0748	92985	261023	No Replacement Repair With Individual Parts.								All	3100		
0749	92908	261030	122K02	0515					25		All	3300		
0750	92905	261030	No Replacement Repair With Individual Parts.								All	3300		
0751	92905	261014	No Replacement Repair With Individual Parts.								All	3500		
0752	92992	260224	No Replacement Repair With Individual Parts.								All	3300		
0753	92905	261030	No Replacement Repair With Individual Parts.								All	3500		
0754	92902	260098	122K02	0518	1	690319	1	691851	25		All	3500		
0755	92902	260096	122K02	0516					25		All	3300		
0756	92902	260124	122K02	0515					25		All	3000		
0757	92902	260096	9M902	0016							All	3500		
0758	92982	260912	No Replacement Repair With Individual Parts.								All	3500		
0759	92988	261021	No Replacement Repair With Individual Parts.								All	3500		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
0760	92902	260096	9M902	0016					73		All	3500			
0761	92906	260096	9M902	0016							All	3300			
0762	92992	260224	No Replacement Repair With Individual Parts.									All	3000		
0763	92996	260224	No Replacement Repair With Individual Parts.									All	3300		
0764	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
0765	92908	261013	No Replacement Repair With Individual Parts.									All	3500		
0766	92902	260096	9M902	0016							All	3500			
0767	92906	260124	9M902	0015							All	3000			
0768	92902	260124	122K02	0515					25		All	3000			
0769	92902	260124	9M902	0015					73		All	3500			
0770	92902	260098	No Replacement Repair With Individual Parts.									All	4000		
0771	92901	260096	122K02	0516	1	492177	1	492893	25		All	3300			
0772	92982	260912	No Replacement Repair With Individual Parts.									All	3500		
0773	92902	260097	No Replacement Repair With Individual Parts.									All	3100		
0774	92902	260098	122K02	0518	1	690319	1	691851	25		All	3300			
0775	92906	260098	122K02	0518					25		All	3000			
0776	92908	261014	122K02	0518	1	690319	1	691851	25		All	3300			
0777	92908	261012	122K02	0516					25		All	3000			
0778	92902	260124	122K02	0515	1	690319	1	691851	25		All	3300			
0779	92998	261028	No Replacement Repair With Individual Parts.									All	3500		
0780	92902	260098	122K02	0518	1	492177	1	492893	25		All	4000			
					1	690319	1	691862							
0781	92906	260124	9M902	0015							All	3200			
0782	92902	260124	9M902	0015	1	690251	1	690252			All	3500			
0783	92902	260098	122K02	0518	1	492177	1	492893	25		All	4000			
					1	690319	1	691862							
0784	92902	260124	122K02	0515	1	690319	1	691862	25		All	4000			
0785	92902	260124	9M902	0015					25		All	4000			
0786	92902	260096	9M902	0016					25		All	4000			
0787	92902	260096	122K02	0516					25		All	3200			
0788	92992	260099	No Replacement Repair With Individual Parts.									All	3200		
0789	92996	260099	No Replacement Repair With Individual Parts.									All	3200		
0790	92908	261014	No Replacement Repair With Individual Parts.									All	3100		
0791	92908	261014	No Replacement Repair With Individual Parts.									All	3300		
0792	92902	260370	No Replacement Repair With Individual Parts.									All	3300		
0793	92905	261050	No Replacement Repair With Individual Parts.									All	3300		
0794	92908	261050	No Replacement Repair With Individual Parts.									All	3300		
0795	92902	260098	No Replacement Repair With Individual Parts.									All	4000		
0796	92905	261030	122K02	0515	1	690319	1	691851	25		All	3300			
0797	92902	260096	9M902	0016							All	3300			
0798	92905	261029	No Replacement Repair With Individual Parts.									All	3100		
0799	92985	261052	No Replacement Repair With Individual Parts.									All	3100		
0800	92998	261006	No Replacement Repair With Individual Parts.									All	3200		
0801	92902	260124	122K02	0515	1	690319	1	691851	25		All	3300			
0802	92982	260911	No Replacement Repair With Individual Parts.									All	3300		
0803	92902	260124	9M902	0015					73		All	4000			
0804	92908	261030	122K02	0515					25		All	3200			
0805	92902	260096	122K02	0516	1	492177	1	492893	25		All	3300			
0806	92902	260124	No Replacement Repair With Individual Parts.									All	4000		
0807	92982	260911	No Replacement Repair With Individual Parts.									All	3300		
0808	92988	261023	No Replacement Repair With Individual Parts.									All	3100		
0809	92986	260911	No Replacement Repair With Individual Parts.									All	3300		
0810	92988	261021	No Replacement Repair With Individual Parts.									All	3300		
0811	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0812	92998	261051	No Replacement Repair With Individual Parts.								All	3500		
0813	92902	260124	122K02	0515					25		All	3200		
0814	92906	260124	9M902	0015							All	3200		
0815	92908	261030	122K02	0515					25		All	3200		
0816	92902	260096	122K02	0516					25		All	3200		
0817	92992	260099	No Replacement Repair With Individual Parts.								All	3200		
0818	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500		
0819	92902	260098	122K02	0518	1	492177	1	492893	25		All	3300		
					1	690319	1	691851						
0820	92908	261012	122K02	0516					25		All	3300		
0821	92902	260096	122K02	0516					25		All	3300		
0822	92902	260096	9M902	0016							All	3300		
0823	92992	260099	No Replacement Repair With Individual Parts.								All	3500		
0824	92902	260124	122K02	0515					25		All	3000		
0825	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500		
0826	92902	260124	9M902	0015					73		All	3500		
0827	92905	261012	No Replacement Repair With Individual Parts.								All	3500		
0828	92905	261014	No Replacement Repair With Individual Parts.								All	3200		
0829	92905	261012	No Replacement Repair With Individual Parts.								All	3300		
0830	92905	261013	No Replacement Repair With Individual Parts.								All	3100		
0831	92905	261030	No Replacement Repair With Individual Parts.								All	4000		
0832	92905	261012	No Replacement Repair With Individual Parts.								All	3500		
0833	92905	261014	No Replacement Repair With Individual Parts.								All	3500		
0834	92905	261030	No Replacement Repair With Individual Parts.								All	3300		
0835	92985	261021	No Replacement Repair With Individual Parts.								All	3300		
0836	92905	261030	No Replacement Repair With Individual Parts.								All	3100		
0837	92905	261012	No Replacement Repair With Individual Parts.								All	3200		
0838	92995	261007	No Replacement Repair With Individual Parts.								All	3000		
0839	92995	261028	No Replacement Repair With Individual Parts.								All	3500		
0840	92905	261014	No Replacement Repair With Individual Parts.								All	3500		
0841	92995	261007	No Replacement Repair With Individual Parts.								All	3300		
0842	92982	260911	No Replacement Repair With Individual Parts.								All	3300		
0843	92902	260096	9M902	0016							All	3300		
0844	92902	260096	9M902	0016							All	3300		
0845	92902	260098	122K02	0518					25		All	3100		
0846	92908	261014	122K02	0518					25		All	3100		
0847	92906	260097	No Replacement Repair With Individual Parts.								All	3000		
0848	92908	261013	No Replacement Repair With Individual Parts.								All	3100		
0849	92998	261007	No Replacement Repair With Individual Parts.								All	3100		
0850	92908	261012	122K02	0516					25		All	3500		
0851	92902	260124	122K02	0515	1	690319	1	691862	25		All	4000		
0852	92908	261030	122K02	0515					25		All	3000		
0853	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500		
0854	92998	261006	No Replacement Repair With Individual Parts.								All	3500		
0855	92902	260124	9M902	0015					73		All	3500		
0856	92902	260096	9M902	0016							All	3000		
0857	92902	260096	9M902	0016					73		All	3000		
0858	92906	260096	9M902	0016							All	3000		
0859	92996	260224	No Replacement Repair With Individual Parts.								All	3000		
0860	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500		
0861	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500		
0862	92988	261021	No Replacement Repair With Individual Parts.								All	3000		
0863	92906	260096	9M902	0016							All	3500		
0864	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500		
0865	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block			
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes		
0866	92906	260096	9M902	0016							All	3300				
0867	92902	260096	9M902	0016							All	3500				
0868	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500				
0869	92992	260099	No Replacement Repair With Individual Parts.										All	3500		
0870	92998	261006	No Replacement Repair With Individual Parts.										All	3500		
0871	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500				
0872	92902	260957	9M902	0015					14		All	3100				
0873	92906	260957	9M902	0015					14		All	3100				
0874	92988	261021	No Replacement Repair With Individual Parts.										All	3000		
0875	92902	260098	122K02	0518	1	492177	1	492893	25		All	3300				
					1	690319	1	691851								
0876	92905	261032	No Replacement Repair With Individual Parts.										All	3300		
0877	92902	260097	No Replacement Repair With Individual Parts.										All	3500		
0878	92902	260124	122K02	0515					25		All	3000				
0879	92982	260957	No Replacement Repair With Individual Parts.										All	3100		
0880	92995	261007	No Replacement Repair With Individual Parts.										All	3300		
0881	92908	261030	No Replacement Repair With Individual Parts.										All	3500		
0882	92908	261012	122K02	0516					25		All	3300				
0883	92992	260099	No Replacement Repair With Individual Parts.										All	3500		
0884	92908	261012	122K02	0516					25		All	3300				
0885	92982	260914	No Replacement Repair With Individual Parts.										All	3100		
0886	92902	260096	122K02	0516					25		All	3500				
0887	92992	260099	No Replacement Repair With Individual Parts.										All	3500		
0888	92905	261013	No Replacement Repair With Individual Parts.										All	3300		
0889	92992	260099	No Replacement Repair With Individual Parts.										All	3300		
0890	92905	261014	No Replacement Repair With Individual Parts.										All	3000		
0891	92906	260124	9M902	0015					73		All	4000				
0892	92908	261030	122K02	0515	1	690319	1	691851	25		All	3300				
0893	92902	260096	9M902	0016					73		All	3500				
0894	92902	260098	No Replacement Repair With Individual Parts.										All	3300		
0895	92905	261030	No Replacement Repair With Individual Parts.										All	3300		
0896	92985	261021	No Replacement Repair With Individual Parts.										All	3300		
0897	92982	260911	No Replacement Repair With Individual Parts.										All	3300		
0898	92905	261030	No Replacement Repair With Individual Parts.										All	3500		
0899	92982	260911	No Replacement Repair With Individual Parts.										All	3500		
0900	92905	261013	No Replacement Repair With Individual Parts.										All	3100		
0901	92902	260096	122K02	0516	1	492177	1	492893	25		All	3500				
					1	690319	1	691851								
0902	92902	260124	122K02	0515	1	690319	1	691851	25		All	3300				
0903	92982	260911	No Replacement Repair With Individual Parts.										All	3500		
0904	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500				
0905	92992	260224	No Replacement Repair With Individual Parts.										All	3000		
0906	92905	261030	No Replacement Repair With Individual Parts.										All	3000		
0907	92908	261030	122K02	0515	1	690319	1	691851	25		All	3300				
0908	92905	261030	No Replacement Repair With Individual Parts.										All	3300		
0909	92908	261012	122K02	0516					25		All	3300				
0910	92908	261012	122K02	0516					25		All	3000				
0911	92986	260911	No Replacement Repair With Individual Parts.										All	3500		
0912	92906	260124	9M902	0015							All	3500				
0913	92902	260096	9M902	0016							All	3300				
0914	92992	260224	No Replacement Repair With Individual Parts.										All	3500		
0915	92902	260096	122K02	0516	1	492177	1	492893	25		All	3500				
					1	690319	1	691851								
0916	92902	260124	122K02	0515					25		All	3000				
0917	92902	260096	9M902	0016							All	3000				

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0918	92902	260097	No Replacement Repair With Individual Parts.								All	3500		
0919	92902	260124	9M902	0015					73		All	3300		
0920	92902	260124	9M902	0015					73		All	3500		
0921	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500		
0922	92902	260124	9M902	0015					73		All	3300		
0923	92902	260124	122K02	0515					25		All	3000		
0924	92988	261021	No Replacement Repair With Individual Parts.								All	3300		
0925	92988	261021	No Replacement Repair With Individual Parts.								All	3500		
0926	92908	261030	122K02	0515	1	690319	1	691851	25		All	3300		
0927	92988	261021	No Replacement Repair With Individual Parts.								All	3500		
0928	92901	260097	No Replacement Repair With Individual Parts.								All	3300		
0929	92902	260098	122K02	0518	1	492177	1	492893	25		All	3500		
					1	690319	1	691851						
0930	92992	260224	No Replacement Repair With Individual Parts.								All	3300		
0931	92992	260224	No Replacement Repair With Individual Parts.								All	3100		
0932	92996	260224	No Replacement Repair With Individual Parts.								All	3100		
0933	92902	260096	9M902	0016					73		All	3500		
0934	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500		
0935	92908	261014	122K02	0518					25		All	3200		
0936	92908	261014	122K02	0518					25		All	3200		
0937	92992	260224	No Replacement Repair With Individual Parts.								All	3000		
0938	92902	260124	122K02	0515					25		All	3200		
0939	92902	260098	122K02	0518					25		All	3300		
0940	92982	260914	No Replacement Repair With Individual Parts.								All	3300		
0941	92905	261014	No Replacement Repair With Individual Parts.								All	3300		
0942	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500		
0943	92982	260911	No Replacement Repair With Individual Parts.								All	3500		
0944	92905	261012	No Replacement Repair With Individual Parts.								All	3300		
0945	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500		
0946	92905	261030	No Replacement Repair With Individual Parts.								All	3300		
0947	92905	261014	No Replacement Repair With Individual Parts.								All	3300		
0948	92902	260096	9M902	0016							All	3500		
0949	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500		
0950	92902	260124	9M902	0015					73		All	3300		
0951	92902	260096	9M902	0016							All	3500		
0952	92908	261030	122K02	0515	1	690319	1	691851	25		All	3300		
0953	92902	260096	9M902	0016					73		All	3500		
0954	92982	260911	No Replacement Repair With Individual Parts.								All	3500		
0955	92906	260096	9M902	0016							All	4000		
0956	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500		
0957	92902	260124	122K02	0515	1	492177	1	492893	25		All	3200		
0958	92985	261024	No Replacement Repair With Individual Parts.								All	3300		
0959	92988	260124	No Replacement Repair With Individual Parts.								All	3300		
0960	92988	261021	No Replacement Repair With Individual Parts.								All	3500		
0961	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500		
0962	92902	260204	No Replacement Repair With Individual Parts.								All	3500		
0963	92902	260096	9M902	0016							All	3300		
0964	92902	260096	9M902	0016							All	3500		
0965	92902	260096	122K02	0516					25		All	3300		
0966	92908	261012	122K02	0516	1	690319	1	691851	25		All	4000		
0967	92902	260098	122K02	0518	1	492177	1	492893	25		All	3500		
					1	690319	1	691851						
0968	92908	261012	No Replacement Repair With Individual Parts.								All	3500		
0969	92906	260096	122K02	0516					25		All	3300		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
0970	92902	260124	9M902	0015							All	3000			
0971	92902	260098	122K02	0518	1	492177	1	492893	25		All	3500			
					1	690319	1	691851							
0972	92902	260124	9M902	0015					25		All	3500			
0973	92902	260235	9M902	0015					73		All	4000			
0974	92902	260098	122K02	0518	1	492177	1	492893	25		All	3500			
					1	690319	1	691851							
0975	92902	260098	122K02	0518					25		All	3100			
0976	92982	260911	No Replacement Repair With Individual Parts.									All	3000		
0977	92908	261030	122K02	0515	1	690319	1	691851	25		All	3300			
0978	92982	260911	No Replacement Repair With Individual Parts.									All	3300		
0979	92982	260912	No Replacement Repair With Individual Parts.									All	3500		
0980	92902	260124	9M902	0015					73		All	3200			
0981	92902	260096	9M902	0016							All	3300			
0982	92982	260911	No Replacement Repair With Individual Parts.									All	3500		
0983	92902	260096	122K02	0516	1	492177	1	492893	25		All	3500			
					1	690319	1	691851							
0984	92902	260098	122K02	0518	1	690319	1	691851	25		All	3500			
0985	92988	261052	No Replacement Repair With Individual Parts.									All	3100		
0986	92902	260098	122K02	0518					25		All	3100			
0987	92902	260124	122K02	0515					25		All	3000			
0988	92902	260098	122K02	0518	1	492177	1	492893	25		All	3000			
0989	92902	260096	9M902	0016					73		All	3500			
0990	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500			
0991	92992	260099	No Replacement Repair With Individual Parts.									All	3500		
0992	92902	260098	122K02	0518	1	492177	1	492893	25		All	3300			
0993	92985	261021	No Replacement Repair With Individual Parts.									All	3300		
0994	92988	261021	No Replacement Repair With Individual Parts.									All	3300		
0995	92906	260096	9M902	0016							All	3200			
0996	92908	261012	122K02	0516					25		All	3200			
0997	92902	260098	122K02	0518					25		All	3000			
0998	92908	261014	122K02	0518					25		All	3000			
0999	92902	260096	9M902	0016							All	3000			
1000	92905	261014	No Replacement Repair With Individual Parts.									All	3000		
1001	92982	260911	No Replacement Repair With Individual Parts.									All	3000		
1002	92902	260098	122K02	0518	1	690319	1	691851	25		All	3500			
1003	92908	261014	122K02	0518	1	690319	1	691851	25		All	3300			
1004	92908	261014	122K02	0518					25		All	3000			
1005	92992	260099	No Replacement Repair With Individual Parts.									All	3000		
1006	92902	260096	122K02	0516	1	690319	1	691851	25		All	3500			
1007	92995	261028	No Replacement Repair With Individual Parts.									All	3300		
1008	92998	261028	No Replacement Repair With Individual Parts.									All	3300		
1009	92982	260914	No Replacement Repair With Individual Parts.									All	3100		
1010	92985	261021	No Replacement Repair With Individual Parts.									All	3000		
1011	92988	261021	No Replacement Repair With Individual Parts.									All	3000		
1012	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500			
1013	92908	261030	122K02	0515					25		All	3200			
1014	92998	261007	No Replacement Repair With Individual Parts.									All	3000		
1015	92988	261021	No Replacement Repair With Individual Parts.									All	3000		
1016	92902	260098	122K02	0518					25		All	3000			
1017	92902	260098	122K02	0518					25		All	3000			
1018	92902	260096	9M902	0016							All	3100			
1019	92905	261012	No Replacement Repair With Individual Parts.									All	3100		
1020	92902	260124	122K02	0515					25		All	3000			

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
1021	92982	260911	No Replacement Repair With Individual Parts.								All	3000	.	
1022	92985	261021	No Replacement Repair With Individual Parts.								All	3000	.	
1023	92988	261021	No Replacement Repair With Individual Parts.								All	3000	.	
1024	92906	260124	122K02	0515					25	All	3000			
1025	92902	260096	9M902	0016					73	All	3000			
1026	92992	260224	No Replacement Repair With Individual Parts.								All	3000		
1027	92998	261006	No Replacement Repair With Individual Parts.								All	3000		
1028	92996	260099	No Replacement Repair With Individual Parts.								All	3300		
1029	92982	260914	No Replacement Repair With Individual Parts.								All	3200		
1030	92982	260914	No Replacement Repair With Individual Parts.								All	3200		
1031	92985	261024	No Replacement Repair With Individual Parts.								All	3200		
1032	92988	261024	No Replacement Repair With Individual Parts.								All	3200		
1033	92902	260096	9M902	0016						All	3100			
1034	92908	261012	122K02	0516					25	All	3100			
1035	92908	261030	122K02	0515					25	All	3100			
1036	92908	261014	122K02	0518					25	All	3100			
1037	92905	261014	No Replacement Repair With Individual Parts.								All	3100		
1038	92985	261024	No Replacement Repair With Individual Parts.								All	3100		
1039	92988	261024	No Replacement Repair With Individual Parts.								All	3100		
1040	92908	261012	122K02	0516					25	All	3100			
1041	92902	260098	122K02	0518					25	All	3200			
1042	92902	260235	122K02	0515	1	690319	1	691851	25	All	3900			
								1	93061					
1043	92902	260124	122K02	0515					25	All	2900			
1044	92905	261030	No Replacement Repair With Individual Parts.								All	2900		
1045	92908	261030	122K02	0515					25	All	2900			
1046	92982	260911	No Replacement Repair With Individual Parts.								All	2900	.	
1047	92985	261021	No Replacement Repair With Individual Parts.								All	2900	.	
1048	92988	261021	No Replacement Repair With Individual Parts.								All	2900	.	
1049	92902	260096	9M902	0016					73	All	3500			
1050	92902	260957	9M902	0015					14	All	3100			
1051	92982	260912	No Replacement Repair With Individual Parts.								All	3300		
1052	92902	260124	122K02	0515	1	690319	1	691851	25	All	3500			
1053	92908	261014	122K02	0518					25	All	3000			
1055	92902	260096	122K02	0516	1	492177	1	492893	25	All	3500			
						1	690319	1	691851					
1056	92906	260124	9M902	0015						All	2900			
1057	92902	260124	122K02	0515					25	All	3100			
1058	92906	260124	9M902	0015						All	3100			
1059	92908	261014	122K02	0518					25	All	3000			
1060	92988	261022	No Replacement Repair With Individual Parts.								All	3500		
1061	92902	260124	9M902	0015					73	All	3200			
1062	92902	260124	122K02	0515					25	All	2900			
1063	92908	261013	No Replacement Repair With Individual Parts.								All	3300		
1064	92908	261012	122K02	0516	1	690319	1	691851	25	All	3500			
1065	92902	260124	122K02	0515	1	690319	1	691851	25	All	3300			
1066	92908	261013	No Replacement Repair With Individual Parts.								All	3000		
1067	92985	261021	No Replacement Repair With Individual Parts.								All	3200		
1068	92988	261021	No Replacement Repair With Individual Parts.								All	3200		
1069	92908	261012	122K02	0516					25	All	3100			
1070	92992	260099	No Replacement Repair With Individual Parts.								All	3000		
1071	92985	261024	No Replacement Repair With Individual Parts.								All	3100		
1072	92902	260096	9M902	0016					73	All	3300			
1073	92902	260096	9M902	0016						All	3000			
1074	92902	260096	9M902	0016						All	3000			

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
1075	92908	261012	122K02	0516					25		All	3000			
1076	92902	260096	122K02	0516					25		All	3100			
1077	92998	261006	No Replacement Repair With Individual Parts.									All	3000		
1078	92902	260235	9M902	0515							All	4000			
1079	92982	260911	No Replacement Repair With Individual Parts.									All	3000		
1080	92908	261014	122K02	0518					25		All	3100			
1081	92908	261030	122K02	0515					25		All	3200			
1082	92902	260098	122K02	0518					25		All	3100			
1083	92908	261014	122K02	0518					25		All	3100			
1084	92905	261030	No Replacement Repair With Individual Parts.									All	3100		
1085	92902	260097	No Replacement Repair With Individual Parts.									All	3000		
1086	92905	261013	No Replacement Repair With Individual Parts.									All	3000		
1087	92902	260096	9M902	0016							All	3500			
1088	92902	260098	122K02	0518					25		All	3300			
1089	92988	261021	No Replacement Repair With Individual Parts.									All	3500		
1090	92906	260096	9M902	0016							All	3100			
1091	92992	260099	No Replacement Repair With Individual Parts.									All	3100		
1092	92996	260099	No Replacement Repair With Individual Parts.									All	3100		
1093	92998	261006	No Replacement Repair With Individual Parts.									All	3100		
1094	92908	261030	122K02	0515					25		All	3000			
1095	92988	261021	No Replacement Repair With Individual Parts.									All	3000		
1096	92982	260911	No Replacement Repair With Individual Parts.									All	3000		
1097	92902	260097	No Replacement Repair With Individual Parts.									All	3700		
1098	92988	261021	No Replacement Repair With Individual Parts.									All	3000		
1099	92901	260124	122K02	0515	1	690319	1	691851	25		All	3300			
1100	92905	261012	No Replacement Repair With Individual Parts.									All	3300		
1101	92906	260098	122K02	0518					25		All	3100			
1102	92982	260911	No Replacement Repair With Individual Parts.									All	3500		
1103	92902	260124	122K02	0515					25		All	3000			
1104	92905	261012	No Replacement Repair With Individual Parts.									All	3000		
1105	92982	260914	No Replacement Repair With Individual Parts.									All	3100		
1106	92906	260124	9M902	0015							All	3300			
1107	92905	261012	No Replacement Repair With Individual Parts.									All	3500		
1108	92905	261012	No Replacement Repair With Individual Parts.									All	3300		
1109	92985	261022	No Replacement Repair With Individual Parts.									All	3100		
1110	92988	261022	No Replacement Repair With Individual Parts.									All	3100		
1111	92985	261023	No Replacement Repair With Individual Parts.									All	3100		
1112	92905	261013	No Replacement Repair With Individual Parts.									All	3100		
1113	92902	260124	122K02	0515					25		All	3200			
1114	92902	260124	122K02	0515					25		All	2900			
1115	92902	260098	122K02	0518	1	492177	1	492893	25		All	4000			
					1	690319	1	691290							
1116	92902	260096	9M902	0016							All	3200			
1117	92992	260099	No Replacement Repair With Individual Parts.									All	3200		
1118	92982	260914	No Replacement Repair With Individual Parts.									All	3300		
1119	92902	260097	No Replacement Repair With Individual Parts.									All	3300		
1120	92902	260097	No Replacement Repair With Individual Parts.									All	3300		
1121	92908	261013	No Replacement Repair With Individual Parts.									All	3300		
1122	92982	260911	No Replacement Repair With Individual Parts.									All	3100		
1123	92988	261021	No Replacement Repair With Individual Parts.									All	3100		
1124	92905	261012	No Replacement Repair With Individual Parts.									All	3500		
1125	92902	260096	9M902	0016							All	3300			
1126	92908	261012	122K02	0516					25		All	3100			
1127	92988	261022	No Replacement Repair With Individual Parts.									All	3100		
1128	92985	261022	No Replacement Repair With Individual Parts.									All	3100		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block				
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes			
1129	92908	261050	No Replacement Repair With Individual Parts.									All	3300				
1130	92908	261133	No Replacement Repair With Individual Parts.									All	3300				
1131	92988	261021	No Replacement Repair With Individual Parts.									All	3100				
1132	92985	261021	No Replacement Repair With Individual Parts.									All	3300				
1133	92988	261022	No Replacement Repair With Individual Parts.									All	3300				
1134	92988	261024	No Replacement Repair With Individual Parts.									All	3200				
1135	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500					
1136	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500					
1137	92988	261021	No Replacement Repair With Individual Parts.									All	3300				
1138	92902	260096	122K02	0516	1	492177	1	492893	25		All	3300					
1139	92908	261013	No Replacement Repair With Individual Parts.									All	3000				
1140	92902	260124	9M902	0015					73		All	3300					
1141	92985	261052	No Replacement Repair With Individual Parts.									All	3300				
1142	92982	260957	No Replacement Repair With Individual Parts.									14		All	3100		
1143	92905	261050	No Replacement Repair With Individual Parts.									All	3300				
1144	92902	260097	No Replacement Repair With Individual Parts.									All	3100				
1145	92992	260224	No Replacement Repair With Individual Parts.									All	3100				
1146	92908	261012	122K02	0516					25		All	3100					
1147	92902	260096	No Replacement Repair With Individual Parts.									All	3500				
1148	92902	260124	122K02	0515	1	690319	1	691851	25		All	3700					
1149	92902	260124	9M902	0015					73		All	3700					
1150	92982	260914	No Replacement Repair With Individual Parts.									All	3100				
1151	92905	261012	No Replacement Repair With Individual Parts.									All	3200				
1152	92998	261006	No Replacement Repair With Individual Parts.									All	3200				
1153	92988	261022	No Replacement Repair With Individual Parts.									All	3100				
1154	92905	261014	No Replacement Repair With Individual Parts.									All	3100				
1155	92905	261014	No Replacement Repair With Individual Parts.									All	3500				
1156	92905	261012	No Replacement Repair With Individual Parts.									All	3300				
1157	92985	261023	No Replacement Repair With Individual Parts.									All	3300				
1158	92988	261023	No Replacement Repair With Individual Parts.									All	3300				
1159	92985	261021	No Replacement Repair With Individual Parts.									All	3100				
1160	92988	261021	No Replacement Repair With Individual Parts.									All	3100				
1161	92908	261012	122K02	0516					25		All	3300					
1162	92908	261030	122K02	0515	1	690319	1	691851	25		All	3300					
1163	92902	260097	No Replacement Repair With Individual Parts.									All	3500				
1164	92905	261014	122K02	0518	1	690319	1	691851	25		All	3500					
1165	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500					
1166	92902	260124	122K02	0515					25		All	3100					
1167	92908	261012	122K02	0516					25		All	3300					
1168	92985	261024	No Replacement Repair With Individual Parts.									All	3200				
1169	92988	261024	No Replacement Repair With Individual Parts.									All	3200				
1170	92982	260957	No Replacement Repair With Individual Parts.									All	3100				
1171	92902	260098	122K02	0518					25		All	3100					
1172	92988	261022	No Replacement Repair With Individual Parts.									All	3500				
1173	92902	260096	122K02	0516					25		All	3100					
1174	92908	261012	122K02	0516					25		All	3100					
1175	92992	260224	No Replacement Repair With Individual Parts.									All	3000				
1176	92982	261022	No Replacement Repair With Individual Parts.									All	3100				
1177	92996	260224	No Replacement Repair With Individual Parts.									All	3000				
1178	92902	260096	122K02	0516					25		All	3100					
1179	92908	261012	122K02	0516					25		All	2900					
1180	92982	260911	No Replacement Repair With Individual Parts.									All	3000				
1181	92902	260124	122K02	0515					25		All	3000					
1182	92902	260096	9M902	0016					14		All	4000					
1183	92902	260124	9M902	0015							All	4000					

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
1184	92902	260124	122K02	0515					25		All	3000			
1185	92908	261013	No Replacement Repair With Individual Parts.									All	3300		
1186	92902	260098	122K02	0518	1	690319	1	691851	25		All	3300			
1187	92902	260097	No Replacement Repair With Individual Parts.									All	3000		
1188	92982	260911	No Replacement Repair With Individual Parts.									All	3300		
1189	92982	260957	No Replacement Repair With Individual Parts.									All	3300		
1190	92908	261014	122K02	0518					25		All	3000			
1191	92985	261024	No Replacement Repair With Individual Parts.									All	3100		
1192	92988	261024	No Replacement Repair With Individual Parts.									All	3100		
1193	92908	261030	122K02	0515					25		All	3100			
1194	92908	261012	122K02	0516					25		All	3300			
1195	92905	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1196	92982	260914	No Replacement Repair With Individual Parts.									All	3500		
1197	92985	261021	No Replacement Repair With Individual Parts.									All	3100		
1198	92988	261021	No Replacement Repair With Individual Parts.									All	3100		
1199	92902	260098	122K02	0518					25		All	3200			
1200	92988	261023	No Replacement Repair With Individual Parts.									All	3100		
1201	92982	260911	No Replacement Repair With Individual Parts.									All	3000		
1202	92988	261021	No Replacement Repair With Individual Parts.									All	3500		
1203	92902	260097	No Replacement Repair With Individual Parts.									All	3100		
1204	92908	261014	122K02	0518					25		All	3000			
1205	92902	260124	122K02	0515					25		All	3000			
1206	92992	260099	No Replacement Repair With Individual Parts.									All	3300		
1207	92902	260235	9M902	0015			1	93061	73		All	3000			
1208	92902	260124	122K02	0515	1	690319	1	691851	25		All	3300			
1209	92902	260098	122K02	0518	1	492177	1	492893	25		All	3500			
					1	690319	1	691851							
1210	92908	261050	No Replacement Repair With Individual Parts.									All	3300		
1211	92905	261050	No Replacement Repair With Individual Parts.									All	3300		
1212	92902	260096	122K02	0516					25		All	2900			
1213	92908	261012	122K02	0516					25		All	2900			
1214	92988	261024	No Replacement Repair With Individual Parts.									All	3100		
1215	92902	260124	9M902	0015					73		All	3200			
1216	92902	260370	No Replacement Repair With Individual Parts.									All	3300		
1217	92902	260124	9M902	0015					73		All	4000			
1218	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500			
1219	92902	260124	9M902	0015							All	3500			
1220	92902	260098	122K02	0518	1	492177	1	492893	25		All	4000			
					1	690319	1	691290							
1221	92902	260124	9M902	0015					73		All	3200			
1222	92902	260124	9M902	0015							All	3300			
1223	92908	261050	No Replacement Repair With Individual Parts.									All	3300		
1224	92908	261133	No Replacement Repair With Individual Parts.									All	3300		
1225	92902	260098	122K02	0518	1	690319	1	691851	25		All	3500			
1226	92902	260098	122K02	0518					25		All	3200			
1227	92992	260224	No Replacement Repair With Individual Parts.									All	3200		
1228	92998	261007	No Replacement Repair With Individual Parts.									All	3200		
1229	92902	260098	122K02	0518					25		All	3000			
1230	92902	260124	9M902	0015							All	3100			
1231	92982	260911	No Replacement Repair With Individual Parts.									All	3500		
1232	92908	261012	122K02	0516					25		All	3500			
1233	92982	260911	No Replacement Repair With Individual Parts.									All	3500		
1234	92982	260911	No Replacement Repair With Individual Parts.									All	3500		
1235	92982	260911	No Replacement Repair With Individual Parts.									All	2900		
1236	92985	261021	No Replacement Repair With Individual Parts.									All	2900		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
1237	92988	261021	No Replacement Repair With Individual Parts.									All	2900		
1238	92902	260097	No Replacement Repair With Individual Parts.									All	3100		
1239	92988	261021	No Replacement Repair With Individual Parts.									All	3500		
1241	92902	260124	122K02	0515					25		All	3000			
1242	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500			
1243	92988	261024	No Replacement Repair With Individual Parts.									All	3000		
1244	92902	260124	122K02	0515	1	690319	1	691290	25		All	4000			
1245	92902	260096	122K02	0516					25		All	3000			
1246	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
1247	92985	261024	No Replacement Repair With Individual Parts.									All	3200		
1248	92988	261021	No Replacement Repair With Individual Parts.									All	3000		
1249	92908	261012	122K02	0516					25		All	3300			
1250	92988	261024	No Replacement Repair With Individual Parts.									All	3100		
1251	92982	260913	No Replacement Repair With Individual Parts.									All	3100		
1252	92908	261013	No Replacement Repair With Individual Parts.									All	3100		
1253	92902	260098	122K02	0518					25		All	3000			
1254	92902	260124	122K02	0515	1	690319	1	691290	25		All	3700			
1255	92902	260097	No Replacement Repair With Individual Parts.									All	3100		
1256	92902	260097	No Replacement Repair With Individual Parts.									All	3300		
1257	92902	260096	9M902	0016							All	3500			
1258	92902	260098	122K02	0518					25		All	3100			
1259	92982	260957	No Replacement Repair With Individual Parts.									All	3300		
1260	92985	261052	No Replacement Repair With Individual Parts.									All	3300		
1261	92902	260124	122K02	0515					25		All	3000			
1262	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
1263	92902	260235	9M902	0015			1	93061			All	3000			
1264	92908	261013	No Replacement Repair With Individual Parts.									All	3500		
1265	92908	261014	122K02	0518					25		All	3100			
1266	92908	261013	No Replacement Repair With Individual Parts.									All	3300		
1267	92902	260097	No Replacement Repair With Individual Parts.									All	3300		
1268	92902	260096	9M902	0016							All	3000			
1269	92988	261021	No Replacement Repair With Individual Parts.									All	3300		
1270	92988	261021	No Replacement Repair With Individual Parts.									All	3100		
1271	92902	260097	No Replacement Repair With Individual Parts.									All	3000		
1272	92902	260124	122K02	0515					25		All	2900			
1273	92982	260911	No Replacement Repair With Individual Parts.									All	3300		
1274	92902	260097	No Replacement Repair With Individual Parts.									All	3200		
1275	92985	261024	No Replacement Repair With Individual Parts.									All	3100		
1276	92902	260098	122K02	0518	1	492177	1	492893	25		All	3000			
1277	92992	260224	No Replacement Repair With Individual Parts.									All	3000		
1278	92908	261012	122K02	0516					25		All	3300			
1279	92902	260124	122K02	0515					25		All	2900			
1280	92908	261030	122K02	0515					25		All	2900			
1281	92908	261014	122K02	0518					25		All	3000			
1282	92982	260911	No Replacement Repair With Individual Parts.									All	3500		
1283	92908	261014	122K02	0518					25		All	3200			
1284	92982	260913	No Replacement Repair With Individual Parts.									All	3100		
1285	92902	260235	No Replacement Repair With Individual Parts.									All	3300		
1286	92902	260097	No Replacement Repair With Individual Parts.									All	3100		
1287	92902	260098	122K02	0518	1	492177	1	492893	25		All	4000			
					1	690319	1	691290							
1288	92902	260096	122K02	0516					25		All	3200			
1289	92905	261013	No Replacement Repair With Individual Parts.									All	3500		
1290	92902	260124	9M902	0015							All	3500			
1291	92902	260124	9M902	0015					73		All	3500			

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
1292	92992	260099	No Replacement Repair With Individual Parts.								All	3200			
1293	92982	260911	No Replacement Repair With Individual Parts.								All	3200			
1294	92985	261023	No Replacement Repair With Individual Parts.								All	3100			
1295	92902	260096	9M902	0016							All	3100			
1296	92992	260099	No Replacement Repair With Individual Parts.								All	3100			
1297	92908	261050	No Replacement Repair With Individual Parts.								All	3300			
1298	92905	261030	No Replacement Repair With Individual Parts.								All	3300			
1299	92988	261024	No Replacement Repair With Individual Parts.								All	3100			
1300	92985	261024	No Replacement Repair With Individual Parts.								All	3100			
1301	92908	261030	122K02	0515					25		All	3300			
1302	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500			
1303	92902	260124	122K02	0515					25		All	3100			
1304	92988	261021	No Replacement Repair With Individual Parts.												
1305	92902	260096	122K02	0516	1	690319	1	691851	25		All	3500			
1306	92902	260098	122K02	0518	1	492177	1	492893	25		All	4000			
					1	690319	1	691290							
1307	92988	261022	No Replacement Repair With Individual Parts.								All	2900			
1308	92985	261022	No Replacement Repair With Individual Parts.								All	2900			
1309	92908	261012	122K02	0516					25		All	3300			
1310	92902	260096	9M902	0016							All	3500			
1311	92908	261050	No Replacement Repair With Individual Parts.								All	3300			
1312	92905	261050	No Replacement Repair With Individual Parts.								All	3300			
1313	92908	261050	No Replacement Repair With Individual Parts.								All	3300			
1314	92902	260124	122K02	0515	1	492177	1	492893	25		All	3000			
1315	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
1316	92902	260097	No Replacement Repair With Individual Parts.								All	3200			
1317	92908	261014	122K02	0518					25		All	3100			
1318	92902	260098	122K02	0518					25		All	3000			
1319	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500			
1320	92988	261022	No Replacement Repair With Individual Parts.								All	3500			
1321	92985	261022	No Replacement Repair With Individual Parts.								All	3500			
1322	92988	261022	No Replacement Repair With Individual Parts.								All	3500			
1323	92905	261012	No Replacement Repair With Individual Parts.								All	3500			
1324	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500			
1325	92988	261024	No Replacement Repair With Individual Parts.								All	3100			
1326	92985	261024	No Replacement Repair With Individual Parts.								All	3100			
1327	92902	260096	122K02	0516	1	690319	1	691851	25		All	3500			
1328	92902	260124	9M902	0015					73		All	3500			
1329	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
1330	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500			
1331	92988	261022	No Replacement Repair With Individual Parts.								All	3500			
1332	92982	260911	No Replacement Repair With Individual Parts.								All	3500			
1333	92902	260124	9M902	0015							All	3300			
1334	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1335	92905	261030	No Replacement Repair With Individual Parts.								All	3300			
1336	92908	261030	122K02	0515					25		All	3300			
1337	92902	260096	122K02	0516	1	690319	1	691851	25		All	3500			
1338	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500			
1339	92908	261030	122K02	0515	1	690319	1	691851	25		All	3300			
1340	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1341	92902	260098	122K02	0518	1	492177	1	492893	25		All	3000			
1342	92908	261014	122K02	0518					25		All	3000			
1343	92992	260224	No Replacement Repair With Individual Parts.								All	3000			
1344	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
1345	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1346	92902	260096	9M902	0016					73		All	3000			
1347	92992	260224	No Replacement Repair With Individual Parts.									All	3300		
1348	92998	261007	No Replacement Repair With Individual Parts.									All	3300		
1349	92982	260912	No Replacement Repair With Individual Parts.									All	2900		
1350	92992	260099	No Replacement Repair With Individual Parts.									All	3100		
1351	92908	261013	No Replacement Repair With Individual Parts.									All	3100		
1352	92982	260911	No Replacement Repair With Individual Parts.									All	3100		
1353	92988	261021	No Replacement Repair With Individual Parts.									All	3100		
1354	92985	261021	No Replacement Repair With Individual Parts.									All	3300		
1355	92902	260097	No Replacement Repair With Individual Parts.									All	3100		
1356	92908	261012	122K02	0516					25		All	3100			
1357	92902	260096	122K02	0516					25		All	3100			
1358	92902	260098	122K02	0518	1	690319	1	691851	25		All	3500			
1359	92908	261013	No Replacement Repair With Individual Parts.									All	3300		
1360	92905	261013	No Replacement Repair With Individual Parts.									All	3300		
1361	92988	261024	No Replacement Repair With Individual Parts.									All	3100		
1362	92985	261024	No Replacement Repair With Individual Parts.									All	3100		
1363	92902	260097	No Replacement Repair With Individual Parts.									All	3500		
1364	92908	261013	No Replacement Repair With Individual Parts.									All	3500		
1365	92908	261013	No Replacement Repair With Individual Parts.									All	3200		
1366	92902	260097	No Replacement Repair With Individual Parts.									All	3500		
1367	92988	261022	No Replacement Repair With Individual Parts.									All	3200		
1368	92985	261022	No Replacement Repair With Individual Parts.									All	3200		
1369	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500			
1370	92902	260098	122K02	0518	1	690319	1	691290	25		All	4000			
1371	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500			
1372	92985	261024	No Replacement Repair With Individual Parts.									All	3200		
1373	92988	261024	No Replacement Repair With Individual Parts.									All	3200		
1374	92905	261014	No Replacement Repair With Individual Parts.									All	3500		
1375	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500			
1376	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
1377	92988	261021	No Replacement Repair With Individual Parts.									All	3700		
1378	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1379	92988	261021	No Replacement Repair With Individual Parts.									All	3500		
1380	92902	260957	9M902	0016					14		All	3100			
1381	92902	260096	122K02	0516	1	690319	1	691851	25		All	3500			
1382	92908	261030	122K02	0515	1	690319	1	691290	25		All	3700			
1383	92902	260098	122K02	0518	1	492177	1	492893	25		All	3700			
						1 690319	1 691290								
1384	92902	260096	122K02	0516	1	492177	1	492893	25		All	3700			
						1 690319	1 691851								
1385	92908	261014	122K02	0518					25		All	3000			
1386	92908	261014	122K02	0518					25		All	3200			
1387	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1388	92908	261012	122K02	0516					25		All	3300			
1389	92982	260911	No Replacement Repair With Individual Parts.									All	2900		
1390	92902	260124	9M902	0015					73		All	3200			
1391	92902	260124	9M902	0015							All	3500			
1392	92902	260096	9M902	0016					73		All	3200			
1393	92908	261030	122K02	0515					25		All	3300			
1394	92982	260911	No Replacement Repair With Individual Parts.									All	3000		
1395	92988	261021	No Replacement Repair With Individual Parts.									All	3000		
1396	92902	260098	122K02	0518					25		All	3100			

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
1397	92908	261014	122K02	0518					25		All	3100			
1398	92902	260096	122K02	0516	1	492177	1	492893	25		All	4000			
						1 690319	1	691851							
1399	92902	260124	9M902	0015							All	3700			
1400	92988	261052	No Replacement Repair With Individual Parts.									All	3300		
1401	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1402	92988	261021	No Replacement Repair With Individual Parts.									All	3200		
1403	92908	261238	No Replacement Repair With Individual Parts.									All	3100		
1404	92908	261238	No Replacement Repair With Individual Parts.									All	3100		
1405	92905	261237	No Replacement Repair With Individual Parts.									All	3100		
1406	92908	261237	No Replacement Repair With Individual Parts.									All	3100		
1407	92902	260124	9M902	0015							All	3500			
1408	92982	260911	No Replacement Repair With Individual Parts.									All	3100		
1409	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1410	92982	260911	No Replacement Repair With Individual Parts.									All	3000		
1411	92982	260911	No Replacement Repair With Individual Parts.									All	3100		
1412	92988	261021	No Replacement Repair With Individual Parts.									All	3100		
1413	92908	261133	No Replacement Repair With Individual Parts.									All	3500		
1414	92902	260097	No Replacement Repair With Individual Parts.									All	3100		
1415	92908	261013	No Replacement Repair With Individual Parts.									All	3100		
1416	92908	261012	122K02	0516					25		All	3300			
1417	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
1418	92908	261012	122K02	0516					25		All	3000			
1419	92992	260224	No Replacement Repair With Individual Parts.									All	3500		
1420	92902	260124	122K02	0515					25		All	3000			
1421	92902	260096	122K02	0516					25		All	3300			
1422	92908	261012	122K02	0516					25		All	3000			
1423	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500			
1424	92908	261030	122K02	0515					25		All	3000			
1425	92902	260096	9M902	0016							All	3500			
1426	92908	261014	122K02	0518	1	690319	1	691290	25		All	3700			
1427	92908	261013	No Replacement Repair With Individual Parts.									All	3100		
1428	92985	261023	No Replacement Repair With Individual Parts.									All	3100		
1429	92988	261023	No Replacement Repair With Individual Parts.									All	3100		
1430	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
1431	92902	260124	122K02	0515	1	690319	1	691290	25		All	3700			
1432	92902	260124	122K02	0515	1	492177	1	492893	25		All	3500			
						1 690319	1	691851							
1433	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1434	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
1435	92902	260235	122K02	0515	1	492177	1	492893	25		All	3000			
								1 93061							
1436	92902	260124	9M902	0015	1	690251	1	690252			All	3500			
1437	92908	261029	122K02	0515					25		All	3100			
1438	92908	261012	122K02	0516					25		All	3300			
1439	92902	260096	9M902	0016							All	3500			
1440	92902	260124	122K02	0515					25		All	3100			
1441	92908	261012	122K02	0516					25		All	3300			
1442	92902	260124	122K02	0515					25		All	2900			
1443	92988	261021	No Replacement Repair With Individual Parts.									All	2900		
1444	92902	260124	9M902	0015					73		All	4000			
1445	92982	260914	No Replacement Repair With Individual Parts.									All	3500		
1446	92902	260097	No Replacement Repair With Individual Parts.									All	3500		
1447	92908	261013	No Replacement Repair With Individual Parts.									All	3500		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
1448	92982	260911	No Replacement Repair With Individual Parts.								All	3500		
1449	92988	261021	No Replacement Repair With Individual Parts.								All	3500		
1450	92982	260912	No Replacement Repair With Individual Parts.								All	3100		
1451	92988	261022	No Replacement Repair With Individual Parts.								All	3100		
1452	92902	260124	9M902	0015							All	3500		
1453	92905	261030	No Replacement Repair With Individual Parts.								All	3300		
1454	92908	261030	122K02	0515	1	690319	1	691851	25		All	3300		
1455	92988	261021	No Replacement Repair With Individual Parts.								All	3100		
1456	92908	261293	No Replacement Repair With Individual Parts.								All	3300		
1457	92908	261292	No Replacement Repair With Individual Parts.								All	3100		
1458	92902	260096	9M902	0016							All	3100		
1459	92908	261012	122K02	0516					25		All	3200		
1460	92902	260124	9M902	0015							All	3500		
1461	92902	260124	122K02	0515	1	690319	1	691851	25		All	3300		
1462	92902	260124	9M902	0015					73		All	3300		
1463	92902	260098	122K02	0518	1	492177	1	492893	25		All	4000		
					1	690319	1	692190						
1464	92988	261021	No Replacement Repair With Individual Parts.								All	3500		
1465	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500		
1466	92908	261030	122K02	0515	1	690319	1	691290	25		All	3700		
1467	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500		
1468	92908	261030	122K02	0515	1	690319	1	691851	25		All	3300		
1469	92908	261012	122K02	0516	1	691319	1	691851	25		All	3500		
1470	92982	260911	No Replacement Repair With Individual Parts.								All	3200		
1471	92902	260096	122K02	0516					25		All	3200		
1472	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500		
1473	92988	261021	No Replacement Repair With Individual Parts.								All	3500		
1474	92902	260098	122K02	0518	1	690319	1	691851	25		All	3500		
1475	92908	261030	122K02	0515					25		All	3100		
1476	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500		
1477	92902	260096	122K02	0516	1	690319	1	691851	25		All	3500		
1478	92908	261030	122K02	0515					25		All	3200		
1479	92908	261030	122K02	0515					25		All	3200		
1480	92908	261030	122K02	0515	1	690319	1	691290	25		All	3700		
1481	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500		
1482	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500		
1483	92988	261021	No Replacement Repair With Individual Parts.								All	3700		
1484	92902	260319	122K02	0516	1	492177	1	492893	25		All	4000		
					1	690319	1	691851						
								1	93061					
1485	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500		
1486	92985	261021	No Replacement Repair With Individual Parts.								All	3000		
1487	92988	261021	No Replacement Repair With Individual Parts.								All	3500		
1488	92982	260911	No Replacement Repair With Individual Parts.								All	2900		
1489	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500		
1490	92902	260098	122K02	0518	1	690319	1	691851	25		All	3500		
1491	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500		
1492	93908	261012	122K02	0516	1	690319	1	691851	25		All	3500		
1493	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500		
1494	92988	261021	No Replacement Repair With Individual Parts.								All	3500		
1495	92988	261021	No Replacement Repair With Individual Parts.								All	2900		
1496	92902	260096	122K02	0516	1	492177	1	492893	25		All	3500		
					1	690319	1	691851						

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
1497	92902	260124	9M902	0015					73		All	3300			
1498	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500			
1499	92982	260914	No Replacement Repair With Individual Parts.									All	3200		
1500	92902	260096	9M902	0016							All	3500			
1501	92985	261021	No Replacement Repair With Individual Parts.									All	3000		
1502	92902	260124	9M902	0015							All	2900			
1503	92908	261012	122K02	0516					25		All	2900			
1504	92988	261022	No Replacement Repair With Individual Parts.									All	2900		
1505	92982	260912	No Replacement Repair With Individual Parts.									All	3500		
1506	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
1507	92908	261014	122K02	0518					25		All	3200			
1508	92982	260912	No Replacement Repair With Individual Parts.									All	3200		
1509	92902	260124	122K02	0515	1	690319	1	691851	25		All	3300			
1510	92988	261021	No Replacement Repair With Individual Parts.									All	3300		
1511	92902	260124	122K02	0515	1	690319	1	691290	25		All	3700			
1512	92985	261022	No Replacement Repair With Individual Parts.									All	2900		
1513	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500			
1514	92902	260098	9M902	0018					73		All	3200			
1515	92908	261030	122K02	0515					25		All	3200			
1516	92908	261014	122K02	0518					25		All	3200			
1517	92902	260124	9M902	0015					25		All	3500			
1518	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1519	92902	260124	9M902	0015							All	3200			
1520	92908	261030	122K02	0515	1	690319	1	691290	25		All	3700			
1521	92982	260911	No Replacement Repair With Individual Parts.									All	3000		
1522	92908	261030	No Replacement Repair With Individual Parts.									All	3500		
1523	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500			
1524	92902	260124	122K02	0515	1	492177	1	492893	25		All	3300			
					1	690319	1	691851							
1525	92908	261050	No Replacement Repair With Individual Parts.									All	3300		
1526	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500			
1527	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1528	92902	260096	122K02	0516	1	690319	1	691851	25		All	3500			
1529	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500			
1530	92902	260096	9M902	0016							All	3500			
1531	92902	260096	9M902	0016							All	3500			
1532	92902	260096	122K02	0516					25		All	3300			
1533	92902	260096	9M902	0016							All	2900			
1534	92902	260124	9M902	0015							All	2900			
1535	92908	261030	122K02	0515					25		All	2900			
1536	92982	260911	No Replacement Repair With Individual Parts.									All	2900		
1537	92982	260912	No Replacement Repair With Individual Parts.									All	2900		
1538	92908	261030	122K02	0515	1	690319	1	691851	25		All	3300			
1539	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500			
1540	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1541	92902	260124	122K02	0515	1	690319	1	691851	25		All	3300			
1542	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500			
1543	92902	260124	9M902	1615							All	4000			
1544	92982	260911	No Replacement Repair With Individual Parts.									All	2900		
1545	92982	260911	No Replacement Repair With Individual Parts.									All	2900		
1546	92988	261021	No Replacement Repair With Individual Parts.									All	2900		
1547	92988	261022	No Replacement Repair With Individual Parts.									All	2900		
1548	92985	261022	No Replacement Repair With Individual Parts.									All	2900		
1549	92988	261024	No Replacement Repair With Individual Parts.									All	3200		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
1550	92908	261050	No Replacement Repair With Individual Parts.									All	3300		
1551	92905	261050	No Replacement Repair With Individual Parts.									All	3300		
1552	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500			
1553	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1555	92902	260096	122K02	0516	1	690319	1	691851	25		All	3500			
1556	92902	260124	9M902	0015							All	3300			
1557	92982	260911	No Replacement Repair With Individual Parts.									All	3300		
1558	92902	260411	No Replacement Repair With Individual Parts.									All	4000		
1559	92902	260124	9M902	0015							All	3200			
1560	92908	261030	122K02	0515					25		All	2900			
1561	92982	260912	No Replacement Repair With Individual Parts.									All	2900		
1562	92982	260911	No Replacement Repair With Individual Parts.									All	3200		
1563	92982	260911	No Replacement Repair With Individual Parts.									All	3000		
1564	92988	261021	No Replacement Repair With Individual Parts.									All	3000		
1565	92902	260096	9M902	0016							All	3500			
1566	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500			
1567	92908	261293	No Replacement Repair With Individual Parts.									All	3300		
1568	92908	261293	No Replacement Repair With Individual Parts.									All	3300		
1569	92988	261024	No Replacement Repair With Individual Parts.									All	3200		
1570	92902	260096	122K02	0516	1	690319	1	691851	25		All	3500			
1571	92992	260224	No Replacement Repair With Individual Parts.									All	3000		
1572	92988	261021	No Replacement Repair With Individual Parts.									All	3000		
1573	92998	260224	No Replacement Repair With Individual Parts.									All	3000		
1574	92982	260911	No Replacement Repair With Individual Parts.									All	3000		
1575	92988	261021	No Replacement Repair With Individual Parts.									All	2900		
1576	92998	261007	No Replacement Repair With Individual Parts.									All	3000		
1577	92908	261012	122K02	0516					25		All	3000			
1578	92982	260912	No Replacement Repair With Individual Parts.									All	2900		
1579	92902	260124	9M902	0015					73		All	3200			
1580	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500			
1581	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1582	92902	260098	9M902	0018							All	3500			
1583	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500			
1584	92908	261030	122K02	0515					25		All	3100			
1585	92988	261022	No Replacement Repair With Individual Parts.									All	3500		
1586	92902	260096	122K02	0516	1	690319	1	691851	25		All	3500			
1587	92902	260098	9M902	0018							All	3500			
1588	92902	260096	9M902	0016							All	2900			
1589	92982	260911	No Replacement Repair With Individual Parts.									All	2900		
1590	92902	260319	122K02	0516	1	492177	1	492893	25		All	3500			
					1	690319	1	691851							
1591	92985	261024	No Replacement Repair With Individual Parts.									All	3200		
1592	92982	260911	No Replacement Repair With Individual Parts.									All	3200		
1593	92988	261021	No Replacement Repair With Individual Parts.									All	3200		
1594	92908	261014	122K02	0518					25		All	3000			
1595	92988	261024	No Replacement Repair With Individual Parts.									All	3200		
1596	92908	261293	No Replacement Repair With Individual Parts.									All	3100		
1597	92982	260911	No Replacement Repair With Individual Parts.									All	3000		
1598	92902	260097	No Replacement Repair With Individual Parts.									All	3300		
1599	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500			
1600	92988	261021	No Replacement Repair With Individual Parts.									All	3500		
1601	92902	260124	9M902	0015							All	3500			
1602	92988	261021	No Replacement Repair With Individual Parts.									All	3000		
1604	92988	261024	No Replacement Repair With Individual Parts.									All	3200		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
1605	92905	261030	No Replacement Repair With Individual Parts.								All	3200		
1606	92908	261030	122K02	0515					25		All	3200		
1607	92902	260096	9M902	0016					73		All	3500		
1608	92902	260124	9M902	0015					73		All	3500		
1609	92902	260098	122K02	0518	1	690319	1	691851	25		All	3300		
1610	92988	261021	No Replacement Repair With Individual Parts.								All	3300		
1611	92902	260096	9M902	0016							All	3700		
1612	92902	260097	No Replacement Repair With Individual Parts.								All	3300		
1613	92902	261335	No Replacement Repair With Individual Parts.								All	3100		
1614	92902	260124	122K02	0515	1	690319	1	691862	25		All	4000		
1615	92902	260096	122K02	0516	1	690319	1	691851	25		All	3500		
1616	92902	260098	122K02	0518	1	492177	1	492893	25		All	2900		
1617	92908	261030	122K02	0515	1	690319	1	691851	25		All	3300		
1618	92902	260096	9M902	0016							All	3500		
1619	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500		
1620	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500		
1621	92908	261012	122K02	0516					25		All	3300		
1622	92902	260096	9M902	0016							All	3300		
1623	92902	260096	122K02	0516	1	690319	1	691851	25		All	3500		
1624	92988	261021	No Replacement Repair With Individual Parts.								All	3500		
1625	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500		
1626	92902	260096	122K02	0516	1	492177	1	492893	25		All	3200		
1627	92908	261014	122K02	0518					25		All	3200		
1628	92905	261050	No Replacement Repair With Individual Parts.								All	3100		
1629	92908	261050	No Replacement Repair With Individual Parts.								All	3100		
1631	92902	260124	9M902	0015					73		All	3700		
1632	92908	261030	122K02	0515					25		All	3200		
1633	92902	260124	9M902	0015					73		All	3200		
1634	92908	261014	122K02	0518	1	690319	1	691851	25		All	3700		
1635	92908	261293	No Replacement Repair With Individual Parts.								All	3100		
1636	92902	260096	9M902	0016							All	3500		
1637	92982	260911	No Replacement Repair With Individual Parts.								All	3500		
1638	92902	260096	9M902	0516							All	3300		
1639	92908	261012	122K02	0516					25		All	3300		
1640	92982	260911	No Replacement Repair With Individual Parts.								All	3500		
1641	92908	261014	122K02	0518	1	690319	1	691851	25		All	3300		
1642	92902	260096	9M902	0016							All	4000		
1643	92902	260097	No Replacement Repair With Individual Parts.								All	3300		
1644	92908	261030	122K02	0515					25		All	3100		
1645	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500		
1646	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500		
1647	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500		
1648	92982	260911	No Replacement Repair With Individual Parts.								All	3100		
1649	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500		
1650	92902	260235	122K02	0515	1	492177	1	492893	25		All	4000		
					1	690319	1	691290						
1651	92908	261293	No Replacement Repair With Individual Parts.								All	2900		
1652	92988	261021	No Replacement Repair With Individual Parts.								All	3000		
1653	92908	261014	122K02	0518					25		All	3200		
1654	92982	260912	No Replacement Repair With Individual Parts.								All	3000		
1655	92908	261014	122K02	0518	1	690319	1	691851	25		All	3300		
1656	92908	261013	No Replacement Repair With Individual Parts.								All	3300		
1657	92988	261023	No Replacement Repair With Individual Parts.								All	3300		
1658	92988	261021	No Replacement Repair With Individual Parts.								All	3500		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
1659	92908	261030	122K02	0515					25		All	2900			
1660	92988	261021	No Replacement Repair With Individual Parts.									All	3500		
1661	92902	260235	122K02	0515	1	492177	1	492893	25		All	3500			
						1	690319	1	691851						
								1	93061						
1662	92902	260319	122K02	0516	1	492177	1	492893	25		All	3500			
						1	690319	1	691851						
								1	93061						
1663	92982	260911	No Replacement Repair With Individual Parts.									All	3500		
1664	92988	261021	No Replacement Repair With Individual Parts.									All	3500		
1665	92902	260124	9M902	0015					73		All	3500			
1666	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500			
1667	92905	261030	No Replacement Repair With Individual Parts.									All	3200		
1668	92988	261021	No Replacement Repair With Individual Parts.									All	3200		
1669	92982	260911										All	3500		
1670	92902	260096	9M902	0016							All	3500			
1671	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1672	92992	260224	No Replacement Repair With Individual Parts.									All	4000		
1673	92902	260096	9M902	0016					73		All	3200			
1674	92902	260124	9M902	0015					73		All	3700			
1675	92908	261012	122K02	0516					25		All	3100			
1676	92998	261028	No Replacement Repair With Individual Parts.									All	3100		
1677	92982	260911	No Replacement Repair With Individual Parts.									All	3100		
1678	92988	261021	No Replacement Repair With Individual Parts.									All	3100		
1679	92902	260096	9M902	0016							All	3100			
1680	92902	260098	9M902	0018					73		All	3500			
1681	92982	260914	No Replacement Repair With Individual Parts.									All	3500		
1682	92902	260096	9M902	0016							All	2900			
1683	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500			
1684	92902	260096	9M902	0016							All	3500			
1685	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1686	92902	260096	9M902	0016							All	3100			
1687	92902	260124	9M902	0015							All	3300			
1688	92902	260124	9M902	0015							All	3500			
1689	92902	260124	9M902	0015							All	3300			
1690	92988	261024	No Replacement Repair With Individual Parts.									All	3500		
1691	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500			
1692	92902	260098	122K02	0518	1	492177	1	492893	25		All	4000			
						1	690319	1	691290						
1693	92902	260124	9M902	0515							All	3000			
1694	92908	261012	122K02	0516	1	690319	1	691851	25		All	3300			
1695	92902	260098	122K02	0518	1	492177	1	492893	25		All	3500			
						1	690319	1	691851						
1696	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1697	92902	260098	122K02	05018	1	492177	1	492893	25		All	3500			
						1	690319	1	691851						
1698	92902	260124	122K02	0515	1	492177	1	492893	25		All	3500			
						1	690319	1	691851						
1699	92908	261014	122K02	0518					25		All	3200			
1700	92908	261014	122K02	0518	1	690319	1	691290	25		All	4000			
1701	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
1702	92905	261050	No Replacement Repair With Individual Parts.									All	3100		
1703	92908	261050	No Replacement Repair With Individual Parts.									All	3100		
1704	92982	260911	No Replacement Repair With Individual Parts.									All	3000		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
1705	92908	261014	122K02	0518					25		All	3000			
1706	92988	261021	No Replacement Repair With Individual Parts.									All	3500		
1707	92908	261030	122K02	0515					25		All	3200			
1708	92908	261014	122K02	0518	1	690319	1	691290	25		All	4000			
1709	92908	261030	122K02	0515					25		All	3200			
1710	92908	261050	No Replacement Repair With Individual Parts.									All	3300		
1711	92908	261012	122K02	0516	1	690319	1	691851	25		All	3300			
1712	92902	260098	122K02	0518	1	492177	1	492893	25		All	3700			
					1	690319	1	691290							
1713	92902	260096	122K02	0516					25		All	3100			
1714	92908	261030	122K02	0515					25		All	3100			
1715	92908	261030	122K02	0515					25		All	2900			
1716	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1717	92908	261012	122K02	0516					25		All	3200			
1718	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500			
1719	92982	260911	No Replacement Repair With Individual Parts.									All	3100		
1720	92988	261021	No Replacement Repair With Individual Parts.									All	3100		
1721	92988	261024	No Replacement Repair With Individual Parts.									All	3200		
1722	92902	260124	9M902	0015							All	3100			
1723	92902	260098	122K02	0518	1	690319	1	691290	25		All	4000			
1724	92902	260097	No Replacement Repair With Individual Parts.									All	3300		
1725	92988	261021	No Replacement Repair With Individual Parts.									All	3100		
1726	92988	261021	No Replacement Repair With Individual Parts.									All	3300		
1727	92908	261012	122K02	0516					25		All	3300			
1728	92902	260097	No Replacement Repair With Individual Parts.									All	3500		
1729	92902	260098	122K02	0518					25		All	3000			
1730	92908	261014	122K02	0518					25		All	3000			
1731	92908	261014	122K02	0518					25		All	3100			
1732	92988	261021	No Replacement Repair With Individual Parts.									All	3100		
1733	92902	260124	122K02	0515	1	690319	1	691290	25		All	4000			
1734	92982	260911	No Replacement Repair With Individual Parts.									All	2900		
1735	92908	261292	No Replacement Repair With Individual Parts.									All	2500		
1736	92908	261293	No Replacement Repair With Individual Parts.									All	2500		
1737	92902	260097	No Replacement Repair With Individual Parts.									All	3100		
1738	92988	261021	No Replacement Repair With Individual Parts.									All	3500		
1739	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1740	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
1741	92988	261022	No Replacement Repair With Individual Parts.									All	3000		
1742	92908	261293	No Replacement Repair With Individual Parts.									All	2500		
1743	92908	261293	No Replacement Repair With Individual Parts.									All	2500		
1744	92908	261415	No Replacement Repair With Individual Parts.									All	2500		
1745	92908	261415	No Replacement Repair With Individual Parts.									All	2500		
1746	92908	261292	No Replacement Repair With Individual Parts.									All	2900		
1747	92908	261293	No Replacement Repair With Individual Parts.									All	3000		
1748	92908	261415	No Replacement Repair With Individual Parts.									All	2900		
1749	92982	260912	No Replacement Repair With Individual Parts.									All	3000		
1750	92902	260124	9M902	0015							All	2900			
1751	92902	260319	No Replacement Repair With Individual Parts.									All	3300		
1752	92908	261012	122K02	0516					25		All	3100			
1753	92988	261021	No Replacement Repair With Individual Parts.									All	3100		
1754	92985	261023	No Replacement Repair With Individual Parts.									All	3300		
1755	92902	260098	122K02	0518	1	690319	1	691290	25		All	4000			
1756	92908	261417	No Replacement Repair With Individual Parts.									All	2500		
1757	92908	261417	No Replacement Repair With Individual Parts.									All	2600		
1758	92988	261021	No Replacement Repair With Individual Parts.									All	3500		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
1759	92908	261030	122K02	0515					25		All	2900			
1760	92908	261014	122K02	0518					25		All	3200			
1761	92908	261013	No Replacement Repair With Individual Parts.									All	3100		
1762	92902	260124	9M902	0015							All	3500			
1763	92908	261030	122K02	0515					25		All	3200			
1764	92988	261021	No Replacement Repair With Individual Parts.									All	3100		
1765	92982	260911	No Replacement Repair With Individual Parts.									All	3100		
1766	92988	261021	No Replacement Repair With Individual Parts.									All	3500		
1767	92908	261030	122K02	0515					25		All	3000			
1768	92908	261014	122K02	0518	1	690319	1	691851	25		All	3300			
1769	92902	260124	122K02	0515	1	690319	1	691851	25		All	3300			
1770	92902	260096	122K02	0516	1	690319	1	691851	25		All	3500			
1771	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1772	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1773	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1774	92902	260124	9M902	0015							All	3500			
1775	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1776	92902	261239	No Replacement Repair With Individual Parts.									All	3100		
1777	92902	260124	9M902	0015							All	3500			
1778	92908	261012	122K02	0516					25		All	3100			
1779	92982	260911	No Replacement Repair With Individual Parts.									All	3100		
1780	92902	260124	9M902	0015					73		All	3700			
1781	92902	260097	No Replacement Repair With Individual Parts.									All	3100		
1782	92902	260124	9M902	0015							All	4000			
1783	92902	260124	122K02	0515	1	492177	1	492893	25		All	3100			
1784	92902	260098	122K02	0518	1	492177	1	492893	25		All	3300			
						1	690319	1	691851						
1785	92908	261014	122K02	0518					25		All	3100			
1786	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500			
1787	92902	260124	122K02	0515	1	690319	1	691290	25		All	4000			
1788	92908	261133	No Replacement Repair With Individual Parts.									All	3500		
1789	92902	260124	122K02	0515	1	492177	1	492893	25		All	3500			
						1	690319	1	691851						
1790	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
1791	92908	261014	122K02	0518					25		All	3200			
1792	92908	261030	122K02	0515					25		All	3200			
1793	92982	260911	No Replacement Repair With Individual Parts.									All	3500		
1794	92908	261012	122K02	0516	1	690319	1	691851	25		All	3300			
1795	92908	261014	122K02	0518					25		All	3100			
1796	92902	260124	122K02	0515					25		All	2900			
1797	92982	260911	No Replacement Repair With Individual Parts.									All	2900		
1798	92985	261021	No Replacement Repair With Individual Parts.									All	3200		
1799	92902	260124	122K02	0515					25		All	3100			
1800	92902	260097	No Replacement Repair With Individual Parts.									All	3500		
1801	92902	260124	122K02	0515	1	690319	1	691290	25		All	4000			
1802	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
1803	92902	260096	122K02	0516	1	690319	1	691851	25		All	3500			
1804	92908	261012	122K02	0516					25		All	3100			
1805	92902	260096	9M902	0016							All	2900			
1806	92908	261012	122K02	0516					25		All	2900			
1807	92908	261030	122K02	0515					25		All	2900			
1808	92908	261030	122K02	0515					25		All	2900			
1809	92988	261021	No Replacement Repair With Individual Parts.									All	2900		
1810	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block			
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes		
1811	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500				
1812	92902	260124	122K02	0515	1	492177	1	492893	25		All	3000				
1813	92908	261014	122K02	0518	1	690319	1	691851	25		All	3500				
1814	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500				
1815	92988	261021	No Replacement Repair With Individual Parts.										All	3100		
1816	92902	260124	9M902	0015					73		All	3200				
1817	92902	260098	122K02	0518	1	492177	1	492893	25		All	3500				
					1	690319	1	691851								
1818	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500				
1819	92908	261013	No Replacement Repair With Individual Parts.										All	3300		
1820	92902	260096	9M902	0016							All	3200				
1821	92908	261012	122K02	0516					25		All	3200				
1822	92988	261021	No Replacement Repair With Individual Parts.										All	3200		
1823	92902	260124	122K02	0515	1	690319	1	691851	25		All	3300				
1824	92902	260124	122K02	0515	1	690319	1	691290	25		All	4000				
1825	92905	261030	No Replacement Repair With Individual Parts.										All	3200		
1826	92908	261030	122K02	0515					25		All	3200				
1827	92908	261014	122K02	0518					25		All	3000				
1828	92988	261021	No Replacement Repair With Individual Parts.										All	2900		
1829	92908	261030	122K02	0515					25		All	3300				
1830	92902	260096	122K02	0516					25		All	3100				
1831	92902	260124	122K02	0515	1	690319	1	691290	25		All	3700				
1832	92908	261012	No Replacement Repair With Individual Parts.										All	3500		
1833	92908	261030	122K02	0515					25		All	3100				
1835	92982	260911	No Replacement Repair With Individual Parts.										All	3100		
1836	92982	260911	No Replacement Repair With Individual Parts.										All	3100		
1837	92902	260098	122K02	0518	1	492177	1	492893	25		All	3100				
1838	92908	261014	122K02	0518					25		All	3100				
1839	92905	260096	No Replacement Repair With Individual Parts.										All	3100		
1840	92985	260911	No Replacement Repair With Individual Parts.										All	3100		
1841	92908	261292	No Replacement Repair With Individual Parts.										All	2500		
1842	92908	261293	No Replacement Repair With Individual Parts.										All	2500		
1843	92908	261293	No Replacement Repair With Individual Parts.										All	2500		
1844	92908	261292	No Replacement Repair With Individual Parts.										All	2900		
1845	92908	261293	No Replacement Repair With Individual Parts.										All	3000		
1846	92908	261417	No Replacement Repair With Individual Parts.										All	2600		
1847	92908	261030	122K02	0515	1	690319	1	691851	25		All	3300				
1848	92902	261239	No Replacement Repair With Individual Parts.										All	3100		
1849	92908	261238	No Replacement Repair With Individual Parts.										All	3100		
1850	92908	261050	No Replacement Repair With Individual Parts.										All	3300		
1851	92905	261050	No Replacement Repair With Individual Parts.										All	3100		
1852	92905	261050	No Replacement Repair With Individual Parts.										All	3500		
1853	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500				
1854	92982	260911	No Replacement Repair With Individual Parts.										All	3000		
1855	92988	261021	No Replacement Repair With Individual Parts.										All	3000		
1856	92902	260124	9M902	0015							All	3500				
1857	92908	261050	No Replacement Repair With Individual Parts.										All	3100		
1858	92908	261012	122K02	0516					25		All	3200				
1859	92902	260097	No Replacement Repair With Individual Parts.										All	3200		
1860	92902	260098	122K02	0518	1	492177	1	492893	25		All	3200				
1861	92908	261012	122K02	0516					25		All	3200				
1862	92982	260911	No Replacement Repair With Individual Parts.										All	3200		
1863	92902	260096	9M902	0016							All	3100				
1864	92908	261014	122K02	0518					25		All	3200				

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
1865	92902	260319	No Replacement Repair With Individual Parts.								All	3300		
1866	92902	260098	122K02	0518	1	492177	1	492893	25		All	3200		
1867	92982	260911	No Replacement Repair With Individual Parts.								All	3500		
1868	92902	260124	9M902	0015							All	3000		
1869	92902	260096	9M902	0016							All	3500		
1870	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500		
1871	92908	261050	No Replacement Repair With Individual Parts.								All	3500		
1872	92908	261012	122K02	0516					25		All	3200		
1873	92908	261014	122K02	0518					25		All	3300		
1874	92908	261014	122K02	0518					25		All	3100		
1875	92902	260096	9M902	0016							All	3500		
1876	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500		
1877	92902	260096	122K02	0516					25		All	3100		
1878	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500		
1879	92908	261415	No Replacement Repair With Individual Parts.								All	3000		
1880	92902	260098	122K02	0518	1	492177	1	492893	25		All	4000		
					1	690319	1	691290						
1881	92902	260097	No Replacement Repair With Individual Parts.								All	3100		
1882	92908	261013	No Replacement Repair With Individual Parts.								All	3100		
1883	92982	260912	No Replacement Repair With Individual Parts.								All	3100		
1884	92902	260096	9M902	0015							All	3500		
1885	92902	260124	9M902	0015					73		All	3300		
1886	92902	260096	9M902	0016							All	3500		
1887	92908	261238	No Replacement Repair With Individual Parts.								All	3100		
1888	92982	260911	No Replacement Repair With Individual Parts.								All	3500		
1889	92902	260096	9M902	0016					73		All	3500		
1890	92908	261012	122K02	0516					25		All	3300		
1891	92902	260124	No Replacement Repair With Individual Parts.								All	4000		
1892	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500		
1893	92908	261012	122K02	0516					25		All	3100		
1894	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500		
1895	92908	261415	No Replacement Repair With Individual Parts.								All	2500		
1896	92908	261030	No Replacement Repair With Individual Parts.								All	3300		
1897	92908	261013	No Replacement Repair With Individual Parts.								All	3500		
1898	92908	261013	No Replacement Repair With Individual Parts.								All	3100		
1899	92902	260097	No Replacement Repair With Individual Parts.								All	3100		
1900	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500		
1901	92908	261030	122K02	0515					25		All	3200		
1902	92902	260124	No Replacement Repair With Individual Parts.								All	3200		
1903	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500		
1904	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500		
1905	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500		
1906	92908	261012	122K02	0516					25		All	3100		
1907	92988	261021	No Replacement Repair With Individual Parts.								All	3100		
1908	92902	260096	9M902	0016					73		All	3300		
1909	92902	260124	9M902	0015					73		All	3300		
1910	92908	261293	No Replacement Repair With Individual Parts.								All	3300		
1911	92908	261030	122K02	0515					25		All	3000		
1912	92982	260911	No Replacement Repair With Individual Parts.								All	3100		
1913	92982	260911	No Replacement Repair With Individual Parts.								All	2900		
1914	92902	260124	122K02	0515	1	690319	1	691851	25		All	3300		
1915	92902	260096	9M902	0016							All	3300		
1916	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500		
1917	92988	261022	No Replacement Repair With Individual Parts.								All	3100		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
1918	92902	260124	No Replacement Repair With Individual Parts.								All	4000		
1919	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500		
1920	92902	260124	9M902	0015							All	3300		
1921	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500		
1922	92902	260096	122K02	0516					25		All	3200		
1923	92982	260911	No Replacement Repair With Individual Parts.								All	3500		
1924	92908	261012	122K02	0516					25		All	3200		
1925	92902	260097	No Replacement Repair With Individual Parts.								All	3100		
1926	92908	261013	No Replacement Repair With Individual Parts.								All	3100		
1927	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500		
1928	92908	261014	122K02	0518					25		All	3100		
1929	92908	261050	No Replacement Repair With Individual Parts.								All	3100		
1930	92908	261030	122K02	0515					25		All	2900		
1931	92908	261293	No Replacement Repair With Individual Parts.								All	2500		
1934	92908	261293	No Replacement Repair With Individual Parts.								All	3000		
1937	92908	261292	No Replacement Repair With Individual Parts.								All	3000		
1938	92902	260096	122K02	0516					25		All	3300		
1939	92902	260124	9M902	0015					73		All	3300		
1940	92988	261022	No Replacement Repair With Individual Parts.								All	3500		
1941	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500		
1942	92908	261030	122K02	0515					25		All	3000		
1943	92908	261012	122K02	0516	1	690319	1	691851	25		All	3700		
1944	92902	260098	122K02	0518	1	492177	1	492893	25		All	3200		
1945	92902	260096	122K02	0516					25		All	3300		
1946	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500		
1947	92908	261012	122K02	0516					25		All	3200		
1948	92902	260096	122K02	0516					25		All	2900		
1949	92908	261030	122K02	0515					25		All	2900		
1950	92988	261021	No Replacement Repair With Individual Parts.								All	3100		
1951	92908	261014	122K02	0518					25		All	3200		
1952	92988	261022	No Replacement Repair With Individual Parts.								All	3500		
1953	92988	261021	No Replacement Repair With Individual Parts.								All	3100		
1954	92908	261012	122K02	0516					25		All	3000		
1955	92908	261012	122K02	0516					25		All	3200		
1956	92908	261417	No Replacement Repair With Individual Parts.								All	2600		
1957	92902	260096	9M902	0016					25		All	3500		
1958	92902	260124	122K02	0515	1	690319	1	691290	25		All	3700		
1959	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500		
1960	92902	260124	122K02	0515	1	690319	1	691290	25		All	4000		
1961	92982	260911	No Replacement Repair With Individual Parts.								All	3300		
1962	92902	260124	122K02	0515					25		All	3200		
1963	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500		
1964	92908	261417	No Replacement Repair With Individual Parts.								All	2900		
1965	92902	260096	122K02	0516					25		All	3300		
1966	92982	260911	No Replacement Repair With Individual Parts.								All	3500		
1967	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500		
1968	92908	261012	122K02	0516					25		All	3100		
1969	92908	261030	122K02	0515	1	690319	1	691290	25		All	3700		
1970	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500		
1971	92988	261021	No Replacement Repair With Individual Parts.								All	3100		
1972	92902	260096	122K02	0516	1	690319	1	691851	25		All	3500		
1973	92908	261012	122K02	0516					25		All	3300		
1974	92908	261012	122K02	0516	1	690319	1	691851	25		All	4000		
1975	92902	260097	No Replacement Repair With Individual Parts.								All	3500		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
1976	92908	261012	122K02	0516	1	690319	1	691851	25		All	3500		
1977	92902	260124	9M902	0015					73		All	3500		
1978	92908	261014	122K02	0518					25		All	3100		
1979	92902	260098	9M902	0018							All	3100		
1980	92902	261024	122K02	0515	1	690319	1	691290	25		All	3700		
1981	92902	261024	122K02	0515					25		All	3100		
1982	92902	261024	9M902	0015					73		All	3200		
1983	92982	260911	No Replacement Repair With Individual Parts.								All	3100		
1984	92908	261012	122K02	0516					25		All	3100		
1985	92988	261021	No Replacement Repair With Individual Parts.								All	3100		
1986	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500		
1987	92982	260911	No Replacement Repair With Individual Parts.								All	3200		
1988	92902	260096	9M902	0016							All	2900		
1989	92908	261030	122K02	0515					25		All	3300		
1990	92985	260911	No Replacement Repair With Individual Parts.								All	3100		
1991	92908	261030	No Replacement Repair With Individual Parts.								All	3300		
1992	92905	261014	No Replacement Repair With Individual Parts.								All	3100		
1993	92902	260096	122K02	0516					25		All	3100		
1994	92902	260097	No Replacement Repair With Individual Parts.								All	3200		
1995	92902	260098	122K02	0518					25		All	3200		
1996	92908	261030	122K02	0515					25		All	3000		
1997	92908	261013	No Replacement Repair With Individual Parts.								All	3300		
1998	92908	261030	122K02	0515	1	690319	1	691851	25		All	3300		
1999	92902	260124	9M902	0015					73		All	3000		
2000	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500		
2001	92988	261021	No Replacement Repair With Individual Parts.								All	3300		
2002	92908	261014	122K02	0518					25		All	3300		
2003	92908	261014	122K02	0518					25		All	3300		
2004	92902	260096	122K02	0516	1	690319	1	691851	25		All	3300		
2005	92902	260096	122K02	0516					25		All	3100		
2006	92985	260911	No Replacement Repair With Individual Parts.								All	3300		
2007	92988	261021	No Replacement Repair With Individual Parts.								All	3100		
2008	92905	260096	No Replacement Repair With Individual Parts.								All	3300		
2009	92902	260124	9M902	0015					73		All	3300		
2010	92908	261014	122K02	0518					25		All	3000		
2011	92982	260911	No Replacement Repair With Individual Parts.								All	3000		
2012	92908	260124	122K02	0515					25		All	3300		
2013	92908	260124	122K02	0515	1	690251	1	691851	25		All	3500		
2014	92908	260124	122K02	0515					25		All	3100		
2015	92908	261014	122K02	0518					25		All	3100		
2016	92902	260098	122K02	0518	1	492177	1	492893	25		All	3500		
					1	690319	1	691851						
2017	92902	261024	9M902	0015	1	690251	1	691862	73		All	4000		
2018	92902	261024	9M902	0015							All	3300		
2019	92905	260098	No Replacement Repair With Individual Parts.								All	3200		
2020	92902	260098	122K02	0518	1	492177	1	492893	25		All	3700		
					1	690319	1	691290						
2021	92908	261012	122K02	0516					25		All	3100		
2022	92908	261013	No Replacement Repair With Individual Parts.								All	2900		
2023	92988	261021	No Replacement Repair With Individual Parts.								All	3000		
2024	92908	260124	122K02	0515	1	690319	1	691851	25		All	3500		
2025	92908	260124	122K02	0515	1	690319	1	691851	25		All	3500		
2026	92908	260124	122K02	0515	1	690319	1	691851	25		All	3500		
2027	92908	260319	No Replacement Repair With Individual Parts.								All	3500		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
2028	92902	260098	122K02	0518	1	690319	1	691851	25		All	3500		
2029	92982	260911	No Replacement Repair With Individual Parts.								All	2900		
2030	92908	261030	122K02	0515	1	690319	1	691851	25		All	3300		
2031	92902	261024	122K02	0515	1	492177	1	492893	25		All	3200		
2032	92908	260097	No Replacement Repair With Individual Parts.								All	3300		
2033	92908	260096	122K02	0516					25		All	3300		
2034	92902	261024	9M902	0015					73		All	3200		
2035	92902	260096	No Replacement Repair With Individual Parts.								All	3500		
2036	92908	260096	122K02	0516					25		All	3100		
2037	92982	260911	No Replacement Repair With Individual Parts.								All	2900		
2038	92982	260911	No Replacement Repair With Individual Parts.								All	2900		
2039	92982	260911	No Replacement Repair With Individual Parts.								All	2900		
2040	92908	261030	122K02	0015	1	690319	1	691851	25		All	3500		
2041	92908	260096	122K02	0516					25		All	3100		
2042	92902	260096	9M902	0016					73		All	3200		
2043	92902	260124	9M902	0015					25		All	3200		
2044	92902	260124	122K02	0515					25		All	3300		
2045	92982	260911	No Replacement Repair With Individual Parts.								All	3300		
2046	92902	260096	9M902	0016							All	3500		
2047	92902	260124	9M902	0015							All	3300		
2048	92908	261030	122K02	0515					25		All	3200		
2049	92988	261021	No Replacement Repair With Individual Parts.								All	3200		
2051	92908	261030	122K02	0515					25		All	3000		
2052	92908	261293	No Replacement Repair With Individual Parts.								All	2600		
2053	92908	261293	No Replacement Repair With Individual Parts.								All	2600		
2054	92908	261293	No Replacement Repair With Individual Parts.								All	3100		
2055	92908	261417	No Replacement Repair With Individual Parts.								All	3000		
2056	92902	260096	122K02	0516					25		All	3200		
2057	92902	260096	122K02	0516	1	690319	1	691851	25		All	3500		
2058	92902	260096	9M902	0016							All	3500		
2059	92908	261417	No Replacement Repair With Individual Parts.								All	2900		
2060	92902	260096	122K02	0516					25		All	3300		
2061	92902	260098	122K02	0518	1	492177	1	492893	25		All	3300		
					1	690319	1	691851						
2062	92902	260124	9M902	0015							All	3200		
2063	92902	260124	122K02	0515	1	690319	1	691851	25		All	3300		
2064	92982	260911	No Replacement Repair With Individual Parts.								All	3000		
2066	92902	260096	9M902	0016							All	2900		
2067	92902	260124	9M902	0015							All	2900		
2068	92988	261021	No Replacement Repair With Individual Parts.								All	2900		
2069	92988	260911	No Replacement Repair With Individual Parts.								All	2900		
2070	92982	260911	No Replacement Repair With Individual Parts.								All	2900		
2071	92982	260911	No Replacement Repair With Individual Parts.								All	2900		
2072	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500		
2073	92988	261021	No Replacement Repair With Individual Parts.								All	3500		
2074	92902	260098	122K02	0518	1	492177	1	492893	25		All	3700		
					1	690319	1	691290						
2075	92998	261028	No Replacement Repair With Individual Parts.								All	3300		
2076	92908	261012	122K02	0516					25		All	3300		
2077	92905	260098	No Replacement Repair With Individual Parts.								All	3000		
2078	92905	260095	No Replacement Repair With Individual Parts.								All	3000		
2079	92982	260911	No Replacement Repair With Individual Parts.								All	3500		
2080	92982	260911	No Replacement Repair With Individual Parts.								All	3000		
2081	92902	260098	122K02	0518	1	492177	1	492893	25		All	3100		
2082	92905	260095	No Replacement Repair With Individual Parts.								All	3000		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
2083	92982	260911	No Replacement Repair With Individual Parts.									All	3500		
2084	92908	260098	No Replacement Repair With Individual Parts.									All	3200		
2085	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
2086	92902	260097	No Replacement Repair With Individual Parts.									All	3500		
2087	92908	260097	No Replacement Repair With Individual Parts.									All	3500		
2088	92908	260124	122K02	0515	1	690319	1	691851	25		All	3300			
2089	92982	260911	No Replacement Repair With Individual Parts.									All	3500		
2090	92908	261030	122K02	0515	1	690319	1	691851	25		All	3300			
2091	92902	260096	122K02	0516	1	492177	1	492893	25		All	3500			
					1	690319	1	691851							
2092	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
2093	92982	260911	No Replacement Repair With Individual Parts.									All	3300		
2094	92982	260911	No Replacement Repair With Individual Parts.									All	3100		
2095	92985	261021	No Replacement Repair With Individual Parts.									All	3100		
2096	92908	260096	122K02	0516					25		All	3000			
2097	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
2098	92908	261030	122K02	0515					25		All	3200			
2099	92908	260096	122K02	0516	1	690319	1	691851	25		All	3500			
2100	92908	261030	122K02	0515					25		All	3200			
2101	92902	260098	122K02	0518	1	492177	1	492893	25		All	3300			
2102	92908	261030	122K02	0515	1	690319	1	691851	25		All	3500			
2103	92988	261021	No Replacement Repair With Individual Parts.									All	3500		
2104	92908	260096	122K02	0516	1	690319	1	691851	25		All	3500			
2105	92908	260096	122K02	0516					25		All	3200			
2106	92908	261030	122K02	0515	1	690319	1	691851	25		All	3300			
2107	92988	261021	No Replacement Repair With Individual Parts.									All	3200		
2108	92902	260096	122K02	0516					25		All	3200			
2109	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500			
2110	92902	260124	9M902	0015					73		All	3000			
2111	92908	260096	122K02	0516					25		All	3900			
2112	92908	260097	No Replacement Repair With Individual Parts.									All	3300		
2113	92908	260096	122K02	0516					25		All	3300			
2114	92902	260098	122K02	0518	1	492177	1	492893	25		All	3000			
2115	92902	260096	9M902	0016					73		All	3500			
2116	92902	260096	9M902	0016					73		All	3200			
2117	92908	260097	No Replacement Repair With Individual Parts.									All	3500		
2118	92902	260096	122K02	0516					25		All	3300			
2119	92982	260911	No Replacement Repair With Individual Parts.									All	3300		
2120	92902	260096	9M902	0016							All	3500			
2121	92908	260096	No Replacement Repair With Individual Parts.									All	3100		
2122	92902	260096	122K02	0516	1	690319	1	691851	25		All	3500			
2123	92902	260096	9M902	0016							All	3500			
2124	92908	260096	122K02	0516					25		All	3200			
2125	92902	260124	122K02	0515	1	690319	1	691290	25		All	3700			
2126	92982	260911	No Replacement Repair With Individual Parts.									All	3000		
2127	92988	260912	No Replacement Repair With Individual Parts.									All	3100		
2128	92908	260124	122K02	0515	1	690319	1	691851	25		All	3500			
2129	92908	260097	No Replacement Repair With Individual Parts.									All	3500		
2130	92902	260097	No Replacement Repair With Individual Parts.									All	2900		
2131	92905	260098	No Replacement Repair With Individual Parts.									All	3200		
2132	92902	260124	122K02	0515	1	690319	1	691851	25		All	3300			
2133	92902	260097	No Replacement Repair With Individual Parts.									All	3300		
2134	92902	260096	9M902	0016							All	3500			
2135	92902	260098	9M902	0018							All	3100			

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
2136	92982	260911	No Replacement Repair With Individual Parts.								All	3100	.	
2137	92982	260911	No Replacement Repair With Individual Parts.								All	3100	.	
2138	92902	260124	122K02	0515					25					
2139	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500		
2140	92908	260096	No Replacement Repair With Individual Parts.								All	3100	.	
2141	92908	260096	122K02	0516					25		All	3200		
2142	92908	260098	122K02	0518					25		All	3000		
2143	92902	260096	122K02	0516	1	690319	1	691851	25		All	3500		
2144	92988	260911	No Replacement Repair With Individual Parts.								All	3500	.	
2145	92902	260124	9M902	0015			1	66538	73		All	3200		
2146	92902	260096	9M902	0016							All	3200		
2147	92908	260096	122K02	0516							All	3300		
2148	92908	260124	122K02	0515					25		All	3200		
2149	92905	261050	No Replacement Repair With Individual Parts.								All	3100	.	
2150	92908	261050	No Replacement Repair With Individual Parts.								All	3200	.	
2151	92908	260096	122K02	0516					25		All	3100		
2152	92988	260911	No Replacement Repair With Individual Parts.								All	3500	.	
2153	92982	260911	No Replacement Repair With Individual Parts.								All	3500	.	
2154	92988	260911	No Replacement Repair With Individual Parts.								All	3500	.	
2155	92908	260124	122K02	0515	1	690319	1	691851	25		All	3300		
2156	92988	260911	No Replacement Repair With Individual Parts.								All	3100	.	
2157	92908	260096	122K02	0516	1	690319	1	691851	25		All	3500		
2158	92908	260124	122K02	0515	1	690319	1	691851	25		All	3300		
2159	92905	260098	No Replacement Repair With Individual Parts.								All	3500	.	
2160	92902	260096	122K02	0516					25		All	2900		
2161	92908	260098	122K02	0518					25		All	3200		
2162	92902	260124	122K02	0515					25		All	3000		
2163	92902	260319	9M902	0016							All	3300		
2164	92902	260096	122K02	0516					25		All	3100		
2165	92905	260098	122K02	0518					25		All	3200		
2166	92988	260911	No Replacement Repair With Individual Parts.								All	3100	.	
2167	92902	260096	122K02	0516	1	690319	1	691851	25		All	3500		
2168	92902	260098	122K02	0518					25		All	3200		
2169	92908	260124	122K02	0515					25		All	3000		
2170	92902	260096	9M902	0016					73		All	3500		
2171	92902	260124	122K02	0515					25		All	3200		
2172	92908	260096	122K02	0516	1	690319	1	691851	25		All	4000		
2173	92908	260098	122K02	0518					25		All	3100		
2174	92902	260097	No Replacement Repair With Individual Parts.								All	3500	.	
2175	92902	260124	122K02	0515	1	690319	1	691851	25		All	3500		
2176	92902	260097	No Replacement Repair With Individual Parts.								All	3500	.	
2177	92908	260124	122K02	0515					25		All	3200		
2178	92902	260096	122K02	0516	1	690319	1	691851	25		All	3500		
2179	92908	260098	122K02	0515	1	690319	1	691851	25		All	3500		
2180	92908	260096	122K02	0516					25		All	3200		
2181	92982	260911	No Replacement Repair With Individual Parts.								All	3000	.	
2182	92908	260096	122K02	0516					25		All	3200		
2183	92908	260096	122K02	0516					25		All	3000		
2184	92908	260098	122K02	0518					25		All	3100		
2185	92982	260911	No Replacement Repair With Individual Parts.								All	3100	.	
2186	92988	260911	No Replacement Repair With Individual Parts.								All	3100	.	
2187	92902	260124	122K02	0515					25		All	3100		
2188	92908	260124	122K02	0515					25		All	3100		
2190	92982	260911	No Replacement Repair With Individual Parts.								All	3100	.	

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
2191	92908	260124	122K02	0515					25		All	3000			
2192	92988	260911	No Replacement Repair With Individual Parts.									All	3000		
2193	92982	260911	No Replacement Repair With Individual Parts.									All	3000		
2194	92902	260096	122K02	0516					25		All	3200			
2195	92902	260124	9M902	0015					73		All	3300			
2196	92902	260097	No Replacement Repair With Individual Parts.									All	3500		
2197	92988	260911	No Replacement Repair With Individual Parts.									All	3200		
2198	92908	260124	122K02	0515	1	690319	1	691851	25		All	3300			
2199	92908	260124	122K02	0515					25		All	3200			
2200	92902	260097	No Replacement Repair With Individual Parts.									All	3300		
2201	92908	261024	122K02	0515	1	690319	1	691851	25		All	3300			
2202	92902	261024	122K02	0515	1	690319	1	691851	25		All	3500			
2203	92988	261024	No Replacement Repair With Individual Parts.									All	3200		
2204	92908	260096	122K02	0516	1	690319	1	691851	25		All	3500			
2205	92902	261024	122K02	0515	1	690319	1	691851	25		All	3500			
2206	92905	261050	No Replacement Repair With Individual Parts.									All	3200		
2207	92908	261050	No Replacement Repair With Individual Parts.									All	3200		
2208	92908	260124	122K02	0515	1	690319	1	691851	25		All	3300			
2209	92908	260098	122K02	0518	1	690319	1	691851	25		All	3500			
3015	92902	493016	122K02	0515					25		All	3100	398210		
3016	92902	492086	122K02	0516					25		All	3100	398211		
3017	92902	493618	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398212	
3018	92902	494034	122K02	0518					25		All	3100	398213		
3019	92902	492086	122K02	0516					25		All	3100	398211		
3050	92982	493016	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398215	
3051	92982	493016	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398214	
3052	92982	492086	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398217	
3053	92982	492086	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398216	
3060	92907	493016	No Replacement Repair With Individual Parts.									All	3100		
3064	92907	494034	No Replacement Repair With Individual Parts.									All	3100		
3065	92987	492748	No Replacement Repair With Individual Parts.									All	3100		
3081	92907	492748	No Replacement Repair With Individual Parts.									All	3200		
3084	92907	494034	No Replacement Repair With Individual Parts.									All	3200		
3088	92987	493016	No Replacement Repair With Individual Parts.									All	3200		
3130	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3000	398214	PP
3131	92902	492748	122K02	0515					25		All	3000	398210		
3132	92902	494034	122K02	0518					25		All	3000	398213		
3133	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3000	398215	CC
3134	92902	492748	9M902	0015							All	3100	398210		
3135	92902	492748	122K02	0515					25		All	3100	398210		
3136	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398214	
3137	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398215	FF
3138	92907	492748	No Replacement Repair With Individual Parts.									All	3200		
3139	92987	492748	No Replacement Repair With Individual Parts.									All	3000		
3140	92907	494034	No Replacement Repair With Individual Parts.									All	3000		
3141	92987	492748	No Replacement Repair With Individual Parts.									All	3100		
3142	92902	492748	122K02	0515	1	492177	1	492893	25		All	3300	398210		
						1	690319	1	691851						
3143	92902	492086	122K02	0516					25		All	3100	398211		
3144	92902	492086	122K02	0516	1	690319	1	691851	25		All	3500	398211		
3145	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3000	398215	DD
3146	92902	492748	122K02	0515	1	690319	1	691851	25		All	3300	398210		
3147	92902	492748	122K02	0515					25		All	3200	398210		
3148	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398215	
3149	92902	492086	9M902	0016							All	3100	398211		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
3150	92902	492086	9M902	0016							All	3200	398211		
3151	92902	492086	122K02	0516					25		All	3000	398211		
3152	92902	494375	No Replacement Repair With Short Block and/or Individual Parts									All	3300	398212	G
3153	92902	494375	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398212	G
3154	92987	492748	No Replacement Repair With Individual Parts.									All	3000		
3155	92902	492086	122K02	0516					25		All	3300	398211		
3156	92902	492748	122K02	0515					25		All	3000	398210		
3157	92907	492748	No Replacement Repair With Individual Parts.									All	3000		
3158	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398214	CC
3159	92902	492748	122K02	0515	1	690319	1	691851	25		All	3300	398210		
3160	92907	492748	No Replacement Repair With Individual Parts.									All	3100		
3161	92907	261050	No Replacement Repair With Individual Parts.									All	3100		
3162	92992	260856	No Replacement Repair With Individual Parts.									All	3300		
3163	92902	492086	9M902	0016							All	3100	398211		
3164	92907	492748	No Replacement Repair With Individual Parts.									All	3000		
3165	92907	494034	No Replacement Repair With Individual Parts.									All	3000		
3166	92987	492748	No Replacement Repair With Individual Parts.									All	3000		
3167	92902	492748	9M902	0015							All	3200	398210		
3168	92902	492748	9M902	0015							All	3200	398210		
3169	92902	494034	9M902	0018							All	3200	398213		
3170	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3000	398215	FF
3171	92902	494034	9M902	0018							All	3000	398213		
3172	92902	492748	9M902	0015							All	3000	398210		
3173	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	2900	398215	
3174	92982	492086	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398217	II
3175	92902	492748	122K02	0515					25		All	3200	398210		
3176	92902	492748	122K02	0515					25		All	3200	398210		
3177	92907	492748	No Replacement Repair With Individual Parts.									All	3200		
3178	92902	492086	9M902	0016							All	3200	398211		
3179	92902	492748	9M902	0015							All	3200	398210		
3180	92982	492086	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398217	
3181	92902	492086	122K02	0516					25		All	3100	398211		
3182	92982	492086	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398216	
3183	92982	492086	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398217	DD
3184	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3000	398215	FF
3185	92902	492748	122K02	0516	1	492177	1	492893	25		All	3000	398211		
3186	92902	492748	9M902	0015							All	3300	398210		
3187	92902	493618	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398212	
3188	92902	492086	9M902	0016							All	3000	398211		
3189	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3000	398215	AA
3190	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	2900	398215	DD
3191	92902	492748	9M902	0015							All	2900	398210		
3192	92902	492748	122K02	0515	1	492177	1	492893	25		All	3200	398210	T	
3193	92902	494034	9M902	0018							All	3200	398213		
3194	92902	492748	9M902	0015							All	3000	398210		
3195	92908	492748	No Replacement Repair With Individual Parts.									All	3000		
3196	92908	261293	No Replacement Repair With Individual Parts.									All	3100		
3197	92902	492086	9M902	0016							All	3200	398211		
3198	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3000	398215	DD
3199	92908	492748	No Replacement Repair With Individual Parts.									All	3200		
3200	92902	492086	122K02	0516	1	690319	1	691851	25		All	3500	398210		
3201	92902	492086	122K02	0516					25		All	3000	398211		
3202	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3000	398215	DD
3203	92902	492086	122K02	0516					25		All	3000	398211		
3204	92902	492086	122K02	0516					25		All	3200	398211		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
3205	92902	492086	122K02	0516					25		All	2900	398211		
3206	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	2900	398214	
3207	92902	492086	122K02	0516					25		All	2900	398211		
3208	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3000	398214	PP
3209	92902	492748	122K02	0515					25		All	2900	398210		
3210	92902	494034	122K02	0518					25		All	3000	398213		
3211	92907	492748	No Replacement Repair With Individual Parts.									All	3200		
3212	92982	492748	No Replacement Repair With Individual Parts.									All	3100		
3213	92902	492748	9M902	0015							All	3000	398210		
3214	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3000	398215	DD
3215	92988	492748	No Replacement Repair With Individual Parts.									All	3000		
3216	92902	492748	9M902	0015							All	3000	398210		
3217	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3000	398214	CC
3218	92902	492086	9M902	0016							All	2900	398211		
3219	92902	492748	9M902	0015							All	2900	398210		
3220	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	2900	398215	
3221	92907	492086	No Replacement Repair With Individual Parts.									All	3100		
3222	92902	492086	122K02	0516					25		All	3200	398211		
3223	92902	492748	122K02	0515					25		All	3200	398210		
3224	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	2900	398215	AA
3225	92902	492748	122K02	0515					25		All	3100	398210		
3226	92907	492748	No Replacement Repair With Individual Parts.									All	3000		
3227	92902	492086	9M902	0016							All	3200	398211		
3228	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3000	398215	DD
3229	92982	492086	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398216	BB
3230	92907	494375	No Replacement Repair With Individual Parts.									All	3100		
3231	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3000	398215	PP
3232	92902	492086	9M902	0016							All	2900	398211		
3233	92982	492086	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398216	
3234	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398214	Y
3235	92902	492748	122K02	0515					25		All	3000	398210		
3236	92907	492748	No Replacement Repair With Individual Parts.									All	3100		
3237	92907	494375	No Replacement Repair With Individual Parts.									All	3100		
3238	92902	492748	9M902	0015							All	3000	398210		
3239	92902	492748	9M902	0015							All	3000	398210		
3240	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3000	398215	CC
3241	92902	492086	9M902	0016							All	2900	398211		
3242	92902	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210		
3243	92902	494034	9M902	0018							All	3000	398213		
3244	92902	492748	122K02	0515					25		All	3000	398210		
3245	92902	494034	122K02	0518					25		All	3000	398213		
3246	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3000	398214	PP
3247	92902	492748	9M902	0015							All	3000	398210		
3248	92902	492086	9M902	0016							All	3200	398211		
3249	92902	494034	9M902	0018							All	3100	398213		
3250	92982	492086	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398216	CC
3251	92902	493618	No Replacement Repair With Short Block and/or Individual Parts									All	3500	398212	
3252	92902	492748	9M902	0015							All	3200	398210		
3253	92902	492086	122K02	0516					25		All	3100	398211		
3254	92982	492086	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398217	
3255	92902	492086	122K02	0516					25		All	3100	398212		
3256	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3000	398215	DD
3257	92902	492748	9M902	0015							All	3100	398210		
3258	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398215	CC
3259	92902	492748	122K02	0515					25		All	3300	398210		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
3260	92907	260370	No Replacement Repair With Individual Parts.								All	3100		
3261	92902	492086	9M902	0016						All	3200	398211		
3262	92902	492086	9M902	0016						All	3200	398211		
3263	92987	492086	No Replacement Repair With Individual Parts.								All	3100		
3264	92902	492748	122K02	0515	1	492177	1	492893	25	All	3300	398210		
					1	690319	1	691851						
3265	92902	492086	122K02	0516					25	All	3100	398211		
3266	92982	492086	No Replacement Repair With Short Block and/or Individual Parts								All	3100	398217	
3267	92907	494034	No Replacement Repair With Individual Parts.								All	3000		
3268	92987	494034	No Replacement Repair With Individual Parts.								All	3000		
3269	92902	492086	9M902	0016						All	3500	398211		
3270	92902	492086	9M902	0016						All	3100	398211		
3271	92902	492748	122K02	0515	1	690319	1	691851	25	All	3300	398210		
3272	92902	492748	122K02	0515	1	690319	1	691851	25	All	3300	398210		
3273	92902	492086	122K02	0516					25	All	3100	398211		
3274	92902	492086	122K02	0516	1	690319	1	691851	25	All	3500	398211		
3275	92902	492748	122K02	0515	1	690319	1	691851	25	All	3500	398210		
3276	92902	492086	122K02	0516					25	All	3100	398211		
3277	92902	492086	122K02	0516					25	All	3100	398211		
3278	92902	492748	9M902	0015						All	3300	398210		
3279	92902	492086	9M902	0016						All	2900	398211		
3280	92982	492086	No Replacement Repair With Short Block and/or Individual Parts								All	3000	398215	
3281	92902	492748	122K02	0515					25	All	3200	398210		
3282	92902	494034	9M902	0018						All	3100	398213		
3283	92902	492748	122K02	0515					25	All	2900	398210		
3284	92908	492748	No Replacement Repair With Individual Parts.								All	3100		
3285	92982	492748	No Replacement Repair With Short Block and/or Individual Parts								All	3200	398214	
3286	92902	492748	122K02	0515	1	690319	1	691851	25	All	3300	398210		
3287	92982	492748	No Replacement Repair With Short Block and/or Individual Parts								All	3100	398214	PP
3288	92902	492748	122K02	0515	1	690319	1	691851	25	All	3300	398210		
3289	92982	492748	No Replacement Repair With Short Block and/or Individual Parts								All	3100	398215	DD
3290	92982	492086	No Replacement Repair With Short Block and/or Individual Parts								All	3200	398216	
3291	92902	492086	9M902	0016						All	3100	398211		
3292	92982	492748	No Replacement Repair With Short Block and/or Individual Parts								All	3200	398214	
3293	92982	492748	No Replacement Repair With Short Block and/or Individual Parts								All	3100	398215	PP
3294	92982	492748	No Replacement Repair With Short Block and/or Individual Parts								All	3200	398214	
3295	92902	492748	9M902	0015						All	3000	398210		
3300	92902	492748	9M902	0015						All	3000	398210		
3301	92902	492086	9M902	0016						All	3000	398211		
3303	92902	492086	9M902	0018						All	3000	398213		
3304	92902	492086	122K02	0516					25	All	3200	398211		
3305	92902	492748	122K02	0515					25	All	3000	398210		
3306	92902	492748	122K02	0515					25	All	3000	398210		
3308	92902	492086	122K02	0516					25	All	3000	398211		
3309	92902	494034	122K02	0518					25	All	3000	398213		
3310	92902	492086	122K02	0516					25	All	3000	398211		
3311	92902	492748	122K02	0515					25	All	3000	398210		
3312	92902	492086	122K02	0516					25	All	3100	398211		
3313	92902	492748	122K02	0515					25	All	3200	398210		
3314	92982	492748	No Replacement Repair With Short Block and/or Individual Parts								All	3200	398215	PP
3911	92902	492748	122K02	0515					25	All	3000			
3912	92902	492748	122K02	0515					25	All	3200			
3913	92982	492086	No Replacement Repair With Individual Parts.								All	3100		
3914	92902	492748	122K02	0515					25	All	3300			
5001	92908	492748	122K02	0515					25	All	3200	398210		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
5002	92908	492086	122K02	0516					25		All	3200	398211		
5004	92908	494034	No Replacement Repair With Short Block and/or Individual Parts									All	3200	398213	
5005	92902	492748	9M902	0015					73		All	3200	398210		
5006	92988	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3200	398214	
5007	92902	492086	9M902	0016							All	3200	398211		
5008	92988	493618	No Replacement Repair With Individual Parts.									All	3100		
5015	92902	493016	122K02	0515	1	492177	1	492893	25		All	3200			
5016	92902	493016	122K02	0515					25		All	3200			
5017	92902	492086	122K02	0516					25		All	3200			
5019	92902	494034	122K02	0518	1	492177	1	492893	25		All	3200			
5021	92902	260670	122K02	0515					25		All	3200			
5023	92902	493618	No Replacement Repair With Individual Parts.									All	3200		
5029	92902	260370	No Replacement Repair With Individual Parts.									All	3200		
5036	92902	492748	122K02	0515	1	690319	1	691851	25		All	3500			
5043	92992	492748	No Replacement Repair With Individual Parts.									All	3200		
5045	92998	261007	No Replacement Repair With Individual Parts.									All	3200		
5050	92982	494034	No Replacement Repair With Individual Parts.									All	3200		
5051	92982	493416	No Replacement Repair With Individual Parts.									All	3200		
5065	92988	493016	No Replacement Repair With Individual Parts.									All	3200		
5066	92988	493016	No Replacement Repair With Individual Parts.									All	3200		
5071	92908	493016	122K02	0515					25		All	3200			
5072	92908	492086	122K02	0516					25		All	3200			
5073	92908	493618	No Replacement Repair With Individual Parts.									All	3200		
5074	92908	494034	122K02	0518					25		All	3200			
5075	92908	261050	No Replacement Repair With Individual Parts.									All	3300		
5078	92908	261050	No Replacement Repair With Individual Parts.									All	3100		
5079	92908	261133	No Replacement Repair With Individual Parts.									All	3300		
5080	92908	261293	No Replacement Repair With Individual Parts.									All	3000		
5082	92988	261028	No Replacement Repair With Individual Parts.									All	3300		
5090	92908	492748	122K02	0515					25		All	3000			
5091	92908	492086	122K02	0516					25		All	3300			
5093	92908	492748	122K02	0515					25		All	3200			
5101	92902	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210		
5104	92908	492748	122K02	0515					25		All	3300	398210		
5107	92907	492748	No Replacement Repair With Individual Parts.									All	3500		
5110	92987	492748	No Replacement Repair With Individual Parts.									All	3500		
5111	92902	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210		
5112	92902	492086	122K02	0516	1	690319	1	691851	25		All	3500	398211		
5113	92902	493618	See Equipment Manufacturer for Replacement Engines and Parts.									All	3500	398212	
5114	92902	494034	122K02	0518	1	690319	1	691851	25		All	3500	398213		
5115	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3500	398214	
5116	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3500	398215	FF
5123	92907	492748	No Replacement Repair With Individual Parts.									All	3500		
5125	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3500	398214	
5126	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3500	398215	FF
5129	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3500	398214	
5130	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3000	398214	PP
5131	92902	492748	122K02	0515					25		All	3000	398210		
5132	92902	494034	9M902	0018							All	3000	398213		
5134	92902	492748	9M902	0015							All	3100	398210		
5135	92902	492748	122K02	0515					25		All	3100	398210		
5138	92907	492748	9M902	0015							All	3200			
5139	92987	492748	No Replacement Repair With Individual Parts.									All	3000		
5140	92907	494034	No Replacement Repair With Individual Parts.									All	3000		
5148	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398215	

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
5149	92902	492086	9M902	0016							All	3100	398211		
5150	92902	492086	9M902	0016							All	3500	398211		
5151	92902	492086	9M902	0016							All	3300	398211		
5152	92902	494375	No Replacement Repair With Short Block and/or Individual Parts									All	3500	398212	G
5153	92902	494375	No Replacement Repair With Short Block and/or Individual Parts									All	3200	398212	G
5154	92988	492086	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398217	
5155	92902	492086	122K02	0516	1	690319	1	691851	25		All	3500	398211		
5156	92988	492086	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398216	
5157	92908	492086	122K02	0516					25		All	3100	398211		
5158	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398215	DD
5159	92902	492748	122K02	0515	1	690319	1	691851	25		All	3300	398210		
5160	92907	492748	No Replacement Repair With Individual Parts.									All	3300		
5161	92907	494375	No Replacement Repair With Individual Parts.									All	3200		
5162	92908	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3500	398210	
5163	92902	492086	122K02	0516					25		All	3100	398211		
5164	92902	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210		
5165	92907	492748	No Replacement Repair With Individual Parts.									All	3500		
5166	92902	493618	No Replacement Repair With Short Block and/or Individual Parts									All	3500	398212	
5167	92902	492748	122K02	0515					25		All	3200	398210		
5168	92902	492748	122K02	0515					25		All	3100	398210		
5169	92902	494034	122K02	0518					25		All	3200	398213		
5170	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3000	398215	FF
5171	92902	494034	122K02	0518					25		All	3000	398213		
5172	92902	492748	122K02	0515					25		All	3000	398210		
5173	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	2900	398215	
5174	92982	492086	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398217	II
5175	92908	494034	122K02	0518	1	690319	1	691851	25		All	3500	398213		
5176	92902	492748	122K02	0515					25		All	3200	398210		
5178	92902	492748	122K02	0515					25		All	3200	398210		
5179	92902	492748	122K02	0515					25		All	3200	398210		
5180	92982	492086	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398217	
5181	92902	492086	122K02	0516					25		All	3100	398211		
5182	92982	492086	No Replacement Repair With Short Block and/or Individual Parts											398216	
5184	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3000	398215	
5185	92908	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210		
5186	92902	492086	122K02	0516	1	690319	1	691851	25		All	3500	398211		
5187	92902	493618	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398212	
5188	92902	492086	122K02	0516					25		All	3000	398211		
5189	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3000	398215	AA
5190	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	2900	398215	DD
5191	92902	492748	122K02	0515					25		All	2900	398210		
5192	92908	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210		
5193	92908	494034	122K02	0518	1	690319	1	691851	25		All	3500	398213		
5194	92902	492086	122K02	0516	1	690319	1	691851	25		All	3500	398211		
5195	92902	492086	9M902	0016							All	3500	398211		
5196	92908	261292	See Equipment Manufacturer for Replacement Engines and Parts.									All	3000	398211	G
5197	92982	494034	No Replacement Repair With Individual Parts.									All	3300		
5199	92908	492748	122K02	0515	1	690319	1	691851	25		All	3300	398210		
5200	92908	492748	122K02	0515	1	690319	1	691851	25		All	3300	398210		
5201	92908	492086	122K02	0516					25		All	3300	398211		
5202	92902	492086	122K02	0516	1	690315	1	691851	25		All	3500	398211		
5203	92908	494034	122K02	0518					25		All	3000	398213		
5204	92988	492086	No Replacement Repair With Short Block and/or Individual Parts									All	3000	398217	DD
5205	92908	261293	No Replacement Repair With Individual Parts.												

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block		
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes	
5208	92908	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210		
5209	92902	492086	122K02	0516	1	690319	1	691851	25		All	3500	398211		
5210	92902	492748	122K02	0515					25		All	3300	398210		
5211	92902	493618	No Replacement Repair With Individual Parts.									All	3300		
5212	92908	493618	No Replacement Repair With Individual Parts.									All	3500		
5213	92902	492086	No Replacement Repair With Short Block and/or Individual Parts									All	4000	398211	
5214	92902	492086	9M902	0016							All	3500	398211		
5215	92902	492086	9M902	0016							All	3500	398211		
5216	92902	494034	122K02	0518	1	492177	1	492893	25		All	4000	398213		
					1	690319	1	691290							
5217	92988	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3000	398214	
5218	92902	492748	122K02	0515					25		All	3200	398210		
5219	92902	494034	122K02	0518	1	492177	1	492893	25		All	3200	398213		
5220	92902	494034	122K02	0518	1	492177	1	492893	25		All	3000	398213		
5221	92908	492086	122K02	0516					25		All	3300	398211		
5222	92902	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210		
5223	92902	492086	9M902	0016							All	3500	398211		
5224	92908	492086	122K02	0516	1	690319	1	691851	25		All	3500	398211		
5225	92982	493618	No Replacement Repair With Individual Parts.									All	3300		
5226	92902	492086	9M902	0016							All	3000	398211		
5227	92902	492748	122K02	0515	1	690319	1	691851	25		All	3700	398210		
5228	92908	492086	122K02	0516	1	690319	1	691851	25		All	3500	398211		
5229	92908	492086	122K02	0516	1	690319	1	691851	25		All	3500	398211		
5230	92908	492086	122K02	0516	1	690319	1	691851	25		All	3500	398211		
5232	92908	492748	122K02	0515	1	690319	1	691851	25		All	3300	398210		
5233	92982	492748	No Replacement Repair With Individual Parts.									All	3200		
5234	92902	492748	122K02	0515					25		All	2900	398210		
5235	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	2900	398215	
5236	92988	492086	No Replacement Repair With Short Block and/or Individual Parts									All	3300	398216	II
5237	92902	494034	122K02	0518	1	492177	1	492893	25		All	3300	398213		
5238	92908	492086	122K02	0516	1	690319	1	691851	25		All	3700	398211		
5239	92902	492748	122K02	0515	1	492177	1	492893	25		All	3500	398210		
					1	690319	1	691851							
5240	92902	494034	122K02	0518	1	492177	1	492893	25		All	4000	398213		
					1	690319	1	691290							
5241	92908	492748	122K02	0515					25		All	3200	398210		
5242	92988	492086	See Equipment Manufacturer for Replacement Engines and Parts.									All	3000	398216	
5243	92908	492086	122K02	0516					25		All	3000	398211		
5244	92902	492748	9M902	0015					73		All	3200	398210		
5245	92902	492748	122K02	0515	1	492177	1	492893	25		All	3300	398210		
					1	690319	1	691851							
5246	92982	492748	No Replacement Repair With Individual Parts.									All	3500		
5247	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3000	398214	
5248	92902	492748	9M902	0015					73		All	3700	398210		
5249	92902	492748	9M902	0015					73		All	3000	398210		
5250	92902	492748	122K02	0515					25		All	3000	398210		
5251	92902	494034	122K02	0518	1	492177	1	492893	25		All	3700	398213		
					1	690319	1	691290							
5252	92902	492748	9M902	0015					73		All	3000	398210		
5253	92902	492086	9M902	0016							All	3500	398211		
5254	92902	492748	122K02	0515					25		All	3100	398210		
5255	92908	492748	122K02	0515					25		All	3100	398210		
5256	92982	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398215	DD
5257	92988	492748	No Replacement Repair With Short Block and/or Individual Parts									All	3100	398215	FF

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
5258	92988	492748	No Replacement Repair With Short Block and/or Individual Parts						All	3100	398215	DD		
5259	92902	493618	No Replacement Repair With Short Block and/or Individual Parts						All	3300	398212			
5260	92908	492748	122K02	0515	1	690319	1	691851	25	All	3500	398210		
5261	92902	492086	122K02	0516	1	690319	1	691851	25	All	3500	398211		
5262	92902	492748	No Replacement Repair With Short Block and/or Individual Parts						All	3300	398215			
5263	92902	492748	122K02	0515	1	690319	1	691290	25	All	4000	398210		
5264	92902	492748	122K02	0515					25	All	3200	398210		
5265	92902	492086	9M902	0016					73	All	3300	398211		
5266	92902	492748	9M902	0015					73	All	3300	398210		
5267	92908	492748	122K02	0515					25	All	3000	398210		
5268	92908	492748	122K02	0515					25	All	3200	398210		
5269	92907	492748	No Replacement Repair With Individual Parts.						All	3500				
5270	92902	492748	9M902	0015					73	All	3500	398210		
5271	92902	492748	122K02	0515	1	690319	1	691851	25	All	3300	398210		
5272	92908	494034	122K02	0518	1	690319	1	691851	25	All	3500	398213		
5273	92902	494034	122K02	0518	1	492177	1	492893	25	All	3000	398213		
5274	92908	492086	9M902	0016						All	3200	398211		
5275	92902	492086	9M902	0016						All	3000	398211		
5276	92988	492748	No Replacement Repair With Short Block and/or Individual Parts						All	3000	398215	DD		
5278	92902	493618	No Replacement Repair With Short Block and/or Individual Parts						All	4000	398212			
5279	92907	492748	No Replacement Repair With Individual Parts.						All	3200				
5280	92907	492748	No Replacement Repair With Individual Parts.						All	3500				
5281	92902	493618	No Replacement Repair With Short Block and/or Individual Parts						All	3100	398212			
5282	92902	493618	No Replacement Repair With Short Block and/or Individual Parts						All	3700	398212			
5283	92908	493034	122K02	0518	1	690319	1	691851	25	All	3500	398213		
5284	92902	492748	9M902	0015					73	All	3200	398210		
5285	92902	494034	No Replacement Repair With Individual Parts.						All	2900				
5286	92902	492086	No Replacement Repair With Individual Parts.						All	3100				
5287	92908	494034	122K02	0518					25	All	3100	398213		
5288	92902	492086	9M902	0016						All	3500	398211		
5289	92908	492748	122K02	0515	1	690319	1	691851	25	All	3300	398210		
5290	92908	492748	122K02	0515	1	690319	1	691851	25	All	3300	398210		
5291	92902	492748	122K02	0515	1	690319	1	691851	25	All	3500	398210		
5292	92902	492086	9M902	0016	1	690251	1	690252	73	All	3700	398211		
5293	92908	493618	No Replacement Repair With Short Block and/or Individual Parts						All	3300	398212			
5294	92908	492748	122K02	0515	1	690319	1	691290	25	All	3700	398210		
5295	92988	492086	No Replacement Repair With Short Block and/or Individual Parts						All	3100	398216	II		
5296	92988	492086	No Replacement Repair With Short Block and/or Individual Parts						All	3000	398216			
5297	92908	492748	122K02	0515	1	690319	1	691851	25	All	3500	398210		
5298	92908	492086	122K02	0516	1	690319	1	691851	25	All	3500	398211		
5299	92988	492748	No Replacement Repair With Short Block and/or Individual Parts						All	3000	398214			
5300	92908	492748	122K02	0515					25	All	3300	398210		
5301	92908	492086	122K02	0516					25	All	3300	398211		
5302	92908	492086	122K02	0516					25	All	3300	398211		
5303	92982	492748	No Replacement Repair With Individual Parts.						All	3200				
5304	92988	492086	No Replacement Repair With Short Block and/or Individual Parts						All	2900	398217			
5305	92982	494034	No Replacement Repair With Individual Parts.						All	3300				
5306	92982	494034	No Replacement Repair With Individual Parts.						All	3300				
5307	92982	492748	No Replacement Repair With Individual Parts.						All	3300				
5308	92902	492086	9M902	0016						All	3200	398211		
5309	92902	492748	122K02	0515	1	690319	1	691290	25	All	4000	398210		
5310	92908	492086	122K02	0516					25	All	3000	398211		
5311	92988	492748	No Replacement Repair With Short Block and/or Individual Parts						All	3200	398215	DD		
5312	92908	492086	122K02	0516	1	690319	1	691851	25	All	3500	398211		

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block			
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes		
5313	92902	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210			
5314	92902	492086	9M902	0016							All	3500	398211			
5315	92982	492748	No Replacement Repair With Short Block and/or Individual Parts								All	3200	398214			
5316	92907	494375	No Replacement Repair With Individual Parts.													
5317	92902	494375	No Replacement Repair With Short Block and/or Individual Parts								All	3100	398212	G		
5318	92902	492748	122K02	0515	1	492177	1	492893	25		All	3200	398210			
5319	92908	492086	122K02	0516	1	690319	1	691851	25		All	3500	398211			
5320	92908	492748	122K02	0515					25		All	3100	398210			
5321	92988	492748	No Replacement Repair With Short Block and/or Individual Parts								All	3100	398214			
5322	92902	492086	9M902	0016							All	4000	398211			
5323	92902	492748	122K02	0515					25		All	3100	398210			
5324	92988	492748	No Replacement Repair With Individual Parts.								All	3500				
5325	92987	492748	No Replacement Repair With Individual Parts.								All	3500				
5326	92907	492748	No Replacement Repair With Individual Parts.								All	3500				
5327	92902	492086	9M902	0016							All	2900	398211			
5328	92902	492086	9M902	0016							All	2900	398211			
5329	92902	492748	122K02	0515					25		All	2900	398210			
5330	92902	494375	No Replacement Repair With Short Block and/or Individual Parts								All	3500	398212	G		
5331	92902	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210			
5332	92902	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210			
5333	92982	492748	No Replacement Repair With Individual Parts.								All	3200				
5334	92987	492748	No Replacement Repair With Individual Parts.								All	3200				
5335	92902	492086	9M902	0016					73		All	3200	398211			
5336	92988	492748	No Replacement Repair With Short Block and/or Individual Parts								All	3500	398215	FF		
5337	92902	492086	9M902	0016					73		All	4000	398211			
5339	92902	492086	122K02	0516	1	690319	1	691851	25		All	3700	398211	S		
5340	92902	494034	122K02	0518	1	690319	1	691851	25		All	3500	398213			
5341	92902	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210			
5342	92902	492748	122K02	0515	1	492177	1	492893	25		All	3500	398210			
						1	690319	1	691851							
5343	92902	492086	9M902	0016							All	3500	398211			
5344	92906	492086	No Replacement Repair With Individual Parts.								All	3500				
5345	92902	492086	122K02	0516	1	690319	1	691851	25		All	3700	398211			
5346	92902	492748	9M902	0015					73		All	3500	398210			
5347	92908	492748	122K02	0515					25		All	3100	398210			
5348	92908	492748	122K02	0515					25		All	3200	398210			
5349	92908	492086	122K02	0516					25		All	3200	398211			
5350	92987	492748	No Replacement Repair With Individual Parts.								All	3200				
5351	92902	492748	122K02	0515	1	690319	1	263042	25		All	3300	398210			
5352	92902	493618	No Replacement Repair With Short Block and/or Individual Parts								All	3100	398212			
5353	92902	494034	122K02	0518	1	492177	1	262656	25		All	3500	398213			
						1	690319	1	492893							
5354	92982	492748	No Replacement Repair With Short Block and/or Individual Parts								All	3500	398215	PP		
5355	92902	492748	122K02	0515	1	492177	1	492893	25		All	3300	398210			
5356	92908	493034	122K02	0518	1	690319	1	691851	25		All	3500	398213			
5357	92982	493034	No Replacement Repair With Individual Parts.								All	3100				
5358	92988	492086	No Replacement Repair With Individual Parts.								All	3500				
5359	92902	492086	9M902	0016							All	3200	398211			
5360	92908	492086	122K02	0516					25		All	3100	398211			
5361	92988	492086	No Replacement Repair With Short Block and/or Individual Parts								All	3100	398217			
5362	92902	261790	No Replacement Repair With Individual Parts.							73						
5363	92902	492748	9M902	0015							All	3100	398210			
5364	92908	492748	122K02	0515					25		All	2500	398210			
5365	92982	492748	No Replacement Repair With Short Block and/or Individual Parts								All	3100	398214			

92900 to 92999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
5366	92902	493618	No Replacement Repair With Short Block and/or Individual Parts							All	3700	398212		
5367	92902	492086	9M902	0016					73		All	3200	398211	
5368	92982	492748	No Replacement Repair With Short Block and/or Individual Parts							All	3200	398214		
5369	92908	492748	122K02	0515					25		All	3300	398210	
5370	92902	492748	122K02	0515	1	690319	1	691290	25		All	3700	398210	
5371	92908	492748	122K02	0515					25		All	3100	398210	
5372	92908	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5373	92907	494034	No Replacement Repair With Individual Parts.								All	3500		
5374	92907	492748	No Replacement Repair With Individual Parts.								All	3500		
5375	92902	492748	9M902	0015					73		All	3500	398210	
5376	92908	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5377	92908	261417	No Replacement Repair With Individual Parts.								All	3000		
5378	92907	492748	No Replacement Repair With Individual Parts.								All	3500		
5379	92902	492748	9M902	0015					73		All	3500	398210	
5380	92982	492748	No Replacement Repair With Short Block and/or Individual Parts								All	2900	398215	
5381	92907	492748	No Replacement Repair With Individual Parts.											
5382	92902	493618	No Replacement Repair With Short Block and/or Individual Parts								All	3300	398212	
5383	92902	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5384	92908	492086	122K02	0516	1	690319	1	691851	25		All	3500	398210	
5385	92902	492748	122K02	0515					25		All	3300	398210	
5386	92902	482748	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5387	92902	492748	9M902	0015					73		All	3200	398210	
5388	92902	492086	9M902	0016					73		All	3300	398211	
5389	92908	494034	122K02	0518	1	690319	1	691851	25		All	3500	398213	
5390	92908	494034	No Replacement Repair With Short Block and/or Individual Parts								All	3200	398211	
5391	92902	492086	9M902	0016							All	3100	398211	
5392	92902	492086	9M902	0016					73		All	3500	398211	
5393	92907	492748	No Replacement Repair With Short Block and/or Individual Parts								All	3500	398210	
5394	92902	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5395	92902	492748	9M902	0015					73		All	3500	398210	
5396	92902	492086	No Replacement Repair With Short Block and/or Individual Parts								All	4000	398210	
5397	92908	492748	122K02	0515	1	690319	1	691851	25		All	3400	398210	
5398	92902	492748	122K02	0515	1	690319	1	691290	25		All	4000	398210	
5399	92902	492086	9M902	0016					73		All	3500	398211	
5400	92902	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5401	92902	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5402	92908	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5403	92908	492748	122K02	0515	1	690319	1	691851	25		All	3500	398210	
5404	92908	492086	122K02	0516					25		All	3000	398211	
5405	92907	492086	No Replacement Repair With Short Block and/or Individual Parts								All	4000	398210	
5911	92908	261293	No Replacement Repair With Individual Parts.								All	3000		
5912	92908	492086	122K02	0516					25		All	3000		