

126600 to 126699

Illustrated Parts List Model Series 126600 to 126699

TYPE NUMBER

0101, 0108, 0109,
0130, 0131, 0132,
0133, 0134, 0135,
0136, 0137, 0138.

TO FIND


THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW

- A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- B. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- C. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. **THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."**
- D. If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- E. If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- F. For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.

PRINTED IN U.S.A.



COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.




★ **REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL.**

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	692670	Cylinder Assembly	10	691125	Screw (Breather Assembly)	584	692342	Cover-Breather Passage
2	399269	Kit-Bushing/Seal (Magneto Side)	11	691260	Tube-Breather	585	★272238	Gasket-Breather Passage
3	★299819	Seal-Oil (Magneto Side)	306	691232	Shield-Cylinder	684	690345	Screw (Breather Passage Cover)
8	495786	Breather Assembly	307	690345	Screw (Cylinder Shield)	718	230192	Pin-Locating
9	★272481	Gasket-Breather						

★ Included in Engine Gasket Set-Ref 358.
 Δ Included in Valve Gasket Set-Ref 1095.

● Included in Carburetor Overhaul Kit-Ref 121.
 ◆ Included in Carburetor Gasket Set-Ref 977.


126600 to 126699



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
5	695276	Head-Cylinder (Used After Code Date 99113000). Note 692800 Cylinder Head (Used Before Code Date 99120100).	35	691304	Spring-Valve (Intake)	635	66538	Boot-Sparkplug
7	★△695166	Gasket-Cylinder Head (Used After Code Date 99113000). Note ★△273240 Gasket-Cylinder Head (Used Before Code Date 99120100).	36	691304	Spring-Valve (Exhaust)	830	694544	Stud (Rocker Arm)
13	691137	Screw (Cylinder Head)	40	93312	Retainer-Valve	868	★△498592	Seal-Valve
33	499642	Valve-Exhaust	45	262679	Tappet-Valve	883	★△273348	Gasket-Exhaust
34	499641	Valve-Intake	51	★◆△692668	Gasket-Intake	914	691108	Screw (Rocker Arm Cover)
			122	★◆△692799	Spacer-Carburetor	993	★△694088	Gasket-Cylinder Head Plate
			155	695168	Plate-Cylinder Head (Used After Code Date 99113000).	1019	695259	Kit-Label
			155A	691231	Plate-Cylinder Head (Used Before Code Date 99120100).	1022	★△691890	Gasket-Rocker Cover
			189	694543	Rocker Arm Ball	1023	499624	Cover-Rocker Arm
			238	691300	Cap-Valve	1026	498597	Rod-Push
			337	499608	Sparkplug	1029	691230	Arm-Rocker
			383	19374	Wrench-Sparkplug	1034	691343	Guide-Push Rod
			619	691108	Screw (Cylinder Head Plate)	1058	274782	Owner's Manual (Emission Engines)

★ Included in Engine Gasket Set-Ref 358.
△ Included in Valve Gasket Set-Ref 1095.

● Included in Carburetor Overhaul Kit-Ref 121.
◆ Included in Carburetor Gasket Set-Ref 977.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
16	691457	Crankshaft Note 498616 Crankshaft Used on Type No(s). 0108.	26	499631	Ring Set (Standard) Note 692785 Ring Set (.010" O.S.) 692786 Ring Set (.020" O.S.) 692787 Ring Set (.030" O.S.)	29	499424	Rod-Connecting
24	222698	Key-Flywheel	27	263190	Lock-Piston Pin	32	94699	Screw (Connecting Rod)
25	690021	Piston Assembly (Standard) Note 694167 Piston Assembly (.010" O.S.) 694168 Piston Assembly (.020" O.S.) 694169 Piston Assembly (.030" O.S.)	28	499423	Piston Pin	32A	695759	Screw (Connecting Rod) (Used After Code Date 00042200)
						146	94388	Key-Timing
						741	262598	Gear-Timing

★ Included in Engine Gasket Set-Ref 358.
 △ Included in Valve Gasket Set-Ref 1095.

● Included in Carburetor Overhaul Kit-Ref 121.
 ◆ Included in Carburetor Gasket Set-Ref 977.


126600 to 126699



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
4	499619	Sump-Engine	22	691092	Screw (Crankcase Cover/ Sump)	43	493737	Slinger-Governor/Oil
12	★272198	Gasket-Crankcase			Note	46	694039	Camshaft
15	94880	Plug-Oil Drain			94612 Screw (Crankcase Cover/ Sump) (One Used in Hole Nearest Breather)			
20	★399781	Seal-Oil (PTO Side)						

★ Included in Engine Gasket Set-Ref 358.
 Δ Included in Valve Gasket Set-Ref 1095.

● Included in Carburetor Overhaul Kit-Ref 121.
 ◆ Included in Carburetor Gasket Set-Ref 977.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
51	◆◆692668	Gasket-Intake	122	◆◆692799	Spacer-Carburetor	137	◆◆693981	Gasket-Float Bowl
95	94098	Screw (Throttle Valve)	125	694202	Carburetor	163	◆◆273364	Gasket-Air Cleaner
97	499682	Shaft-Throttle	127	◆694468	Plug-Welch	276	◆◆271716	Washer-Sealing
104	◆691242	Pin-Float Hinge	130	691203	Valve-Throttle	365	691136	Screw (Carburetor)
117	498978	Jet-Main (Standard)	133	398187	Float-Carburetor	708	◆◆691321	Seal-Throttle Shaft
		Note	134	◆398188	Kit-Needle/Seat	975	493640	Bowl-Float
		498975 Jet-Main (High Altitude)						

★ Included in Engine Gasket Set-Ref 358.
 △ Included in Valve Gasket Set-Ref 1095.

◆ Included in Carburetor Overhaul Kit-Ref 121.
 ◆ Included in Carburetor Gasket Set-Ref 977.


126600 to 126699



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
	51◆◆692668	Gasket-Intake	222	692723	Bracket-Control	524	★280966	Seal-Dipstick Tube
	122◆◆692799	Spacer-Carburetor	222A	692617	Bracket-Control Used on Type No(s). 0100.	525	495265	Tube-Dipstick
	188	691147 Screw		227	691467 Lever-Governor Control	562	94852	Bolt (Governor Control Lever)
	202	691303 Link-Mechanical Governor		265	213146 Clamp-Casing	615	690340	Retainer-Governor Shaft
	209	263044 Spring-Governor		267	94882 Screw (Casing Clamp)	616	691306	Crank-Governor
		Note		287	94511 Screw (Dipstick Tube)	621	396847	Switch-Stop
		691291 Spring-Governor		333	802574 Armature-Magneto	745	94512	Screw (Brake)
		Used on Type No(s). 0135, 0136.		334	94731 Screw (Magneto Armature)	842	★280393	Seal-Dipstick/Tube
		263042 Spring-Governor		356	692390 Wire-Stop	847	498715	Dipstick/Tube Assembly
		Used on Type No(s). 0100.		404	690272 Washer (Governor Crank)	851	493880	Terminal-Sparkplug
		263041 Spring-Governor		505	231082 Nut (Governor Control Lever)	922	262640	Spring-Brake
		Used on Type No(s). 0101, 0108, 0109.		523	499621 Dipstick	923	493442	Brake
						935	398758	Switch-Interlock
						1160	93758	Screw (Interlock Switch)

★ Included in Engine Gasket Set-Ref 358.
 △ Included in Valve Gasket Set-Ref 1095.

● Included in Carburetor Overhaul Kit-Ref 121.
 ◆ Included in Carburetor Gasket Set-Ref 977.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
163	273364	Gasket–Air Cleaner	676	497682	Deflector–Muffler Used on Type No(s). 0137, 0138.	836A	94874	Screw
259	691189	Bracket–Casing Clamp	677	94896	Screw (Muffler Deflector) Used on Type No(s). 0137, 0138.	883	273348	Gasket–Exhaust
300	694248	Muffler	832	691466	Guard–Muffler	Note		
300A	693982	Muffler Used on Type No(s). 0108, 0109.	836	94786	Screw (Muffler Guard)	966	499684	Base–Air Cleaner Primer
425	690244	Screw (Air Cleaner Cover)	Note		968	691342	Cover–Air Cleaner	
443	690255	Screw (Air Cleaner Primer Base)	690960	690960	Screw (Muffler Guard) Used on Type No(s). 0137, 0138.	968A	692692	Cover–Air Cleaner
445	690610	Filter–Air Cleaner Cartridge	Note		976	496115	Primer–Carburetor	
613	691108	Screw (Exhaust Muffler)	Note					
613A	691140	Screw (Exhaust Muffler) (Muffler Guard)	Note					

★ Included in Engine Gasket Set–Ref 358.
 Δ Included in Valve Gasket Set–Ref 1095.

● Included in Carburetor Overhaul Kit–Ref 121.
 ◆ Included in Carburetor Gasket Set–Ref 977.


126600 to 126699



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
187	298049	Line-Fuel	601	93053	Clamp-Hose	972	499618	Tank-Fuel
190	94511	Screw (Fuel Tank)	670	280512	Spacer-Fuel Tank	1059	398540	Kit-Screw/Washer
			957	498697	Cap-Fuel Tank			

★ Included in Engine Gasket Set-Ref 358.
 △ Included in Valve Gasket Set-Ref 1095.

● Included in Carburetor Overhaul Kit-Ref 121.
 ◆ Included in Carburetor Gasket Set-Ref 977.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
23	692452	Flywheel	592	94908	Nut (Rewind Starter)	921A	691465	Cover-Blower Housing
37	694086	Guard-Flywheel	789	695552	Harness-Wiring (Used After Code Date 00040600)	925	690595	Cover-Brake Used on Type No(s). 0108, 0109.
65	94904	Screw (Rewind Starter)			Note	930	692691	Guard-Rewind
78	691108	Screw (Flywheel Guard)			691372	930A	692675	Guard-Rewind
304	499677	Blower Housing			Harness-Wiring (Used Before Code Date 00040700)	969	691138	Screw (Blower Housing Cover)
305	690960	Screw (Blower Housing)	910	691094	Stud (Alternator)	1005	691346	Fan-Flywheel
332	94877	Nut (Flywheel)	921	692699	Cover-Blower Housing	1036	695109	Label-Emissions
363	19069	Flywheel Puller				1119	692979	Screw (Alternator)
455	691219	Cup-Flywheel						
474	492841	Alternator						

★ Included in Engine Gasket Set-Ref 358.
 Δ Included in Valve Gasket Set-Ref 1095.

● Included in Carburetor Overhaul Kit-Ref 121.
 ◆ Included in Carburetor Gasket Set-Ref 977.


126600 to 126699



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
55	691421	Housing-Rewind Starter	456	281503	Plate-Pawl Friction	689	263073	Spring-Friction
58	280399	Rope-Starter (Cut To Length)	459	281505	Pawl-Ratchet	1210	498144	Pulley/Spring Assembly (Pulley)
60	281434	Grip-Starter Rope	592	94908	Nut (Rewind Starter)	1211	498144	Pulley/Spring Assembly (Spring)
65	94904	Screw (Rewind Starter)	597	94943	Screw (Pawl Friction Plate)			
			608	497680	Starter-Rewind			

★ Included in Engine Gasket Set-Ref 358.
 △ Included in Valve Gasket Set-Ref 1095.

● Included in Carburetor Overhaul Kit-Ref 121.
 ◆ Included in Carburetor Gasket Set-Ref 977.







REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
309	695550	Motor-Starter (Used After Code Date 00040600) Note 691376 Motor-Starter (Used Before Code Date 00040700)	545	492919	Washer Set (Starter Motor)	802	695267	Cap-End (Used After Code Date 00040600). Note 690787 Cap-End (Used Before Code Date 00040700).
310	692327	Bolt (Starter Motor)	651	690345	Screw (Starter Gear Cover)	803	695266	Housing-Starter (Used After Code Date 00040600). Note 690785 Housing-Starter (Used Before Code Date 00040700).
510	494147	Drive-Starter	697	691127	Screw (Drive Cap)	853	695268	Adapter-Wire
513	692358	Clutch-Drive	742	93941	Retainer-E Ring	937	691325	Spline-Starter
544	690786	Armature-Starter	783	691918	Gear-Pinion			
			783A	691269	Gear-Pinion			
			784	692341	Cover-Starter Gear			
			785	692352	Gasket-Starter Cover			
			801	690782	Cap-Drive			

★ Included in Engine Gasket Set-Ref 358.
 △ Included in Valve Gasket Set-Ref 1095.

● Included in Carburetor Overhaul Kit-Ref 121.
 ◆ Included in Carburetor Gasket Set-Ref 977.

126600 to 126699



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
3	★299819	Seal-Oil (Magneto Side)	51	◆◆692668	Gasket-Intake	708	◆◆691321	Seal-Throttle Shaft
7	★Δ273240	Gasket-Cylinder Head (Used Before Code Date 99120200). Note _____	104	◆691242	Pin-Float Hinge	842	◆280393	Seal-Dipstick/Tube
		695166 Gasket-Cylinder Head (Used After Code Date 99120100).	121	692703	Kit-Carburetor Overhaul	868	★Δ498592	Seal-Valve
9	★272481	Gasket-Breather	122	◆◆692799	Spacer-Carburetor	883	★Δ273348	Gasket-Exhaust
12	★272198	Gasket-Crankcase	127	◆694468	Plug-Welch	977	692704	Gasket Set-Carburetor
20	★399781	Seal-Oil (PTO Side)	134	◆398188	Kit-Needle/Seat	993	★Δ694088	Gasket-Cylinder Head Plate
			137	◆◆693981	Gasket-Float Bowl	1022	★Δ691890	Gasket-Rocker Cover
			163	◆◆273364	Gasket-Air Cleaner	1095	694091	Gasket Set-Valve
			276	◆◆271716	Washer-Sealing			
			358	694090	Gasket Set-Engine			
			524	★280966	Seal-Dipstick Tube			
			585	★272238	Gasket-Breather Passage			

★ Included in Engine Gasket Set-Ref 358.
 Δ Included in Valve Gasket Set-Ref 1095.

◆ Included in Carburetor Overhaul Kit-Ref 121.
 ◆◆ Included in Carburetor Gasket Set-Ref 977.