FORM MS-5793-2Q-7/2000 REPLACES FORM MS-5793-1Q-2/2000 FILE IN SECT. 2 OF SERVICE MANUAL

#### 135400 to 135499

## Illustrated Parts List Model Series 135400 to 135499

TYPE NUMBERS 0022, 0023, 0024, 0120, 0134, 0136.


# TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW

- A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- B. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- C. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."
- D. If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- E. If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- F. For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.

BRIGGS & STRATTON

PRINTED IN U.S.A

COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.



# ★ REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL.


#### 1019 LABEL KIT

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	495133	Cylinder Assembly	14	690368	Stud	635	66538	Boot-Sparkplug
2		Kit-Bushing/Seal			(Cylinder Head)	718		Pin-Locating
		(Magneto Side)	15	94916	` ,	869	211787	Seat-Valve
3	<b>±299819</b>	Seal-Oil			Note			(Intake)
		(Magneto Side)			94687 Plug-Oil Drain	870	263094	Seat-Valve
5	692729	Head-Cylinder			(Magnetic)			(Exhaust)
7	<b>*272157</b>	Gasket-Cylinder Head	185	94010	Nut	871	262001	Bushing-Valve Guide
8	495774	Breather Assembly			(Air Cleaner Base)			(Exhaust)
9	<b>★27549</b>	Gasket-Breather	306	694514	Shield-Cylinder			Note
10	691666	Screw	307	94680	Screw			63709 Bushing-Valve
		(Breather Assembly)			(Cylinder Shield)			Guide
11	691246	Tube-Breather	308	690473	,			(Intake)
13	94221	Screw	337	802592	Sparkplug	978	<b>*273326</b>	Gasket-Oil Gard®
		(Cylinder Head)			(Resistor)	979	691382	Cover-Oil Gard
13A	94679	Screw	383	89838	Wrench-Sparkplug	982	690351	Screw
		(Cylinder Head)	529	66578	Grommet			(Oil Guard)
			552	690508	Bushing-Governor	1019	692733	Kit-Label
					Crank			

<sup>Included in Engine Gasket Set-Ref. 358.
Included in Carburetor Overhaul Kit-Ref. 121</sup> 

Included in Valve Gasket Set-Ref. 1095.

Included in Carburetor Gasket Set-Ref. 977.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
17 24 25	494874 222698	Crankshaft Note 495643 Crankshaft Used On Type No(s). 0023, 0136. 495644 Crankshaft Used On Type No(s). 0022. Bearing-Ball Key-Flywheel Piston Assembly (Standard) Note 393820 Piston Assembly (.010" O.S.) 393821 Piston Assembly (.020" O.S.) 393822 Piston Assembly (.030" O.S.)	27 28 29	26026 298909	Ring Set (Standard)	30 32 33 34 35 36 40 40A 45 146 741	94699 211119 261044 260552 26478 93312 225257 260642 94388	Dipper-Connecting Rod Screw (Connecting Rod) Valve-Exhaust Valve-Intake Spring-Valve (Intake) Spring-Valve (Exhaust) Retainer-Valve Retainer-Valve Tappet-Valve Key-Timing Gear-Timing


<sup>★</sup> Included in Engine Gasket Set-Ref. 358.
◆ Included in Carburetor Overhaul Kit-Ref. 121

Included in Valve Gasket Set-Ref. 1095.

• Included in Carburetor Gasket Set-Ref. 977.








REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
12	*270080	Gasket-Crankcase (.015", Standard) Note *270125 Gasket- Crankcase (.005" Thick) *270126 Gasket- Crankcase (.009" Thick)	18	694319	Cover-Crankcase (Ball Bearing) (Used After Code Date 99031400) Note 495641 Cover- Crankcase (Ball Bearing) (Used Before Code Date 99031500).	20 21 22 46 219 220 415 1194	281658 691129 691164 494845 221551 691363	(PTO Side) Cap-Oil Fill Screw (Crankcase Cover) Camshaft Gear-Governor Washer (Governor Gear)

<sup>★</sup> Included in Engine Gasket Set-Ref. 358.
◆ Included in Carburetor Overhaul Kit-Ref. 121

Included in Valve Gasket Set-Ref. 1095.

• Included in Carburetor Gasket Set-Ref. 977.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
50 51 51A 54 95 97 98	NO.  281247 *272295 *273113 94923 94098 493556 398185	Manifold-Intake Gasket-Intake Gasket-Intake Screw (Intake Manifold)		NO. 691182 498593 692730 692724 •223472 •694468 691181 398187	DESCRIPTION  Valve-Choke Shaft-Choke Jet-Main Carburetor Plug-Welch Plug-Welch Valve-Throttle Float-Carburetor Kit-Needle/Seat	NO. 137 186 276 365	NO.  •+693981 493496 •+271716 94920 •+693867 •+691321 690572	Gasket-Float Bowl Connector-Hose Washer-Sealing

<sup>★</sup> Included in Engine Gasket Set-Ref. 358.
◆ Included in Carburetor Overhaul Kit-Ref. 121

Included in Valve Gasket Set-Ref. 1095.


• Included in Carburetor Gasket Set-Ref. 977.





REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
15A 98A 188 188A 202 209 222 232 268	94687 493280 690297 94929 691282 262283 691383 260585 691072	Screw (Control Bracket) Screw (Control Bracket) Link-Mechanical Governor Spring-Governor	270 271 333 334 347 347A	93414 493521 495098	(Magneto Armature) Switch-Rocker Switch-Rocker Used On Type No(s). 0136.	356A 356B 427 428 497 546 627 789 843 851 978 980 982A	690474 693397 691322 493880 *273326	(Stop Switch) Wire-Stop (OIL GARD®Switch) Nut (Control Bracket) Nut (OIL GARD® Kit) Screw (Stop Switch Bracket) Washer Set-Friction Bracket-Stopswitch Harness-Wiring Sleeve-Lever Terminal-Sparkplug Gasket-Oil Gard® Kit-Oil Gard®


<sup>★</sup> Included in Engine Gasket Set-Ref. 358.◆ Included in Carburetor Overhaul Kit-Ref. 121

Included in Valve Gasket Set-Ref. 1095. ◆ Included in Carburetor Gasket Set-Ref. 977.










REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
227	690842	Lever-Governor Control	524 525	*271485 694379	Seal-Dipstick Tube Tube-Dipstick	842A	<b>★270920</b>	O-Ring Seal (Used Before Code
287	94807	Screw (Dipstick)	5_5		(Used After Code Date 99031400).	847	694381	Date 99031500). Dipstick/Tube
287A	691693 94927	Screw (Dipstick) Washer	525A	694531	Tube-Dipstick (Used Before Code			Assembly (Used After Code Date
404		(Governor Crank) Bracket-Oil Fill	562	691119	Date 99031500). Bolt	847A	691379	99031400). Dipstick/Tube Assembly
505					(Governor Control Lever)			(Used Before Code Date 99031500).
523	495264	Lever) Dipstick	614 616	93306 495243		1167	94929	Screw (Remote Link
		(Used After Code Date 99031400).	842	<b>★280393</b>	(Used After Code Date			Attachment)
523A	691388	Dipstick (Used Before Code			99031400).			
		Date 99031500).						

<sup>★</sup> Included in Engine Gasket Set-Ref. 358.
◆ Included in Carburetor Overhaul Kit-Ref. 121

Included in Valve Gasket Set-Ref. 1095. • Included in Carburetor Gasket Set-Ref. 977.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
182 182A		Bracket-Fuel Tank Bracket-Fuel Tank	429 527		Cover-Sparkplug Clamp-Tube	674A	94895	Screw (Fuel Tank Bracket)
187	298049	Line-Fuel (Cut to Length)	601		Clamp-Hose (Green)	957	692665	Cap-Fuel Tank (For Kerosene Fuel
187A		Line-Fuel (Molded)	601A		Clamp-Hose (Black)	957A	692662	Tank) Cap-Fuel Tank
240 360	298090 94010		674	94905	Screw (Fuel Tank Bracket)		40.4700	(For Auxiliary Petrol Fuel Tank)
		(Fuel Tank Bracket)				958 972		Valve-Fuel Shut-Off Tank-Fuel
						<u> </u>		

<sup>★</sup> Included in Engine Gasket Set-Ref. 358.
◆ Included in Carburetor Overhaul Kit-Ref. 121

Included in Valve Gasket Set-Ref. 1095.

• Included in Carburetor Gasket Set-Ref. 977.



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
161 163		Base-Air Cleaner Gasket-Air Cleaner	613	94905	Screw (Muffler)	864 883		Adapter-Muffler Gasket-Exhaust
300 425	494562		613A	94929	Screw	902 967	692741	Filter-Primer Filter-Pre Cleaner
		(Air Cleaner Cover)	643	280871	(Muffler) Retainer-Air Filter	968	691327	Cover-Air Cleaner
445	494511	Filter-Air Cleaner Cartridge	821	692661	Washer (Carburetor Primer)	971	690370	(Air Cleaner Base)
528	692792	Hose-Primer (Cut to Required	823	94706	Screw (Muffler Adapter)	976 1054		Primer-Carburetor Tie-Cable
529	66578	Length) Grommet	832 836	690811 94929	Guard-Muffler Screw			
			843	280149	(Muffler Guard) Sleeve-Lever			
			043	200173	Oleeve-Level			


Assemblies include all parts shown in frames.

2Q-7/2000

<sup>★</sup> Included in Engine Gasket Set-Ref. 358.
◆ Included in Carburetor Overhaul Kit-Ref. 121

Included in Valve Gasket Set-Ref. 1095.

• Included in Carburetor Gasket Set-Ref. 977.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
23 37 78	222443	Flywheel Guard-Flywheel Screw (Flywheel Guard)	304 305	691410 690960	Housing-Blower Screw (Blower Housing)	332 363		(Flywheel) Flywheel Puller
215	223886	(Flywheel Guard) Guide-Air				1212	690368	Stud (Blower Housing)

5793-10

<sup>★</sup> Included in Engine Gasket Set-Ref. 358.
◆ Included in Carburetor Overhaul Kit-Ref. 121

Included in Valve Gasket Set-Ref. 1095.

• Included in Carburetor Gasket Set-Ref. 977.





REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
55	691421	Housing-Rewind	455	691219	Cup-Flywheel	597	94943	Screw
	001001	Starter			(Used After Code Date		407000	(Pawl Friction Plate)
58	691921	Rope-Starter	455A	691426	95020300).	608 689A		Starter-Rewind
		(Cut To Required Length)	455A	091420	Cup-Flywheel (Used After Code Date	1210		Spring-Friction Pulley/Spring
60	281101	<b>o</b> ,			95010800).	1210	100111	Assembly
65	94904	Screw	456	281503	Plate-Pawl Friction			(Pulley)
		(Rewind Starter)	459		Pawl-Ratchet	1211	498144	,, I O I
73	691225	Screen-Rotating	592	94908	* *			Assembly
		(Used After Code Date 95020300).			(Rewind Starter)			(Spring)
73A	691226	Screen-Rotating						
		(Used After Code Date						
		95010800).						


<sup>★</sup> Included in Engine Gasket Set-Ref. 358.
◆ Included in Carburetor Overhaul Kit-Ref. 121


Included in Valve Gasket Set-Ref. 1095.

• Included in Carburetor Gasket Set-Ref. 977.









REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
NO. 3 7 9 12	*299819 *272157	Seal-Oil (Magneto Side) Gasket-Cylinder Head Gasket-Breather	51 51A 104 121 127 127A 134 137 163 276 358 524	*272295 *273113 •691242 493762 •223472 •694468 •398188 •4693981 *272948 •+271716 495661 *271485	Gasket-Intake Gasket-Intake Pin-Float Hinge Kit-Carburetor Overhaul	633A 842	◆◆691321 ★280393 ★270920 ★272309 490937 ★273326 498531	Seal-Throttle Shaft

<sup>Included in Engine Gasket Set-Ref. 358.
Included in Carburetor Overhaul Kit-Ref. 121</sup> 

Included in Valve Gasket Set-Ref. 1095. ◆ Included in Carburetor Gasket Set-Ref. 977.