FORM MS-0438-9/97 REPLACES FORM MS-0438-5/97 FILE IN SECT. 2 OF SERVICE MANUAL

#### 19B400 to 19B499

## Illustrated Parts List Model Series 19B400 to 19B499

TYPE NUMBERS 0066, 0067, 0123, 0124, 0128.


# TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW

- A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- B. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- C. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."
- D. If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- E. If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- F. For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.



PRINTED IN U.S.A

COPYRIGHT by BRIGGS & STRATTON CORPORATION All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.



1058 OWNER'S MANUAL 1019 LABEL KIT

**★** REQUIRES SPECIAL TOOLS TO INSTALL. SEE REPAIR INSTRUCTION MANUAL.


PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
495656	Cylinder Assembly (Includes OIL GARD® Cover)	11B		(Used Before Code Date 94111100).	529		(Used Before Code Date 94111100).
495657	Bushing	13	94565	Screw-Hex.	552		Bushing-Gov. Crank
<b>*391086</b>	Seal-Oil	13A	94733	Stud-Hex. Drive	635	66538	Boot-Spark Plug
				(Used in Positions	869	211661	Seat-Valve
							(Intake)
498038					870	262924	Seat-Valve
	•						(Exhaust)
	,				871	261961	Bushing-Guide
495736							(Exhaust)
							Note
			0.4000				231218 Bushing-
407740							Guide
497710		15	94239		4040	404400	(Intake)
	•						Owner's Manual
±⁄⁄⁄37903	,			-	1056	212040	Owner S Manual
		306	496797				
				-			
200010							
		337					
280225	Tube-Breather	354					
	(Used After Code Date	383	89838	Wrench-Spark Plug			
	95010100 and Before						
	Code Date 95040300).						
	NO.  495656  495657  ★391086 214347  Ø272163 498038  495736  497710  ★Ø27803 94621 280819	NO. DESCRIPTION  495656 Cylinder Assembly (Includes OIL GARD® Cover)  495657 Bushing  *391086 Seal—Oil 214347 Head—Cylinder  ©272163 Gasket—Cylinder Head 498038 Breather Assembly (Used After Code Date 95040200).  495736 Breather Assembly (Used After Code Date 95010100 and Before Code Date 95010100 and Before Code Date 95010200).  497710 Breather Kit (Used Before Code Date 95010200).  *Ø27803 Gasket—Breather 94621 Screw—Hex. 280819 Tube—Breather (Used After Code Date 95040200).  280225 Tube—Breather (Used After Code Date 95010100 and Before	NO.         DESCRIPTION         NO.           495656         Cylinder Assembly (Includes OIL GARD® Cover)         11B           495657         Bushing         13           ★391086         Seal—Oil         13A           214347         Head—Cylinder         13A           498038         Breather Assembly (Used After Code Date 95040200).         14           495736         Breather Assembly (Used After Code Date 95010100 and Before Code Date 95010200).         14           497710         Breather Kit (Used Before Code Date 95010200).         15           ★Ø27803         Gasket—Breather         306           94621         Screw—Hex.         306           280819         Tube—Breather (Used After Code Date 95040200).         337           280225         Tube—Breather (Used After Code Date 95010100 and Before         383	NO.       DESCRIPTION       NO.       NO.         495656       Cylinder Assembly (Includes OIL GARD® Cover)       11B       281426         495657       Bushing       13       94565         ★391086       Seal—Oil       13A       94733         214347       Head—Cylinder       34       94733         2272163       Gasket—Cylinder Head       34       34       94733         498038       Breather Assembly (Used After Code Date 95040200).       35040200).       35040200).       34       34       34         495736       Breather Assembly (Used After Code Date 95010200).       35040200).       36 <td< th=""><th>NO.         DESCRIPTION           495656         Cylinder Assembly (Includes OIL GARD® Cover)         11B         281426         Tube-Breather (Used Before Code Date 94111100).           495657         Bushing         13         94565         Screw-Hex.           *391086         Seal-Oil         13A         94733         Stud-Hex. Drive (Used in Positions 5 &amp; 6)           214347         Head-Cylinder Head 498038         Breather Assembly (Used After Code Date 95040200).         94931         Stud-Hex. Drive (Used in Positions 5 &amp; 6)           495736         Breather Assembly (Used After Code Date 95010100 and Before Code Date 95010200).         1 &amp; 2)         Used on Type No(s). 0123.           497710         Breather Kit (Used Before Code Date 95010200).         14         94622         Screw-Hex.           497780         Gasket-Breather (Used After Code Date 95040200).         92738 Plug-Oil Drain (Magnetic)           *Ø27803         Gasket-Breather (Used After Code Date 95040200).         306         496797         Shield-Cylinder           94621         Screw-Hex.         307         94386         Screw-Hex.           280819         Tube-Breather (Used After Code Date 95040200).         337         496018         Plug-Spark           280225         Tube-Breather (Used After Code Date 95010100 and Before         354         94726</th><th>NO.         DESCRIPTION         NO.         DESCRIPTION         NO.           495656         Cylinder Assembly (Includes OIL GARD® Cover)         11B         281426         Tube—Breather (Used Before Code Date 94111100).         529           495657         Bushing         13         94565         Screw—Hex.         552           *391086         Seal—Oil         13A         94733         Stud—Hex. Drive (Used in Positions         635           214347         Head—Cylinder Head 498038         Breather Assembly (Used After Code Date 95040200).         94931         Stud—Hex.         870           495736         Breather Assembly (Used After Code Date 95010100 and Before Code Date 95010200).         Used on Type No(s). 0123.         871           497710         Breather Kit (Used Before Code Date 95010200).         15         94239         Plug—Oil Drain (Magnetic)         1019           *Ø27803         Gasket—Breather (Used After Code Date 95040200).         306         496797         Shield—Cylinder 95040200).         1058           *Ø20225         Tube—Breather (Used After Code Date 95040200).         337         496018         Plug—Spark           280225         Tube—Breather (Used After Code Date 95010100 and Before         354         94726 Nut—Hex.         94726 Nut—Hex.           49501000         383         8983</th><th>NO. DESCRIPTION  NO. NO. DESCRIPTION  NO. NO. DESCRIPTION  NO. NO. DESCRIPTION  NO. NO. NO. NO. NO. NO. NO. NO. NO. NO.</th></td<>	NO.         DESCRIPTION           495656         Cylinder Assembly (Includes OIL GARD® Cover)         11B         281426         Tube-Breather (Used Before Code Date 94111100).           495657         Bushing         13         94565         Screw-Hex.           *391086         Seal-Oil         13A         94733         Stud-Hex. Drive (Used in Positions 5 & 6)           214347         Head-Cylinder Head 498038         Breather Assembly (Used After Code Date 95040200).         94931         Stud-Hex. Drive (Used in Positions 5 & 6)           495736         Breather Assembly (Used After Code Date 95010100 and Before Code Date 95010200).         1 & 2)         Used on Type No(s). 0123.           497710         Breather Kit (Used Before Code Date 95010200).         14         94622         Screw-Hex.           497780         Gasket-Breather (Used After Code Date 95040200).         92738 Plug-Oil Drain (Magnetic)           *Ø27803         Gasket-Breather (Used After Code Date 95040200).         306         496797         Shield-Cylinder           94621         Screw-Hex.         307         94386         Screw-Hex.           280819         Tube-Breather (Used After Code Date 95040200).         337         496018         Plug-Spark           280225         Tube-Breather (Used After Code Date 95010100 and Before         354         94726	NO.         DESCRIPTION         NO.         DESCRIPTION         NO.           495656         Cylinder Assembly (Includes OIL GARD® Cover)         11B         281426         Tube—Breather (Used Before Code Date 94111100).         529           495657         Bushing         13         94565         Screw—Hex.         552           *391086         Seal—Oil         13A         94733         Stud—Hex. Drive (Used in Positions         635           214347         Head—Cylinder Head 498038         Breather Assembly (Used After Code Date 95040200).         94931         Stud—Hex.         870           495736         Breather Assembly (Used After Code Date 95010100 and Before Code Date 95010200).         Used on Type No(s). 0123.         871           497710         Breather Kit (Used Before Code Date 95010200).         15         94239         Plug—Oil Drain (Magnetic)         1019           *Ø27803         Gasket—Breather (Used After Code Date 95040200).         306         496797         Shield—Cylinder 95040200).         1058           *Ø20225         Tube—Breather (Used After Code Date 95040200).         337         496018         Plug—Spark           280225         Tube—Breather (Used After Code Date 95010100 and Before         354         94726 Nut—Hex.         94726 Nut—Hex.           49501000         383         8983	NO. DESCRIPTION  NO. NO. DESCRIPTION  NO. NO. DESCRIPTION  NO. NO. DESCRIPTION  NO.

0438-2

Assemblies include all parts shown in frames.

<sup>Included in Gasket Set–Part No. 497070.
Included in Carburetor Kit–See Ref. No. 121.</sup> 

<sup>◆</sup> Included in Carburetor Gasket Set–Part No. 497069. Ø Included in Valve Overhaul Gasket Set–Part No. 498534.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
16 25		Crankshaft Piston Assembly (Standard) Note	28	499302	Pin–Piston (Standard) — Note — 295840 Pin–Piston	36		Spring–Valve (Exhaust) (Used Before Code Date 95041700).
26	393881	<b>393869</b> Piston Assy. (.010" O.S.) <b>393879</b> Piston Assy. (.020" O.S.) <b>393880</b> Piston Assy. (.030" O.S.) Ring Set			(Standard) (Used Before Code Date 96102800) <b>499303</b> Pin–Piston (.005" O.S.) <b>295841</b> Pin–Piston (.005" O.S.)	40	221596	Retainer–Valve (Intake)  Note  221596 Retainer– Valve (Used on Exhaust
26	393001	(Standard) ——— Note ——— 299743 Ring Set	29	390401	(Used Before Code Date 96102800) Rod–Connecting	44	202260	Side) (Used After Code Date 95041600).
		(Std., Chrome) <b>393882</b> Ring Set (.010" O.S.)			(Standard) <b>390773</b> Rod–Conn. (.020" Undersize)	41	292260	Retainer–Valve (Exhaust) (Used Before Code Date 95041700).
		<b>393883</b> Ring Set (.020" O.S.) <b>393884</b> Ring Set (.030" O.S.)	30 32	94670	Dipper–Connecting Rod Screw–Connecting Rod.	42	494553	Keeper–Valve (Exhaust) (Used Before Code
27	263181	Lock-Piston Pin  Note ——— 68546 Lock-Piston Pin	33	263017	Valve–Exhaust (Used After Code Date 95041600).	45 146	94388	Date 95041700). Tappet–Valve Key–Timing
		(Used Before Code Date 96102800).	33A	390419	(Used Before Code Date 95041700).	741	263025	Gear–Timing  Note  262479 Gear–Timing
			34 35		Valve-Intake Spring-Valve (Intake) (Used After Code Date 95041600).	868	497212	(Used Before Code Date 96061700). Seal–Valve
	l- di- O-	Sket Set_Part No. 407070			lockeded in C	orburotor C	askat Cat	-Part No. 497069

0438-3

Assemblies include all parts shown in frames.

<sup>Included in Gasket Set–Part No. 497070.
Included in Carburetor Kit–See Ref. No. 121.</sup> 

 <sup>◆</sup> Included in Carburetor Gasket Set–Part No. 497069.
 Ø Included in Valve Overhaul Gasket Set–Part No. 498534.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
12	<b>★271701</b>	Gasket–Crankcase (.015" Thick, Std.)  Note  *27876 Gasket– Crankcase (.005" Thick)	15 18 19 20 21 22	496984 295964 *391086 66768 93585	Cap-Oil Fill Screw-Hex	186		Connector-Hose Note 67218 Connector- Hose (Used Before Code Date 94071800).
		*27877Gasket– Crankcase (.009" Thick)	46	211689	Gear-Cam	219 220		Gear-Governor Washer-Thrust

0438-4

Assemblies include all parts shown in frames.

<sup>★</sup> Included in Gasket Set-Part No. 497070.
• Included in Carburetor Kit-See Ref. No. 121.

 <sup>◆</sup> Included in Carburetor Gasket Set–Part No. 497069.
 Ø Included in Valve Overhaul Gasket Set–Part No. 498534.



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
_	◆★272708	Manifold-Intake Gasket-Intake Gasket-Intake Stud-Carb. Mounting Bushing-Throttle Shaft Valve-Idle Adjustment Screw-Round Head Screw-Idle Speed Pin-Float Hinge Valve-Needle Seat-Inlet Valve-Choke Screw-Torx®Hex. Carburetor (Used on LMT 171) —Note 497038 Carburetor (Used on LMT 69, 103) Plug-Welch (Sold in Kit Only) Valve-Throttle	_	497042 494381 ••281165 ••281164 497043 499094	Choke–AShaft Kit Nozzle–Carburetor (Standard Used on LMT 171) ———————————————————————————————————	186A 618 634 950 965 975 987	●262803 ●281168 94642 94010 494378	Connector-Hose Spring Seal-Choke Shaft Screw-Bowl Mounting Nut-Hex. Bowl-Float Seal-Throttle Shaft


<sup>★</sup> Included in Gasket Set-Part No. 497070.

0438-5

Assemblies include all parts shown in frames.

<sup>•</sup> Included in Carburetor Kit-See Ref. No. 121.

 <sup>◆</sup> Included in Carburetor Gasket Set–Part No. 497069.
 Ø Included in Valve Overhaul Gasket Set–Part No. 498534.



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
75 98A 165 209	493280 94692	Washer Set Screw–Idle Speed Nut–Wing Spring–Governor	212B 222		Link-Throttle Bracket-Control (Used After Code Date 97042700).	258 268		Screw–Hex. Casing–Wire (72" Long Cut to Required Length)
209A	263054	(Used After Code Date 97042700). Spring–Governor				269	26633	Wire—Control (78" Long Cut to Required Length)
		(Used After Code Date 94083100 and Before Code Date 97042800). Used on Type No(s). 0066, 0067, 0123, 0124, 0128.	227	499096	(Used Before Code Date 97042800). Lever–Governor (Used After Code Date 97042700).  Note	270 271 353 354A 507 520	290568 92791 90576 398525	Locknut–Casing Lever–Control Washer–Lock Nut–Hex. Insulator Terminal
209B	260723	Spring–Governor (Used Before Code Date 94090100). Used on Type No(s). 0066, 0067, 0123.	227A	496253	496254 Lever– Governor (Used Before Code Date 97042800). Lever–Governor	562 590 592 623 624	94995 231082 231520	Bolt-Governor Lever Screw-Slotted Hex. Nut-Hex. Screw-Shoulder Lever-Linkage
212 212A	263049 262970	Link–Throttle Link–Throttle	232 232A		Spring–Link Spring–Link	1042	225224	Bracket–Electro Mag


<sup>★</sup> Included in Gasket Set-Part No. 497070.


0438 - 6


Assemblies include all parts shown in frames.


<sup>•</sup> Included in Carburetor Kit-See Ref. No. 121.

 <sup>◆</sup> Included in Carburetor Gasket Set–Part No. 497069.
 Ø Included in Valve Overhaul Gasket Set–Part No. 498534.










REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
230 333 334 346 353 354A 356	492341 94731 93705 92791 90576	Washer Armature–Magneto Screw–Hex. Screw–Hex. Washer–Lock Nut–Hex. Wire–Stop	614 616 728 729 851 948 978	496818 94627 223528 493880	Pin-Cotter Crank-Governor Screw-Hex. Clip-Wire Terminal-Cable Harness-Wiring Gasket	979 980 982 982A 983 984	398182 94657 94658 398660	Cover-OIL GARD® OIL GARD® Kit Screw-Hex. Screw-Hex. Light-Indicator Bracket-Stop Switch

0438-7

Assemblies include all parts shown in frames. 7

<sup>Included in Gasket Set–Part No. 497070.
Included in Carburetor Kit–See Ref. No. 121.</sup> 

 <sup>◆</sup> Included in Carburetor Gasket Set-Part No. 497069.
 Ø Included in Valve Overhaul Gasket Set-Part No. 498534.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
NO.  13A 116 182 187  187A 240	94733 280203 495664 296004	DESCRIPTION  Stud-Hex. Drive Seal-O-Ring Bracket-Fuel Tank Line-Fuel (Cut to Required Length) Line-Fuel Filter-Fuel	NO.  354 385 387 601 728 729 918	94726 94789 496257 93053 94627 223528	DESCRIPTION  Nut-Hex. Screw-Hex. Pump-Fuel Clamp-Hose Screw-Hex. Clip-Wire Hose-Vacuum	957 958 960 961 972	493988 399517 492990 94095	DESCRIPTION  Cap-Fuel Tank (Plastic) Valve-Shut-Off Bracket-Fuel Tank Screw-Hex. Tank-Fuel (Plastic)

0438 - 8

Assemblies include all parts shown in frames.

<sup>Included in Gasket Set–Part No. 497070.
Included in Carburetor Kit–See Ref. No. 121.</sup> 

 <sup>◆</sup> Included in Carburetor Gasket Set–Part No. 497069.
 Ø Included in Valve Overhaul Gasket Set–Part No. 498534.



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
11 53A 81 161	94706 222263 497669	Tube-Breather Screw-Torx®Hex Lock-Muffler Screw Base-Air Cleaner	258 300 300A 346 445 467 529A	391370 496127 93705 496077 280715	Screw-Hex Muffler-Exhaust Muffler-Exhaust Screw-Hex Filter-Air Knob-Control Tube-Breather (Used Before Code Date 94111100).	613 642 843 864 883 969 994	281357 280149 497140 ★Ø272309 94777	Screw-Shoulder Cover-Air Cleaner Sleeve-Lever Adapter-Muffler Gasket-Exhaust Screw-Slotted Hex. Arrester-Spark


<sup>★</sup> Included in Gasket Set-Part No. 497070.

0438 - 9

Assemblies include all parts shown in frames.

<sup>•</sup> Included in Carburetor Kit-See Ref. No. 121.

 <sup>◆</sup> Included in Carburetor Gasket Set–Part No. 497069.
 Ø Included in Valve Overhaul Gasket Set–Part No. 498534.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
23 24 37 38	NO. 298260 222698 222475	Plywheel Key-Flywheel Guard-Flywheel Screw-Hex.	73 74 75A 215	NO. 224874 93758 224061	DESCRIPTION  Screen-Rotating Screw-Hex. Washer-Flywheel Guide-Air	304 305 347 363	NO. 491596 94786 396691	DESCRIPTION  Housing-Blower Screw-Hex. Switch-Rotary Flywheel Puller


0438-10

Assemblies include all parts shown in frames. 10

<sup>Included in Gasket Set–Part No. 497070.
Included in Carburetor Kit–See Ref. No. 121.</sup> 

 <sup>◆</sup> Included in Carburetor Gasket Set–Part No. 497069.
 Ø Included in Valve Overhaul Gasket Set–Part No. 498534.






REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
55	393576	Housing–Rewind Starter	60 63		Grip-Starter Rope Spring-Ratchet	70 71		Ratchet–Clutch Cover–Ratchet
56	295871	Pulley-Starter	64		Adapter–Spring	373		Nut-Hex.
57	490179	Spring-Rewind Starter	65	94128	Screw-Hex.	608		Starter-Rewind
58	66884	Rope-Starter	66		Clutch-Starter	655		Anchor–Spring
59	4006E2	(63" Long) Insert–Grip	67 68		Housing–Clutch Ball–Clutch	1016	490817	Spacer=Rewind
	730000	шэви-опр	00	03110	Dall-Oldton			

0438-11

Assemblies include all parts shown in frames. 11

<sup>★</sup> Included in Gasket Set-Part No. 497070.
◆ Included in Carburetor Kit-See Ref. No. 121.

 <sup>◆</sup> Included in Carburetor Gasket Set–Part No. 497069.
 Ø Included in Valve Overhaul Gasket Set–Part No. 498534.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
309	693054	Motor-Starter	544	497603	Armature-Starter	797	92278	
		(3 5/8" Housing Lgth.)			(3 5/8" Housing Lgth.)			(Starter Terminal)
310	94003	Bolt	675	225137	Washer	801	394856	Cap-Drive
		(Starter Motor)			(Starter Motor)	802	497607	Cap-End
		(3 5/8" Housing Lgth.)	697	94773	Screw	803	497604	Housing-Starter
311	497608	Brush Set			(Starter Motor			(3 5/8" Housing Lgth.)
503	806000	Strap-Starter			Mounting)	1051	263080	Ring-Retainer
510		Drive-Starter	729	225170	Clip-Wire	1090		Retainer-Brush
513	398003	Clutch-Drive	783		Gear-Starter			

0438-12

Assemblies include all parts shown in frames. 12

<sup>★</sup> Included in Gasket Set-Part No. 497070.
◆ Included in Carburetor Kit-See Ref. No. 121.

 <sup>◆</sup> Included in Carburetor Gasket Set–Part No. 497069.
 Ø Included in Valve Overhaul Gasket Set–Part No. 498534.



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
309A		For Replacement Starter Motor, See Ref 309, Previous Page.	503 510A 513 544A	806000 495878 398003 390837	Drive–Starter Clutch–Drive	783 801 802A	394856	Gear–Starter Cap–Drive Cap–End (For 3 5/8" Housing
310A	94003	Bolt. (Starter Motor) (For 3 5/8" Housing Length)	697	94773	(For 3 5/8" Housing Length) Screw (Starter Motor	803A	398159	Length) Housing–Starter (For 3 5/8" Housing Length)
311A	395538	Brush Set (For 3 5/8" Housing Lengths)			Mounting)	876 896	495877 94288	Kit–Gear Pin–Roll


<sup>★</sup> Included in Gasket Set-Part No. 497070.


0438-13


Assemblies include all parts shown in frames.


<sup>•</sup> Included in Carburetor Kit-See Ref. No. 121.

 <sup>◆</sup> Included in Carburetor Gasket Set–Part No. 497069.
 Ø Included in Valve Overhaul Gasket Set–Part No. 498534.









REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
9 12 20 51	<pre></pre>	Gasket-Cylinder Head Gasket-Breather Gasket-Crankcase (.015" Thick, Std.)  Note *27876 Gasket- Crankcase (.005" Thick) *27877 Gasket- Crankcase (.009" Thick)	_	•231789 •231935 •231856 497578 • • •+281165 •+281164	Screw-Round Head Pin-Float Hinge Valve-Needle Seat-Inlet Carburetor Kit	163 358 618 634	497070 •262803 •281168 ∅*272309 497069 *271736 •281166	(Used on LMT 69, 103, 171) Gasket-Air Cleaner Gasket Set Spring Seal-Choke Shaft Gasket-Exhaust Gasket Set- Carburetor

<sup>Included in Gasket Set–Part No. 497070.
Included in Carburetor Kit–See Ref. No. 121.</sup> 

0438-14

Assemblies include all parts shown in frames. 14

<sup>◆</sup> Included in Carburetor Gasket Set–Part No. 497069. Ø Included in Valve Overhaul Gasket Set–Part No. 498534.