

28B700 to 28B799

Illustrated Parts List

Model Series

28B700 to 28B799

TYPE NUMBERS

0001, 0008, 0009,
0101, 0102,
0111 through 0132,
0134 through 0139,
0145, 0146, 0151,
0604, 0610, 0629,
0630, 0632, 0633,
1001 through 1129,
1130 through 1148,
1151 through 1155,
1160 through 1164,
1166, 1168, 1193,
1194.

TO FIND

THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW

- A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- B. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- C. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. **THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."**
- D. If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- E. If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- F. For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.

PRINTED IN U.S.A.




COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.



- ★ Included in Engine Gasket Set—Ref. 358.
- Included in Carburetor Overhaul Kit—Ref. 121.

2

28B700 to 28B799



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
4	494238	Sump-Engine	15	94239	Plug-Oil Drain	287	94903	Screw
12	★271916	Gasket-Crankcase (.015" Thick, Standard)	20	★291675	Seal-Oil (PTO Side)			(Dipstick Tube)
		----- Note -----	22	692125	Screw (Crankcase Cover/ Sump)	523	495229	Dipstick
		★271997 Gasket- Crankcase (.005" Thick)	43	490815	Slinger-Governor/Oil	524	★281370	Seal-Dipstick Tube
		★271996 Gasket- Crankcase (.009" Thick)	46	692123	Camshaft	525	690841	Tube-Dipstick
						842	★270920	O-Ring Seal
						847	496367	Dipstick/Tube Assembly


- ★ Included in Engine Gasket Set- Ref. 358.
- Included in Carburetor Overhaul Kit-Ref. 121.

- ◆ Included in Carburetor Gasket Set-Ref. 977.
- Ø Included in Valve Overhaul Gasket Set-Ref. 1095.

0153-4

Assemblies include all parts shown in frames.

2Q-9/2000




★ REQUIRES SPECIAL TOOLS TO INSTALL.
SEE REPAIR INSTRUCTION MANUAL.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
50	213819	Manifold-Intake	142	●499037	Nozzle-Carburetor (Standard) (LMT 162, 165, 169)			●498545 Nozzle-Carburetor (Standard) (LMT 108, 111)
51A	★0272554	Gasket-Intake			----- Note -----			●499039 Nozzle-Carburetor (Standard) (LMT 166, 168)
53	691098	Stud (Carburetor)			●496519 Nozzle-Carburetor (Standard) (LMT 63, 65, 66)			497737 Nozzle-Carburetor (High Altitude) (LMT 92)
54	94913	Screw (Intake Manifold)			●691434 Nozzle-Carburetor (Standard) (LMT 92, 93, 94, 96)			498258 Nozzle-Carburetor High Altitude) (LMT 63, 65, 66, 108, 111, 133, 135, 136)
106	●231854	Seat-Inlet (Gravity Feed)			●497568 Nozzle-Carburetor (Standard) (LMT 97, 99, 100)			499040 Nozzle-Carburetor (High Altitude) (LMT 162, 165, 166, 168, 169)
		----- Note -----			●497860 Nozzle-Carburetor (Standard) (LMT 133, 135, 136)	654	94010	Nut (Carburetor)
		●231856 Seat-Inlet (Pump Feed, LMT 168, 169)						
125	498027	Carburetor (Walbro)						
		----- Note -----						
		498231 Carburetor (LMT 108, 111)						
		499163 Carburetor (LMT 168, 169)						




★ Included in Engine Gasket Set- Ref. 358.
● Included in Carburetor Overhaul Kit-Ref. 121.

◆ Included in Carburetor Gasket Set-Ref. 977.
○ Included in Valve Overhaul Gasket Set-Ref. 1095.

28B700 to 28B799



★ REQUIRES SPECIAL TOOLS
TO INSTALL. SEE REPAIR
INSTRUCTION MANUAL.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
51	♦272465	Gasket-Intake	127	●695005	Plug-Welch	147	●497472	Jet-Pilot
93	690602	Bushing-Throttle Shaft	130	690468	Valve-Throttle			(LMT 63, 65, 66, 97,
94	498030	Kit-Idle Mixture	130A	224539	Valve-Throttle			99, 100, 133, 135, 136)
94A	496589	Kit-Idle Mixture			(Use on LMT 92)			----- Note -----
95	●94098	Screw	131	494885	Kit-Throttle Shaft			231983 Jet-Pilot
		(Throttle Valve)	131A	494379	Kit-Throttle Shaft			(LMT 136)
98	495800	Kit-Idle Speed			(Use on LMT 92)	186	493496	Connector-Hose
104	●690525	Pin-Float Hinge	133	494381	Float-Carburetor	231	●94098	Screw
105	●231855	Valve-Float Needle	137	♦281165	Gasket-Float Bowl			(Choke Valve)
106		Seat-Inlet	141	495097	Kit-Choke Shaft	276	♦281164	Washer-Sealing
		(See Previous Page)			(Manual Choke)	634	●690801	Spring/Seal Assembly
108	690464	Valve-Choke	141A	495931	Kit-Choke Shaft			(Manual Choke)
		(Manual Choke)			(Choke A Matic)	634A	●690802	Spring/Seal Assembly
108A	692344	Valve-Choke			(Choke A Matic)			(Choke A Matic)
		(Choke A Matic)	142		Carburetor Nozzle	692	690572	Spring-Detent
125		Carburetor			(See Previous Page)	950	94642	Screw-Float Bowl
		(Walbro)				975	495933	Bowl-Float
		(See Previous Page)				987	●691326	Seal-Throttle Shaft
						1091	691333	Cap-Limiter

★ Included in Engine Gasket Set- Ref. 358.
● Included in Carburetor Overhaul Kit-Ref. 121.

◆ Included in Carburetor Gasket Set-Ref. 977.
Ø Included in Valve Overhaul Gasket Set-Ref. 1095.

28B700 to 28B799



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
188	94929	Screw (Control Bracket)		261306	Spring– Governor	222A	494041	Bracket–Control
202	262767	Link–Mechanical Governor			Used on Type No(s). 0112, 0123, 0132, 0135, 0610, 0632, 1019, 1025, 1026, 1112, 1114, 1123, 1132, 1135, 1147, 1148, 1152, 1153, 1154, 1155, 1193.	232	262785	Spring –Governor Link
203	691381	Crank–Bell		690576	Spring– Governor	261	690278	Screw (Control Slide)
209	691278	Spring–Governor			Used on Type No(s). 0137, 0151.	265	221535	Clamp–Casing
		----- Note -----				267	94906	Screw (Casing Clamp)
		260695 Spring– Governor	216	262766	Link–Choke	359	691077	Washer (Ground Terminal)
		Used on Type No(s). 0113, 0115, 0127, 0128, 0130, 1128, 1160.	216A	690574	Link–Choke	373	90576	Nut (Ground Terminal)
		260871 Spring– Governor	216B	691281	Link–Choke	507	398525	Insulator
		Used on Type No(s). 0101, 0102, 0111, 0122, 0126, 0145, 0604, 1016, 1101, 1114, 1142, 1143, 1144.	222	694042	Bracket–Control (Used After Code Date 99011100).	520	691084	Terminal–Ground
		261126 Spring– Governor			----- Note -----	621	396847	Switch–Stop
		Used on Type No(s). 0139, 0146, 1139, 1146, 1166.			495611 Bracket– Control (Used Before Code Date 99011200).	687	390701	Slide–Control
						688	690395	Cap–Friction
						689	690529	Spring–Friction
						892	493625	Switch–Key
						990	392832	Key Set


- ★ Included in Engine Gasket Set– Ref. 358.
- Included in Carburetor Overhaul Kit–Ref. 121.

- ◆ Included in Carburetor Gasket Set–Ref. 977.
- ⊙ Included in Valve Overhaul Gasket Set–Ref. 1095.

0153–7


Assemblies include all parts shown in frames.

2Q–9/2000




8


K&T Saw Shop 606-678-9623 or 606-561-4983



K&T Saw Shop 606-678-9623 or 606-561-4983



K&T Saw Shop 606-678-9623 or 606-561-4983






REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
73	691191	Screen-Rotating	455	695113	Cup-Flywheel (Used After Code Date 99102400). ----- Note ----- 695113 Cup-Flywheel (Used After Code Date 99102400). Used on Type No(s). 1041, 1148.	1005	695056	Fan-Flywheel (Used After Code Date 99102400). ----- Note ----- 695056 Fan-Flywheel (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.
73A	224517	Screen-Rotating						
74	93758	Screw (Rotating Screen)						
74A	94626	Screw (Rotating Screen)	455A	691173	Cup-Flywheel	1005A	280687	Fan-Flywheel (Used Before Code Date 99102500). ----- Note ----- 280687 Fan-Flywheel (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.
75	225136	Washer (Flywheel)	668A	691323	Spacer			
332	690662	Nut (Flywheel)	934	94627	Screw (Fan Retainer)	1006	690452	Retainer-Fan

★ Included in Engine Gasket Set- Ref. 358.
● Included in Carburetor Overhaul Kit-Ref. 121.

◆ Included in Carburetor Gasket Set-Ref. 977.
Ø Included in Valve Overhaul Gasket Set-Ref. 1095.

28B700 to 28B799




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
23	693557	Flywheel (Steel Ring Gear) ----- Note ----- 693556 Flywheel (Steel Ring Gear) (16 Amp.) Used on Type No(s). 0123, 0146, 1125, 1140, 1146.	23B	693555	Flywheel (For Rewind Starter Only Engines)	726		Gear-Ring (Steel) (See Ref. 23 for Service)
23A	492326	Flywheel (Plastic Ring Gear) ----- Note ----- 692682 Flywheel (Plastic Ring Gear) (16 Amp.) Used on Type No(s). 0123, 0146, 1146.	165	693148	Nut (Ring Gear)	726A	399676	Gear-Ring (Aluminum) (Services Plastic Ring Gear Only)
			363	19203	Flywheel Puller	783	693713	Gear-Pinion (For Steel Ring Gear Only)
			695	693109	Screw (Ring Gear)	1051	263080	Ring-Retaining

- ★ Included in Engine Gasket Set- Ref. 358.
- Included in Carburetor Overhaul Kit-Ref. 121.

- ◆ Included in Carburetor Gasket Set-Ref. 977.
- ⊘ Included in Valve Overhaul Gasket Set-Ref. 1095.

28B700 to 28B799




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
37	690456	Guard-Flywheel	493A	692825	Bracket-Mounting (Used Before Code Date 99102500). ----- Note ----- 692825 Bracket-Mounting (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.			695448 Guard-Debris Screen (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.
37A	690806	Guard-Flywheel				949A	397530	Guard-Debris Screen (Used Before Code Date 99102500). ----- Note ----- 397530 Guard-Debris Screen (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.
78	94896	Screw (Flywheel Guard)						
304	695065	Housing-Blower (Used After Code Date 99102400). ----- Note ----- 691400 Housing-Blower (Used Before Code Date 99102500). 695065 Housing-Blower (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.	563	695449	Screw (Debris Screen Guard) (Used After Code Date 99102400). ----- Note ----- 695449 Screw (Debris Screen Guard) (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.	1036	695699	Label-Emissions (Used After Code Date 00063000). ----- Note ----- 695036 Label-Emissions (Used After Code Date 99093000 and Before Code Date 00070100). 694325 Label-Emissions (Used After Code Date 99100100 and Before Code Date 98123100). 499362 Label-Emissions (Used After Code Date 99010100 and Before Code Date 97052500). 499361 Label-Emissions (Used Before Code Date 97052600).
305	94786	Screw (Blower Housing)	563A	94902	Screw (Debris Screen Guard) (Used Before Code Date 99102500). ----- Note ----- 94902 Screw (Debris Screen Guard) (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.			
305A	692127	Screw (Blower Housing)						
493	695450	Bracket-Mounting (Used After Code Date 99102400). ----- Note ----- 695450 Bracket-Mounting (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.	727	490324	Cover-Starter Drive			
			732	691002	Screw (Starter Drive Cover)			
			949	695448	Guard-Debris Screen (Used After Code Date 99102400). ----- Note -----			

- ★ Included in Engine Gasket Set- Ref. 358.
- Included in Carburetor Overhaul Kit-Ref. 121.

- ◆ Included in Carburetor Gasket Set-Ref. 977.
- ⊗ Included in Valve Overhaul Gasket Set-Ref. 1095.

28B700 to 28B799




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
55	695130	Housing-Rewind Starter (Used After Code Date 99102400). ----- Note ----- 695130 Housing-Rewind Starter (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.	459	281505	Pawl-Ratchet (Used After Code Date 99102400). ----- Note ----- 281505 Pawl-Ratchet (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.	689A	263073	Spring-Friction (Used After Code Date 99102400). ----- Note ----- 263073 Spring-Friction (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.
58	695132	Rope-Starter (Used After Code Date 99102400). ----- Note ----- 695132 Rope-Starter (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.	597	94943	Screw (Pawl Friction Plate) (Used After Code Date 99102400). ----- Note ----- 94943 Screw (Pawl Friction Plate) (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.	1210	695129	Pulley-Rewind Starter (Used After Code Date 99102400). ----- Note ----- 695129 Pulley-Rewind Starter (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.
59	490653	Insert-Grip	608	695058	Starter-Rewind (Used After Code Date 99102400). ----- Note ----- 695058 Starter-Rewind (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.	1211	695131	Spring-Rewind Starter (Used After Code Date 99102400). ----- Note ----- 695131 Spring-Rewind Starter (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.
60	490652	Grip-Starter Rope						
65	695453	Screw (Rewind Starter) (Used After Code Date 99102400). ----- Note ----- 695453 Screw (Rewind Starter) (Used After Code Date 00022000). Used on Type No(s). 1041, 1148.						
456	695128	Plate-Pawl Friction (Used After Code Date 99102400). ----- Note -----						

★ Included in Engine Gasket Set- Ref. 358.
● Included in Carburetor Overhaul Kit-Ref. 121.

◆ Included in Carburetor Gasket Set-Ref. 977.
⊙ Included in Valve Overhaul Gasket Set-Ref. 1095.

28B700 to 28B799




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
55A	393576	Housing–Rewind Starter (Used Before Code Date 99102500). ----- Note ----- 393576 Housing–Rewind Starter (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.	63	260414	Spring–Ratchet (Used Before Code Date 99102500). ----- Note ----- 260414 Spring–Ratchet (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.	592	690800	Nut (Rewind Starter) (Used Before Code Date 99102500). ----- Note ----- 690800 Nut (Rewind Starter) (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.
56A	295871	Pulley–Starter (Used Before Code Date 99102500). ----- Note ----- 295871 Pulley–Starter (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.	64	281204	Adapter–Ratchet Spring (Used Before Code Date 99102500). ----- Note ----- 281204 Adapter–Ratchet Spring (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.	608A	390391	Starter–Rewind (Used Before Code Date 99102500). ----- Note ----- 390391 Starter–Rewind (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.
57A	490179	Spring–Rewind Starter (Used Before Code Date 99102500). ----- Note ----- 490179 Spring–Rewind Starter (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.	65A	690837	Screw (Rewind Starter) (Used Before Code Date 99102500). ----- Note ----- 690837 Screw (Rewind Starter) (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.	655	222598	Anchor–Rewind Spring (Used Before Code Date 99102500). ----- Note ----- 222598 Anchor–Rewind Spring (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.
58A	66884	Rope–Starter (Used Before Code Date 99102500). ----- Note ----- 66884 Rope–Starter (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.				678	490817	Spacer–Rewind (Used Before Code Date 99102500). ----- Note ----- 490817 Spacer–Rewind (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.
59	490653	Insert–Grip						
60	490652	Grip–Starter Rope						

- ★ Included in Engine Gasket Set–Ref. 358.
- Included in Carburetor Overhaul Kit–Ref. 121.

- ◆ Included in Carburetor Gasket Set–Ref. 977.
- ⊙ Included in Valve Overhaul Gasket Set–Ref. 1095.

28B700 to 28B799




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
66	399671	Clutch-Starter (Used Before Code Date 99102500). ----- Note ----- 399671 Clutch-Starter (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.	68	63770	Ball-Clutch (Used Before Code Date 99102500). ----- Note ----- 63770 Ball-Clutch (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.	71	691359	Cover-Ratchet (Used Before Code Date 99102500). ----- Note ----- 691359 Cover-Ratchet (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.
67	394897	Clutch-Housing (Used Before Code Date 99102500). ----- Note ----- 394897 Clutch-Housing (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.	70	298799	Ratchet-Clutch (Used Before Code Date 99102500). ----- Note ----- 298799 Ratchet-Clutch (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.	76	68238	Seal-Ratchet (Used Before Code Date 99102500). ----- Note ----- 68238 Seal-Ratchet (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.
						930	280685	Guard-Rewind (Used Before Code Date 99102500). ----- Note ----- 280685 Guard-Rewind (Used Before Code Date 00022100). Used on Type No(s). 1041, 1148.

★ Included in Engine Gasket Set- Ref. 358.
● Included in Carburetor Overhaul Kit-Ref. 121.

◆ Included in Carburetor Gasket Set-Ref. 977.
Ø Included in Valve Overhaul Gasket Set-Ref. 1095.

28B700 to 28B799



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
309	693551	Motor-Starter (3 5/8" Housing Length) (For Steel Ring Gear Only)	310	690323	Bolt (Starter Motor) (For 3 5/8" Housing Length)	729A	691224	Clip-Wire
		----- Note -----			----- Note -----	783	693713	Gear-Pinion (For Steel Ring Gear Only)
	693552	Motor-Starter (4 3/8" Housing Length) (For Steel Ring Gear Only)		691263	Bolt (Starter Motor) (For 4 3/8" Housing Length)	783A	693058	Gear-Pinion (For Plastic Ring Gear Only)
	497595	Motor-Starter (3 5/8" Housing Length) (For Plastic Ring Gear Only)	311	497608	Brush Set	783B	693059	Gear-Pinion (For Aluminum Ring Gear Only)
	497401	Motor-Starter (4 3/8" Housing Length) (For Plastic Ring Gear Only)	503	691532	Strap-Starter	797	693167	Nut (Brush Retainer)
	693054	Motor-Starter (3 5/8" Housing Length) (For Aluminum Ring Gear Only)	510	693699	Drive-Starter (Used With Steel Ring Gear)	797A	92278	Nut (Brush Retainer)
	499521	Motor-Starter (4 3/8" Housing Length) (For Aluminum Ring Gear Only)	510A	497606	Drive-Starter (Used With Aluminum & Plastic Ring Gears)	801	691429	Cap-Drive
			513	398003	Clutch-Drive	802	497607	Cap-End
			544	497603	Armature-Starter (3 5/8" Housing Length)	803	693757	Housing-Starter (3-5/8" Housing Length) (4-3/8" Housing Length, Serviced by Ref. 309)
			697	690372	Screw (Drive Cap)	1051	263080	Ring-Retaining
						1090	497605	Retainer-Brush

- ★ Included in Engine Gasket Set- Ref. 358.
- Included in Carburetor Overhaul Kit-Ref. 121.

- ◆ Included in Carburetor Gasket Set-Ref. 977.
- ⊗ Included in Valve Overhaul Gasket Set-Ref. 1095.

28B700 to 28B799

