

Illustrated Parts List

Model Series

326400 to 326499

TYPE NUMBERS
0010 through 0080,
0110 through 0399,
0611, 0620,
0630 through 0799,
0801 through 0804,
1160, 2256,
2520 through 2563,
2580, 2581, 2582,
2583, 2596.

TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW


- A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- B. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- C. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. **THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."**
- D. If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- E. If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- F. For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.

PRINTED IN U.S.A.



COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

326400 to 326499




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	395663	Cylinder Assembly (Used After Code Date 81073100). ----- Note ----- 393670 Cylinder Assembly (Used After Code Date 78061300 and Before Code Date 81080100). 392096 Cylinder Assembly (Includes Piston and Ring Assembly) (Used Before Code Date 78061400).	10	690294	Screw (Breather Assembly)	362	392273	Shield-Sparkplug
5	213961	Head-Cylinder (Used After Code Date 75060800). ----- Note ----- 211889 Head-Cylinder (Used Before Code Date 75060900). Used on Type No(s). 0205, 0255, 0291, 0648. 212514 Head-Cylinder (Gasoline/Kerosene) Used on Type No(s). 0080, 0386, 0387, 0393, 0395, 0396, 0397, 0631, 0640, 0641, 0662, 2580.	11	68818	Tube-Breather	383	89838	Wrench-Sparkplug
6	691261	Washer (Cylinder Head)	13	91203	Screw (Cylinder Head) (1 3/4" Long) ----- Note ----- 94221 Screw (Cylinder Head) (2 1/16" Long)	406	690533	Spring-Breather Tube
7	272166	Gasket-Cylinder Head	13A	92674	Screw (Cylinder Head) (2 7/16" Long)	552	393666	Bushing-Governor Crank
8	495738	Breather Assembly	14	94926	Stud (Cylinder Head)	635	66538	Boot-Sparkplug
9	27803	Gasket-Breather	15	692833	Plug-Oil Drain	645	692880	Bushing-Plunger
			21	281658	Cap-Oil Fill	722	68768	Seal-Plunger
			306	299536	Shield-Cylinder	724	93516	Retainer-Seal
			307	690294	Screw (Cylinder Shield)	724A	221873	Retainer-Seal
			308	222357	Cover-Cylinder Head (Used After Code Date 75060800). ----- Note ----- 221953 Cover-Cylinder Head (Used Before Code Date 75060900). Used on Type No(s). 0291, 0648.	870	21612	Seat-Valve (Exhaust)
			322	94786	Screw (Cylinder Head Cover)	871	231218	Bushing-Valve Guide
			337	492167	Sparkplug ----- Note ----- 802592 Sparkplug (Resistor Type)	989	690578	Stopswitch-Sparkplug ----- Note ----- 293739 Stopswitch-Sparkplug Used on Type No(s). 0200. 298926 Stopswitch-Sparkplug Used on Type No(s). 0028, 0062, 0138, 0187, 0195, 0220, 0232, 0237, 0238, 0243, 0266, 0295, 0320, 0327, 0658, 0663, 0675, 0680, 0681, 0687, 0691, 0729, 0730, 0735, 2528, 2562. 390785 Stopswitch-Sparkplug Used on Type No(s). 0640, 0734.
			342	298125	Plunger-Breaker	989A	690633	Stopswitch-Sparkplug
						1058	270373	Owner's Manual

★ Included in Engine Gasket Set-Ref. No. 358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set-Ref. No. 1095.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
25	390364	Piston Assembly (Standard) ----- Note ----- 390365 Piston Assembly (.010" O.S.) 390366 Piston Assembly (.020" O.S.) 390367 Piston Assembly (.030" O.S.)	29	299632	Rod-Connecting (Standard) ----- Note ----- 390306 Rod-Connecting (.020" Undersize)	219	291192	Gear-Governor
26	390484	Ring Set (Standard) ----- Note ----- 390679 Ring Set (Standard Chrome) 390486 Ring Set (.010" O.S.) 390505 Ring Set (.020" O.S.) 390507 Ring Set (.030" O.S.)	30	221777	Dipper-Connecting Rod	219A	393720	Gear-Governor
27	260924	Lock-Piston Pin	31	690396	Lock-Rod Screw	225	691357	Shaft-Governor Gear
28	299691	Pin-Piston (Standard) ----- Note ----- 391286 Pin-Piston (.005" O.S.)	32	692345	Screw (Connecting Rod)	407	94905	Screw (Camshaft Bearing)
			33	394436	Valve-Exhaust	511	690402	Washer (Camshaft Bearing)
			34	394435	Valve-Intake	552	393666	Bushing-Governor Crank
			35	26828	Spring-Valve (Intake)	553	690269	Retainer-Valve Spring
			36	26828	Spring-Valve (Exhaust)	591	224083	Plug-Camshaft
			40	292260	Retainer-Valve ----- Note ----- 690274 Retainer-Valve Used on Type No(s). 0722.	598	★270516	Shim-End Play (.009") ----- Note ----- ★270517 Shim-End Play (.007") ★270518 Shim-End Play (.005")
			42	494553	Keeper-Valve (Used After Code Date 80111200). ----- Note ----- 68283 Keeper-Valve (Used Before Code Date 80111300).	626	690512	Spacer-Governor Crank
			45	26670	Tappet-Valve	742	691080	Retainer-E Ring
			46	211794	Camshaft	743	691153	Gear-Drive
						746	261466	Gear-Idler
						755	299706	Bearing-Camshaft
						900	230890	Shaft-Gear
						900A	231006	Shaft-Gear
						1143	691081	Screw (Drive Gear Cover)
						1144	690301	Washer (Drive Gear Cover)

★ Included in Engine Gasket Set-Ref. No. 358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set-Ref. No. 1095.

326400 to 326499




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
16	261218	Crankshaft ----- Note ----- 690534 Crankshaft Used on Type No(s). 0237, 0133, 0190, 0252, 0315, 0788, 2582. 261221 Crankshaft Used on Type No(s). 0136. 261222 Crankshaft Used on Type No(s). 0139, 0204, 0228, 0328, 0678. 690535 Crankshaft Used on Type No(s). 0050, 0116, 0130, 0143, 0147, 0149, 0150, 0151, 0156, 0167, 0170, 0172, 0173, 0174, 0185, 0186, 0188, 0192, 0193, 0208, 0219, 0231, 0248, 0257, 0286, 0290, 0310, 0317, 0318, 0329, 0337, 0343, 0371, 0636, 0638, 0666, 0669, 0684, 0690, 0706, 0721, 0751, 2550. 261225 Crankshaft Used on Type No(s). 0113, 0171, 0196, 0304, 0319, 0322. 690536 Crankshaft Used on Type No(s). 0022, 0063, 0114, 0129, 0153, 0175, 0176, 0183, 0198, 0205, 0217, 0224, 0233, 0235, 0236, 0238, 0247, 0255, 0261, 0265, 0266, 0273, 0277, 0278, 0279, 0285, 0287, 0291, 0296, 0303, 0320, 0334, 0338, 0340, 0344, 0345, 0346, 0347, 0348,			0353, 0359, 0361, 0363, 0366, 0367, 0374, 0375, 0383, 0385, 0394, 0396, 0633, 0634, 0648, 0650, 0654, 0661, 0671, 0674, 0676, 0680, 0687, 0692, 0693, 0694, 0696, 0698, 0699, 0702, 0703, 0708, 0714, 0718, 0722, 0724, 0729, 0733, 0736, 0746, 0753, 0754, 0757, 0764, 0771, 0772, 0774, 0776, 0782, 0787, 2522, 2563, 2596. 261255 Crankshaft Used on Type No(s). 0158, 0160, 0197, 0216, 0237. 690537 Crankshaft Used on Type No(s). 0210, 0262, 0630. 690540 Crankshaft Used on Type No(s). 0062, 0241, 0242, 0243, 0244, 0260, 0269, 0272, 0292, 0295, 0297, 0300, 0302, 0312, 0327, 0352, 0365, 0369, 0373, 0391, 0635, 0670, 0681, 0686, 0691, 0719, 0723, 0726, 0730, 0732, 0735, 0737, 0740, 0744, 0745, 0750, 0755, 0759, 0780, 0786, 2562. 690541 Crankshaft Used on Type No(s). 0061, 0124, 0246, 0253, 0305, 0308, 0335, 0341, 0342, 0646, 0710, 0711, 0713, 0728, 0781, 0785, 2529, 2561.			690543 Crankshaft Used on Type No(s). 0259, 0293, 0647, 0756. 261543 Crankshaft (Used After Code Date 77072410). Used on Type No(s). 0021, 0112, 0128, 0181, 0189, 0203, 0209, 0254, 0256, 0258, 0314, 0321, 0357, 0362, 0368, 0395, 0656, 0668, 0675, 0709, 0717, 0739, 0743, 0752, 0765, 0778, 0779, 0784, 0789, 0790, 0792, 0793, 0794, 0801, 0802, 0804, 2521, 2526, 2530. 261219 Crankshaft (Used Before Code Date 77072510). Used on Type No(s). 0021, 0112, 0128, 0181, 0189, 0203, 0209, 0254, 0256, 0258, 0314, 0321, 0357, 0362, 0368, 0395, 0656, 0668, 0675, 0709, 0717, 0739, 0743, 0752, 0765, 0778, 0779, 0784, 0789, 0790, 0792, 0793, 0794, 0801, 0802, 0804, 2521, 2526, 2530. 690546 Crankshaft Used on Type No(s). 0682, 2560. 261944 Crankshaft Used on Type No(s). 0720, 0758, 0788.
						17	291667	Bearing—Ball
						24	222698	Key—Flywheel
						357	91540	Key—Drive Pulley

★ Included in Engine Gasket Set—Ref. No. 358.

● Included in Carburetor Overhaul Kit—Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set—Ref. No. 1095.





REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
20	★299609	Seal–Oil (PTO Side)			0329, 0334, 0337, 0338, 0340, 0344, 0345, 0347, 0357, 0359, 0361, 0368, 0373, 0374, 0383, 0385, 0395, 0396, 0634, 0636, 0648, 0650, 0656, 0661, 0666, 0670, 0671, 0674, 0675, 0684, 0686, 0690, 0692, 0693, 0696, 0698, 0699, 0702, 0703, 0706, 0708, 0709, 0714, 0717, 0721, 0724, 0726, 0732, 0733, 0735, 0737, 0739, 0740, 0743, 0744, 0745, 0746, 0750, 0751, 0752, 0753, 0754, 0755, 0757, 0759, 0771, 0776, 0780, 0783, 0784, 0789, 0794, 0801, 0802, 2522, 2550, 2562, 2563, 2596.	571B	299705	Support–Bearing (Magneto Side)
20A	★291675	Seal–Oil (PTO Side)				593	★691311	Gasket–Bearing Support
228	93415	Screw (Bearing Support)				593A	★270513	Gasket–Bearing Support (.015")
228A	94627	Screw (Bearing Support)						----- Note -----
571	391062	Support–Bearing						★270514 Gasket Bearing Support (.010")
571A	291665	Support–Bearing Used on Type No(s). 0022, 0050, 0062, 0063, 0112, 0113, 0114, 0116, 0130, 0143, 0147, 0149, 0150, 0151, 0153, 0156, 0160, 0167, 0171, 0172, 0173, 0174, 0175, 0176, 0183, 0185, 0186, 0188, 0192, 0193, 0196, 0197, 0198, 0205, 0208, 0209, 0216, 0217, 0219, 0224, 0233, 0235, 0236, 0241, 0242, 0244, 0247, 0255, 0256, 0257, 0260, 0261, 0265, 0266, 0269, 0272, 0273, 0277, 0278, 0279, 0285, 0286, 0287, 0290, 0291, 0292, 0296, 0297, 0302, 0303, 0304, 0310, 0312, 0318, 0327,						★270515 Gasket Bearing Support (.005")
					----- Note ----- 291710 Support– Bearing Used on Type No(s). 0647, 0668, 0682, 0713, 0717, 0755, 0772, 0782, 0788, 0790, 0792, 0793, 0801, 0804, 2521, 2530.	1141	690402	Washer (Bearing Support)

★ Included in Engine Gasket Set–Ref. No. 358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set–Ref. No. 1095.

326400 to 326499




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
15A	94239	Plug—Oil Drain		391165	Base—Engine			0293, 0306, 0308,
15B	94880	Plug—Oil Drain			Used on Type No(s).			0310, 0311, 0312,
21	281658	Cap—Oil Fill			0062, 0120, 0121,			0315, 0316, 0326,
568	291404	Base—Engine			0123, 0126, 0127,			0328, 0331, 0333,
		(Engine Base is			0133, 0135, 0136,			0341, 0351, 0354,
		Furnished by the			0140, 0144, 0149,			0360, 0384, 0392,
		Equipment			0157, 0158, 0162,			0630, 0638, 0647,
		Manufacturer)			0163, 0164, 0165,			0648, 0649, 0659,
		Used on Type No(s).			0169, 0170, 0172,			0660, 0669, 0673,
		0134, 0135.			0173, 0174, 0178,			0678, 0679, 0686,
		----- Note -----			0180, 0182, 0183,			0705, 0712, 0723,
		294751 Base—Engine			0184, 0185, 0186,			0724, 0725, 0726,
		Used on Type No(s).			0190, 0192, 0198,			0732, 0735, 0737,
		0020, 0023, 0050,			0201, 0204, 0205,			0740, 0744, 0750,
		0139, 0145, 0150,			0210, 0215, 0222,			0755, 0756, 0759,
		0151, 0152, 0155,			0223, 0227, 0228,			0780, 0781, 0786,
		0159, 0175, 0191,			0230, 0234, 0235,			2562, 2581.
		0199, 0203, 0206,			0240, 0246, 0248,	569	★27351	Gasket—Engine Base
		0208, 0212, 0218,			0252, 0253, 0254,			
		0219, 0226, 0356,			0255, 0259, 0262,			
		0804, 2583.			0283, 0284, 0291,			

★ Included in Engine Gasket Set—Ref. No. 358.

● Included in Carburetor Overhaul Kit—Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set—Ref. No. 1095.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
20	★299609	Seal—Oil (PTO Side)	525	690622	Tube—Dipstick ----- Note ----- 690623 Tube—Dipstick Used on Type No(s). 0121, 0144, 0157, 0158, 0164, 0165, 0169, 0170, 0182, 0184, 0192, 0198, 0210, 0222, 0234, 0235, 0240, 0248, 0262, 0266, 0309, 0312, 0316, 0331, 0338, 0341, 0351, 0358, 0630, 0638, 0679, 0705, 0707, 0724, 0744, 0750, 0755, 0770, 1160, 2581. 491872 Tube—Dipstick (Used After Code Date 88102500). Used on Type No(s). 0755, 2581. 690623 Tube—Dipstick (Used Before Code Date 88102600). Used on Type No(s). 0755, 2581.	567	691104	Screw (Engine Base)
88	★691310	Gasket—Gear Reduction Cover (Magnetto Side)				587	690389	Clamp—Cable
88A	★692914	Gasket—Gear Reduction Cover (PTO Side)				665	298860	Minder—Oil
276	690258	Washer—Sealing				704	691083	Screw (Counterweight Cover)
338	★690270	Gasket—Dipstick				749	391061	Cover—Counterweight
366	690304	Screw (Timing Hole Plug)				749A	391361	Cover—Counterweight (Used on Alternator Equipped Engines)
523	691352	Dipstick				998	690307	Pipe—Oil
523A	690620	Dipstick				998A	690502	Pipe—Oil
524	★281370	Seal—Dipstick Tube				1054	280275	Tie—Cable

★ Included in Engine Gasket Set—Ref. No. 358.
● Included in Carburetor Overhaul Kit—Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set—Ref. No. 1095.

326400 to 326499




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
109	691353	Shaft-Choke ----- Note ----- 690617 Shaft-Choke Used on Type No(s). 0121, 0127, 0133, 0134, 0135, 0136, 0139, 0140, 0144, 0149, 0157, 0158, 0162, 0163, 0164, 0165, 0166, 0169, 0170, 0172, 0180, 0184, 0185, 0186, 0192, 0201, 0204, 0206, 0211, 0212, 0213, 0226, 0227, 0228, 0229, 0249, 0251, 0271, 0298, 0326, 0328, 0332, 2581, 2582.	125	391065	Carburetor ----- Note ----- 391068 Carburetor Used on Type No(s). 0121, 0144, 0157, 0158, 0164, 0165, 0169, 0170, 0184, 0192, 0240, 0331. 391070 Carburetor Used on Type No(s). 0127, 0133, 0134, 0135, 0136, 0139, 0140, 0149, 0162, 0163, 0166, 0172, 0173, 0180, 0185, 0186, 0201, 0204, 0206, 0211, 0212, 0213, 0226, 0227, 0228, 0229, 0249, 0251, 0271, 0298, 0326, 0328, 0332. 392035 Carburetor Used on Type No(s). 0182, 0210, 0222, 0309.	134	392235	Carburetor Used on Type No(s). 0198, 0234, 0235, 0248, 0266, 0312, 0316, 0338, 0341, 0351, 0358, 0707, 0724, 0744, 0750, 0759, 0770. 393431 Carburetor Used on Type No(s). 0262, 0630. 395320 Carburetor (Gasoline/Kerosene) Used on Type No(s). 0080, 0386, 0387, 0393, 0395, 0396, 0397, 0631, 0640, 0641, 0662, 2580. 134 • 394681 Kit-Needle/Seat ----- Note ----- 394682 Kit-Needle/ Seat (Includes Brass Seat) 394683 Kit-Needle/ Seat (Includes Brass Seat For Impulse Pump)

★ Included in Engine Gasket Set-Ref. No. 358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set-Ref. No. 1095.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
50	691152	Manifold-Intake ----- Note ----- 692525 Manifold-Intake Used on Type No(s). 0248, 0308, 0358, 0638, 0707, 0770.	95	93499	Screw (Throttle Valve)	142	●394730	Nozzle-Carburetor (Labeled B) (Used After Code Date 81090800). ----- Note ----- 390950 Nozzle-Carburetor (Labeled 40) (Used Before Code Date 81090900).
51	★Ø27381	Gasket-Intake	97	298535	Shaft-Throttle	150	●68667	Gasket-Nozzle
51A	★●270267	Gasket-Intake	98	693942	Kit-Idle Speed	158	27590	Plug-Carburetor Filter/Drain
54	93415	Screw (Intake Manifold)	101	93043	Pin-Shaft	186	230318	Connector-Hose
91	299687	Body-Upper Carburetor ----- Note ----- 391067 Body-Upper Carburetor Used on Type No(s). 0121, 0144, 0157, 0158, 0164, 0165, 0169, 0170, 0182, 0184, 0192, 0240, 0309, 0331, 0630, 0707, 0724, 0770.	102	●270268	Gasket-Carburetor Body	231	93499	Screw (Choke Valve)
94	●292681	Kit-Idle Mixture	104	●691775	Pin-Float Hinge	267	691082	Screw (Casing Clamp)
			107	391069	Body-Lower Carburetor	681	391213	Kit-Needle Valve
			108	690621	Valve-Choke	689	26157	Spring-Friction
			109		Shaft-Choke (See Previous Page)	689A	26155	Spring-Friction
			110	691186	Washer (Choke Shaft)	800	220521	Retainer-Carburetor Drain
			118	●99525	Valve-High Speed Carburetor (See Previous Page)	971	691090	Screw (Air Cleaner Base to Carburetor)
			125			1146	23123	Screw (Choke Shaft)
			127	●221747	Plug-Welch			
			130	221939	Valve-Throttle			
			132	212904	Stop-Throttle			
			133	298514	Float-Carburetor			
			134		Kit-Needle/Seat (See Previous Page)			

★ Included in Engine Gasket Set-Ref. No. 358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set-Ref. No. 1095.

326400 to 326499




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
162	690267	Collar–Bell Crank	212	260923	Link–Throttle	268	65616	Casing–Control Wire
201	261027	Link–Air Vane			----- Note -----			(Cut to Required Length)
		Used on Type No(s).			26725 Link–Throttle	269	26633	Wire–Control
		0234, 0705.			Used on Type No(s).			(Cut to Required Length)
203	690263	Crank–Bell			0248, 0308, 0358,	270	63426	Nut
205	93415	Screw	227	690607	Lever–Governor Control			(Control Wire Casing)
		(Bell Crank)			----- Note -----	271	290568	Lever–Control
		Used on Type No(s).			690616 Lever–	404	690264	Washer
		0136, 0139, 0204,			Governor Control			(Governor Crank)
		0228, 0234, 0248,			Used on Type No(s).	414	692810	Washer
		0328, 0678, 0705.			0611, 0630, 0647,			(Bell Crank)
205A	94905	Screw			0651, 0684, 0690,			Used on Type No(s).
		(Bell Crank)			0706, 0721, 0660,			0136, 0139, 0204,
206	691079	Nut			0671, 0675, 0681,			0228, 0234, 0248,
		(Governor Control Rod)			0683, 0685, 0689,			0328, 0678, 0705.
206A	21772	Nut			0692, 0694, 0697,	505	691251	Nut
		(Governor Control Rod)			0699, 0801, 2520,			(Governor Control Lever)
208	230040	Rod–Governor Control			2527, 2528, 2529,	562	92613	Bolt
209	26764	Spring–Governor			2550, 2561, 2581,			(Governor Control Lever)
		----- Note -----			2582.	614	93306	Pin–Cotter
		260815 Spring–			221987 Lever–	616	291364	Crank–Governor
		Governor			Governor Control	629	690538	Spring–Throttle Return
		Used on Type No(s).			Used on Type No(s).			Used on Type No(s).
		0611, 0630, 0647,			0678, 0705.			0234, 0637, 0705,
		0651, 0690, 0760,	232	260478	Spring–Governor Link			0803.
		0781, 0801, 2256,			----- Note -----	668	690313	Spacer
		2520, 2527, 2528,			260584 Spring–			
		2529, 2550, 2581,			Governor Link			
		2582.			Used on Type No(s).			
211	260816	Spring–Governed Idle			0248, 0308, 0358,			
		Used on Type No(s).			0638, 0707, 0770.			
		0611, 0630, 0647,						
		0651, 0690, 0760,	266	494554	Control–Throttle			
		0781, 0801, 2256,			----- Note -----			
		2520, 2527, 2528,			299361 Control–			
		2529, 2550, 2581,			Throttle			
		2582.			(Dial Control)			

★ Included in Engine Gasket Set–Ref. No. 358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set–Ref. No. 1095.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
161	392391	Base—Air Cleaner	171	94289	Nut (Air Cleaner)	643	222272	Retainer—Air Filter
163	67247	Gasket—Air Cleaner Used on Type No(s). 0308.	171A	690284	Nut (Air Cleaner)	967	271794	Filter—Pre Cleaner
163A	270987	Gasket—Air Cleaner	445	393957	Air Cleaner Cartridge Filter	968	224885	Cover—Air Cleaner
166	691241	Stud (Air Cleaner) (9 1/2" Long)	467	493903	Knob—Air Cleaner	1158	690293	Screw (Carburetor) (Used to plug Air Cleaner Stud Hole in Bottom of Carburetor) Used on Type No(s). 0262, 0630.
----- Note -----			536	391063	Cleaner—Air			
		231114 Stud (Air Cleaner) (10 3/4" Long)						

★ Included in Engine Gasket Set—Ref. No. 358.
● Included in Carburetor Overhaul Kit—Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set—Ref. No. 1095.

326400 to 326499




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
81	691178	Lock-Muffler Screw	303	690281	Elbow-Exhaust (1" 90°)	676	393761	Deflector-Muffler
237	690409	Retainer-Guard			----- Note -----	676A	397630	Deflector-Muffler
264	691105	Nut (Muffler Adapter)		91296	Elbow-Exhaust (1" 90°)	676B	396903	Deflector-Muffler
298	261564	Locknut-Muffler/Elbow			Used on Type No(s). 0391, 0686, 0726, 0732, 0737, 0744, 0750, 0759, 0781.	677	94896	Screw (Muffler Deflector)
300	393232	Muffler				725	690420	Shield-Heat
300A	498984	Muffler				823	94905	Screw (Muffler Adapter)
300B	392989	Muffler				832	690648	Guard-Muffler
300C	291519	Muffler				834	691075	Washer (Muffler Adapter)
300D	399635	Muffler				836	691083	Screw (Muffler Guard)
301	93734	Pipe-Exhaust (8" Long)	346	94896	Screw (Spark Arrester)	836A	690367	Screw (Muffler Guard)
301A	92107	Pipe-Exhaust (4" Long)	613	93927	Screw (Exhaust Muffler)	863	694016	Bracket-Muffler
301B	91416	Pipe-Exhaust Used on Type No(s). 0163, 0327.	613A	690297	Screw (Exhaust Muffler) (Used After Code Date 97012300).	864	394584	Adapter-Muffler
					----- Note -----	864A	690637	Adapter-Muffler
					94786 Screw (Exhaust Muffler) (Used Before Code Date 97012400).	883	★272293	Gasket-Exhaust
						944	94926	Stud (Muffler Adapter)
						994	392390	Arrester-Spark

★ Included in Engine Gasket Set-Ref. No. 358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set-Ref. No. 1095.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
179	690280	Screw (Fuel Tank Strap)	187	499167	Line-Fuel ----- Note ----- 89248 Line-Fuel (2 1/4" Long) (Metal) Used on Type No(s). 0080, 0386, 0387, 0393, 0395, 0396, 0397, 0631, 0640, 0641, 0662, 2580.	387	491922	Pump-Fuel
182	691068	Bracket-Fuel Tank ----- Note ----- 222671 Bracket-Fuel Tank (8 Quart) 222669 Bracket-Fuel Tank Used on Type No(s). 0205, 0291, 0648.	195	91635	Nipple-Fuel	387A	494280	Pump-Fuel Used on Type No(s). 0170, 0182, 0198, 0248, 0309, 0331, 0638, 0679, 0744, 0755, 0759.
182A	690262	Bracket-Fuel Tank	199	297563	Valve-Fuel Shut Off	450	691075	Washer (Fuel Tank Bracket)
183	291490	Strap-Fuel Tank ----- Note ----- 291367 Strap-Fuel Tank (4 Quart) Used on Type No(s). 0206, 0211, 0213, 0229, 0271.	199A	293934	Valve-Fuel Shut Off	601	95162	Clamp-Hose
186	230318	Connector-Hose	210	22547	Strainer-Fuel	670	690505	Spacer-Fuel Tank
186A	67218	Connector-Hose	240	298090	Filter-Fuel ----- Note ----- 394358 Filter-Fuel Used on Type No(s). 0630, 0705, 0707, 0724, 0744, 0750, 0755, 0759, 0770, 0774, 2581.	674	690303	Screw (Fuel Tank Bracket)
186B	231238	Connector-Hose	240A	393169	Filter-Fuel	707	690279	Nut (Fuel Tank Strap)
186C	231282	Connector-Hose	241	690612	Cover-Fuel Filter	788	224123	Bracket-Fuel Pump
			245	★68477	Gasket-Fuel Bowl	861	394462	Kit-Fuel Pump (Walbro) (For Pump Ref 387A Only)
			246	298683	Bowl-Fuel Filter	917	223271	Handle-Shut Off Valve
			247	99665	Yoke-Bowl	918	393815	Hose-Vacuum (Cylinder To Impulse Pump) (Cut to Required Length)
			385	94786	Screw (Fuel Pump)	958	295913	Valve-Fuel Shut Off

★ Included in Engine Gasket Set-Ref. No. 358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set-Ref. No. 1095.

326400 to 326499





REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
180	291488	Tank–Fuel (6 Quart) ----- Note ----- 290816 Tank–Fuel (4 Quart) Used on Type No(s). 0206, 0211, 0213, 0229, 0271. 292415 Fuel Tank (8 Quart) Used on Type No(s). 0137, 0140, 0141, 0143, 0148, 0151, 0152, 0153, 0156, 0162, 0163, 0167, 0172, 0173, 0175, 0176, 0178, 0180, 0181, 0183, 0185, 0186, 0197, 0199, 0201, 0203, 0205, 0212, 0215, 0219,			0226, 0227, 0242, 0245, 0249, 0254, 0255, 0257, 0259, 0273, 0282, 0284, 0286, 0289, 0291, 0293, 0300, 0303, 0307, 0311, 0318, 0330, 0336, 0347, 0354, 0369, 0372, 0376, 0377, 0381, 0384, 0392, 0635, 0640, 0647, 0648, 0657, 0659, 0661, 0664, 0666, 0674, 0682, 0685, 0690, 0694, 0696, 0697, 0698, 0704, 0712, 0714, 0721, 0723, 0729, 0730, 0743, 0745, 0746, 0754, 0757, 0771, 0772.	181	392305	Cap–Fuel Tank (Metal) ----- Note ----- 297866 Cap–Fuel Tank (Metal) Used on Type No(s). 0162, 0180, 0201, 0215, 0284, 0392, 0712.

★ Included in Engine Gasket Set–Ref. No. 358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set–Ref. No. 1095.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	
23	395249	Flywheel (For Electronic Ignition, Identified by Two Red Stripes) ----- Note ----- 395250 Flywheel (For Electronic Ignition, Identified by Two Red Stripes) Used on Type No(s). 0611, 0620, 0632, 0633, 0635, 0637, 0640, 0641, 0642, 0644, 0645, 0646, 0647, 0648, 0650, 0651, 0652, 0655, 0656, 0657, 0659, 0662, 0664, 0670, 0674, 0677, 0681, 0683, 0686, 0689, 0690, 0691, 0694, 0695, 0696, 0700, 0706, 0709, 0710, 0713, 0717, 0722, 0723, 0727, 0728, 0730, 0734, 0735, 0737, 0739, 0743, 0744, 0745, 0747, 0750, 0755, 0756, 0757, 0759, 0762, 0763, 0766, 0775, 0778, 0780, 0785, 0786, 0790, 0791, 0792, 0793, 0794, 0799, 0801, 0802, 2520, 2521, 2522, 2529, 2530, 2550, 2560, 2561, 2562, 2580, 2581, 2582.	23A	395251	Flywheel (For Electronic Ignition, Identified by Two Red Stripes) ----- Note ----- 395269 Flywheel (For Electronic Ignition, Identified by Two Red Stripes) Used on Type No(s). 0736. 391363 Flywheel (10 Amp) (Used With Breaker Points and Condenser System) Used on Type No(s). 0027, 0028, 0063, 0115, 0123, 0126, 0135, 0143, 0148, 0149, 0162, 0163, 0164, 0165, 0167, 0168, 0170, 0171, 0172, 0174, 0178, 0180, 0182, 0184, 0185, 0188, 0189, 0192, 0193, 0198, 0201, 0209, 0210, 0211, 0213, 0215, 0217, 0221, 0222, 0224, 0229, 0230, 0231, 0234, 0235, 0236, 0238, 0240, 0248, 0249, 0250, 0251, 0252, 0257, 0261, 0262, 0265, 0271, 0273, 0274, 0275, 0276, 0277, 0278, 0279, 0281,	0282, 0283, 0284, 0285, 0286, 0287, 0288, 0296, 0298, 0303, 0304, 0306, 0307, 0309, 0310, 0311, 0315, 0316, 0317, 0318, 0319, 0320, 0321, 0322, 0323, 0324, 0325, 0326, 0328, 0330, 0331, 0332, 0333, 0334, 0337, 0338, 0340, 0343, 0347, 0348, 0349, 0350, 0351, 0353, 0355, 0358, 0359, 0360, 0363, 0364, 0367, 0370, 0371, 0372, 0374, 0375, 0376, 0377, 0378, 0379, 0381, 0382, 0383, 0388, 0389, 0392, 0394, 0399. 394919 Flywheel (Used With Breaker Points and Condenser System) Used on Type No(s). 0387.	726	391362	Gear-Ring

★ Included in Engine Gasket Set-Ref. No. 358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set-Ref. No. 1095.

326400 to 326499




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
73	691171	Screen-Rotating ----- Note ----- 222044 Screen-Rotating Used on Type No(s). 0136, 0139, 0140, 0148, 0152, 0163, 0169, 0184, 0199, 0204, 0227, 0228, 0282, 0307, 0319, 0322, 0326, 0328, 0343, 0372, 0376, 0669, 0678, 0697. 690404 Screen-Rotating Used on Type No(s). 0127, 0133, 0182, 0190, 0210, 0222, 0252, 0262, 0315, 0333, 0630, 0649, 2582, 2583.	73A	690410	Screen-Rotating	321A	690377	Fan-Booster
			74	94626	Screw (Rotating Screen)	321B	212000	Fan-Booster
			75	691056	Washer (Flywheel)	331	691075	Washer (Booster Fan)
			321	691151	Fan-Booster ----- Note ----- 211739 Fan-Booster Used on Type No(s). 0136, 0139, 0140, 0148, 0152, 0163, 0169, 0184, 0199, 0204, 0227, 0228, 0282, 0307, 0319, 0322, 0326, 0328, 0343, 0372, 0376, 0669, 0678, 0697.	332	230674	Nut (Flywheel)
						363	19203	Flywheel Puller
						440	691076	Screw (Booster Fan)
						773	690265	Retainer
						838	211983	Adapter-Blower Housing Ring


★ Included in Engine Gasket Set-Ref. No. 358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set-Ref. No. 1095.



304A



1019 LABEL KIT





REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
304	294698	Housing–Blower ----- Note ----- 297010 Housing–Blower Used on Type No(s). 0060, 0119, 0160, 0197, 0216, 0223, 0237. 297453 Housing–Blower Used on Type No(s). 0020, 0023, 0050, 0136, 0139, 0140, 0145, 0150, 0151, 0152, 0155, 0159, 0175, 0181, 0183, 0191, 0199, 0203, 0204, 0205, 0206, 0208, 0212, 0218, 0219, 0226, 0227, 0228, 0254, 0255, 0259. 391229 Housing–Blower Used on Type No(s). 0027, 0028, 0063, 0115, 0123, 0126, 0135, 0143, 0148, 0149, 0162, 0163, 0165, 0167, 0168, 0170, 0171, 0172, 0174, 0178, 0180, 0182, 0184, 0185, 0188, 0189, 0192, 0193, 0198, 0201, 0209, 0210, 0211, 0213, 0215, 0217, 0221, 0224, 0229, 0230, 0231, 0234, 0235, 0236, 0238,		0248, 0249, 0259, 0251, 0252, 0257, 0261, 0262, 0265, 0271, 0273, 0275, 0276, 0277, 0278, 0279, 0281, 0282, 0283, 0284, 0285, 0286, 0287, 0288, 0296, 0298, 0303, 0304, 0306, 0307, 0309, 0310, 0311, 0315, 0316, 0317, 0318, 0319, 0320, 0321, 0322, 0323, 0324, 0325, 0326, 0328, 0330, 0331, 0332, 0333, 0334, 0337, 0338, 0340, 0343, 0347, 0348, 0349, 0350, 0351, 0353, 0355, 0358, 0359, 0360, 0363, 0364, 0367, 0370, 0371, 0372, 0374, 0375, 0376, 0377, 0378, 0379, 0381, 0382, 0383, 0388, 0389, 0392, 0394, 0399, 0630, 0634, 0636, 0638, 0640, 0643, 0649, 0653, 0654, 0658, 0660, 0661, 0663, 0665, 0666, 0667, 0668, 0669, 0671, 0672, 0673, 0675, 0676, 0678, 0679, 0680, 0684, 0685, 0687, 0688, 0692, 0693, 0697, 0698, 0699,		0701, 0702, 0703, 0704, 0705, 0707, 0708, 0712, 0714, 0715, 0716, 0718, 0720, 0721, 0724, 0725, 0729, 0731, 0733, 0736, 0738, 0741, 0742, 0746, 0748, 0749, 0751, 0752, 0753, 0754, 0760, 0761, 0764, 0765, 0770, 0771, 0772, 0774, 0776, 0779, 0782, 0783, 0784, 0787, 0789, 0797, 2527, 2528, 2563, 2596. 692359 Housing–Blower Used on Type No(s). 0682. 395513 Housing–Blower Used on Type No(s). 0711, 0719, 0732, 0740, 0781, 2529. 399177 Housing–Blower Used on Type No(s). 0758, 0788. 304A 392343 Housing–Blower (Low Profile) Used on Type No(s). 0713, 0744, 0750, 0755, 0759, 0780, 0785, 0786, 2561, 2562. 305 94786 Screw (Blower Housing) 1019 491258 Kit–Label		

★ Included in Engine Gasket Set-Ref. No. 358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set-Ref. No. 1095.

326400 to 326499




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
197	90072	Screw (Back Plate)	452C	691077	Washer (Back Plate)	589	690300	Screw (Armature Bracket)
215	222445	Guide-Air	475	390892	Rectifier	668A	231065	Spacer Used on Type No(s). 0164, 0240.
316	90576	Nut (Back Plate)	488	222211	Bracket-Fuse	685	94896	Screw (Rectifier)
318	94621	Screw (Mounting Bracket)	488A	222345	Bracket-Fuse	727	692338	Cover-Starter Drive
344	690305	Screw (Cable Clamp)	491	222344	Bracket-Rectifier	729	690432	Clip-Wire (Alternator Lead)
367	690305	Screw (Wire Clip)	573	299450	Plate-Back	729A	690588	Clip-Wire
384	90832	Washer (Back Plate)	573A	391220	Plate-Back (Used on Engines With Electric Starter)	732	93410	Screw (Starter Drive Cover)
405	690290	Screw (Back Plate)	587	690389	Clamp-Cable	736	690302	Nut-Clip
452	92864	Washer (Back Plate)	588	211440	Bracket-Armature	895	396691	Switch-Rotary
452A	66154	Washer (Back Plate)	588A	690375	Bracket-Armature (Used on Engines With Electric Starter)			
452B	26404	Washer (Back Plate)						

★ Included in Engine Gasket Set-Ref. No. 358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set-Ref. No. 1095.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
55	691355	Housing-Rewind Starter (Low Profile)	58	66884	Rope-Starter (63\" Long) (For Use With Plastic Pulley)	63	260414	Spring-Ratchet
56	392630	Pulley-Starter (Low Profile)	----- Note -----			64	690511	Adapter-Ratchet Spring (Low Profile)
56A	295871	Pulley-Starter (Wide Legs Starter Housing, Includes 63\" Rope)		66894	Rope-Starter (99\" Long) (Cut to Required Length) (For Use With Plastic Pulley)	64A	281204	Adapter-Ratchet Spring (Wide Legs Starter Housing)
57	490179	Spring-Rewind Starter		66564	Rope-Starter (63\" Long) (For Use With Metal Pulley)	65	94929	Screw (Rewind Starter)
				66574	Rope-Starter (99\" Long) (Cut to Required Length) (For Use With Metal Pulley)	65A	93254	Screw (Rewind Starter)
			59	490653	Insert-Grip	289	230228	Pin-Starter Grip
			60	490652	Grip-Starter Rope	458	69932	Kit-Handle/Rope
			61	68848	Bumper-Starter Pulley (Wide Legs Starter Housing)	592	690276	Nut (Rewind Starter)
						608	392677	Starter-Rewind
						655	222598	Anchor-Rewind Spring
						655A	221014	Anchor-Rewind Spring (Wide Legs Starter Housing)
						678	490817	Spacer-Rewind
						1140	690286	Washer (Rewind Starter)

★ Included in Engine Gasket Set-Ref. No. 358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set-Ref. No. 1095.


326400 to 326499



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
66	393127	Clutch-Starter	69	690271	Washer (Starter Clutch)	70	298799	Ratchet-Clutch
66A	399671	Clutch-Starter (Sealed)	69A	690260	Washer (Starter Clutch)	71	691359	Cover-Ratchet
67	690542	Housing-Clutch	69B	690277	Washer (Starter Clutch)	76	68238	Seal-Ratchet
67A	394897	Housing-Clutch				257	690309	Screw (Starter Clutch)
68	63770	Ball-Clutch						

★ Included in Engine Gasket Set-Ref. No. 358.
 ● Included in Carburetor Overhaul Kit-Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set-Ref. No. 1095.





REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
323	68898	Belt-Vee (For Low Position Mounting)	526	690297	Screw (Regulator)	736A	93593	Nut-Clip
		----- Note -----	575	299139	Switch-Starting	890	221472	Bracket-Support
		68878 Belt-Vee (For High Position Mounting)	606	221442	Strap-Adjusting	1217	92278	Nut (Starting Switch)
361	93415	Screw (Starting Switch)	641	691075	Washer (Starting Switch)			
501	297196	Regulator (Saddle Mount) (Delco Remy No. 1119577)	641A	690282	Washer (Starting Switch)			
			652	93585	Screw (Support Bracket)			
			652A	93142	Screw (Support Bracket)			

★ Included in Engine Gasket Set-Ref. No. 358.
● Included in Carburetor Overhaul Kit-Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set-Ref. No. 1095.

326400 to 326499




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
356	398808	Wire–Stop (Ignition Switch to Breaker Box)	606A	221931	Strap–Adjusting	1152	691105	Nut (Adjusting Strap)
361	93415	Screw (Starting Switch)	641	691075	Washer (Starting Switch)	1215	691075	Washer (Starter Motor Bracket)
493	221933	Bracket–Mounting	641A	690282	Washer (Starting Switch)	1216	691105	Nut (Starter Motor Bracket)
574	295158	Ammeter (Stewart Warner No. 357 W)	795	298590	Switch–Toggle	1217	92278	Nut (Starting Switch)
575	299139	Switch–Starting	840	298561	Kit–Panel (Generator Panel)			
578	298583	Wire Assembly (To Generator Terminal, Regulator and Indicator Light Terminal)	945	211785	Bracket–Starter Motor			
578A	298582	Wire Assembly (Starter Switch to Ignition Switch and “Bat.” on Regulator)	1054	280275	Tie–Cable			
			1142	690303	Screw (Starter Motor Bracket)			
			1142A	91203	Screw (Starter Motor Bracket) (1 3/4" Long)			
			1150	94627	Screw (Adjusting Strap)			
			1151	690282	Washer (Adjusting Strap)			

★ Included in Engine Gasket Set–Ref. No. 358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set–Ref. No. 1095.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
51	★Ø27381	Gasket-Intake	501A	295924	Regulator (Flat Mount) (Delco Remy No. 1118988) Used on Type No(s). 0199.	664	691087	Nut (Key Switch)
51B	★Ø692917	Gasket-Intake				775	690315	Nut (Toggle Switch)
215A	291871	Guide-Air				795A	496590	Switch-Toggle
265	22372	Clamp-Casing				840A	395408	Kit-Panel (Toggle)
267A	93107	Screw (Casing Clamp)						----- Note -----
		----- Note -----	526	690297	Screw (Regulator)			395409 Kit-Panel (Key)
		94882 Screw (Casing Clamp) Used on Type No(s). 0644, 0672.	575	299139	Switch-Starting	892	392833	Switch-Key
478A	395410	Panel	577	690630	Cable-Starter	945	692132	Bracket-Starter Motor
497	94786	Screw (Stopswitch Bracket)	578B	393109	Wire Assembly (Starter Switch to Alternator)	990	392832	Key Set
500	691086	Washer (Key Switch)	578C	690647	Wire Assembly (Starter Switch to Ground Wire Terminal)	1113	94874	Screw (Panel)
						1113A	93415	Screw (Panel)
			621	297472	Switch-Stop	1142	692329	Screw (Starter Motor Bracket)
			627	392884	Bracket-Stopswitch			
			641	691075	Washer (Starting Switch)			

★ Included in Engine Gasket Set-Ref. No. 358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set-Ref. No. 1095.

326400 to 326499










REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
333	395326	Armature-Magneto (Electronic Ignition Without Module)	356A	690650	Wire-Stop (Used With Armature Ref 333A)	636	230783	Nut (Starting Switch)
333A	398811	Armature-Magneto (For Breaker Ignition) (Used After Code Date 81073100).	356B	396585	Wire-Stop Used on Type No(s). 0643, 0646, 0735.	639	★270176	Gasket-Breaker Box
333B	298968	Armature-Magneto (For Breaker Ignition) (Used Before Code Date 81080100).	359	691077	Washer (Ground Terminal)	744	690277	Washer (Breaker Cover)
334	94731	Screw (Magneto Armature)	373	90576	Nut (Ground Terminal)	851	493880	Terminal-Sparkplug
340	26018	Spring-Breaker Arm	375	298185	Breaker-Ignition	888	690295	Screw (Insulator)
343	298060	Condenser	470	93400	Screw (Breaker Cover)	897	394970	Kit-MAGNETRON® Ignition (Used After Code Date 81080100 and Before Code Date 85012200).
345	211327	Cover-Breaker	484	690294	Screw (Condenser)	989B	221976	Stopswitch-Sparkplug
351	690292	Screw (Ground Terminal)	507	690584	Insulator			
351A	690295	Screw (Ground Terminal)	507A	66895	Insulator			
356	398808	Wire-Stop			----- Note -----			
					299598 Insulator Used on Type No(s). 0131.			
			520	691084	Terminal-Ground			
			521	291508	Shield-Cable			

★ Included in Engine Gasket Set-Ref. No. 358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set-Ref. No. 1095.

DUAL CIRCUIT	REGULATED	10,13,16AMP	AC ONLY	DC ONLY
23A	23A	23A	23A	23A
474 	474A 	474C 	474D 	474E 
878 	878C 	878A 	878B 	878A 




NOTE: THE PROPER FLYWHEEL PART NUMBER AND/OR THE ALTERNATOR MAGNET SIZE WILL DETERMINE THE ALTERNATOR TYPE OR OUTPUT. SEE REPAIR INSTRUCTION MANUAL FOR ADDITIONAL INFORMATION

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
474	393474	Alternator	501B	394890	Regulator (10 Amp)	877B	393537	Wire/Connector–Alternator (Tri Circuit)
474A	392595	Alternator	526	690297	Screw (Regulator)	878	393362	Harness–Alternator (Dual Circuit)
474B	393800	Alternator	844	261269	Spring–Diode	878A	393422	Harness–Alternator
474C	393295	Alternator	877	393456	Wire/Connector–Alternator (Dual Circuit)	878B	390867	Harness–Alternator
474D	391595	Alternator	877A	393814	Wire/Connector–Alternator (DC Only)	878C	392606	Harness–Alternator (Tri Circuit)
474E	391529	Alternator				1119	93621	Screw (Alternator)
475A	391507	Rectifier						
481	230976	Bushing–Alternator (Loose)						
486	67125	Fuse (7 1/2 Amp)						
487	390888	Cap–Wire/Fuse						

★ Included in Engine Gasket Set–Ref. No. 358.
● Included in Carburetor Overhaul Kit–Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set–Ref. No. 1095.


326400 to 326499



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
309	396306	Motor-Starter	668B	396515	Spacer	797	92278	Nut (Brush Retainer)
310	691263	Bolt (Starter Motor)	675	225137	Washer (Brush Retainer)	801	394802	Cap-Drive
311	497608	Brush Set	697	94627	Screw (Drive Cap)	802	497607	Cap-End
510	497606	Drive-Starter	727	692338	Cover-Starter Drive	803		Housing-Starter (Served By 396306 Starter Motor Only)
513	398003	Clutch-Drive	732	93410	Screw (Starter Drive Cover)	1051	263080	Ring-Retaining
544		Armature-Starter (Served By 396306 Starter Motor Only)	783	693059	Gear-Pinion	1090	497605	Retainer-Brush

★ Included in Engine Gasket Set-Ref. No. 358.
● Included in Carburetor Overhaul Kit-Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set-Ref. No. 1095.






REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
309A		Motor-Starter (For Replacement Starter Motor, See Ref 309, Previous Page)	503	690406	Strap-Starter	801	394802	Cap-Drive
310A	692329	Bolt (Starter Motor)	510A	495878	Drive-Starter	802A	395537	Cap-End
311A	395538	Brush Set	510B	391461	Drive-Starter	803A	494205	Housing-Starter
442	94929	Screw (Starter Strap)	513	692024	Clutch-Drive	876	495877	Kit-Pinion Spring
			544A	490309	Starter-Armature	896	94288	Pin-Drive Retainer (Copper)
			697	94627	Screw (Drive Cap)	896A	94192	Pin-Drive Retainer (Black)
			773A	391462	Retainer			
			783	693059	Gear-Pinion			

★ Included in Engine Gasket Set-Ref. No. 358.
● Included in Carburetor Overhaul Kit-Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set-Ref. No. 1095.

326400 to 326499



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
7	★272166	Gasket-Cylinder Head	121	394989	Kit-Carburetor Overhaul (Used After Code Date 81090800). ----- Note ----- 391071 Kit-Carburetor Overhaul (Used Before Code Date 81090900).	593A	★270513	Gasket-Bearing Support (.015") ----- Note ----- ★270514 Gasket-Bearing Support (.010") ★270515 Gasket-Bearing Support (.005")
9	★27803	Gasket-Breather	127	●221747	Plug-Welch	598	★270516	Shim-End Play (.009") ----- Note ----- ★270517 Shim-End Play (.007") ★270518 Shim-End Play (.005")
20	★299609	Seal-Oil (PTO Side)	134	●394681	Kit-Needle/Seat	639	★270176	Gasket-Breaker Box
20A	★291675	Seal-Oil (PTO Side)	142	●394730	Nozzle-Carburetor (Labeled B)	883	★272293	Gasket-Exhaust
51	★27381	Gasket-Intake	150	●68667	Gasket-Nozzle	1095	498540	Gasket Set-Valve
51A	★270267	Gasket-Intake	245	★68477	Gasket-Fuel Bowl			
51B	★692917	Gasket-Intake	338	★690270	Gasket-Dipstick			
88	★691310	Gasket-Gear Reduction Cover (Magneto Side)	358	299719	Gasket Set-Engine			
88A	★692914	Gasket-Gear Reduction Cover (PTO Side)	524	★281370	Seal-Dipstick Tube			
94	●292681	Kit-Idle Mixture	569	★27351	Gasket-Engine Base			
102	●270268	Gasket-Carburetor Body	593	★691311	Gasket-Bearing Support			
104	●691775	Pin-Float Hinge						
118	●99525	Valve-High Speed						

★ Included in Engine Gasket Set-Ref. No. 358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

Ø Included in Valve Overhaul Gasket Set-Ref. No. 1095.