



111600

Illustrated Parts List

Model Series

111600

TYPE NUMBERS
0100 through 0176.

TABLE OF CONTENTS


Air Cleaner	6
Blower Housing/Shrouds	7
Camshaft	2
Carburetor	4
Controls	5
Crankshaft	2
Cylinder	2
Cylinder Head	3
Electric Starter	7
Engine Sump	2
Exhaust System	6
Flywheel	7
Flywheel Brake	5
Fuel Supply	4
Governor Spring	5
Ignition	5
Kits/Gaskets Sets	8
Lubrication	2
Piston Group	2
Rewind Starter	7





PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

111600







Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 6237-2 Assemblies include all parts shown in frames. 10/11/2005












914

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 6237-3 Assemblies include all parts shown in frames. 10/11/2005

111600












Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 6237-4 Assemblies include all parts shown in frames. 10/11/2005






Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 6237-5 Assemblies include all parts shown in frames. 10/11/2005



111600



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
6237-6 Assemblies include all parts shown in frames. **10/11/2005**







1036 Emission Label



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 6237-7 Assemblies include all parts shown in frames. 10/11/2005

111600



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
6237-8 Assemblies include all parts shown in frames.

10/11/2005

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	
1	790363	Cylinder Assembly (Used After Code Date 04040400). ----- Note ----- 499678 Cylinder-Assembly (Used Before Code Date 04040500).	20A	★691952	Seal-Oil (PTO Side) (Auxiliary PTO)	28	499423	Pin-Piston	
2	399269	Kit-Bushing/Seal (Magneto Side)	22	691092	Screw (Crankcase Cover/Sump)	29	692671	Rod-Connecting	
3	★299819	Seal-Oil (Magneto Side)	23	696569	Flywheel	32	691664	Screw (Connecting Rod)	
4	493279	Sump-Engine	23A	692693	Flywheel Used on Type No(s). 0156, 0157, 0158, 0159, 0164.	32A	695759	Screw (Connecting Rod) (Used After Code Date 00022000).	
4A	493365	Sump-Engine (Auxiliary PTO)	24	222698	Key-Flywheel	33	499642	Valve-Exhaust	
5	695276	Head-Cylinder	25	790358	Piston Assembly (Standard) ----- Note ----- 499434 Piston Assembly (.010" Oversize)	34	499641	Valve-Intake	
7	★△695166	Gasket-Cylinder Head				35	691304	Spring-Valve (Intake)	
8	495786	Breather Assembly				36	691304	Spring-Valve (Exhaust)	
9	★272481	Gasket-Breather				37	694086	Guard-Flywheel	
10	691125	Screw (Breather Assembly)				40	692194	Retainer-Valve	
11A	499675	Tube-Breather				43	691997	Slinger-Governor/Oil	
12	★692232	Gasket-Crankcase				45	690977	Tappet-Valve	
13	691137	Screw (Cylinder Head)				46	694039	Camshaft (Used After Code Date 99030700). ----- Note ----- 694035 Camshaft (Used Before Code Date 99030800).	
15	691680	Plug-Oil Drain (Square Socket)	26	790360	Ring Set (Standard) (Used After Code Date 05030700). ----- Note ----- 499425 Ring Set (Standard) (Used Before Code Date 05030800). 499426 Ring Set 791324 Ring Set (.020" Oversize) (Used After Code Date 05030700). 499427 Ring Set (.020" Oversize) (Used Before Code Date 05030800). (.010" Oversize) 499428 Ring Set (.030" Oversize)	46A	694038	Camshaft (Used After Code Date 99030700). ----- Note ----- 694034 Camshaft (Used Before Code Date 99030800). 694037 Camshaft (Used After Code Date 99030700). Used on Type No(s). 0135, 0143, 0144, 0148, 0152, 0155, 0163, 0164, 0165, 0166, 0170, 0171. 694033 Camshaft (Used Before Code Date 99030800). Used on Type No(s). 0135, 0143, 0144, 0148, 0152.	
15A	691093	Plug-Oil Drain (Hex Socket)							
16	692676	Crankshaft ----- Note ----- 695264 Crankshaft Used on Type No(s). 0168, 0172, 0176. 692798 Crankshaft Used on Type No(s). 0143, 0145. 692797 Crankshaft Used on Type No(s). 0136, 0148, 0162, 0163. 692795 Crankshaft Used on Type No(s). 0141, 0142, 0159.							
20	★399781	Seal-Oil (PTO Side)	27	691866	Lock-Piston Pin				

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

111600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
51	692668	Gasket-Intake	121	692703	Kit-Carburetor Overhaul	209	690319	Spring-Governor
55	691421	Housing-Rewind Starter	122	692799	Spacer-Carburetor			----- Note -----
58	697316	Rope-Starter (Cut To Required Length)	125	694432	Carburetor (Primer System) (Used After Code Date 99050200).			692906 Spring-Governor
60	281434	Grip-Starter Rope						Used on Type No(s). 0164, 0165, 0171.
65	690837	Screw (Rewind Starter)						691851 Spring-Governor
78	691108	Screw (Flywheel Guard)						Used on Type No(s). 0100, 0139, 0143, 0145, 0155.
83	691778	Shaft-Auxiliary Drive						691292 Spring-Governor
		----- Note -----	125B	694205	Carburetor (Choke System)			Used on Type No(s). 0170, 0172.
		690527 Shaft-Auxiliary Drive (Used on Type No(s). 0143.	127	694468	Plug-Welch			691291 Spring-Governor
95	691636	Screw (Throttle Valve)	127A	691739	Plug-Welch			Used on Type No(s). 0141, 0142, 0144, 0146, 0151, 0157, 0158.
97	499682	Shaft-Throttle	130	691203	Valve-Throttle			
98	398185	Kit-Idle Speed	130A	691181	Valve-Throttle			
101	691623	Pin-Shaft	133	398187	Float-Carburetor			
104	691242	Pin-Float Hinge	134	398188	Kit-Needle/Seat			
108	691182	Valve-Choke	137	693981	Gasket-Float Bowl	211	692434	Spring-Governed Idle
109A	499779	Shaft-Choke	146	690979	Key-Timing			Used on Type No(s). 0164, 0165, 0166, 0171.
117	694250	Jet-Main (Standard) (Used After Code Date 99050200).	187	791766	Line-Fuel (Cut to Required Length) (Used After Code Date 05063000).	217	690354	Spring-Choke Return
		----- Note -----				222C	692618	Bracket-Control
		494870 Jet-Main (Standard) (Used Before Code Date 99050300).						----- Note -----
117A	498978	Jet-Main (Standard)	163A	692667	Gasket-Air Cleaner			692617 Bracket-Control
118	497466	Jet-Main (High Altitude) (Used After Code Date 99050200).	188	691147	Screw (Control Bracket)			Used on Type No(s). 0100, 0101, 0105, 0135, 0136, 0139, 0143, 0145, 0148, 0162, 0163, 0164, 0168, 0169, 0172, 0174, 0175, 0176.
		----- Note -----	190	690940	Screw (Fuel Tank)	222G	692722	Bracket-Control
		497315 Jet-Main (High Altitude) (Used Before Code Date 99050300).	192	694543	Adjuster-Rocker Arm			Used on Type No(s). 0165, 0166, 0171.
118A	497466	Jet-Main (High Altitude)	202	691303	Link-Mechanical Governor	227	691467	Lever-Governor Control
						238	691300	Cap-Valve
						259	691189	Bracket-Casing Clamp
						265	690798	Clamp-Casing
						267	691044	Screw (Casing Clamp)

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
268	691072	Casing-Control Wire (Cut To Required Length)	365	691136	Screw (Carburetor)	615	690340	Retainer-Governor Shaft
269	691026	Wire-Control (Cut To Required Length)	374	691074	Washer (Camshaft)	616	698801	Crank-Governor
270	691027	Nut (Control Wire Casing)	383	19374	Wrench-Spark Plug	619	691108	Screw (Cylinder Head Plate)
271	691028	Lever-Control	404	690272	Washer (Governor Crank)	621	692310	Switch-Stop
276	◆271716	Washer-Sealing (Main Jet)	425A	690244	Screw (Air Cleaner Cover)	633	◆693867	Seal-Choke/Throttle Shaft
287	690940	Screw (Dipstick Tube)	443B	690255	Screw (Air Cleaner Primer Base)	633A	◆691321	Seal-Choke/Throttle Shaft
300	694248	Muffler (Used After Code Date 99030700).	445A	697029	Filter-Air Cleaner Cartridge	635	66538	Boot-Spark Plug
		----- Note -----	455	695161	Cup-Flywheel	651	691660	Screw (Starter Gear Cover)
		692275 Muffler (Used Before Code Date 99030800).	456	692299	Plate-Pawl Friction	670	692294	Spacer-Fuel Tank
300B	699769	Muffler	459	281505	Ratchet-Pawl	676	397931	Deflector-Muffler
304	499677	Housing-Blower ----- Note -----	474	691991	Alternator	676D	697915	Deflector-Muffler
		695976 Housing- Blower Used on Type No(s). 0175.	505	691251	Nut (Governor Control Lever)	677	690661	Screw (Muffler Deflector)
		499676 Housing- Blower Used on Type No(s). 0141, 0151, 0156, 0159, 0164.	510	494147	Drive-Starter	684	690345	Screw (Breather Passage Cover)
305	691108	Screw (Blower Housing)	513	692358	Clutch-Drive	689	691855	Spring-Friction
306	691232	Shield-Cylinder	523	499621	Dipstick	697	691127	Screw (Drive Cap)
307	690345	Screw (Cylinder Shield)	524	★692296	Seal-Dipstick Tube	715	691147	Screw (Shaft Stop)
309	695550	Motor-Starter	525	495265	Tube-Dipstick	718	690959	Pin-Locating
310	692327	Bolt (Cylinder Shield)	529	692937	Grommet	721	690449	Stop-Shaft
332	690662	Nut (Flywheel)	544	690786	Armature-Starter	741	790345	Gear-Timing (Use Without Woodruff Key)
333	802574	Armature-Magneto	545	492919	Washer Set (Starter Motor)			----- Note -----
334	691061	Screw (Magneto Armature)	562	691119	Bolt (Governor Control Lever)	742	93941	Retainer-E Ring
337	692051	Plug-Spark	584	697734	Cover-Breather Passage	743	690516	Gear-Drive (Clockwise)
356	692390	Wire-Stop	585	★691879	Gasket-Breather Passage			----- Note -----
358	694090	Gasket Set-Engine	592	690800	Nut (Rewind Starter)			691772 Gear-Drive (Counterclockwise) Used on Type No(s). 0135, 0143, 0144, 0148, 0152, 0155, 0163, 0164, 0165, 0166, 0170, 0171.
363	19069	Puller-Flywheel	597	691696	Screw (Pawl Friction Plate)			
			601	95162	Clamp-Hose			
			601A	691038	Clamp-Hose			
			608	497680	Starter-Rewind			
			613	691108	Screw (Muffler)			
			613A	691140	Screw (Muffler)			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

111600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
745	691648	Screw (Brake)	847	692047	Dipstick/Tube Assembly	977	692704	Gasket Set-Carburetor
783	691918	Gear-Pinion	851	493880	Terminal-Spark Plug	993	★△694088	Gasket-Cylinder Head Plate
783A	691269	Gear-Pinion	868	★△692044	Seal-Valve	1005	691346	Fan-Flywheel
784	692341	Cover-Starter Gear	883	★△691893	Gasket-Exhaust	1019	695811	Kit-Label
785	692352	Gasket-Starter Cover	886	696268	Gasket Kit-Cylinder Head/Plate	1022	★△691890	Gasket-Rocker Cover
789	696547	Harness-Wiring (Used After Code Date 00040600). ----- Note ----- 691372 Harness- Wiring (Used Before Code Date 00040700).	910	691094	Stud (Alternator)	1023	499624	Cover-Rocker
			914	691108	Screw (Rocker Cover)	1026	692045	Rod-Push
			921A	699633	Cover-Blower Housing	1029	691230	Arm-Rocker
			922	691831	Spring-Brake	1034	691343	Guide-Push Rod
789A	696546	Harness-Wiring (Used After Code Date 00040600). ----- Note ----- 690790 Harness- Wiring (Used Before Code Date 00040700).	923	691994	Brake	1036		Label-Emission (Available From An Authorized Briggs & Statton Sevice Dealer)
			930	691919	Guard-Rewind	1058	276348	Manual-Owner's
			935	499421	Switch-Interlock	1059	692311	Kit-Screw/Washer
			937	691325	Spline-Starter	1095	694091	Gasket Set-Valve
			957	692046	Cap-Fuel Tank (Plastic)	1102	691255	Pilot-Guide
			958	698183	Valve-Fuel Shutoff (Plastic)	1102A	691266	Pilot-Guide
801	690782	Cap-Drive	966B	690243	Base-Air Cleaner Primer	1119	692979	Screw (Alternator)
802	695975	Cap-End	967A	273356	Filter-Pre Cleaner	1160	691627	Screw (Interlock Switch)
803	695975	Housing-Starter	968A	691342	Cover-Air Cleaner	1210	498144	Pulley/Spring Assembly
830	694544	Stud-Rocker Arm	968B	692435	Cover-Air Cleaner			(Pulley)
832	691466	Guard-Muffler	969	691138	Screw (Blower Housing Cover)	1211	498144	Pulley/Spring Assembly (Spring)
832C	695593	Guard-Muffler				1330	272147	Manual-Repair
836	691147	Screw (Muffler Guard)	972	699374	Tank-Fuel (Plastic)			
836A	697551	Screw (Muffler Guard)	975	493640	Bowl-Float			
842	★691031	Seal-O Ring (Dipstick Tube)	976	694395	Primer-Carburetor			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.