



121200

Illustrated Parts List

Model Series

121200

TYPE NUMBERS
0101 through 0121.

TABLE OF CONTENTS

Air Cleaner	5
Blower Housing	6
Camshaft	2
Carburetor	4
Controls	5
Crankcase Cover	2
Crankshaft	2
Cylinder	2
Cylinder Head	3
Electric Starter	6
Exhaust System	5
Flywheel	6
Fuel Supply	5
Gear Reduction	6
Governor Spring	5
Ignition	5
Kits/Gaskets - Carburetor	4
Kits/Gaskets - Engine	2
Kits/Gaskets - Valve	3
Lubrication	2
Piston Group	2
Rewind Starter	6














PRINTED IN U.S.A.




COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

121200

- 1019 LABEL KIT
- 1058 OWNER'S MANUAL
- 1330 REPAIR MANUAL







Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 3244-2 Assemblies include all parts shown in frames. 11/02/2005




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 3244-3 Assemblies include all parts shown in frames.

11/02/2005

121200




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

121200



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	699510	Cylinder Assembly	22	699478	Screw (Crankcase Cover/ Sump)	27	691866	Lock-Piston Pin
2	399269	Kit-Bushing/Seal (Magneto Side)				28	499423	Pin-Piston
3	★299819S	Seal-Oil (Magneto Side)	23	699488	Flywheel ----- Note -----	29	690124	Rod-Connecting
5	699486	Head-Cylinder		699514	Flywheel Used on Type No(s). 0118.	30	692562	Dipper-Connecting Rod
7	★∅698210	Gasket-Cylinder Head	24	222698S	Key-Flywheel	32	691664	Screw (Connecting Rod)
11	692600	Tube-Breather (Flat Panel Air Cleaner)	25	792004	Piston Assembly (Standard) (Used After Code Date 05030800).	32A	695759	Screw (Connecting Rod)
11A	693647	Tube-Breather (High Mount Air Cleaner)				33	499642	Valve-Exhaust
12	★699485	Gasket-Crankcase				34	499641	Valve-Intake
13	699482	Screw (Cylinder Head)		499627	Piston Assembly (Standard) (Used Before Code Date 05030900).	35	691304	Spring-Valve (Intake)
15	691686	Plug-Oil Drain (Square Head)		791325	Piston Assembly (.020" Oversize) (Used After Code Date 05030800).	36	691304	Spring-Valve (Exhaust)
15A	691682	Plug-Oil Drain (Flush)		692789	Piston Assembly (.020" Oversize) (Used Before Code Date 05030900).	37	699661	Guard-Flywheel
16	699451	Crankshaft ----- Note ----- 699445 Crankshaft Used on Type No(s). 0112. 699444 Crankshaft Used on Type No(s). 0117. 699447 Crankshaft Used on Type No(s). 0119. 699443 Crankshaft Used on Type No(s). 0101, 0120.	26	791969	Ring Set (Standard) (Used After Code Date 05030800). ----- Note -----	40	692194	Retainer-Valve
17	692517	Bearing-Ball		499631	Ring Set (Standard) (Used Before Code Date 05030900).	45	690977	Tappet-Valve
18	699804	Cover-Crankcase Used on Type No(s). 0110, 0112, 0113, 0117, 0119, 0121.		791324	Ring Set (.020" Oversize) (Used After Code Date 05030800).	46	693404	Camshaft
18A	699672	Cover-Crankcase Used on Type No(s). 0101, 0111, 0115, 0118, 0120.		692786	Ring Set (.020" Oversize) (Used Before Code Date 05030900).	51	★◆∅692555	Gasket-Intake
20	★692550	Seal-Oil (PTO Side)				55	691422	Housing-Rewind Starter
21	281658S	Cap-Oil Fill				58	693389	Rope-Starter (Cut to Required Length)
						59	490653	Grip-Insert
						60	490652	Grip-Starter Rope (2 Piece)
						65	699228	Screw (Rewind Starter)
						78	699205	Screw (Flywheel Guard)
						79	694511	Case-Gear Reduction
						82	690369	Screw (Gear Reduction Case)
						82A	790197	Screw (Gear Reduction Case)
						83	690374	Shaft-Auxiliary Drive
						84	691121	Plug-Breather
						85	692551	Screw (Gear Cover to Gear Reduction)
						86	690608	Cover-Gear
						87	691582	Seal-Gear Reduction
						88	691600	Gasket-Gear Reduction Cover

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

121200

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
95	691636	Screw (Throttle Valve)	155	★698214	Plate-Cylinder Head	219	693578	Gear-Governor
97	690024	Shaft-Throttle	161	699207	Base-Air Cleaner (Flat Panel Air Cleaner)	220	691724	Washer (Governor Gear)
98	398185	Kit-Idle Speed (Carburetor)	163★◆696024		Gasket-Air Cleaner (Flat Panel Air Cleaner)	222	699589	Bracket-Control
104	◆691242	Pin-Float Hinge				222A	699493	Bracket-Control
108	692567	Valve-Choke				227	692573	Lever-Governor Control
109	690023	Shaft-Choke	163A★◆696979		Gasket-Air Cleaner (High Mount)	238	691300	Valve-Cap
109A	693628	Shaft-Choke				240A	298090S	Filter-Fuel
109C	790624	Shaft-Choke	186	692317	Connector-Hose	265	691024	Clamp-Casing
117	697355	Jet-Main ----- Note ----- 498975 Jet-Main (Standard) Used on Type No(s). 0119.	187	791766	Line-Fuel (Cut to Required Length) (Used After Code Date 05063000).	267	699492	Screw (Casing Clamp)
118	494870	Jet-Main ----- Note ----- 497466 Jet-Main (High Altitude) Used on Type No(s). 0119.				268	691025	Casing-Control Wire (72" Long) (Cut to Required Length)
121	696998	Kit-Carburetor Overhaul	187A	791867	Line-Fuel (Molded) (Used After Code Date 05063000).	269	691026	Wire-Control (78" Long) (Cut to Required Length)
122	★◆693749	Spacer-Carburetor				270	691027	Nut (Control Wire Casing)
125	697354	Carburetor Used on Type No(s). 0101, 0111, 0112, 0113, 0115, 0117, 0118, 0120. ----- Note ----- 697028 Carburetor Used on Type No(s). 0110, 0121. 698859 Carburetor Used on Type No(s). 0119.				271	691028	Lever-Control
127	◆691739	Plug-Welch				271A	694256	Lever-Control
127B	691585	Plug-Welch				276	◆271716	Washer-Sealing
130	691181	Valve-Throttle	188	699479	Screw (Control Bracket)	281	699639	Panel-Control
130A	691203	Valve-Throttle Used on Type No(s). 0119.	190	699220	Screw (Fuel Tank)	286	698611	Module-Oil Sensor
133	398187	Float-Carburetor	192	694543	Adjuster-Rocker Arm	287	699629	Screw (Dipstick Tube)
134	◆398188	Kit-Needle/Seat	209	692571	Spring-Governor Used on Type No(s). 0101, 0111, 0115, 0117, 0118, 0119, 0120. ----- Note ----- 693206 Spring- Governor Used on Type No(s). 0110, 0112, 0113, 0121.	300	693593	Muffler
137	◆◆693981	Gasket-Float Bowl				304	699598	Housing-Blower
146	690979	Key-Timing	209A	691278	Spring-Governor	305	699480	Screw (Blower Housing)
						306	693610	Shield-Cylinder
						307	699483	Screw (Cylinder Shield)
						309	694504	Motor-Starter
						310	690323	Screw (Starter Motor)
						311	497608	Brush Set
						317	695494	Cover-Starter
						332	699359	Nut (Flywheel)
						333	695711	Armature-Magneto
						334	699477	Screw (Magneto Armature)

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

⊘ Included in Valve Gasket Set-Ref. No.1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
337	491055	Plug-Spark (Resistor)	564	699491	Screw (Control Cover)	783	692353	Gear-Pinion
		----- Note -----	564A	699492	Screw (Control Cover)	797	691029	Nut (Brush Retainer)
		691043 Plug-Spark (EMS)	597	691696	Screw (Pawl Friction Plate)	799	699202	Screw (Oil Sensor)
347	697854	Switch-Rocker	601	95162S	Clamp-Hose	801	694482	Cap-Drive
356	693651	Wire-Stop	604	697326	Cover-Control	802	691286	Cap-End
356A	692390	Wire-Stop	608	693394	Starter-Rewind	803	693757	Housing-Starter
356B	692602	Wire-Stop	613	699209	Screw (Muffler)	830	694544	Stud-Rocker Arm
356C	695630	Wire-Stop	615	692576	Retainer-Governor Shaft	832	693583	Guard-Muffler
358	699638	Gasket Set-Engine	616	692547	Crank-Governor	836	699203	Screw (Muffler Guard)
363	19069	Puller-Flywheel	619	699230	Screw (Cylinder Head Plate)	836A	699632	Screw (Muffler Guard)
364	695693	Terminal-Oil Plug	621	692310	Switch-Stop	842	691031	Seal-O Ring (Dipstick Tube)
365	699484	Screw (Carburetor)	632	693408	Spring/Link-Mechanical Governor	847	693617	Dipstick/Tube Assembly
383	19374S	Wrench-Spark Plug	633	◆693867	Seal-Choke/Throttle Shaft	851	493880S	Terminal-Spark Plug
415	693463	Plug	633A	◆691321	Seal-Choke/Throttle Shaft	868	★∅692044	Seal-Valve
425	699208	Screw (Air Cleaner Cover)	635	692076	Boot-Spark Plug	875	697030	Base-Air Cleaner (High Mount)
427	694255	Nut (Control Bracket)	663	699206	Screw (Control Panel)	883	★691893	Gasket-Exhaust
445	491588S	Filter-Air Cleaner Cartridge (Flat Panel)	668	694257	Spacer	914	699481	Screw (Rocker Cover) (Bottom)
445A	697029	Filter-Air Cleaner Cartridge (High Mount)	675	691261	Washer (Brush Retainer)	914A	692557	Screw (Rocker Cover) (Top)
455	692591	Cup-Flywheel	676	393757	Deflector-Muffler	914B	697551	Screw (Rocker Cover) (Center)
456	692299	Plate-Pawl Friction	677	690661	Screw (Muffler Deflector)	957	694261	Cap-Fuel Tank
459	281505S	Pawl-Ratchet	689	691855	Spring-Friction	958	698180	Valve-Fuel Shut Off
467	691668	Knob-Air Cleaner	692	690572	Spring-Detent	961	698304	Screw (Air Cleaner Bracket)
474	695730	Alternator	697	790537	Screw (Starter Motor)	967	493537S	Filter-Pre Cleaner (Flat Panel)
504	694254	Washer Set-Friction	717	693462	Bracket-Air Cleaner	967A	273356S	Filter-Pre Cleaner (High Mount)
505	691251	Nut (Governor Control Lever)	718	690959	Pin-Locating	968	692584	Cover-Air Cleaner (Flat Panel Air Cleaner)
510	499308	Drive-Starter	727	698039	Cover-Starter Drive	968A	693460	Cover-Air Cleaner (High Mount)
513	692024	Drive-Clutch	732	699200	Screw (Starter Drive Cover)			
523	693618	Dipstick	741	695087	Gear-Timing			
524	281370S	Seal-Dipstick Tube	742	692564	Retainer-E Ring			
544	692966	Armature-Starter	746	692566	Gear-Idler			
552	692346	Bushing-Governor Crank	773	694258	Retainer			
562	691119	Bolt (Governor Control Lever)						

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

121200

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
971	690370	Screw (Air Cleaner Base)	1023	499924	Cover-Rocker Arm	1090	691293	Retainer-Brush
971A	690349	Screw (Air Cleaner Base)	1026	790287	Rod-Push	1095	698215	Gasket Set-Valve
971B	699629	Screw (Air Cleaner Base)	1029	691230	Arm-Rocker	1119	699772	Screw (Alternator)
972	694260	Tank-Fuel	1034	691343	Guide-Push Rod	1210	498144	Pulley/Spring Assembly (Pulley)
975	493640	Bowl-Float	1036		Label-Emission (Available From An Authorized Briggs & Statton Sevice Dealer)	1211	498144	Pulley/Spring Assembly (Spring)
977	697001	Gasket Set-Carburetor	1051	691265	Ring-Retaining	1305	699691	Screw (Oil Sensor Module)
993	Ø694088	Gasket-Cylinder Head Plate	1052	790141	Sensor-Oil	1330	272147	Repair Manual
1005	692592	Fan-Flywheel	1054	280275	Cable-Tie			
1019	694852	Kit-Label	1058	276355	Owner's Manual			
1022	★Ø691890	Gasket-Rocker Cover	1070	699201	Screw (Flywheel Fan)			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

Ø Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.