



# 127H00

## Illustrated Parts List

### Model Series

# 127H00

TYPE NUMBERS  
0110 through 0112.

### TABLE OF CONTENTS


- Air Cleaner** ..... 4
- Alternator** ..... 4
- Blower Housing/Shrouds** ..... 5
- Camshaft** ..... 2
- Carburetor** ..... 3
- Controls** ..... 4
- Crankshaft** ..... 2
- Cylinder** ..... 2
- Electric Starter** ..... 5
- Electrical** ..... 4
- Engine Sump** ..... 2
- Exhaust System** ..... 4
- Flywheel** ..... 5
- Fuel Supply** ..... 3
- Governor Spring** ..... 4
- Ignition** ..... 4
- Kits/Gaskets** ..... 2 & 3
- Lubrication** ..... 2
- Piston Group** ..... 2
- Rewind Starter** ..... 5
- Valves** ..... 2



PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION  
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

# 127H00



1019 LABEL KIT  
 1058 OWNER'S MANUAL  
 1330 REPAIR MANUAL

1095 VALVE GASKET SET






358 ENGINE GASKET KIT

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

3241-2


Assemblies include all parts shown in frames.

10/05/2005







Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
 3241-3 Assemblies include all parts shown in frames. 10/05/2005

# 127H00



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
 3241-4 Assemblies include all parts shown in frames. 10/05/2005



1036 EMISSION LABEL

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
 3241-5 Assemblies include all parts shown in frames. 10/05/2005

# 127H00

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	697322	Cylinder Assembly	26	790360	Ring Set (Standard)	95	691636	Screw (Throttle Valve)
2	399269	Kit-Bushing/Seal (Magneto Side)			----- <b>Note</b> -----	97	696565	Shaft-Throttle
3	★299819	Seal-Oil (Magneto Side)			<b>791324</b> Ring Set (.020" Oversize)	104	●691242	Pin-Float Hinge
4	493279	Sump-Engine			(Used After Code Date 04102100).	117	498978	Jet-Main (Standard)
5	691160	Head-Cylinder			<b>499427</b> Ring Set (.020" Oversize)	118	497466	Jet-Main (High Altitude)
7	★∅692249	Gasket-Cylinder Head			(Used Before Code Date 04102200).	121	498260	Kit-Carburetor Overhaul
8	695250	Breather Assembly	27	691866	Lock-Piston Pin	125	498170	Carburetor (Primer System)
9	★∅696125	Gasket-Breather	28	499423	Pin-Piston (Standard)	127	●694468	Plug-Welch
10	691125	Screw (Breather Assembly)	29	499424	Rod-Connecting (Standard)	130	696564	Valve-Throttle
11	691781	Tube-Breather	32	691664	Screw (Connecting Rod)	133	398187	Float-Carburetor
12	★692232	Gasket-Crankcase	32A	695759	Screw (Connecting Rod)	134	●398188	Kit-Needle/Seat
13	690912	Screw (Cylinder Head)	33	262651	Valve-Exhaust	137	◆693981	Gasket-Float Bowl
15	691680	Plug-Oil Drain (Square Socket)	34	262652	Valve-Intake	146	690979	Key-Timing
16	691452	Crankshaft Used on Type No(s) 0110.	35	691270	Spring-Valve (Intake)	159	691753	Bracket-Air Cleaner Primer
		----- <b>Note</b> -----	36	691270	Spring-Valve (Exhaust)	163	★◆272653	Gasket-Air Cleaner
		<b>691451</b> Crankshaft Used on Type No(s) 0111, 0112.	37	694086	Guard-Flywheel	187	791766	Line-Fuel (Cut to Required Length) (Used After Code Date 05063000).
20	★399781	Seal-Oil (PTO Side)	40	692194	Retainer-Valve			----- <b>Note</b> -----
22	691092	Screw (Crankcase Cover/Sump)	43	691997	Slinger-Governor/Oil			<b>691050</b> Line-Fuel (Cut to Required Length) (Used Before Code Date 05070100).
23A	691992	Flywheel	45	690548	Tappet-Valve	187A	791873	Line-Fuel (Molded) (Used After Code Date 05063000).
24	222698	Key-Flywheel	46	691449	Camshaft			----- <b>Note</b> -----
25	790359	Piston Assembly (Standard)	50	497465	Manifold-Intake			<b>691371</b> Line-Fuel (Molded) (Used Before Code Date 05070100).
		----- <b>Note</b> -----	51	★272199	Gasket-Intake	188	693399	Screw (Control Bracket)
		<b>791326</b> Piston Assembly (.020" Oversize) (Used After Code Date 04102100).	54	691650	Screw (Intake Manifold)	190	690940	Screw (Fuel Tank)
		<b>697341</b> Piston Assembly (.020" Oversize) (Used Before Code Date 04102200).	55	691421	Housing-Rewind Starter			
			58	697316	Rope-Starter (Cut To Required Length)			
			60	281434	Grip-Starter Rope			
			65	690837	Screw (Rewind Starter)			
			78	691108	Screw (Flywheel Guard)			
			81	691740	Lock-Muffler Screw			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

*Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.*

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
202	691829	Link-Mechanical Governor	383	89838	Wrench-Spark Plug	615	690340	Retainer-Governor Shaft
209B	691291	Spring-Governor	404	690272	Washer (Governor Crank)	616	698801	Crank-Governor
222	790143	Bracket-Control (Remote/Manual Friction)(Primer)	425A	690670	Screw (Air Cleaner Cover)	617★◆	270344	Seal-O Ring (Intake Manifold)
227	690783	Lever-Governor Control	443A	692523	Screw (Air Cleaner Primer Base)	621	692310	Switch-Stop
265	690798	Clamp-Casing	445A	491588	Filter-Air Cleaner Cartridge	633	◆691321	Seal-Choke/Throttle Shaft
267	691044	Screw (Casing Clamp)	455	695161	Cup-Flywheel	635	66538	Boot-Spark Plug
268	691072	Casing-Control Wire (Cut to Required Length)	456	692299	Plate-Pawl Friction	651	690345	Screw (Starter Gear Cover)
269	691026	Wire-Control (Cut to Required Length)	459	281505	Plate-Ratchet	668	★493823	Spacer
270	691027	Nut (Control Wire Casing)	474	691991	Alternator	670	692294	Spacer-Fuel Tank
271	691028	Lever-Control	505	691251	Nut (Governor Control Lever)	676A	393756	Deflector-Muffler
276	◆271716	Washer-Sealing (Main Jet)	510	494147	Drive-Starter	676E	393760	Deflector-Muffler
287	690940	Screw (Dipstick Tube)	513	692358	Clutch-Drive	677	690661	Screw (Muffler Deflector)
300	692038	Muffler (Super Lo Tone)	523	495264	Dipstick	684	690345	Screw (Breather Passage Cover)
304A	493294	Housing-Blower	524	★692296	Seal-Dipstick Tube	689	691855	Spring-Friction
305	691108	Screw (Blower Housing)	525	495265	Tube-Dipstick	697	691127	Screw (Drive Cap)
306	690450	Shield-Cylinder	529	691923	Grommet	703	696309	Clip
307	690345	Screw (Cylinder Shield)	544	690786	Armature-Starter	718	690959	Pin-Locating
309	695550	Motor-Starter	545	492919	Washer Set (Starter Motor)	741	790345	Gear-Timing (Use Without Woodruff Key)
310	692327	Bolt (Starter Motor)	562	92613	Bolt (Governor Control Lever)	----- <b>Note</b> -----		
332	690662	Nut (Flywheel)	563	691138	Screw (Debris Guard Screen)	742	93941	Retainer-E Ring
333	802574	Armature-Magneto	564	690664	Screw (Control Cover)	783	691918	Gear-Pinion
334	691061	Screw (Magneto Armature)	584	697734	Cover-Breather Passage	783A	691269	Gear-Pinion
337	802592	Plug-Spark	585	★691879	Gasket-Breather Passage	784	692341	Cover-Starter Gear
356	692390	Wire-Stop	592	690800	Nut (Rewind Starter)	785	692352	Gasket-Starter Cover
358	497316	Gasket Set-Engine	597	691696	Screw (Pawl Friction Plate)	801	690782	Cap-Drive
363	19069	Flywheel Puller	601	95162	Clamp-Hose	802	695267	Cap-End
365	691688	Screw (Carburetor)	604	691757	Cover-Control	803	695266	Housing-Starter
			608	497680	Starter-Rewind	842	★691031	Seal-O Ring (Dipstick Tube)
			613	691340	Screw (Muffler)	847	692047	Dipstick/Tube Assembly
						851	493880	Terminal-Spark Plug
						868	697338	Seal-Valve

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

*Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.*

# 127H00

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
869	691155	Seat-Valve (Intake)	957	397974	Cap-Fuel Tank (Plastic)	1036		Label-Emission (Available From An Authorized Briggs & Stratton Service Dealer)
870	690380	Seat-Valve (Exhaust)	966A	496116	Base-Air Cleaner Primer	1058	276171	Manual-Owner's
871	262001	Bushing-Valve Guide (Exhaust)	967A	493537	Filter-Pre Cleaner	1059	692311	Kit-Screw/Washer
		----- <b>Note</b> -----	968B	692298	Cover-Air Cleaner	1095	498528	Gasket Set-Valve
	63709	Bushing-Valve Guide (Intake)	970	691669	Screw (Air Cleaner Primer Bracket)	1119	691648	Screw (Alternator)
883	∅691881	Gasket-Exhaust	972B	699374	Tank-Fuel (Plastic)	1210	498144	Pulley/Spring Assembly (Pulley)
910	691094	Stud (Alternator)	975	493640	Bowl-Float	1211	498144	Pulley/Spring Assembly (Spring)
925	690595	Cover-Linkage	976	694395	Primer-Carburetor	1229	696308	Extension-Blower Housing
937	691325	Spline-Starter	977	498261	Gasket Set-Carburetor	1330	270962	Manual-Repair
949	696306	Guard-Debris Screen	997	696310	Shield-Debris			
			1005	691346	Fan-Flywheel			
			1019	696438	Kit-Label			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

∅ Included in Valve Gasket Set-Ref. No 1095.

*Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.*