



12E600

Illustrated Parts List

Model Series

12E600

TYPE NUMBERS
0135.

TABLE OF CONTENTS


Air Cleaner	5
Blower Housing/Shrouds	6
Camshaft	2
Carburetor	4
Controls	5
Crankshaft	2
Cylinder	2
Cylinder Head	3
Engine Sump	2
Exhaust System	5
Flywheel	6
Flywheel Brake	5
Fuel Supply	4
Governor Spring	5
Ignition	5
Lubrication	2
Piston Group	2
Rewind Starter	6






PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

12E600







Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
3246-2 Assemblies include all parts shown in frames. 10/12/2005















Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 3246-3 Assemblies include all parts shown in frames. 10/12/2005

12E600







Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 3246-4 Assemblies include all parts shown in frames. 10/12/2005



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 3246-5 Assemblies include all parts shown in frames. 10/12/2005

12E600



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
3246-6 Assemblies include all parts shown in frames. 10/12/2005

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	790363	Cylinder Assembly	35	691304	Spring-Valve (Intake)	146	690979	Key-Timing
2	399269	Kit-Bushing/Seal (Magneto Side)	36	691304	Spring-Valve (Exhaust)	163A	◆◆692667	Gasket-Air Cleaner
3	★299819	Seal-Oil (Magneto Side)	37	694086	Guard-Flywheel	187	791766	Line-Fuel (Cut to Required Length)
4	493279	Sump-Engine	40	692194	Retainer-Valve			(Used After Code Date 05063000).
5	695276	Head-Cylinder	43	691997	Slinger-Governor/Oil			----- Note -----
7	★△695166	Gasket-Cylinder Head	45	690977	Tappet-Valve			691050 Line-Fuel (Cut to Required Length)
8	495786	Breather Assembly	46	694039	Camshaft			(Used Before Code Date 05070100).
9	★272481	Gasket-Breather	51	◆◆692668	Gasket-Intake			
10	691125	Screw (Breather Assembly)	55	691421	Housing-Rewind Starter			
11	499675	Tube-Breather	58	697316	Rope-Starter (Cut To Required Length)	188	691147	Screw (Control Bracket)
12	★692232	Gasket-Crankcase	60	281434	Grip-Starter Rope	190	690940	Screw (Fuel Tank)
13	691137	Screw (Cylinder Head)	65	690837	Screw (Rewind Starter)	192	694543	Adjuster-Rocker Arm
15	691680	Plug-Oil Drain (Square Socket)	73	691222	Screen-Rotating	202	691303	Link-Mechanical Governor
16	691456	Crankshaft	78	691108	Screw (Flywheel Guard)	209A	691291	Spring-Governor
20	★399781	Seal-Oil (PTO Side)	95	691636	Screw (Throttle Valve)	222B	692672	Bracket-Control
22	691092	Screw (Crankcase Cover/Sump)	97	499682	Shaft-Throttle (Metal)	227	691467	Lever-Governor Control
23	696569	Flywheel			----- Note -----	238	691300	Cap-Valve
24	222698	Key-Flywheel			790121 Shaft-Throttle (Plastic)	265	690798	Clamp-Casing
25	792004	Piston Assembly (Standard)	104	◆691242	Pin-Float Hinge	267	691044	Screw (Casing Clamp)
		----- Note -----	117	498981	Jet-Main (Standard)	268	691025	Casing-Control Wire (Cut To Required Length)
		791325 Piston Assembly (.020" Oversize)	118	497466	Jet-Main (High Altitude)	269	691026	Wire-Control (Cut To Required Length)
26	791969	Ring Set (Standard)	121	692703	Kit-Carburetor Overhaul	270	691027	Nut (Control Wire Casing)
		----- Note -----	122	◆◆692799	Spacer-Carburetor	271	691028	Lever-Control
		791324 Ring Set (.020" Oversize)	125	790120	Carburetor	276	◆◆271716	Washer-Sealing
27	691866	Lock-Piston Pin	127	◆694468	Plug-Welch	287	690940	Screw (Dipstick Tube)
28	499423	Pin-Piston	130	691203	Valve-Throttle			----- Note -----
29	499424	Rod-Connecting			696564 Valve-Throttle (Used With Plastic Throttle Shaft)	300	694248	Muffler
32	691664	Screw (Connecting Rod)	133	398187	Float-Carburetor	304	695976	Housing-Blower
32A	695759	Screw (Connecting Rod)	134	◆398188	Kit-Needle/Seat	305	691108	Screw (Blower Housing)
33	499642	Valve-Exhaust	137	◆◆693981	Gasket-Float Bowl	306	691232	Shield-Cylinder
34	499641	Valve-Intake				307	690345	Screw (Cylinder Shield)

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

12E600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
332	690662	Nut (Flywheel)	597	691696	Screw (Pawl Friction Plate)	883	*Δ691893	Gasket-Exhaust
333	802574	Armature-Magneto	601	95162	Clamp-Hose	886	696268	Gasket Kit-Cylinder Head/Plate
334	691061	Screw (Magneto Armature)	604	791054	Cover-Control	914	691108	Screw (Rocker Cover)
337	692051	Plug-Spark (Resistor)	608	497680	Starter-Rewind	921A	699633	Cover-Blower Housing
356	692390	Wire-Stop	613	691108	Screw (Muffler)	922	692135	Spring-Brake
358	694090	Gasket Set-Engine	613A	691140	Screw (Muffler)	923	695891	Brake
363	19069	Puller-Flywheel	615	690340	Retainer-Governor Shaft	957	692046	Cap-Fuel Tank (Plastic)
365	691136	Screw (Carburetor)	616	698801	Crank-Governor	966	692673	Base-Air Cleaner Primer
383	19374	Wrench-Spark Plug	619	691108	Screw (Cylinder Head Plate)	967	493537	Filter-Pre Cleaner
404	690272	Washer (Governor Crank)	621	692310	Switch-Stop	968	692298	Cover-Air Cleaner
443	692523	Screw (Air Cleaner Primer Base)	633A◆	691321	Seal-Choke/Throttle Shaft (Throttle Shaft)	969	691138	Screw (Blower Housing Cover)
443A	691637	Screw (Air Cleaner Primer Base)	635	66538	Boot-Spark Plug	972	699374	Tank-Fuel (Plastic)
445	491588	Filter-Air Cleaner Cartridge	670	692294	Spacer-Fuel Tank	975	493640	Bowl-Float
455	695161	Cup-Flywheel	684	690345	Screw (Breather Passage Cover)	976	694395	Primer-Carburetor
456	692299	Plate-Pawl Friction	689	691855	Spring-Friction	977	692704	Gasket Set-Carburetor
459	281505	Ratchet-Pawl	718	690959	Pin-Locating	993	*Δ694088	Gasket-Cylinder Head Plate
467	790842	Knob-Air Cleaner	741	790345	Gear-Timing (Use Without Woodruff Key)	1005	691346	Fan-Flywheel
505	691251	Nut (Governor Control Lever)	----- Note -----			1019	695247	Kit-Label
523	499621	Dipstick	691830		Gear-Timing (Uses Woodruff Key)	1022	*Δ691890	Gasket-Rocker Cover
524	*692296	Seal-Dipstick Tube	745	691648	Screw (Brake)	1023	499624	Cover-Rocker
525	495265	Tube-Dipstick	830	694544	Stud-Rocker Arm	1026	692045	Rod-Push
529A	691923	Grommet	832	691466	Guard-Muffler	1029	691230	Arm-Rocker
562	691119	Bolt (Governor Control Lever)	836	691147	Screw (Muffler Guard)	1034	691343	Guide-Push Rod
564	693808	Screw (Control Cover)	836A	697551	Screw (Muffler Guard)	1036		Label-Emission (Available From An Authorized Briggs & Statton Sevice Dealer)
584	697734	Cover-Breather Passage	842	*691031	Seal-O Ring (Dipstick Tube)	1058	276348	Manual-Owner's
585	*691879	Gasket-Breather Passage	847	692047	Dipstick/Tube Assembly	1059	692311	Kit-Screw/Washer
592	690800	Nut (Rewind Starter)	851	493880	Terminal-Spark Plug	1095	694091	Gasket Set-Valve
			868	*Δ692044	Seal-Valve	1210	498144	Pulley/Spring Assembly (Pulley)
						1211	498144	Pulley/Spring Assembly (Spring)
						1330	272147	Manual-Repair

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

Δ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.