



12F600

Illustrated Parts List

Model Series

12F600

TYPE NUMBERS
0115.

TABLE OF CONTENTS

Air Cleaner	5
Blower Housing/Shrouds	6
Camshaft	2
Carburetor	4
Controls	5
Crankshaft	2
Cylinder	2
Cylinder Head	3
Engine Sump	2
Exhaust System	5
Flywheel	6
Fuel Supply	4
Governor Spring	5
Ignition	5
Lubrication	2
Piston Group	2
Rewind Starter	6


BRIGGS & STRATTON






PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.



12F600




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5483-2 Assemblies include all parts shown in frames. 10/12/2005




12F600



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5483-4 Assemblies include all parts shown in frames. 10/12/2005



12F600



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5483-6 Assemblies include all parts shown in frames. 10/12/2005

12F600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	697893	Cylinder Assembly	26	791969	Ring Set (Standard) (Used After Code Date 04040400).	97	499682	Shaft-Throttle
2	399269	Kit-Bushing/Seal (Magneto Side)				104	●691242	Pin-Float Hinge
3	★299819	Seal-Oil (Magneto Side)			----- Note -----	108	691182	Valve-Choke
4	498983	Sump-Engine		499631	Ring Set (Standard) (Used Before Code Date 04040500).	109	693866	Shaft-Choke
5	695276	Head-Cylinder				117A	692677	Jet-Main (Standard)
7	★△695166	Gasket-Cylinder Head				118A	497315	Jet-Main (High Altitude)
8	495786	Breather Assembly		692785	Ring Set (.010" Oversize)	121	692703	Kit-Carburetor Overhaul
9	★272481	Gasket-Breather		791324	Ring Set (.020" Oversize) (Used After Code Date 04102100).	122★♦♦△692799		Spacer-Carburetor
10	691125	Screw (Breather Assembly)				125A	694505	Carburetor
11	499675	Tube-Breather		692786	Ring Set (.020" Oversize) (Used Before Code Date 04102200).	127	●694468	Plug-Welch
12	★692232	Gasket-Crankcase		692787	Ring Set (.030" Oversize)	130	691203	Valve-Throttle
13	691137	Screw (Cylinder Head)				133	398187	Float-Carburetor
15	691680	Plug-Oil Drain (Square Socket)				134	●398188	Kit-Needle/Seat
16	691457	Crankshaft				137	♦♦693981	Gasket-Float Bowl
20	★399781	Seal-Oil (PTO Side)				146	690979	Key-Timing
22	691092	Screw (Crankcase Cover/Sump)	27	691866	Lock-Piston Pin	163A♦♦●692667		Gasket-Air Cleaner Line-Fuel (Cut to Required Length) (Used After Code Date 05063000).
23	697586	Flywheel	28	499423	Pin-Piston			----- Note -----
24	222698	Key-Flywheel	29	499424	Rod-Connecting			691050 Line-Fuel (Cut to Required Length) (Used Before Code Date 05070100).
25	791968	Piston Assembly (Standard) (Used After Code Date 04040400).	32	691664	Screw (Connecting Rod)	188	691147	Screw (Control Bracket)
		----- Note -----	32A	695759	Screw (Connecting Rod)	190	690940	Screw (Fuel Tank)
		690021 Piston Assembly (Standard) (Used Before Code Date 04040500).	33	499642	Valve-Exhaust	192	694543	Adjuster-Rocker Arm
		694167 Piston Assembly (.010" Oversize)	34	499641	Valve-Intake	202	691303	Link-Mechanical Governor
		791326 Piston Assembly (.020" Oversize) (Used After Code Date 04102100).	35	691304	Spring-Valve (Intake)	209	691290	Spring-Governor
		694168 Piston Assembly (.020" Oversize) (Used Before Code Date 04102200).	36	691304	Spring-Valve (Exhaust)	222A	693378	Bracket-Control
		694169 Piston Assembly (.030" Oversize)	37	694086	Guard-Flywheel	227	691467	Lever-Governor Control
			40	692194	Retainer-Valve	238	691300	Cap-Valve
			43	691486	Slinger-Governor/Oil	265	690798	Clamp-Casing
			45	690977	Tappet-Valve	267	691044	Screw (Casing Clamp)
			46	694039	Camshaft	268	691025	Casing-Control Wire (Cut To Required Length)
			51♦♦♦△692668	Gasket-Intake				
			55	691421	Housing-Rewind Starter	269	691026	Wire-Control (Cut To Required Length)
			58	697316	Rope-Starter (Cut To Required Length)			
			60	281434	Grip-Starter Rope			
			65	690837	Screw (Rewind Starter)			
			78	691108	Screw (Flywheel Guard)			
			95	691636	Screw (Throttle Valve)			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

♦ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5483-7

Assemblies include all parts shown in frames.

10/12/2005

12F600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
270	691027	Nut (Control Wire Casing)	564A	693808	Screw (Control Cover)	842	★691031	Seal-O Ring (Dipstick Tube)
271	691028	Lever-Control	584	697734	Cover-Breather Passage	847	692047	Dipstick/Tube Assembly
276	◆271716	Washer-Sealing	585	★691879	Gasket-Breather Passage	851	493880	Terminal-Spark Plug
287	690940	Screw (Dipstick Tube)	592	690800	Nut (Rewind Starter)	868	★Δ692044	Seal-Valve
300	697590	Muffler-Exhaust	597	691696	Screw (Pawl Friction Plate)	883	★Δ691893	Gasket-Exhaust
304	499676	Housing-Blower	601	95162	Clamp-Hose	886	696268	Gasket Set-Cylinder Head/Plate
305	691108	Screw (Blower Housing)	604A	693807	Cover-Control	914	691108	Screw (Rocker Cover)
306	691232	Shield-Cylinder	608	497680	Starter-Rewind	930A	692675	Guard-Rewind
307	690345	Screw (Cylinder Shield)	613	691108	Screw (Muffler)	957	692046	Cap-Fuel Tank (Plastic)
332	690662	Nut (Flywheel)	613A	691140	Screw (Muffler)	966A	693863	Base-Air Cleaner Primer (Choke System)
333	802574	Armature-Magneto	615	690340	Retainer-Governor Shaft	968	692298	Cover-Air Cleaner
334	691061	Screw (Magneto Armature)	616	698801	Crank-Governor	972	699374	Tank-Fuel (Plastic)
337	692051	Plug-Spark	619	691108	Screw (Cylinder Head Plate)	975	493640	Bowl-Float
356	692390	Wire-Stop	621	692310	Switch-Stop	977	692704	Gasket Set-Carburetor
358	694090	Gasket Set-Engine	633	◆693867	Seal-Choke/Throttle Shaft	993	★Δ694088	Gasket-Cylinder Head Plate
363	19069	Puller-Flywheel			Shaft (Choke Shaft)	1005	691346	Fan-Flywheel
365	691136	Screw (Carburetor)	633A◆691321		Seal-Choke/Throttle Shaft (Throttle Shaft)	1019	695247	Kit-Label
383	19374	Wrench-Spark Plug			Boot-Spark Plug	1022	★Δ691890	Gasket-Rocker Cover
404	690272	Washer (Governor Crank)	635	66538	Spacer-Fuel Tank	1023	499624	Cover-Rocker Arm
425	690670	Screw (Air Cleaner Cover)	670	692294	Screw (Breather Passage Cover)	1026	692045	Rod-Push
443	691637	Screw (Air Cleaner Primer Base)	689	691855	Spring-Friction	1029	691230	Arm-Rocker
443A	692523	Screw (Air Cleaner Primer Base)	692	690572	Spring-Detent	1034	691343	Guide-Push Rod
445	491588	Filter-Air Cleaner Cartridge	718	690959	Pin-Locating	1036		Label-Emission (Available From An Authorized Briggs & Statton Sevice Dealer)
455	695161	Cup-Flywheel	741	790345	Gear-Timing (Use Without Woodruff Key)	1058	276348	Manual-Owner's
456	692299	Plate-Pawl Friction			----- Note -----	1059	692311	Kit-Screw/Washer
459	281505	Ratchet-Pawl			691830 Gear-Timing (Uses Woodruff Key)	1095	694091	Gasket Set-Valve
472	693809	Knob-Choke Bracket	830	694544	Stud-Rocker Arm	1102	691255	Pilot-Guide
505	691251	Nut (Governor Control Lever)	832	691466	Guard-Muffler	1210	498144	Pulley/Spring Assembly (Pulley)
523	499621	Dipstick	836	691147	Screw (Muffler Guard)	1211	498144	Pulley/Spring Assembly (Spring)
524	★692296	Seal-Dipstick Tube	836A	697551	Screw (Muffler Guard)	1330	272147	Manual-Repair
525	495265	Tube-Dipstick						
529A	691923	Grommet						
562	691119	Bolt (Governor-Control Lever)						

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5483-8

Assemblies include all parts shown in frames.

10/12/2005