FORM MS-5906-8/97 FILE IN SECT. 2 OF SERVICE MANUAL

#### 12K700 to 12K799

### Illustrated Parts List Model Series 12K700 to 12K799

TYPE NUMBERS 0109.


## TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW

- A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- B. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- C. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."
- D. If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- E. If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- F. For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.

PRINTED IN U.S.A



COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted,
in any form or by any means, electronic or mechanical, including photocopying,
recording or by any information storage and retrieval system, without permission
in writing from Briggs & Stratton Corporation.





REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
8	293708 ★299819 214626 Ø272916 495786 Ø272481 94650 231933 94547 ★272199 94526 ★280393 ★280966	Cylinder Assembly Bushing Seal-Oil Head-Cylinder Gasket-Cylinder Head Breather Assembly Gasket-Breather Screw-Hex. Tube-Breather Screw-Hex. Gasket-Intake Screw-Hex. Seal-O-Ring Seal-O-Ring Lever-Governor	230 284 306 307 337 383 523 525 562 584 585 592 615 616	94511 224324 94515 802592 89838 495264 495265 92613 224328 *272238	Shield-Cylinder Screw-Hex. Plug-Spark Wrench-Spark Plug Dipstick Tube-Oil Fill Bolt-Governor Lever Gasket-Breather Passage Gasket-Breather Passage Nut-Hex. Retainer	625 635 847 869 870 871	66538 495263 213512 213513 262001	Assembly Seat-Valve (Intake) Seat-Valve (Exhaust) Bushing-Guide (Exhaust Valve) Note 63709 Bushing-Guide (Intake Valve)


<sup>★</sup> Included in Gasket Set-Part Number 497316.

<sup>•</sup> Included in Carburetor Kit-Part No. 498260.

<sup>◆</sup> Included in Carburetor Gasket Set–Part No. 498261. Ø Included in Valve Overhaul Gasket Set–Part No. 498528.








REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
25	493262	Piston Assembly (Standard) 493385 Piston Assy. (.010" O.S.) 493386 Piston Assy. (.020" O.S.)	26	493261	Ring Set (Standard) 493388 Ring Set (.010" O.S.) 493389 Ring Set (.020" O.S.)	28 29		Pin–Piston (Standard) 298908 Pin–Piston (.005" O.S.) Rod–Connecting (Standard)
		<b>493387</b> Piston Assy. (.030" O.S.)	27	26026	<b>493390</b> Ring Set (.030" O.S.) Lock–Piston Pin	32	94699	490743 Rod- Connecting (.020" Undersize) Screw-Connecting Rod
		leat Cat. Dort Number 407						. Dort No. 400204

<sup>★</sup> Included in Gasket Set-Part Number 497316.

<sup>•</sup> Included in Carburetor Kit-Part No. 498260.

<sup>◆</sup> Included in Carburetor Gasket Set–Part No. 498261. Ø Included in Valve Overhaul Gasket Set–Part No. 498528.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
NO.  16 24 33 34	493363 222698 262651	DESCRIPTION  Crankshaft Key–Flywheel Valve–Exhaust Valve–Intake	NO. 35 40 45	262224 93312	DESCRIPTION  Spring–Valve Retainer–Valve Tappet–Valve	NO. 146 357 741	94388 91539	Key-Timing Key-Drive Pulley Gear-Timing

<sup>★</sup> Included in Gasket Set-Part Number 497316.

<sup>•</sup> Included in Carburetor Kit-Part No. 498260.

<sup>◆</sup> Included in Carburetor Gasket Set–Part No. 498261. Ø Included in Valve Overhaul Gasket Set–Part No. 498528.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
4 12 15 20	<b>★272198</b>	Sump-Engine Gasket-Crankcase Plug-Oil Drain Seal-Oil	22	94220	Screw-Hex.	43 46		Governor/Oil Slinger Gear–Cam

<sup>★</sup> Included in Gasket Set-Part Number 497316.

Included in Carburetor Kit–Part No. 498260.

<sup>◆</sup> Included in Carburetor Gasket Set–Part No. 498261. Ø Included in Valve Overhaul Gasket Set–Part No. 498528.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
	94098 •231371	DESCRIPTION  Screw-Choke/Throttle Pin-Float Hinge Washer-Bowl (Sold in Kit Only) Jet-Main (Standard) — Note —— 496495 Jet-Main (High Altitude)		94525 498254 • 224908 493267 398187	Screw-Hex. Carburetor Plug-Welch (Sold in Kit Only) Valve-Throttle Throttle Shaft Kit Float-Carburetor Needle/Seat Kit	NO. 137	NO.  •+  •+272653 •+270344 •+	Gasket-Bowl (Sold in Kit Only) Gasket-Air Cleaner Seal-Intake Manifold Washer-Foam (Sold in Kit Only) Bowl- Float

<sup>★</sup> Included in Gasket Set-Part Number 497316.

Included in Carburetor Kit–Part No. 498260.

<sup>◆</sup> Included in Carburetor Gasket Set–Part No. 498261. Ø Included in Valve Overhaul Gasket Set–Part No. 498528.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
188		Screw-Hex.	268	66986	Casing-Wire	333		Armature–Magneto
202	262579	Link-Mechanical Governor			(48" Long) (Cut to Required	334 356		Screw-Hex. Wire-Stop
209	263040	Spring–Governor			Length)	620		Bracket–Control
258		Screw-Slotted Hex.	269	26099	Wire-Control	621		Switch-Stop
265		Clamp-Casing			(54" Long)	670	<b>*</b> 493823	•
267	94882	Screw-Slotted Hex.			(Cut to Required Length)	843	272616	(Includes 2) Sleeve-Lever
			270	63426	Locknut–Casing	851		Terminal-Cable
			271		Lever–Control	923	493442	


<sup>★</sup> Included in Gasket Set-Part Number 497316.

Included in Carburetor Kit–Part No. 498260.

<sup>◆</sup> Included in Carburetor Gasket Set–Part No. 498261. Ø Included in Valve Overhaul Gasket Set–Part No. 498528.








REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
187 188A 240 284	398540 298090	Line-Fuel Screw-Shoulder Filter-Fuel Screw-Shoulder	601	95162	Clamp–Fuel Line (Red)  Note  93053 Clamp–Hose (Green)	670A 930 957 972	281187 397974	Spacer-Fuel Tank Guard-Rewind Cap-Fuel Tank Tank-Fuel

<sup>★</sup> Included in Gasket Set-Part Number 497316.

Included in Carburetor Kit–Part No. 498260.


<sup>◆</sup> Included in Carburetor Gasket Set–Part No. 498261. Ø Included in Valve Overhaul Gasket Set–Part No. 498528.



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
81 161 163** 300 346 346A 529	496116 ◆•272653 496106 93705 94602	Lock-Muffler Screw Base-Air Cleaner Gasket-Air Cleaner Muffler-Exhaust Screw-Hex. Screw-Hex. Grommet	613 676 832 967 968 969 971	393756 499034 491588 281340 94120	Screw-Shoulder Deflector-Muffler Guard-Muffler Filter-Air Cover-Air Cleaner Screw-Slotted Hex. Screw-Hex.	971A 974 976 991 994	224815 496115 493537	Screw-Hex. Bracket-Air Cleaner Primer-Carburetor Filter-Air (Pre-Filter) Arrester-Spark

<sup>Included in Gasket Set–Part Number 497316.
Included in Carburetor Kit–Part No. 498260.</sup> 

<sup>♦</sup> Included in Carburetor Gasket Set–Part No. 498261. Ø Included in Valve Overhaul Gasket Set–Part No. 498528.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
23 37 73	NO. 492177 224511	DESCRIPTION  Flywheel Guard–Flywheel Screen–Rotating	REF. NO. 304 305 332	NO. 493293 94744	DESCRIPTION  Housing-Blower Screw-Hex. Nut-Flywheel	REF. NO. 363 455	NO. 19069	DESCRIPTION  Flywheel Puller Cup-Flywheel

<sup>★</sup> Included in Gasket Set-Part Number 497316.

Included in Carburetor Kit–Part No. 498260.

<sup>◆</sup> Included in Carburetor Gasket Set–Part No. 498261. Ø Included in Valve Overhaul Gasket Set–Part No. 498528.




REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
55 56 57	497440 281504	Housing-Rewind Starter Pulley-Starter Spring-Rewind Starter	58 60 65A 369	280399 281434 94904	Rope-Starter (Cut To Required Length) Grip-Starter Rope Screw-Hex. Spring-Friction	NO. 373 456 459 461 608	94980 281503 281505 94943	Nut-Hex. Plate-Pawl Friction Pawl-Ratchet Screw-Shoulder Starter-Rewind


<sup>★</sup> Included in Gasket Set-Part Number 497316.


Included in Carburetor Kit–Part No. 498260.

<sup>◆</sup> Included in Carburetor Gasket Set–Part No. 498261. Ø Included in Valve Overhaul Gasket Set–Part No. 498528.



# 1095 VALVE OVERHAUL GASKET SET 7 9 9





REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
3 7,	*299819 *Ø272916 *Ø272481 *272198 *399781 *272199 •231371 •◆	Seal-Oil Gasket-Cylinder Head Gasket-Breather Gasket-Crankcase Seal-Oil Gasket-Intake	121 127 134 137	498260 • 398188 • 4272653 497316	Carburetor Kit Plug–Welch (Sold in Kit Only) Valve–Needle Gasket–Bowl (Sold in Kit Only) Gasket–Air Cleaner Gasket Set Gasket–Breather Passage		• <b>♦</b> 270344 • <b>♦</b>	Seal-Intake Manifold Washer-Foam (Sold in Kit Only) Spacer (Includes 2) Gasket Set- Carburetor

<sup>★</sup> Included in Gasket Set-Part Number 497316.

Included in Carburetor Kit–Part No. 498260.

<sup>◆</sup> Included in Carburetor Gasket Set–Part No. 498261. Ø Included in Valve Overhaul Gasket Set–Part No. 498528.