FORM MS-0242-11/97 REPLACES FORM MS-0242-5/96 FILE IN SECT. 2 OF SERVICE MANUAL

135700 to 135799

Illustrated Parts List Model Series 135700 to 135799

TYPE NUMBERS 0003, 0015, 0016, 0017, 0019, 0100, 0102, 0105, 0116, 0117, 0118, 0125, 0126.


TO FIND THE CORRECT NUMBER OF THE PART YOU NEED: FOLLOW THE INSTRUCTIONS BELOW

- A. Refer to Engine Model, Type and Code Number that is stamped on the blower housing of engine. Engine type numbers such as 0123 01 are listed only as 0123 in most instances. The two digits (01 or 02, etc.) to the right of the space may be required for more accurate parts identification in some instances. Select the Illustrated Parts List covering the correct Model Series and Type Number.
- B. Refer to the Illustrations and compare the original part with Illustration. The number next to the illustration is the Reference Number. Assemblies include all parts shown in frames. All parts shown in assembly frames having individual reference numbers can be purchased separately.
- C. After the Reference Number has been identified, refer to the Numerical text, where Reference and Primary Part Number are listed. THE PRIMARY PART IS USED ON ALL TYPE NUMBERS EXCEPT THOSE TYPE NUMBERS UNDER "NOTE."
- D. If a "Note" appears below the Primary Part Number, it means that this part differs from the Primary Part for certain types. If your Type number is listed under "Note," order the part referred to at the "Note."
- E. If your Engine Type Number does not appear after any part number listed under "Note," use the Primary Part Number.
- F. For Engine Type Numbers not covered by this book, check other Parts Lists having the same engine model or contact your source of supply.

BRIGGS & STRATTON

PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.




| REF. NO. | PART NO. | DESCRIPTION | REF. NO. | PART NO. | DESCRIPTION | REF. NO. | PART NO. | DESCRIPTION |
|----------------------------|--|------------------------------|---|--|---|---------------------------------|---|-------------|
| 1 2 3 5 7 8 | 496485 297565 ★299819 214040 ②★272157 495758 Ø★27549 94719 231879 94221 | Cylinder Assembly Bushing | 51 54A 306 307 308 337 383 529 552 635 | *270070 93367 93512 223804 94680 224876 802592 89838 67738 231078 | Gasket-Intake Screw-Hex. Screw-Hex. Shield-Cylinder Screw-Hex. Cover-Cylinder Plug-Spark (Resistor Type) Wrench-Spark Plug Grommet Bushing-Governor Crank Boot-Spark Plug | 703 718 869 870 871 | 93376 230192 211787 211172 262001 | |

[★] Included in Gasket Set-Part No. 496659.

Included in Carburetor Kit-Part No. 498260.

Ø Included in Valve Overhaul Gasket Set–Part No 498532.
 ◆ Included in Carburetor Gasket Set–Part No. 498261.




| REF. NO. | PART NO. | DESCRIPTION | REF. NO. | PART NO. | DESCRIPTION | REF. NO. | PART NO. | DESCRIPTION |
|---------------------|------------------|---|----------------------|-------------|---|--|--|--|
| 6 16 24 25 | 492091 222698 | Washer–Flat Crankshaft ——Note ——397109 Crankshaft Used on Type No(s). 0003, 0015, 0019, 0117. 493410 Crankshaft Used on Type No(s). 0017, 0102, 0116, 0118. 496842 Crankshaft Used on Type No(s). 0125. 498234 Crankshaft Used on Type No(s). 0126. Key–Flywheel Piston Assembly (Standard) | 26 27 28 29 | | (Standard) | 35 36 40 45 146 146A 227 377 562 592 614 616 741 | 26478 93312 260642 94388 499047 391967 93065 94907 231978 93306 495242 262992 | Spring–Valve (Intake) Spring–Valve (Exhaust) Retainer–Valve Tappet–Valve Key–Timing Key–Timing Lever–Governor Key–Woodruff Bolt–Governor Lever Nut–Hex. Pin–Cotter Crank–Governor Gear–Timing —Note 261696 Gear–Timing Retainer–E-Ring |
| | | Note ———————————————————————————————————— | 32 33 34 | 211119 | (.020" Undersize) Screw–Conn. Rod Valve–Exhaust Valve–Intake | | | |

[★] Included in Gasket Set-Part No. 496659.

Included in Carburetor Kit-Part No. 498260.


Ø Included in Valve Overhaul Gasket Set−Part No 498532.
 ◆ Included in Carburetor Gasket Set−Part No. 498261.



| REF. NO. | PART NO. | DESCRIPTION | REF. NO. | PART NO. | DESCRIPTION | REF. NO. | PART NO. | DESCRIPTION |
|-------------|-------------|---|--|--|--|--|---------------------------------------|---|
| 12 | | Sump-Engine Gasket-Crankcase Note *270122 Gasket- Crankcase (.005" Thick) *270123 Gasket- Crankcase (.009" Thick) | 15 15A 20 22 43 46 65 116 | 94880 *391485 94980 496544 214726 94874 | Plug-Oil Drain Plug-Oil Drain Seal-Oil Screw-Hex. Gov./Oil Slinger Gear-Cam Screw-Hex. Seal-O-Ring | 441 523 524 525 532 847 | 495228 *281370 280133 260676 | Bracket–Oil Fill Dipstick Seal–Fill Tube Tube–Oil Fill Washer–Spring Dipstick/Tube Assembly |

<sup>Included in Gasket Set–Part No. 496659.
Included in Carburetor Kit–Part No. 498260.</sup>

Ø Included in Valve Overhaul Gasket Set–Part No 498532.
 ◆ Included in Carburetor Gasket Set–Part No. 498261.




| REF. NO. | PART NO. | DESCRIPTION | REF. NO. | PART NO. | DESCRIPTION | REF. NO. | PART NO. | DESCRIPTION |
|--|---|--|--|---|--|--------------------------|--------------------------------|--|
| 94 95 98 104 105 108 117 | 94098 398185 •231371 •398188 223471 | Valve-Idle Adjustment Screw-Choke/Throttle Screw-Idle Speed Pin-Float Hinge Needle/Seat Kit Valve-Choke Jet-Main (Bowl Mounting Screw) | 124 125 127 130 131 133 141 245 | 496649 • 223470 496727 398187 494218 | Plug-Welch (Sold in Kit Only) Valve-Throttle | 355 617 708 975 | • +270344 • + | Washer–Seal (Sold in Kit Only) Seal–Intake Manifold Seal–Dust Bowl–Float |

[★] Included in Gasket Set-Part No. 496659.

Included in Carburetor Kit-Part No. 498260.

Ø Included in Valve Overhaul Gasket Set−Part No 498532.
 Included in Carburetor Gasket Set−Part No. 498261.




| REF. NO. | PART NO. | DESCRIPTION | REF. NO. | PART NO. | DESCRIPTION | REF. NO. | PART NO. | DESCRIPTION |
|--|--|---|-------------|-------------|--|--|--|--|
| 65 98A 169 188 202 212 209 | 493280 92791 94117 260649 262961 | Screw-Hex. Screw-Idle Speed Washer-Lock Screw-Hex. Link-Mechanical Governor Link-Throttle Spring-Governor — Note — 262656 Spring- Governor | 217 222 | 496245 | Spring-Choke Bracket-Control (Remote) Note 496535 Bracket- Control (Manual Friction) Used on Type No(s). 0015, 0016, 0017, 0019, 0117, 0118, 0125. | 270 271 354 507 520 604 621 623 624 843 | 290568 90576 398525 93722 224907 396847 231520 496288 | Locknut-Casing Lever-Control Nut-Hex. Insulator Terminal Cover-Control Switch-Stop Screw-Shoulder Lever-Linkage Sleeve-Lever |
| | | Used on Type No(s). 0003, 0019, 0117, 0118. 262657 Spring– Governor Used on Type No(s). 0015, 0016, 0017, 0102, 0116, 0125. | 268 | | Casing–Wire (48" Long) Note 65616 Casing–Wire (72" Long) (If Shorter Casing is Needed, Cut to Required Length) | | | |
| | | 262659 Spring— Governor Used on Type No(s). 0100, 0105. 262662 Spring— Governor Used on Type No(s). 0125, 0126. | 269 | 26099 | Wire–Control (54" Long) Note 26633 Wire–Control (78" Long Cut to Required Length) | | | |

[★] Included in Gasket Set-Part No. 496659.

Included in Carburetor Kit-Part No. 498260.


Ø Included in Valve Overhaul Gasket Set−Part No 498532.
 Included in Carburetor Gasket Set−Part No. 498261.



| REF. NO. | PART NO. | DESCRIPTION | REF. NO. | PART NO. | DESCRIPTION | REF. NO. | PART NO. | DESCRIPTION |
|---|---|---|--|--|--|--|-----------------------------------|--|
| 163 258 265 267 307A 387 445 482 | 94902 221535 94882 94807 496115 491588 | Gasket-Air Cleaner Screw-Hex. Clamp-Casing Screw-Slotted Hex. Screw-Hex. Primer-Carburetor Filter-A/C Cartridge Screw-Hex. | 529A 621 922 923 925 942 966 | 396847 261647 394867 281285 493248 | Grommet Switch—Stop Spring—Brake Brake Cover—Linkage Bracket—Brake Base—Air Cleaner Primer | 967 968 969 971 971A 1115 | 281340 94872 94873 94749 | Filter-Pre-Cleaner Cover-Air Cleaner Screw-Slotted Hex. Screw-Hex. Screw-Hex. Bracket-Air Cleaner |

<sup>Included in Gasket Set–Part No. 496659.
Included in Carburetor Kit–Part No. 498260.</sup>


Ø Included in Valve Overhaul Gasket Set–Part No 498532.
 ◆ Included in Carburetor Gasket Set–Part No. 498261.



[★] Included in Gasket Set-Part No. 496659.

Included in Carburetor Kit-Part No. 498260.


Ø Included in Valve Overhaul Gasket Set−Part No 498532.
 ◆ Included in Carburetor Gasket Set−Part No. 498261.



| REF. NO. | PART NO. | DESCRIPTION | REF. NO. | PART NO. | DESCRIPTION | REF. NO. | PART NO. | DESCRIPTION |
|---------------------------------------|-------------------------------------|---|---|---------------------------|---|---------------------------------|----------------------------|--|
| 81 187 190 284 300 601 | 298049 496410 94511 494585 | Lock-Muffler Screw Line-Fuel Screw-Shoulder Screw-Shoulder Muffler-Exhaust Clamp-Hose | 601A 613 670 673 676 883 Ø | 281362 94896 393757 | Clamp-Hose Screw-Shoulder Spacer-Fuel Tank Screw-Hex. Deflector-Muffler Gasket-Exhaust | 930 957 958 972 994 | 397974 494768 495224 | Guard-Rewind Cap-Fuel Tank Valve-Shut-Off Tank-Fuel Arrester-Spark |

<sup>Included in Gasket Set–Part No. 496659.
Included in Carburetor Kit–Part No. 498260.</sup>

Ø Included in Valve Overhaul Gasket Set−Part No 498532.
 ◆ Included in Carburetor Gasket Set−Part No. 498261.




| REF. NO. | PART NO. | DESCRIPTION | REF. NO. | PART NO. | DESCRIPTION | REF. NO. | PART NO. | DESCRIPTION |
|-------------|-----------------------------------|--|--|--------------------------|--|---|----------------------------------|---|
| S5 58 59 60 | NO. 497442 280399 396892 | DESCRIPTION Housing–Rewind Starter Rope–Starter Insert–Grip Grip–Starter Rope | REF. NO. 65 325 373 456 | 94904 498144 94908 | DESCRIPTION Screw-Hex. Pulley-Rope Start Nut-Hex. Plate-Pawl Friction | REF. NO. 459 608 623 689 | NO. 281505 497830 94943 | Pawl-Ratchet Starter-Rewind Screw-Shoulder Spring-Friction |
| | | | | | | | | |

[★] Included in Gasket Set-Part No. 496659.

Included in Carburetor Kit-Part No. 498260.


Ø Included in Valve Overhaul Gasket Set−Part No 498532.
 Included in Carburetor Gasket Set−Part No. 498261.





| REF. NO. | PART NO. | DESCRIPTION | REF. NO. | PART NO. | DESCRIPTION | REF. NO. | PART NO. | DESCRIPTION |
|------------------------------------|--------------------------------------|--|--|---|---|---|--------------------------------------|---|
| 6A 55A 56 57A 58 59 | 492831 493824 491889 281228 | Washer–Flat Housing–Rewind Starter Pulley–Starter Spring–Rewind Starter Rope–Starter Insert–Grip | 60 60A 65A 73 101 355A 373 | 281434 94686 225176 262626 280973 | Grip-Starter Rope Grip-Starter Rope Screw-Hex. Screen-Rotating Pin-Shaft Washer-Seal Nut-Hex. | 455 456A 459A 608A 689A 1016 | 224321 492833 496650 262625 | Cup-Flywheel Plate-Pawl Friction Spring-Pawl Starter-Rewind Spring-Friction Spacer-Rewind |


[★] Included in Gasket Set–Part No. 496659.
◆ Included in Carburetor Kit–Part No. 498260.

Ø Included in Valve Overhaul Gasket Set−Part No 498532.
 ◆ Included in Carburetor Gasket Set−Part No. 498261.









| REF. PA NO. N | = = | REF. NO. | PART NO. | DESCRIPTION | REF. NO. | PART NO. | DESCRIPTION |
|---|--|---|---|---|-------------|---|---|
| 7 ⊘±272 9 ⊘±27 12 ±270 20 ±391 | 19 Seal–Oil 57 Gasket–Cylinder Head 49 Gasket–Breather 69 Gasket–Crankcase Note *270122 Gasket– Crankcase (.005" Thick) *270123 Gasket– Crankcase (.009" Thick) 85 Seal–Oil 70 Gasket–Intake | 94 104 116 121 127 105 163 245 | •231371 *270920 498260 • •398188 *272653 | Plug-Welch (Sold in Kit Only) Needle/Seat Kit | 708 | *281370 •+270344 •+ ∅*272309 498261 | Gasket Set Seal–Fill Tube Seal–Intake Manifold Seal–Dust (Sold in Kit Only) Gasket–Exhaust Gasket Set– Carburetor Gasket Set–Valve Overhaul |

[★] Included in Gasket Set-Part No. 496659.

Included in Carburetor Kit-Part No. 498260.

Ø Included in Valve Overhaul Gasket Set–Part No 498532.
 ◆ Included in Carburetor Gasket Set–Part No. 498261.