

28AH00

Illustrated Parts List Model Series 28AH00

TYPE NUMBERS
0112, 0113.

TABLE OF CONTENTS


Air Cleaner	5
Alternator	7
Blower Housing	5
Camshaft	2
Carburetor	4
Controls	7
Engine Sump	2
Crankshaft	2
Cylinder	2
Cylinder Head	3
Electric Starter	7
Exhaust System	5
Flywheel	6
Fuel Supply	4
Gasket Set - Engine	2
Gasket Set - Valve	3
Governor Spring	7
Ignition	7
Intake Manifold	3
Kit - Carburetor Overhaul.	4
Lubrication	3
Piston, Rings, Connecting Rod	2
Rewind Starter	6
Valves	3

PRINTED IN U.S.A.




COPYRIGHT by BRIGGS & STRATTON CORPORATION
 All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

28AH00











Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5328-2 Assemblies include all parts shown in frames. 09/09/2005







Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5328-3 Assemblies include all parts shown in frames. 09/09/2005




28AH00



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5328-4 Assemblies include all parts shown in frames. 09/09/2005




1036 EMISSION LABEL





Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 5328-5 Assemblies include all parts shown in frames. 09/09/2005

28AH00




Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
5328-6 Assemblies include all parts shown in frames. 09/09/2005



NOTE: All stators use a No. 1119 mounting screw. 

NOTE: The proper flywheel part number and/or the alternator magnet size will determine the alternator type or output. See repair instruction manual for additional information.



5328-7 *Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.* Assemblies include all parts shown in frames. 09/09/2005

28AH00

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	697132	Cylinder Assembly	29	697518	Rod-Connecting (Standard)	65	697725	Screw (Rewind Starter)
2	399265	Kit-Bushing/Seal (Magneto Side)			----- Note -----			Used on Type No(s). 0113.
3	★391086	Seal-Oil (Magneto Side)		697264	Rod-Connecting (.020" Undersize)	78	691003	Screw (Flywheel Guard)
4A	697188	Sump-Engine	32	692852	Screw (Connecting Rod)			Used on Type No(s). 0112.
5	698404	Head-Cylinder	33	698370	Valve-Exhaust	78A	690364	Screw (Flywheel Guard)
7	★Δ273280	Gasket-Cylinder Head	34	695761	Valve-Intake			Used on Type No(s). 0113.
9	★697109	Gasket-Breather	35	691279	Spring-Valve (Intake)			
10	697157	Screw (Breather Assembly)	36	691279	Spring-Valve (Exhaust)	81	691178	Lock-Muffler Screw
11	697113	Tube-Breather	37	697108	Guard-Flywheel Used on Type No(s). 0112.	93	●690602	Bushing-Throttle Shaft
12	★697110	Gasket-Crankcase			----- Note -----	94	498030	Kit-Idle Mixture
13	690360	Screw (Cylinder Head)		697352	Guard-Flywheel Used on Type No(s). 0113.	95	●691636	Screw (Throttle Valve)
15	690946	Plug-Oil Drain	37A	697626	Guard-Flywheel Used on Type No(s). 0113.	98	495800	Kit-Idle Speed
16	697516	Crankshaft	42	499586	Keeper-Valve	104	●690525	Pin-Float Hinge
20	★690947	Seal-Oil (PTO Side)	43	691968	Slinger-Governor/Oil	105	●231855	Valve-Float Needle
22	692125	Screw (Crankcase Cover/Sump)	45	690564	Tappet-Valve	106	●691780	Seat-Inlet (Pump Feed)
23	693556	Flywheel	46	698492	Camshaft			Used on Type No(s). 0112.
24	222698	Key-Flywheel	50	690193	Manifold-Intake			----- Note -----
25	698390	Piston Assembly (Standard)	51★Δ●692137	Gasket-Intake				●690577 Seat-Inlet (Gravity Feed)
		----- Note -----	53	690227	Stud (Carburetor)			Used on Type No(s). 0113.
	698393	Piston Assembly (.010" Oversize)	54	691148	Screw (Intake Manifold)	108	690464	Valve-Choke (LMT 697204, 697205)
	698394	Piston Assembly (.020" Oversize)	55	695130	Housing-Rewind Starter Used on Type No(s). 0113.	108A	692344	Valve-Choke (LMT 696179, 697202)
	698395	Piston Assembly (.030" Oversize)	56	695129	Pulley-Starter Used on Type No(s). 0113.	117	●694352	Jet-Main (Standard)
26	698389	Ring Set (Standard)	57	695131	Spring-Rewind Starter Used on Type No(s). 0113.	118	697228	Jet-Main (High Altitude)
		----- Note -----	58	695132	Rope-Starter Used on Type No(s). 0113.	121	697241	Kit-Carburetor Overhaul
	698396	Ring Set (.010" Oversize)	60	494212	Grip-Starter Rope Used on Type No(s). 0113.	125	698445	Carburetor
	698397	Ring Set (.020" Oversize)				127	●695005	Plug-Welch
	698398	Ring Set (.030" Oversize)				130	691750	Valve-Throttle
27	698469	Lock-Piston Pin				131	494379	Kit-Throttle Shaft
28	697099	Pin-Piston (Standard)				133	494381	Float-Carburetor
						137	●281165	Gasket-Float Bowl
						141	495097	Kit-Choke Shaft (LMT 697204, 697205)
						141A	495931	Kit-Choke Shaft (LMT 696179, 697202)

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

Δ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5328-8

Assemblies include all parts shown in frames.

09/09/2005

28AH00

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
142	●697140	Nozzle-Carburetor (Standard)	271	691028	Lever-Control	459	281505	Pawl-Ratchet Used on Type No(s). 0113.
146	690979	Key-Timing	276	◆692255	Washer-Sealing	462	691261	Washer (Starter Cable)
186	692317	Connector-Hose (90 Degree)	300	697349	Muffler	474B	696457	Alternator (Tri Circuit) Used on Type No(s). 0113.
186A	698174	Connector-Hose (Straight)	304	790009	Housing-Blower (Black) Used on Type No(s). 0112.	474C	696458	Alternator (10 Amp Circuit) Used on Type No(s). 0112.
187	791766	Line-Fuel (Cut To Required Length) (Used After Code Date 05063000). ----- Note ----- 691050 Line-Fuel (Cut To Required Length) (Used Before Code Date 05070100).	305	697102	Screw (Blower Housing)	493	695450	Bracket-Mounting Used on Type No(s). 0113.
187B	791805	Line-Fuel (Formed)(10-1/4 Inches Long)(Cut to Required Length)	305A	697103	Screw (Blower Housing)	501	691185	Regulator Used on Type No(s). 0112.
188	691693	Screw (Control Bracket)	306	697107	Shield-Cylinder			----- Note ----- 698315 Regulator Used on Type No(s). 0113.
192	691986	Adjuster-Rocker Arm	307	691003	Screw (Cylinder Shield)	503	691532	Strap-Starter
202	691841	Link-Mechanical Governor	309	693551	Motor-Starter	505	691251	Nut (Governor Control Lever)
209	690480	Spring-Governor (Red)	310	690323	Screw (Starter Motor)	510	693699	Drive-Starter
216	691840	Link-Choke	311	497608	Brush Set	513	692024	Clutch-Drive
222	694042	Bracket-Control	333	492341	Armature-Magneto	523	699908	Dipstick
227	691374	Lever-Governor Control	334	691061	Screw (Magneto Armature)	524	★691032	Seal-Dipstick Tube
232	691842	Spring-Governor Link	337	491055	Plug-Spark	525	697085	Tube-Dipstick Used on Type No(s). 0112.
238	691843	Cap-Valve	356	697089	Wire-Stop			----- Note ----- 697184 Tube-Dipstick Used on Type No(s). 0113.
239	491657	Switch-Oil Pressure	358	697151	Gasket Set-Engine	526	697348	Screw (Regulator)
240	394358	Filter-Fuel (White, 75 Microns) Used on Type No(s). 0113.	363	19203	Puller-Flywheel	544	692034	Armature-Starter
240B	695666	Filter-Fuel (Includes 30 Micron Paper Element) Used on Type No(s). 0112.	383	89838	Wrench-Spark Plug	552	697144	Bushing-Governor Crank
265	691024	Clamp-Casing	385	694476	Screw (Fuel Pump)	559	697561	Screw (Remote Choke Stop)
267	690804	Screw (Casing Clamp)	385A	690297	Screw (Fuel Pump)	562	691119	Bolt (Governor Control Lever)
268	691025	Casing-Control Wire (Cut To Required Length)	387	697090	Pump-Fuel (Includes Mounting Bracket)	563	695449	Screw (Debris Screen Guard)
269	691026	Wire-Control (Cut To Required Length)	387A	808656	Pump-Fuel	578	692306	Wire Assembly Used on Type No(s). 0112.
270	691027	Nut (Control Wire Casing)	404	691691	Washer (Governor Crank)			
			415	690283	Plug (.125-27 NPTF)			
			431	697122	Elbow-Intake			
			445	697153	Filter-Air Cleaner Cartridge (Washable)			
			455	695113	Cup-Flywheel Used on Type No(s). 0113.			
			456	695128	Plate-Pawl Friction Used on Type No(s). 0113.			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5328-9

Assemblies include all parts shown in frames.

09/09/2005

28AH00

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
579	691029	Nut (Starter Cable)	789A	698329	Harness--Wiring Used on Type No(s). 0113.	965	499613	Cover--Oil Pump
584	697112	Cover--Breather Passage	797	693167	Nut (Brush Retainer)	967	697015	Filter--Pre Cleaner
597	691696	Screw (Pawl Friction Plate) Used on Type No(s). 0113.	801	691283	Cap--Drive	968	697574	Cover--Air Cleaner (Black) Used on Type No(s). 0112.
601	95162	Clamp--Hose	802	691286	Cap--End			----- Note -----
608	695058	Starter--Rewind Used on Type No(s). 0113.	803		Housing--Starter (Not Serviced Separately, Order Starter Motor 693551)			698403 Cover--Air Cleaner (Black) Used on Type No(s). 0113.
613	691416	Screw (Muffler)	823	698941	Screw (Muffler Adapter)	975	495933	Bowl--Float
613A	690297	Screw (Muffler)	830	691095	Stud--Rocker Arm	977	690192	Gasket Set--Carburetor
614	691620	Pin--Cotter	842	★691031	Seal--O Ring (Dipstick Tube)	987	●691326	Seal--Throttle Shaft
616	692012	Crank--Governor	847	790443	Dipstick/Tube Assembly Used on Type No(s). 0112.	1005	697546	Fan--Flywheel Used on Type No(s). 0112.
617	★●692138	Seal--O Ring (Intake Manifold)			----- Note -----			----- Note -----
634	●690801	Spring/Seal Assembly (LMT 697204, 697205)			790442 Dipstick/Tube Assembly Used on Type No(s). 0113.			699043 Fan--Flywheel Used on Type No(s). 0113.
634A	●690802	Spring/Seal Assembly (LMT 696179, 697202)				1017	690770	Screen--Oil Pump (Push In)
635	691909	Boot--Spark Plug	851	692424	Terminal--Spark Plug	1019	698414	Kit--Label
643	698401	Retainer--Air Filter	864	697346	Adapter--Muffler	1022	★△272475	Gasket--Rocker Cover
654	690958	Nut (Carburetor)	868	★△690968	Seal--Valve	1023	692492	Cover--Rocker
676	393761	Deflector--Muffler	877B	393537	Wire/Connector-- Alternator (Tri Circuit) Used on Type No(s). 0113.	1024	499054	Pump--Oil
677	690661	Screw (Muffler Deflector)				1026	692003	Rod--Push (Intake) ----- Note -----
689	691855	Spring--Friction Used on Type No(s). 0113.	877C	399916	Wire/Connector-- Alternator Used on Type No(s). 0112.			692011 Rod--Push (Exhaust)
691	★692407	Seal--Governor Shaft	878A	691955	Harness--Alternator Used on Type No(s). 0113.	1027	696854	Filter--Oil
692	690572	Spring--Detent	883	★692236	Gasket--Exhaust	1029	691751	Arm--Rocker
697	690372	Screw (Drive Cap)	914	691108	Screw (Rocker Cover)	1032	491710	Ball--Oil Pump Used on Type No(s). 0113.
718	690959	Pin--Locating	918	697091	Hose--Vacuum (Formed)	1034	690822	Guide--Push Rod
729	691335	Clip--Wire (Wire Saddle)	943	★690589	Seal--O Ring (Oil Pump Cover)	1035	693784	Shaft--Pump
729A	691224	Clip--Wire (Aluminum Coated Steel)	947	694393	Solenoid--Fuel	1036		Label--Emissions (Available from an Authorized Briggs & Stratton Service Dealer)
729B	694123	Clip--Wire (Nylon)	949	697729	Guard--Debris Screen Used on Type No(s). 0112.	1044	698139	Screw (Flywheel)
741	697128	Gear--Timing	949A	695448	Guard--Debris Screen Used on Type No(s). 0113.	1051	691265	Ring--Retaining
750	790832	Screw (Oil Pump Cover)	950	695407	Screw--Float Bowl (Bottom Of Bowl)	1054	280275	Tie--Cable
757	697607	Link--Counterweight				1058	276344	Operator's Manual
758	697134	Counterweight				1059	698516	Kit--Screw/Washer
759	697392	Pin--Counterweight				1070	690372	Screw (Flywheel Fan)
783	693713	Gear--Pinion						
789	692037	Harness--Wiring Used on Type No(s). 0112.						

★ Included in Engine Gasket Set--Ref. No.358.

● Included in Carburetor Overhaul Kit--Ref. No. 121.

◆ Included in Carburetor Gasket Set--Ref. No. 977.

△ Included in Valve Gasket Set--Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

5328-10

Assemblies include all parts shown in frames.

09/09/2005

28AH00

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1090	691293	Retainer-Brush	1266A	●697123	Seal-O Ring (Intake Elbow)	1270	697156	Plug-AVS Counterweight
1091	691333	Cap-Limiter				1279	691108	Screw (Blower Housing Support)
1095	691581	Gasket Set-Valve	1267	697575	Latch-Blower Housing Used on Type No(s). 0112.	1330	272147	Repair Manual
1119	691183	Screw (Alternator)			----- Note -----			
1263	697124	Reed-Breather			697419 Latch-Blower Housing Used on Type No(s). 0113.			
1264	697104	Screw (Breather Reed)						
1265	697125	Support-Blower Housing						
1266	★●691917	Seal-O Ring (Intake Elbow)						

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.