



295700

Illustrated Parts List

Model Series

295700

TYPE NUMBER
0112, 0113.

TABLE OF CONTENTS

Air Cleaner	8
Alternator	7
Blower Housing	9
Camshaft	3
Carburetor	4
Controls	7
Crankshaft	3
Cylinder	2
Cylinder Head	5
Electric Starter	12
Engine Sump	2
Exhaust System	6
Flywheel	9
Fuel Supply	4
Gasket Set – Engine	2
Gasket Set – Valve	5
Governor Spring	7
Ignition	7
Intake Manifolds	3
Kit – Carburetor Overhaul	4
Lubrication	11
Piston, Rings, Connecting Rod	2
Rewind Starter	9
Shrouds	10
Valves	5





BRIGGS & STRATTON




PRINTED IN U.S.A.






COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

295700










1019 LABEL KIT
1330 REPAIR MANUAL
1058 OWNER'S MANUAL






295700



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 3382-4 Assemblies include all parts shown in frames. 12/21/2005

295700






Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.


3382-5

Assemblies include all parts shown in frames.


12/21/2005




295700









295700







1036 EMISSION LABEL




295700



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
3382-10 Assemblies include all parts shown in frames. 12/21/2005



295700



295700

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	692543	Cylinder Assembly	29	807900s	Rod-Connecting (Standard)	78	690688	Screw (Flywheel Guard)
2	808534	Kit-Bushing/Seal (Magneto Side)			----- Note -----	94	●808258	Kit-Idle Mixture
3	★805101s	Seal-Oil (Magneto Side)			807803 Rod-Connecting (.020" Undersize)	95	690728	Screw (Throttle Valve)
4	808846	Sump-Engine	32	690698	Screw (Connecting Rod)	97	842650	Shaft-Throttle (Used After Code Date 05063000).
5	809200	Head-Cylinder (Cylinder 1)	33	807681	Valve-Exhaust			----- Note -----
5A	809201	Head-Cylinder (Cylinder 2)	34	807680	Valve-Intake			808323 Shaft-Throttle (Used Before Code Date 05070100).
7★	△806085s	Gasket-Cylinder Head (Graphoil)	35	692084	Spring-Valve (Intake)			
8	808988	Breather Assembly	36	692084	Spring-Valve (Exhaust)	98	807705	Kit-Idle Speed
9	★809094	Gasket-Breather	37	841309	Guard-Flywheel (Black)	104	●690739	Pin-Float Hinge
10	690751	Screw (Breather Assembly)	40	692058	Retainer-Valve	105	●807706	Valve-Float Needle
11	806083s	Tube-Breather	42	807683	Keeper-Valve	108	690729	Valve-Choke
12	★691684	Gasket-Crankcase	45	690977	Tappet-Valve	109	807711	Shaft-Choke
13	692059	Screw (Cylinder Head)	46	691557	Camshaft	117	●806487	Jet-Main (Standard)
15	690946	Plug-Oil Drain (Square Head)	50B	690754	Manifold-Intake	118	806634	Jet-Main (High Altitude)
16	692159	Crankshaft	51B	★692035	Gasket-Intake (Manifold/Heads)	121	808807	Kit-Carburetor Overhaul
20	★805049s	Seal-Oil (PTO Side)	51C	★691694	Gasket-Intake (Manifold/Carburetor Spacer)	122A	690753	Spacer-Carburetor
22	807362	Screw (Crankcase Cover/Sump)	54	690676	Screw (Intake Manifold)	125	842651	Carburetor
23	841657	Flywheel Used on Type No(s). 0113.	58	66574	Rope-Starter (Cut To Required Length)	127	●690730	Plug-Welch (9mm Diameter)
23E	841908	Flywheel	59	805957	Insert-Grip	127A	●690731	Plug-Welch (6.9mm Diameter)
25	807619	Piston Assembly (Standard)	60	808167	Grip-Starter Rope	130	690732	Valve-Throttle
		----- Note -----	65A	841233	Screw (Rewind Starter)	133	807710	Float-Carburetor
		807809 Piston Assembly (.020" Oversize)	72	●806488	Tube-Jet	137	◆●806481	Gasket-Float Bowl
26	807620	Ring Set (Standard)	73A	841662	Screen-Rotating	142	●806635	Nozzle-Carburetor (Standard)
		----- Note -----			841440 Screen-Rotating Used on Type No(s). 0113.	146	691639	Key-Timing
		807810 Ring Set (.020" Oversize)				161	691561	Base-Air Cleaner (Metal)
27	690683	Lock-Piston Pin	74A	841441	Screw (Rotating Screen)	163	692081	Gasket-Air Cleaner (Used With Metal Air Cleaner Base)
28	807621	Pin-Piston				185	690939	Nut (Air Cleaner Base)

★ Included in Engine Gasket Set-Ref. No. 358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No. 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

3382-13

Assemblies include all parts shown in frames.

12/21/2005

295700

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
187	841858	Line-Fuel ----- Note ----- 791745 Line-Fuel (Used After Code Date 05063000). Used on Type No(s). 0113. 296004 Line-Fuel (Used Before Code Date 05070100). Used on Type No(s). 0113.	239	690233	Switch-Oil Pressure (Oil GARD Only)	308	841232	Cover-Cylinder Head (Cylinder 1)
187A	791766	Line-Fuel (Used After Code Date 05063000). ----- Note ----- 691050 Line-Fuel (Used Before Code Date 05070100).	240A	691035	Filter-Fuel (Includes Paper Element With A 40 Micron Rating)	308F	841182	Cover-Cylinder Head (Cylinder 2)
188	692056	Screw (Control Bracket)	254	807713	Drain-Carburetor Bowl	309A	691564	Motor-Starter
192	807623	Adjuster-Rocker Arm	265	691024	Clamp-Casing (Casing Clamp)	310A	690323	Screw (Starter Motor)
197	807163	Screw (Back Plate)	267	692083	Screw (Casing Clamp)	311A	497608	Brush Set
203	690923	Crank-Bell	268	691025	Casing-Control Wire (Cut To Required Length)	322	841233	Screw (Cylinder Head Cover)
205	692083	Screw (Bell Crank)	269	691026	Wire-Control (Cut To Required Length)	332	690887	Nut (Flywheel)
209	692071	Spring-Governor (White) ----- Note ----- 692072 Spring-Governor (Purple) Used on Type No(s). 0113.	270	691027	Nut (Control Wire Casing)	333	492341	Armature-Magneto
211	692069	Spring-Governed Idle	271	691028	Lever-Control	334	692066	Screw (Magneto Armature)
212	690712	Link-Throttle	273	★690681	Seal-O Ring (Oil Pump)	337	792015	Plug-Spark
216	690705	Link-Choke	276	690704	Washer-Sealing (Crankcase Cover/Sump)	351	692083	Screw (Ground Terminal)
222	808454	Bracket-Control	276A	★△807085	Washer-Sealing (Rocker Cover)	357	691483	Key-Drive Pulley
226	692075	Rod-Hand Choke	276B	◆●806476	Washer-Sealing (Float Bowl)	358	842722	Gasket Set-Engine
227	690236	Lever-Governor Control	276C	◆●806477	Washer-Sealing (Carburetor Plug)	359	691077	Washer (Ground Terminal)
231	690728	Screw (Choke Valve)	278	842122	Washer (Governor Control Lever)	363	19203	Puller-Flywheel
232	692073	Spring-Governor Link	287A	807084	Screw (Dipstick Tube)	373A	691612	Nut (Ground Terminal)
234	691723	Clip-Control Rod	300B	498984s	Muffler	377	808095	Key-Woodruff
			304	841658	Housing-Blower	383	19374s	Wrench-Spark Plug ----- Note ----- 19576s Wrench-Spark Plug Used on Type No(s). 0113.
			305	692056	Screw (Blower Housing) (14mm)	385	807084	Screw (Fuel Pump)
			305B	841233	Screw (Blower Housing) (12 mm)	387	808656	Pump-Fuel
						402	690679	Screw (Oil Filter Cover)
						413	693587	Nut (Starter Motor)
						415	690283	Plug (Square Head)
						436B	691502	Manifold-Exhaust
						437	691902	Screw (Exhaust Manifold)
						439	692154	Seal-O Ring (Crankcase Cover/Sump)

★ Included in Engine Gasket Set-Ref. No. 358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No. 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

295700

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
445	394018s	Filter–Air Cleaner Cartridge (Round)	608	841729	Starter–Rewind	748	692083	Screw (Control Rod Clip)
447	807163	Screw (Air Guide Cover)	613	691902	Screw (Muffler)	788	691559	Bracket–Fuel Pump
455	841794	Cup–Flywheel	613A	690297	Screw (Muffler)	797	693167	Nut (Brush Retainer)
467	691985	Knob–Air Cleaner	615	691550	Retainer–Governor Shaft	797B	691029	Nut (Brush Retainer)
474A	696578	Alternator (DC Only)	616	806685	Crank–Governor	801	808778	Cap–Drive
505	690238	Nut (Governor Control Lever)	628A	806660	Screw (Fuel Pump Bracket)	802A	691286	Cap–End
506	807120	Screw (Carburetor Cover)	633	◆690738	Seal–Choke/Throttle Shaft	803A	693547	Housing–Starter
507	691972	Insulator	635	692076	Boot–Spark Plug	807	◆690733	Spacer–Throttle
510	496881	Drive–Starter	637	◆690735	Washer (Throttle Shaft)	816	690706	Washer (Oil Filter Adapter)
520	691084	Terminal–Ground	638	691551	Washer (Cylinder Head Cover)	830	809157	Stud–Rocker Arm
523	692101	Dipstick	643	692079	Retainer–Air Filter	833A	841233	Screw (Air Cleaner Mounting Strap/Stud)
524	★692053	Seal–Dipstick Tube	668B	690737	Spacer	842	★691870	Seal–O Ring (Dipstick Tube)
525	692093	Tube–Dipstick	676	393761	Deflector–Muffler	851	493880s	Terminal–Spark Plug
527	690423	Clamp–Tube	677	690661	Screw (Muffler Deflector)	862	692542	Strap/Stud–Air Cleaner Mounting
529	690744	Grommet	691	690680	Seal–Governor Shaft	865	807119	Cover–Air Guide (Black)
544A		Armature–Starter (Service With 691564 Starter Motor Only)	697	692062	Screw (Drive Cap)	868	△691963	Seal–Valve
552	690701	Bushing–Governor Crank	710	807689	Cover–Oil Filter	871	692057	Bushing–Valve Guide
552A	806686	Bushing–Governor Crank	711A	807084	Screw (Carburetor Shield)	877A	393814	Wire/Connector–Alternator (DC Only)
562	690239	Bolt (Governor Control Lever)	718	806469	Pin–Locating Gear–Ring (Steel)(See Reference 23 for Service)	879	841861	Cover–Carburetor
565	690682	Stud (Oil Filter Adapter)	726			883A	★△691613	Gasket–Exhaust
572	690686	Baffle–Breather	727	841313	Cover–Starter Drive	884	691956	Clamp–Muffler (1 1/4" Inside Diameter)
573	841310	Plate–Back	729	690586	Clip–Wire (Snap In)(Nylon)	914	807120	Screw (Rocker Cover)
578	692306	Wire Assembly	732	690688	Screw (Starter Drive Cover)	918	393815	Hose–Vacuum
578A	692319	Wire Assembly (With Diodes)	732A	841233	Screw (Starter Drive Cover)	930	841490	Guard–Rewind
592	690939	Nut (Rewind Starter)	737	690679	Screw (Oil Filter Adapter)	947	806472	Solenoid–Fuel
596	691492	Screw (Oil Pump)	739	690451	Clip–Debris	955	807714	Plug–Carburetor
601A	691038	Clamp–Hose	741	691530	Gear–Timing	955A	691511	Screw–Float Bowl
601B	95162s	Clamp–Hose	742	◆805578	Retainer–E Ring	967	272490s	Filter–Pre Cleaner (Round)

★ Included in Engine Gasket Set–Ref. No. 358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

△ Included in Valve Gasket Set–Ref. No. 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

3382–15

Assemblies include all parts shown in frames.

12/21/2005

295700

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
968	699959	Cover-Air Cleaner (Used With Metal Air Cleaner Base)	1022 ★ 806039s		Gasket-Rocker Cover	1051	● 690736	Ring-Retaining
971A	807084	Screw (Air Cleaner Base to Carburetor)	1023A	691558	Cover-Rocker (Cylinder 1) (With Fuel Pump)	1051A	691124	Ring-Retaining
975	807715	Bowl-Float	1023B	691494	Cover-Rocker	1054	280275	Tie-Cable
977	808325	Gasket Set-Carburetor	1024	693186	Pump-Oil	1058	276353	Operator's Manual
987 ♦● 691548		Seal-Throttle Shaft	1025	690689	Spool-Governor	1059	698516	Kit-Screw/Washer
988	692063	Gasket-Oil Adapter	1026	691836	Rod-Push (Intake)(Steel)	1090	691293	Retainer-Brush
988A ★ 690687		Gasket-Oil Adapter			----- Note -----	1091	● 691515	Cap-Limiter
996	691577	Shield-Carburetor			691758 Rod-Push (Exhaust)(Aluminum)	1095	842723	Gasket Set-Valve
1004	841656	Duct-Air (Used With Metal Air Cleaner Base)	1027	492932s	Filter-Oil	1100	690973	Pivot-Rocker Arm
1017	690878	Screen-Oil Pump	1028	808235	Adapter-Oil Filter	1119	691552	Screw (Alternator)
1019	808035	Kit-Label	1029	807323	Arm-Rocker	1130	690746	Stud (Intake Manifold)
			1036		Label-Emissions (Available from an Authorized Briggs & Stratton Service Dealer)	1254	807084	Screw (Rocker Cover Stud)
			1037	● 807717	Ball-Choke Locator	1330	272144	Repair Manual
						1346	492031	Valve-Oil Drain Shut Off
						1392	690939	Nut (Rewind Guard)

★ Included in Engine Gasket Set-Ref. No. 358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

♦ Included in Carburetor Gasket Set-Ref. No. 977.

Δ Included in Valve Gasket Set-Ref. No. 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.