

10E900 to 10E999**SERVICE ENGINE****SALES MANUAL****MODEL 10E900 SERIES ENGINES REPLACED WITH
STANDARD SERVICE ENGINES**

In most cases, the Original Type numbers shown may be replaced by a Service Type Number without making any changes. Necessary changes of engine parts such as crankshafts, reduction parts, blower housings, etc., are noted. Other differences, such as mufflers, elbows, deflectors, etc., are not listed but are very important for safety and engine performance. Be sure the exhaust system on the replacement engine duplicates the system originally selected by the equipment manufacturer. Parts that are suitable for additional use should be transferred. Before making any conversion, check the data shown in the column labeled "REMOVE, ADD and NOTE." See if the changes, which are shown, are actually necessary on the application in question. Often a standard service engine will be a WORKABLE replacement without converting to such things as a special fuel tank or starter position.

If the crankshaft number does not appear in the "Original Engine" column, consult the Illustrated Parts List for the correct service replacement crankshaft number.

Engine Replacement Notes:

NOTE 51: Replacement engine listed is not available in the State of California. Repair with individual parts.

NOTE 81: Transfer Governor Spring to replacement engine.

NOTE 88: Transfer Muffler and/or Spark Arrester Assembly from the original engine if suitable for additional service or add new parts as required

Short Block Notes:

The SHORT BLOCK part number shown, is the assembly which can be used to rebuild the Original Type Number. If a letter appears after the short block number, it indicates the short block must be modified. The change denoted by each letter is as follows:

10E900 to 10E999

Original Engine			Make From		Remove		Add		Note	Change to Type	Trim	RPM	Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #					Part #	Notes
0015	10E902	691472	10M902	0015							All	3100		
0018	10E902	692989	10M902	0018							All	3100		
0050	10E982	691472	No Replacement Repair With Individual Parts.								All	3100		
0100	10E902	691472	10M902	0015							All	3200		
0105	10E902	691471	10M902	0015	1	691472	1	691471			All	3000		
0110	10E902	692989	10M902	0018							All	3100		
0111	10E902	691472	10M902	0015							All	3100		
0112	10E902	691472	10M902	0015					81		All	3300		
0113	10E902	691471	10M902	0015	1	691472	1	691471			All	2900		
0116	10E902	691472	10M902	0015							All	2900		
0117	10E902	691472	10M902	0015					81		All	2800		
0118	10E902	691471	10M902	0016					88		All	3000		
0119	10E902	692989	10M902	0018					88		All	3300		
0207	10E902	691472	10M902	0015							All	3150		
0211	10E902	691472	10M902	0015							All	3150		
0459	10E902	691472	10M902	0015							All	2950		
0462	10E902	691472	10M902	0015					88		All	2950		
0550	10E902	691472	10M902	0015					88		All	2950		