FORM MS-5845-10/05 REPLACES FORM MS-5845-4/05 FILE IN SECT.2B OF SERVICE ENGINE SALES

542400 to 542499



MODEL 542400 SERIES ENGINES REPLACED WITH STANDARD SERVICE ENGINES

In most cases, the Original Type numbers shown may be replaced by a Service Type Number without making any changes. Necessary changes of engine parts such as crankshafts, reduction parts, blower housings, etc., are noted. Other differences, such as mufflers, elbows, deflectors, etc., are not listed but are very important for safety and engine performance. Be sure the exhaust system on the replacement engine duplicates the system originally selected by the equipment manufacturer. Parts that are suitable for additional use should be transferred. Before making any conversion, check the data shown in the column labeled "REMOVE, ADD and NOTE." See if the changes, which are shown, are actually necessary on the application in question. Often a standard service engine will be a WORKABLE replacement without converting to such things as a special fuel tank or starter position.

If the crankshaft number does not appear in the "Original Engine" column, consult the Illustrated Parts List for the correct service replacement crankshaft number.

Engine Replacement Notes:

- NOTE 15: For all Go-Karts use only a Model 136200 series engine as a replacement, regarless of the original Model.
- NOTE 42: Original engine was equipped special Remote Throttle Control or Governor Control. Transfer these parts to replacement engine.
- NOTE 81: Transfer Governor Spring to replacement engine.
- NOTE 93: Transfer Starter Panel group and/or Starter Motor to replacement engine.
- NOTE 96: Transfer the Air Cleaner Assembly and related parts to the replacement engine.

Short Block Notes:

The SHORT BLOCK part number shown, is the assembly which can be used to rebuild the Original Type Number. If a letter appears after the short block number, it indicates the short block must be modified. The change denoted by each letter is as follows:

542400 to 542499

Original Engine			Make From		Remove		Add			Change			Short Block	
Type	Model	Crank	Model	Type #	Qty	Part #	Qty	Part #	Note t	to Type	Trim	RPM	Part #	Notes
0110	542477	809982	543477	0110					15		All	4000	699428	
									81					
									93					
0111	542477	809982	543477	0048					15		All	3600	699428	
									42					
0112	542477	841529	543477	0079					15		All	3600	790815	
0113	542477	809982	543477	0048					15		All	3600	699428	
0115	542477	809982	543477	0048					15		All	4000	699428	
									42					
									81					
									96					