



MODEL 4360

3 Speed Transaxle
4360-22

KEY NO.	DANA PART NO.	NO. REQ'D.	DESCRIPTION	TRANSMISSION MODELS PARTS USED ON	KEY NO.	DANA PART NO.	NO. REQ'D.	DESCRIPTION	TRANSMISSION MODELS PARTS USED ON
1	3865-A	1	Housing, Upper	4360-22	38	4286	1	Ass'y., Gear,	4360-22
2	1919	16	Screw, Tapping, 1/4-20x.734 Lg.	4360-22				Comb., 12T. & 35T.	
3	5112	2	Ball, Detent	4360-22	39	3967	1	Shaft, Idler	4360-22
4	3626	2	Spring, Detent	4360-22	40	3901	1	Spacer,	4360-22
5	3623	2	Screw, Set	4360-22				.635x.875x.755	
6	4265	1	Ass'y., Shifter	4360-22	41	3815	1	Sprocket, 10T.	4360-22
7	5024	1	Boot, Shifter	4360-22	42	3853	1	Gear, Bevel, 42T.	4360-22
8	3917	1	Bracket,	4360-22	43	3749	*	Washer, Plain,	4360-22
			Anti-Rotation					.758x1.12x.010	
9	3847	1	Nut, Lock, 5/16-24	4360-22	43	3652	*	Washer, Plain,	4360-22
10	1099	1	Ring, Retaining	4360-22				.758x1.12x.015	
11	1959	*	Washer, Plain,	4360-22	43	3693	*	Washer, Plain,	4360-22
			.632x1.00x.010					.758x1.12x.020	
11	1441	*	Washer, Plain,	4360-22	43	3653	*	Washer, Plain,	4360-22
			.632x1.00x.020					.758x1.12x.025	
11	1423	*	Washer, Plain,	4360-22	43	3408	*	Washer, Plain,	4360-22
			.632x1.00x.026					.758x1.25x.020	
11	1082	*	Washer, Plain,	4360-22	43	3732	*	Washer, Plain,	4360-22
			.632x1.00x.031					.758x1.25x.025	
11	1424	*	Washer, Plain,	4360-22	43	3184	*	Washer, Plain,	4360-22
			.632x1.00x.036					.758x1.25x.031	
11	1068	*	Washer, Plain,	4360-22	43	3733	*	Washer, Plain,	4360-22
			.632x1.00x.041					.758x1.25x.035	
11	1425	*	Washer, Plain,	4360-22	43	3198	*	Washer, Plain,	4360-22
			.632x1.00x.046					.758x1.25x.040	
11	1358	*	Washer, Plain,	4360-22	43	3734	*	Washer, Plain,	4360-22
			.632x1.00x.050					.758x1.25x.045	
11	1145	*	Washer, Plain,	4360-22	43	3735	*	Washer, Plain,	4360-22
			.632x1.00x.060					.758x1.25x.050	
11	1319	*	Washer, Plain,	4360-22	43	3180	*	Washer, Plain,	4360-22
			.632x1.00x.082					.758x1.25x.062	
12	3760	1	Washer, Plain,	4360-22	44	3882	1	Shaft, Drive	4360-22
			.321x1.00x.055		45	3707	1	Gear, Spur, 15T.	4360-22
13	3876	2	Washer, Plain,	4360-22	46	3684	1	Spacer,	4360-22
			.632x1.38x.046					.781x1.00x.750	
14	1374	1	Key, Woodruff, #9	4360-22	47	3724	1	Screw, Tapping,	4360-22
15	4551	1	Ass'y., Kit, Input Shaft	4360-22				5/16-18x1.44 Lg.	
	3590	1	Pinion, Bevel, 14T.	4360-22	48	3818	1	Gear, Spur, 30T.	4360-22
17	3624	1	Ring, Retaining	4360-22	49	5013	1	Gear, Spur, 23T.	4360-22
18	1090	1	Chain, 22 Pitches	4360-22	50	3714	1	Spacer,	4360-22
19	1542	4	Bearing, Flange	4360-22				.781x1.00x.375	
20	3773	1	Gear, Spur, 14T.	4360-22	51	1145	1	Washer, Plain,	4360-22
21	3631	1	Collar, Clutch	4360-22				.632x1.00x.060	
22	3828	2	Key, Clutch	4360-22	52	3191	2	Seal, Felt	4360-22
23	1369	1	Key, Woodruff, #3	4360-22	53	3180	1	Washer, Plain,	4360-22
24	3883	1	Shaft, Intermediate	4360-22				.758x1.25x.062	
25	1375	1	Key, Woodruff, #61	4360-22	54	3895	1	Axle, L.H.	4360-22
26	3627	1	Ring, Retaining	4360-22	55	3780	2	Gear, Miter, 15T.	4360-22
27	3897	1	Sprocket, Special 14T.	4360-22	56	3656	2	Ring, Retaining	4360-22
					57	3839	1	Gear, Spur, 32T.	4360-22
28	3841	1	Spacer	4360-22	58	3919	1	Shaft, Cross	4360-22
29	3785	1	Gear, Spur, 35T.	4360-22	59	3781	2	Gear, Miter, 15T.	4360-22
30	5026	1	Spacer,	4360-22	60	3896	1	Axle, R.H.	4360-22
			1.133x1.50x.750		61	3864-C	1	Housing, Lower	4360-22
31	5014	1	Gear, Spur, 27T.	4360-22	62	3920	1	Puck, Friction	4360-22
32	3817	1	Gear, Spur, 20T.	4360-22	63	3276	1	Disc, Brake	4360-22
33	3907	1	Puck, Friction	4360-22	64	3758	1	Spacer	4360-22
34	5027	1	Spacer,	4360-22	65	3916	1	Jaw, Brake	4360-22
			1.133x1.50x.375		66	3843	2	Pin, Dowel	4360-22
35	3628	1	Washer, Plain,	4360-22	67	3915	1	Screw, Tapping,	4360-22
			.640x1.37x.061					5/16-18x2.25 Lg.	
36	1423	2	Washer, Plain,	4360-22	68	5023	1	Lever, Actuating	4360-22
			.632x1.00x.026		69	4300	1	Grease	4360-22
37	3422	1	Spacer,	4360-22	70	5110	2	Washer, Sealing #14	4360-22
			.630x1.00x.169						

*Use in various combinations to maintain proper clearances.

**Order key #15.