



The Green Machine®

HMC, P.O. Box 560, Long Beach, CA 90801-0560
20710 So. Alameda Street, Long Beach, CA 90810



PAGE 1

EXPLODED PARTS VIEW AND NUMERICAL PARTS LIST FOR MODEL 2130


ITEM	PART NUMBER	DESCRIPTION
1	20125	3" TFC HEAD ASSY
2	165208	CAP
3	165209	SPOOL
4	166903	PLATE, SPRING
5	167901	SPRING
6	226701	ARBOR
7	220307	HEAD BODY
8	25250	FIXED LINE HEAD ASSY (OPT)
9	31105	GREEN LINE .080 (OPTIONAL)
10	325205	ARBOR BOLT (OPTIONAL)
11	31004	GREEN LINE .080 3 LB (OPTIONAL)
12	31005	GREEN LINE .085 1 LB (OPTIONAL)
13	32005	GREEN LINE 15 FT. (OPTIONAL)
14	300190	SPANNER
15		
16	24700	BLADE GUARD ASSY
17	011417	SCREW
18	011418	SCREW
19	245201	BLADE GUARD BRACKET
20	051012	NUT
21	041004	WASHER
22	041101	WASHER
23	051002	NUT
24	247001	GUARD
25	041102	WASHER
26		
27		
28	280310	GEARCASE ASSY
29	070027	BEARING
30	190609	GEAR SET KIT
31	226706	SHAFT, GEAR
32	070002	BEARING
33	060020	RING
34	070026	BEARING
35	300080	BOLT
36	040007	WASHER
37	041003	WASHER
38	300075	HOLDER B
39	300070	HOLDER A
40	226705	COLLAR
41	280321	HOUSING SET
42	236713	GEARCASE LH
43	236712	GEARCASE RH
44	286710	FITTING ZERK
45	011310	SCREW-SELF TAPPING
46	011309	SCREW-SELF TAPPING
47		
48		
49	92115	SAW BLADE (OPTIONAL)
50	92100	BRUSH BLADE (OPTIONAL)
51	94110	BLADE COVER (OPTIONAL)
52		
53	300185	TOOL SET (OPTIONAL)
54	309925	TOOL BAG (OPTIONAL)
55	190105	SPANNER (OPTIONAL)
56	309928	SOCKET (OPTIONAL)
57	190104	SCREW DRIVER (OPTIONAL)
58		
59		




11 — 0.095 LINE ON SPOOL
12 — 1-LB. 0.095 LINE
13 — 3-LB. 0.095 LINE



OPTIONAL BLADES



BLADE GUARD MUST BE
INSTALLED WHENEVER
METAL BLADES ARE USED





20710 S. ALAMEDA ST., LONG BEACH, CA 90810 • (213) 603-9888 • TELEX 696396
P.O. BOX 560, LONG BEACH, CALIFORNIA 90801-0560 • FAX (213) 635-3526



GM906 10/89

www.mymowerparts.com

ITEM	PART NUMBER	DESCRIPTION
84	280311	HARNES
85	300245	HANGER ASSY
86	300150	HANGER
87	010002	SCREW
88	041101	WASHER
89	050003	NUT
90	235209	ASSIST HANDLE
91	190120	KNOB
92	040016	WASHER
93	257606	BOLT
94	210304	TUBE ASSY
95	300035	FOAM GRIP
96	187801	CABLE, FLEX
97	280361	THROTTLE HOUSING KIT
98	285207	HOUSING LH
99	285206	HOUSING RH
100	235214	THROTTLE LEVER
101	167101	SPRING THROTTLE
102	201044	SCREW
103	190326	SWITCH ASSY
104	193605	HARNES-ELECTRIC
105		
106		
107		
108		
109		
110		
111		
112		
113	193604	TERMINAL
114	010126	SCREW
115	010125	SCREW HEX HEAD M5 X 35
116	040115	WASHER-FLAT M5
117	050060	NUT-HEX M5
118	190304	HOUSING ASSEMBLY-FAN
119	195207	HOUSING-FAN
120	196702	PLATE-THRUST
121	190305	DRUM ASSEMBLY-CLUTCH
122	061103	RING-RETAINING
123	070033	BEARING-BALL
124	197608	DRUM-CLUTCH
125	190306	CLUTCH ASSEMBLY
126	197606	ROTOR CLUTCH
127	197901	SPRING-CLUTCH
128	197607	SHOE-CLUTCH
129	196102	PLATE SIDE
130		
131		
132	196712	FLYWHEEL
133	082003	SEAL-CRANKSHAFT
134	197603	PIN
135	195502	GROMMET
136	196706	CRANKCASE ASSY
137	197405	GASKET
138	071412	BEARING
139	197605	KEY-FLYWHEEL
140	196708	CRANKSHAFT/CON ROD ASSY
141	071411	BEARING
142	010130	SCREW
143	197602	RATCHET ASSEMBLY
144	050062	NUT-STARTER RATCHET
145	062006	RING-SNAP
146	197604	PIN-WRIST
147	196707	PISTON-NON-PLATED
148	062007	RING-PISTON
149		
150	195508	GROMMET
151	194003	CONNECTOR
152	194002	BOOT
153	197404	GASKET
154	010129	SCREW
155	196705	CYLINDER PLATED
156	193901	SPARK PLUG
157	196704	COVER-CYLINDER
158	010128	SCREW
159	020004	STUD-MUFFLER
160	194004	COIL-IGNITION
161	010126	SCREW
162	193602	GND WIRE ASSY
163		
164	197403	GASKET-MUFFLER
165	196701	MUFFLER ASSEMBLY
166	197501	SCREEN
167	195204	COVER
168	011424	SCREW
169	050059	NUT



MODEL 2130



ITEM	PART NUMBER	DESCRIPTION
170	010122	SCREW
171	197601	SPACER MUFFLER
172	010121	SCREW-PAN M4 X 17
173	195203	SHIELD-MUFFLER
174		
175		
176	190302	FUEL TANK/HOSE ASSY
177	195504	CUSHION
178	195206	CAP-FUEL
179	195402	HOSE-FUEL
180		
181	195507	PICK-UP FUEL
182	195401	FUEL HOSE (RETURN)
183		
184	195505	CUSHION
185		
186	197305	ROPE GUIDE
187	190307	STARTER ASSEMBLY
188	010123	SCREW-STARTER
189	197301	HOUSING-STARTER
190	197304	SPRING-STARTER
191	197303	ROPE-STARTER
192	195506	HANDLE-STARTER
193	040114	WASHER
194	197302	DRUM/ROPE
195	040113	WASHER
196	011425	SCREW-DRUM
197	196710	SPACER
198	196711	SPACER
199	197402	GASKET-INSULATOR/CYL.
200	195205	INSULATOR-CARB./CYL.
201	197401	GASKET-CARB./INSULATOR
202	190601	KIT CARB. MAJOR REP
203	190602	KIT CARB. MINOR REP
204	190204	CARBURETOR ASSY
205	010131	SCREW
206	197201	CAP-MAIN
207	197202	DIAPHRAGM-MAIN
208	197203	GASKET-MAIN
209	197102	PUMP COVER
210	197104	SCREW
211	197103	PRIMER PUMP
212	010132	SCREW
213	197101	THROTTLE CABLE
213A	050014	NUT
214	197206	PIN
215	197205	ARM NEEDLE VALVE
216	197208	NEEDLE VALVE
217	197207	SPRING-ARM
218	197209	WELCH PLUG
219	197215	"E" RING
220	197218	THROTTLE VALVE
221	010133	SCREW THROTTLE VALVE
222	197210	SPRING NEEDLE
223	197212	NEEDLE-IDLE
224	197211	NEEDLE-HIGH SPEED
225	197106	RETAINER
226	197107	CHECK VALVE
227	197214	SHAFT ASSY-THROTTLE
228	197213	SPRING THROTTLE RETURN
229	010135	SCREW-IDLE ADJ
230	197105	SPRING
231	197222	COVER-FUEL PUMP
232	197221	GASKET PUMP
233	197220	DIAPHRAGM-FUEL PUMP
234	197219	STRAINER
235	197108	NOZZLE ASSY
236		
237	010120	SCREW-CHOKE COVER
238	195201	COVER ASSEMBLY-CHOKE
239	195901	FILTER-AIR
240	195202	BOX-AIR