


Blower UT-08931  
Carburetor And Fuel Tank

Page 2 of 12


Ref #	Part Number	Qty	S/P/F	Description
1	984907001	1	S/P	FUEL TANK KIT INCLUDES 1-3
2	A09116	1	S/P	FUEL TANK CAP
3	08684	1	S/P	HEAT SHIELD
4	98792	3	/P	RUBBER BUMPER
5	985232001	1	S	CARBURETOR KIT INCLUDES 5-7
6	985304001	1	/P	INLINE FUEL FITTING
7	0143912	1	S/P	RUBBER TUBBING (3 in.)
8	983925001	1		CARBURETOR GASKET
9	00775A	1	S/P	HEAT DAM GASKET
10	04474	2	/P	SCREW (10-24 x 1 in. HEX HD ) PURCHASE LOCALLY
11	98768A	1	/P	HEAT DAM
12	093221	2	S/P	SCREW (10-24 x 1 1/8 in. PAN HD) PURCHASE LOCALLY
13	985077001	1	S/P	FUEL FILTER KIT



Blower UT-08931  
Ignition And Rotor

Page 4 of 12

Ref #	Part Number	Qty	S/P/F	Description
1	985122001	1	S	IGNITION KIT WITH MODULE INCLUDES 1-2
2	PS02227	1	S/P	SPARK PLUG
3	82540	2	/P	SCREW (8-32 x 1 in. TORX PAN HD) PURCHASE LOCALLY
4	984521001	1	S	ROTOR AND STARTER PAWLS
5	95479A	1	/P	FLAT WASHER
6	PS03566	1	S/P	FAN SPACER




Blower UT-08931  
Internal Engine

Page 6 of 12

Ref #	Part Number	Qty	S/P/F	Description
1	983928001	1		SHORT BLOCK (30cc) INCLUDES 1-6
2	985524002	1	/P	30cc CYLINDER
3	985259001	1	S/P	CYLINDER GASKET
4	PS02807	3	/P	SCREW (12-24 x 3/4 in. TORX PAN HD) PURCHASE LOCALLY
5	984543001	1	S	30cc PISTON AND ROD
6	985607001	2	/P	PISTON RING
7	PS02130	1	/P	CRANKCASE COVER
8	06443A	1	S/P	CRANKCASE GASKET
9	PS01565	4	/P	SCREW (10-24 x 9/16 in. PAN HD) PURCHASE LOCALLY
10	82376	3	/P	SCREW (#8 x 1/2 in. PAN HD) PURCHASE LOCALLY
11	82563	1	/P	SCREW (#10 x 3/4 in. TORX TRUSS HD) PURCHASE LOCALLY
12	PS06314	1	/P	SHROUD
13	983924001	1	/P	ZIP START DECAL

Blower UT-08931  
Muffler And Air Cleaner

Page 7 of 12



Blower UT-08931  
Muffler And Air Cleaner


Page 8 of 12

Ref #	Part Number	Qty	S/P/F	Description
1	983895001	1	/P	MUFFLER COMPLETE (UT08120)
	PA01668	1	/P	MUFFLER COMPLETE (UT08931)
2	09217	1	/P	AIR FILTER BOX
3	81208	2	/P	HEX NUT (10-24) PURCHASE LOCALLY
4	98760	1	/P	AIR FILTER
5	09218	1	/P	AIR FILTER COVER
6	983904001	1	/P	CHOKE DECAL



Blower UT-08931  
Starter

Page 9 of 12




Blower UT-08931  
Starter

Page 10 of 12

Ref #	Part Number	Qty	S/P/F	Description
1	983864001	1	/P	THROTTLE LATCH
2	00370	1	S/P	THROTTLE LATCH SPRING
3	00367	1	/P	THROTTLE TRIGGER
4	00369A	1	/P	THROTTLE LEVER
5	82538	4	/P	SCREW (10-24 x 3/4 in. TRUSS HD) PURCHASE LOCALLY
6	JA416903	1	/P	SCREW (10 x 1-5/8 in. HEX HD) PURCHASE LOCALLY
7	00374	1	/P	ROTOR PLATE
8	82528	1	/P	SCREW (#6 x 1 3/8) PURCHASE LOCALLY
9	5946702	1	S/P	STARTER GRIP (YELLOW)
10	969811A	1	/P	BUSHING STARTER
11	00364B	1	S/P	STARTER ROPE GUIDE
12	A98773A	1	S/P	SPRING AND CONTAINER
13	98770A	1	/P	STARTER PULLEY
14	98791	2	/P	RETAINING BRACKET
15	82541	3	/P	SCREW (10-24 x 1/2 in. TORX TRUSS HD) PURCHASE LOCALLY
16	9789901	1	/P	STARTER ROPE
17	PS82146	1	S/P	SCREW (8-32 x 5/8 in. FIL HD) PURCHASE LOCALLY
18	82563	5	/P	SCREW (10-14 x 3/4 in. TORX TRUSS HD) PURCHASE LOCALLY
19	PS03167	1		INNER VOLUTE HOUSING
20	983856001	1	/P	THROTTLE CONTROL KNOB

Blower UT-08931  
Volute, Fan And Tubes



Blower UT-08931  
Volute, Fan And Tubes

Page 12 of 12

Ref #	Part Number	Qty	S/P/F	Description
1	00372B	1	/P	UPPER TUBE
2	03163	1	/P	BELLVILLE WASHER (3/8 in.)
3	00373A	1	S/P	LOWER NOZZLE
4	983906001	1	S/P	CLAMP WITH FASTENERS
5	983857002	1		OUTER VOLUTE HOUSING
6	983861001	1		DOOR
7	00398	1	/P	WIRE LOOP
8	81124A	1	/P	HEX NUT (3/8-24) PURCHASE LOCALLY
9	984911001	1	S/P	BLOWER FAN KIT
10	03165	1	S/P	FLAT WASHER
11	984921001	1		DOOR YARD BROOM DECAL
12	983901001	1	/P	WARNING DECAL
13	983903001	1		OUTER VOLUTE DECAL
14	983912001	1	/P	FAN INTAKE DECAL
15	617205001	1	/P	SCREW (1/4-20) PURCHASE LOCALLY
16	82541	2	/P	SCREW (10-24 X 1/2 in TORX TRUSS HD) PURCHASE LOCALLY
	983000-254	1	S	OPERATOR'S MANUAL
	983000-254R	1		REPAIR SHEET (REV:00)