


9

SX 91.004

GC 970

Grass Catcher



1.1991

Spare parts

Ersatzteile

Pièces détachées

Reserve onderdelen

Repuestos


Reservdelar

MODEL NUMBER GC970


PARTNUMBER	SQUARE	NOTE	PARTNUMBER	SQUARE	NOTE	PARTNUMBER	SQUARE	NOTE	PARTNUMBER	SQUARE	NOTE
506 55 43-01	B										
506 55 44-01	B										
506 59 74-01	B										
506 75 05-01	E										
506 75 17-01	F										
506 75 18-01	F										
506 75 19-01	F										
506 75 21-01	F										
506 75 24-01	E										
506 75 81-01	A										
506 76 22-01	B										
506 76 35-01	B										
506 76 39-01	B										
506 76 40-01	B										
506 76 46-01	B										
506 76 47-01	B										
506 76 48-01	A										
506 76 50-01	A										
506 76 51-01	A										
506 76 54-01	A										
506 76 60-01	B										
506 79 50-01	D										
506 79 51-01	D										
506 79 52-01	D										
506 87 52-01	D										
506 87 52-03	D										
506 87 75-01	A,F										
506 87 77-01	F										
506 87 78-01	C										
506 87 79-01	C										
506 88 27-01	B										
506 89 28-01	A,C										
506 89 30-01	D										
506 89 56-01	D										
506 89 56-02	D										
506 89 57-01	D										
516 82 53-08	B										
720 14 01-51	E										
721 68 01-51	B										
721 68 03-51	B,F										
722 14 16-20	D										
722 78 39-02	D										
722 79 71-02	D										
722 79 79-02	A										
722 79 81-02	A,F										
725 23 70-71	E										
725 23 72-71	C										
725 24 51-51	B										
725 24 55-51	B										
725 25 54-51	B										
729 54 54-01	A										
732 21 16-01	C										
732 21 18-01	B										
732 21 22-01	B										
734 11 36-41	D										
734 11 47-41	A,F										
734 11 53-41	A,C										
734 11 78-01	B										
735 31 18-00	B										
735 31 30-00	B										

A


* compl 506 76 48-01




D



B




E



C

compl 506 87 78-01



F

compl 506 75 17-01

