

LT 1000-14



1.1991

Spare parts

Ersatzteile

Pièces détachées


Reserve onderdelen

Repuestos

Reservdelar

Partnumber	Square	Partnumber	Square	Partnumber	Square	Partnumber	Square	Partnumber	Square
506 55 62-01	A	533 05 36-52	B	533 27 45-17	A	533 30 42-46	C	533 30 75-34	E
506 55 8541	F	533 05 52-73	B,C	533 27 46-54	D	533 30 42-59	D	533 30 81-44	C
506 56 56-01	A	533 05 55-11	F	533 30 01-71	A	533 30 42-60	D	533 30 81-67	F
506 89 15-01	F	533 05 55-47	E	533 30 01-93	F	533 30 42-96	D	533 30 82-01	F
516 84 46-00	F	533 05 60-30	B	533 30 01-94	F	533 30 43-67	C	533 30 83-39	A
532 00 90-40	B	533 05 61-80	E	533 30 03-02	A,B	533 30 44-06	C	533 30 83-40	A
532 10 80-81	F	533 05 62-55	C	533 30 03-03	B	533 30 44-14	E	533 30 83-41	D
532 11 07-12	F	533 05 63-65	E	533 30 03-10	A	533 30 44-20	E	533 30 83-42	A
533 00 06-42	B	533 05 64-25	E	533 30 03-11	A	533 30 44-22	E	533 30 83-43	A
533 00 07-06	B	533 05 64-31	C	533 30 03-17	E	533 30 44-24	E	533 30 83-45	A
533 00 12-82	E	533 05 64-72	C	533 30 03-28	B	533 30 44-39	F	533 30 83-84	D
533 00 13-41	A	533 05 69-07	A	533 30 03-45	E	533 30 44-43	E	533 30 83-99	D
533 00 13-46	E	533 05 71-57	C	533 30 04-40	B	533 30 44-48	A	533 30 84-46	D
533 00 14-98	B,C,D,E	533 05 71-58	B	533 30 06-34	B	533 30 44-75	A	533 30 84-47	D
533 00 14-99	B,C,E	533 05 72-11	F	533 30 11-40	B	533 30 44-76	A	533 30 84-59	F
533 00 15-00	A	533 05 72-17	E	533 30 12-39	A	533 30 44-80	A	533 30 86-42	C
533 00 15-02	B,C,E,F	533 05 72-20	F	533 20 20-31	F	533 30 44-81	A	533 30 87-19	D
533 00 24-83	B,E	533 05 73-25	C,E	533 30 21-97	A,E	533 30 44-90	C	533 30 87-20	D
533 00 29-68	B	533 05 74-44	F	533 30 22-05	A	533 30 47-02	B	533 30 90-70	E
533 00 30-21	C	533 05 75-51	F	533 30 22-08	A	533 30 47-28	A	533 30 94-60	B
533 00 91-43	A	533 05 77-69	F	533 30 23-03	B	533 30 47-29	A	533 30 94-61	B
533 00 94-05	E	533 05 77-91	C	533 30 23-06	B	533 30 47-30	A	533 30 95-46	C
533 00 97-96	C	533 05 82-47	E	533 30 23-07	B	533 30 51-24	E	533 30 96-15	E
533 01 22-80	D	533 05 82-76	D	533 30 23-14	B	533 30 52-83	E	533 31 00-67	F
533 01 22-88	D	533 05 82-78	A	533 30 23-37	C	533 30 52-84	E	533 31 01-62	c
533 01 22-89	D	533 05 83-25	A	533 30 23-57	A	533 30 53-06	A	533 31 03-26	E
533 01 22-90	D	533 05 83-26	A	533 30 23-63	E	533 30 53-39	B	533 31 05-76	A
533 01 23-19	D	533 05 83-30	A	533 30 23-64	E	533 30 53-40	B	533 31 05-77	B
533 01 23-21	D	533 07 10-46	C	533 30 23-83	A	533 30 53-60	B	533 31 06-25	E
533 01 23-25	D	533 10 95-27	E	533 30 23-89	A	533 30 53-79	A	533 31 19-41	E
533 01 24-65	D	533 12 02-28	B,D,E	533 30 24-98	B	533 30 53-80	A	533 31 23-02	E
533 01 24-85	D	533 12 02-38	E	533 30 25-24	B	533 30 55-18	A	533 31 23-42	E
533 01 25-01	B	533 12 03-68	F	533 30 25-38	C	533 30 55-20	A	533 31 30-43	C
533 01 25-53	F	533 12 03-69	B	533 30 25-82	C	533 30 55-22	A	533 31 30-44	C
533 02 05-07	A	533 12 03-72	E	533 30 25-88	D	533 30 55-53	C	533 31 33-16	E
533 02 08-64	B	533 12 03-75	E	533 30 25-93	D	533 30 55-54	C	533 31 38-98	E
533 02 16-82	D	533 12 03-76	E	533 30 25-94	D	533 30 57-20	F	533 31 70-18	E
533 02 20-53	c	533 12 03-77	A,E	533 30 26-11	E	533 30 57-21	B	533 31 70-41	E
533 02 37-63	E	533 12 03-82	B,D,E	533 30 27-14	E	533 30 57-22	B	533 41 23-49	D
533 02 50-86	B,C	533 12 03-83	C	533 30 28-33	E	533 30 58-20	B	533 42 10-51	D
533 02 51-77	D	533 12 03-85	C	533 30 28-77	D	533 30 58-50	B	533 42 86-44	C
533 03 52-87	C	533 12 03-92	B	533 30 26-78	D	533 30 59-89	A	533 44 63-63	D,E
533 03 54-10	C,D,E	533 12 03-93	A,D,E	533 30 29-07	B	533 30 59-91	A	533 45 18-14	D
533 03 54-97	A,C	533 12 03-94	C	533 30 29-12	F	533 30 60-01	D	533 45 63-78	B
533 03 54-98	D	533 12 06-38	A,C	533 30 29-63	E	533 30 61-03	B	533 45 67-22	D
533 03 61-49	A	533 12 08-54	B	533 30 30-64	F	533 30 62-17	D	533 98 53-38	A,C
533 03 63-11	D	533 12 12-22	A,C	533 30 30-72	E	533 30 62-18	D	533 98 53-46	B,C
533 03 63-68	A,C	533 12 12-23	C	533 30 31-09	C	533 30 62-93	A	533 99 64-16	B
533 03 66-25	B	533 12 20-07	A,E	533 30 31-32	B	533 30 62-94	A	725 23 66-71	F
533 03 95-22	E	533 12 20-17	D,E	533 30 32-27	A	533 30 63-35	B	729 22 23-01	B
533 03 95-73	E	533 12 20-27	E	533 30 32-28	B	533 30 63-91	A	731 23 16-01	F
533 03 97-28	D	533 12 21-45	C	533 30 32-30	A	533 30 64-77	E	734 11 63-01	A
533 04 02-23	C	533 12 21-88	A	533 30 32-41	C	533 30 64-78	E	738 22 03-19	E
533 04 14-82	F	533 12 22-07	B	533 30 40-24	C	533 30 65-69	B		
533 04 41-08	A,D,E	533 12 34-18	D	533 30 40-49	C	533 30 65-70	D		
533 04 51-71	C,E	533 12 49-25	B,D	533 30 40-83	C	533 30 65-77	C		
533 04 52453	B	533 12 62-11	A,C	533 30 40-86	C	533 30 65-90	C		
533 04 5642	A,D,E	533 13 71-85	E	533 30 41-02	E	533 30 66-69	B,D		
533 04 67-63	A	533 13 84-85	F	533 30 41-05	C	533 30 68-56	B		
533 04 60-44	E	533 13 84-89	C	533 30 41-15	D	533 30 68-57	B		
533 04 83-06	A	533 15 99-43	F	533 30 41-16	D	533 30 68-58	B		
533 04 93-32	E	533 18 00-18	A	533 30 41-18	E	533 30 68-83	E		
533 05 06-16	E	533 18 00-75	E	533 30 41-22	D	533 30 68-84	E		
533 05 06-34	A,B,E	533 18 00-77	C,E	533 30 41-23	D	533 30 68-85	E		
533 05 08-18	E	533 18 00-89	D	533 30 41-25	C	533 30 70-56	F		
533 05 08-47	C	533 18 01-34	B	533 30 41-27	D	533 30 71-12	B		
533 05 11-89	C	533 18 1646	D	533 30 41-30	C	533 30 71-13	F		
533 05 13-35	A	533 27 11-72	F	533 30 42-08	C	533 30 73-62	F		
533 05 14-49	E	533 27 11-84	C,F	533 30 42-12	C	533 30 74-37	B		
533 05 25-72	F	533 27 11-90	A	533 30 42-17	C	533 30 74-53	B		

A




Pos. no. Part no.
For Husqvarna


Pos. no.	Part no.
1	506 55 62-01
2	533 04 61-63
3	533 30 59-91
4	533 30 44-80
5	533 05 60-90
6	533 12 20-07
7	533 12 06-39
8	533 12 03-93
9	533 30 44-81
10	533 03 63-68
11	533 30 55-20
12	734 11 63-01
13	533 18 00-18
14	533 99 53-46
15	533 30 53-79
16	533 05 82-78
17	533 05 52-73
18	533 30 4475
19	533 30 44-76
20	533 30 22-08
21	533 03 54-97
22	533 30 63-91
23	533 00 15-00
24	533 30 47-29
25	533 30 21-97
26	533 30 53-06
27	533 30 44-48
28	533 30 59-89
29	533 00 14-98
30	533 02 05-07
31	533 30 32-27
32	533 04 83-06
33	533 30 32-30
34	533 30 55-22
35	533 12 62-11
36	533 30 22-05
37	533 30 23-83
38	533 00 91-43
39	533 30 01-71
40	533 04 41-08
41	533 30 03-10
42	533 30 03-11
43	533 30 23-57
44	533 03 61-49
45	533 04 56-02
46	533 05 83-30
47	533 05 83-26
48	533 05 83-25
49	533 30 47-30
50	533 30 12-39
51	533 30 23-89
52	533 12 12-22
53	533 30 83-39
54	533 30 83-45
55	533 30 83-40
56	533 30 83-43
57	533 30 83-42
58	533 03 66-25
59	533 12 02-28
60	533 30 62-93
61	533 05 69-07
62	533 30 62-94
63	533 05 13-35
64	533 30 47-28
65	533 12 03-77
66	533 30 03-02
67	533 30 53-80
68	533 31 05-76
69	533 99 53-38
74	533 00 13-41
75	533 30 55-18
76	533 05 06-34
77	533 12 21-88
78	533 27 11-90
79	533 18 00-16
80	533 00 15-02
81	533 27 45-17
82	506 56 56-01

or

B



C




Pos. no. Part no.
For Husqvarna

Pos. no.	Part no.
1	533 30 44-06
2	533 30 40-24
3	533 30 25-38
4	533 06 54-92
5	533 30 40-86
6	533 00 13-02
7	533 07 10-40
8	533 00 14-99
9	533 12 21-45
14	533 30 55-54
15	533 18 00-77
18	533 99 53-46
21	533 12 62-11
22	533 05 52-73
23	533 30 65-90
24	533 05 64-31
25	533 12 03-83
26	533 42 86-44
27	533 30 32-41
28	533 31 01-62
29	533 05 71-57
30	533 00 14-98
31	533 12 06-38
32	533 05 09-47
33	533 13 84-89
34	533 30 44-90
35	533 30 86-42
36	533 30 23-37
37	533 30 42-08
38	533 30 42-17
39	533 30 43-67
40	533 02 50-86
41	533 12 03-85
42	533 12 12-23
43	533 03 54-10
44	533 30 41-25
45	533 27 11-84
46	533 30 42-12
47	533 30 40-49
48	533 05 11-89
49	533 27 45-17
50	533 03 63-68
51	533 30 40-83
52	533 05 73-25
53	533 04 02-23
54	533 30 41-05
55	533 30 41-30
56	533 04 51-71
57	533 02 20-53
58	533 00 30-21
59	533 30 31-09
60	533 30 95-46
61	533 12 03-94
62	533 30 25-82
63	533 05 62-55
67	533 99 53-38
68	533 05 77-91
69	533 30 42-46
70	533 12 12-22
73	533 03 52-87
74	533 30 55-53
75	533 31 30-44
76	533 31 30-43
78	533 05 64-72
79	533 30 81-44
80	533 30 55-55
81	533 30 65-77
82	533 00 97-96

or

D



For Husqvarna

Pos. no.	Part no.
1	533 12 24-18
2	533 30 65-70
3	533 30 66-69
4	533 30 42-59
5	533 01 22-80
6	533 01 72-90
7	533 03 63-11
8	533 01 24-65
9	533 01 23-25
10	533 45 67-22
11	533 02 16-82
12	533 01 22-88
13	533 01 23-21
14	533 01 22-89
15	533 01 24-85
16	533 12 20-17
17	533 12 03-93
18	533 00 14-98
19	533 30 60-01
20	533 18 00-89
21	533 30 41-23
22	533 30 62-18
23	533 03 97-28
24	533 30 84-46
25	533 30 83-84
26	533 41 23-49
27	533 12 49-25
28	533 30 42-60
29	533 30 84-47
30	533 30 62-17
31	533 18 16-46
33	533 04 41-08
34	533 30 41-15
35	533 02 51-77
36	533 30 87-19
38	533 30 87-20
39	533 42 10-51
40	533 01 23-19
41	533 30 25-93
42	533 44 63-63
43	533 30 41-27
44	533 03 54-98
45	533 12 02-28
46	533 45 18-14
47	533 30 28-77
48	533 30 28-78
49	533 30 42-96
50	533 27 46-54
51	533 30 83-41
52	533 30 83-99
53	533 30 41-16
54	533 30 25-94
55	533 30 41-22
56	533 30 25-88
57	533 03 54-10
58	533 12 03-82
59	533 04 56-02
60	533 05 82-76


606-678-9623 or
606-561-4983

For Husqvarna

Pos. no.	Part no.
1	533 30 03-17
2	533 05 01-80
3	533 30 52-83
4	533 30 96-15
5	533 12 02-38
6	533 10 95-27
7	533 30 21-97
8	533 00 14-98
9	533 18 00-75
10	533 31 23-42
11	533 05 82-47
12	533 12 20-17
13	533 31 19-41
14	533 30 29-63
15	533 31 06-25
16	533 12 20-07
17	533 31 70-41
18	533 30 26-11
19	533 02 37-63
20	533 00 14-99
21	533 30 28-33
22	533 12 03-93
23	533 12 02-28
24	533 30 75-34
25	533 05 64-25
26	533 05 06-16
27	738 22 03-19
28	533 05 55-47
29	533 05 08-18
30	533 05 14-49
31	533 31 38-98
32	533 05 63-65
33	533 00 12-82
34	533 05 06-34
35	533 31 33-16
36	533 00 24-83
37	533 03 95-73
38	533 30 41-02
39	533 18 00-77
40	533 30 44-22
41	533 30 51-24
42	533 30 23-64
43	533 30 44-24
44	533 31 70-18
45	533 30 30-72
46	533 30 52-84
47	533 04 93-32
48	533 30 27-14
49	533 30 44-14
50	533 00 13-46
51	533 31 03-26
52	533 05 73-25
53	533 30 44-20
54	533 30 23-63
55	533 44 63-63
56	533 04 51-71
57	533 30 41-18
58	533 00 15-02
59	533 12 20-27
60	533 04 80-44
61	533 03 54-10
62	533 05 72-17
63	533 30 03-45
64	533 12 03-76
65	533 30 44-43
66	533 12 03-82
67	533 12 03-77
68	533 30 64-77
69	533 30 64-78
70	533 30 68-85
71	533 00 94-05
72	533 03 95-22
73	533 04 56-02
74	533 12 03-72
75	533 12 03-75
76	533 13 71-85
77	533 30 68-84
78	533 30 68-83
79	533 31 23-02
81	533 04 41-08
82	533 30 90-70

or

F



Pos. no. Husqvarna Part no.

Pos. no.	Husqvarna	Part no.
1	533	30 81-87
2	533	01 25-53
3	533	05 55-11
4	533	27 21-84
5	533	30 70-56
6	533	05 74-44
7	516	84 46-00
8	533	30 01-93
9	533	30 01-94
10	533	30 57-20
11	532	11 07-12
12	533	05 75-51
15	533	30 71-13
17	533	05 77-69
19	533	30 44-39
20	533	30 73-62
21	533	15 99-43
22	533	30 84-59
23	533	05 25-72
24	533	30 30-64
25	533	05 72-11
26	533	05 72-20
27	532	10 90-81
28	533	12 03-68
29	533	13 84-85
30	533	27 11-72
31	533	00 15-02
32	725	23 66-71
33	533	55 85-01
34	533	30 29-12
35	533	31 00-67
37	533	30 82-01
38	533	30 20-31
39	533	04 14-82
40	731	23 16-01
41	506	89 15-01

Parts Call
 606-678-9623 or
 606-561-4983