



Illustrated Parts
List

1991-01

I9100027

56 SFEB




954050901

For Husqvarna Parts Call 606-678-9623 or 606-561-4983

REPAIR PARTS

22" ROTARY LAWN MOWER - - MODEL NO. 56sfe, PRODUCT NO. 954 05 09-01



REPAIR PARTS

22" ROTARY LAWN MOWER - - MODEL NO. 56sfe, PRODUCT NO. 954 05 09-01


KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532 80 03-86	Grass Bag Assembly	40	532 06 23-35	Belleville Washer
2	532 80 07-46	Control Bar	41	532 08 49-21	Shoulder Bolt 3/8-16
3	532 85 07-24	Handle Grip	42	532 08 69-43	Wheel & Tire Assembly 9.0 x 2.0
4	532 08 54-36	Hex Washer Head Machine Screw 1/4-20 x 1-1/2	43	532 05 21-60	Washer
5	532 80 05-47	Trim Plate	44	532 08 51-79	Retainer Clip
6	532 12 50-71	Upper Handle	45	532 85 08-45	Hubcap
7	532 03 69-53	Self-tapping Screw #10-24 x 5/8	46	532 80 03-68	Wheel Adjusting Bracket (RR)
8	532 06 36-01	Locknut 1/4-20	47	532 85 09-98	Thread Rolling Screw 3/8-16 x 1
9	532 12 51-73	Lower Handle	48	532 12 50-78	Engine Washer
10	532 05 87-14	Handle Bolt	49	532 85 10-00	Belt Snubber
11	532 85 14-64	Throttle Control	50	532 10 73-39	Danger Decal
12	532 08 57-23	Washer	51	532 80 10-14	Lawn Mower Housing (Includes Key No. 50)
13	532 06 64-26	Wire Tie	52	532 08 79-30	Guide Clip (Housing)
14	532 80 03-57	Rope Guide	53	532 75 00-97	Hex Washer Head Screw #10-24 x 1/2
15	532 06 36-88	Handle Knob	54	532 12 50-81	Front Baffle
16	532 85 11-85	Round Head Screw 1/4-20 x 2-3/4	56	532 85 10-84	Hex Head Screw 3/8-24 x 1-3/8 Gr. 8
17	532 12 50-76	Side Baffle	57	532 85 02-63	Helical Lockwasher 3/8
18	532 12 50-75	Discharge Baffle	58	532 85 10-74	Hardened Washer
19	532 08 63-44	Hex Head Screw #10-24 x 1/2	59	532 85 09-73	22" Blade
20	532 08 12-83	Self-tapping Screw #10-24 x 3/8	60	532 85 15-14	Blade Adapter
21	532 05 45-83	Hex Tapping Screw 1/4-20 x 1/2	61	532 80 03-93	Catcher Frame Assembly
22	532 12 52-19	Back Plate	62	532 05 17-93	Hairpin Cotter
23	532 04 19-45	Thread Screw #10-24 x 1/2	63	532 75 03-28	Hinge Rod
24	532 12 50-73	Rear Baffle	64	532 12 50-80	Rear Door
25	532 06 91-80	Locknut	65	532 10 32-51	* Muffler Deflector
26	532 75 10-83	Rear Skirt	66	532 09 37-05	* Screw #8-32 x 3/8
27	532 05 51-87	Thread Cutting Screw 5/16-18 x 3/4	67	532 21 31-46	* Cable Clamp
28	532 06 31-24	Locknut	68	532 10 74-88	Thread Rolling Screw #10-32 x 5/8
29	532 08 86-52	Hinge Screw	69	532 08 76-77	Hi-Pro Key
30	532 07 44-00	Locknut	70	532 05 97-08	Set Screw 1/4-20 x 5/16
31	532 06 62-38	Carriage Bolt	71	532 08 45-96	Engine Pulley
32	532 12 50-38	Handle Bracket Assembly (Right)	72	-- -- -- -- --	* Engine - Briggs & Stratton Model No. 124707
33	532 12 50-40	Handle Bracket Assembly (Left)			Type No. 3120-01
34	532 80 03-70	Wheel Adjusting Bracket (LR)	--	532 80 16-79	Operator's Manual (English)
35	532 08 49-20	Spacer	--	532 12 84-35	Operator's Manual (French)
36	532 08 83-48	Washer	--	532 80 05-69	Decal (Engine)
37	532 12 50-66	Selector Spring	--	532 85 07-95	Stripe Decal (Housing)
38	532 07 78-65	Selector Knob	--	532 85 07-88	Decal (Trim Plate)
39	532 12 50-79	Axle Arm Assembly			

* These parts must be purchased through an authorized Briggs & Stratton dealer.

For Husqvarna Parts Call 606-678-9623 or 606-561-4983

REPAIR PARTS

22" ROTARY LAWN MOWER - - MODEL NO. 56sfe, PRODUCT NO. 954 05 09-01



REPAIR PARTS

22" ROTARY LAWN MOWER - - MODEL NO. 56sfe, PRODUCT NO. 954 05 09-01


KEY NO.	PART NO.	DESCRIPTION
1	532 08 56-92	Machine Screw 1/4-20 x 2-1/8
2	532 05 34-90	Locknut 1/4-20
3	532 80 16-33	Engine Zone Control Cable
4	532 06 36-01	Locknut 1/4-20
5	532 85 10-97	Drive Control
6	532 08 76-66	Self-tapping Screw #10-24 x 2-3/4
7	532 08 36-91	V-Belt
8	532 80 03-66	Wheel Adjuster Assembly (Right)
9	532 80 03-63	Wheel Adjuster Assembly (Left)
10	532 07 78-65	Selector Knob
11	532 07 64-01	Dust Cover
12	532 07 45-07	Pinion
13	532 05 37-53	E-Ring
14	532 08 69-54	Wheel & Tire Assembly 8.0 x 2.0
15	532 08 69-60	Wheel Bushing
16	532 05 21-60	Washer
17	532 08 51-79	Retainer Clip
18	532 85 08-44	Hubcap

KEY NO.	PART NO.	DESCRIPTION
19	532 05 43-38	Hex Head Bolt 1/4-20 x 2-3/4
20	532 06 15-28	Flat Head Machine Screw 1/4-20 x 3/4
21	532 06 36-01	Locknut 1/4-20
22	532 08 60-12	Drive Shaft Cover
23	532 75 01-08	Hex Washer Head Tapping Screw #10-24 x 3/8
24	532 08 37-00	Cable Clamp
25	532 07 51-92	Spring
26	532 05 70-76	Woodruff Key #213
27	532 06 56-92	Woodruff Key #3
28	532 75 10-01	Gear Case Assembly
29	532 06 80-38	Locknut
30	532 08 36-32	Spring
31	532 08 36-81	Drive Pulley
32	532 07 49-76	Retaining Ring
33	532 75 00-97	Hex Washer Head Screw #10-24 x 1/2
34	532 85 08-25	Drive Cover
--	532 80 05-75	Decal (Drive Cover)

REPAIR PARTS

22" ROTARY LAWN MOWER - - MODEL NO. 56sfe, PRODUCT NO. 954 05 09-01

GEAR CASE ASSEMBLY - - PART NUMBER 532 75 10-01




KEY NO.	PART NO.	DESCRIPTION
1	532 05 38-38	Keps Locknut 1/4-20
2	532 08 51-78	Adjusting Bracket
3	532 08 83-86	Shifter Assembly
4	532 05 70-72	Seal
5	532 05 73-88	Grooved Pin 1/8 x 1/2
6	532 04 80-32	Gear Case Halves (Includes Upper and Lower Halves and Key Nos. 4,5, and 7)
7	532 07 78-81	Bearing
8	532 07 70-39	Spring Bracket
9	532 75 04-30	Drive Shaft
10	532 05 70-79	Hardened Washer
11	532 07 51-44	Yoke Clutch

KEY NO.	PART NO.	DESCRIPTION
12	532 08 78-22	Grooved Pin 1/8 x 3/4
13	532 08 64-47	Plug
14	532 08 36-59	Helical Gear
15	532 75 04-36	Jaw Clutch
16	532 75 03-55	Grease
17	532 05 37-53	E-Ring
18	532 85 08-48	Hi-Pro Key
19	532 08 37-20	Worm Shaft
20	532 06 56-92	Woodruff Key #3
21	532 08 36-80	Worm
22	532 05 09-50	Hex Head Machine Screw 1/4-20 x 1-1/4
23	532 75 10-46	Identification Tag

REPAIR PARTS

22" ROTARY LAWN MOWER - - MODEL NO. 56sfe, PRODUCT NO. 954 05 09-01

GEAR CASE ASSEMBLY - - PART NUMBER 532 75 10-01



KEY NO.	PART NO.	DESCRIPTION
1	532 80 04-10	Battery Bracket
2	532 80 04-11	Battery Cover
3	532 04 80-68	Battery Kit (Includes Key Nos. 5 & 7)
4	532 75 00-97	Hex Washer Head Screw #10-24 x 1/2
5	532 08 63-53	Connector Mounting Clip
6	532 11 15-49	Battery Charger
7	532 08 66-49	Battery Pad