




# 51/55



## 1.1994

**Spare parts**

**Ersatzteile**

**Pièces détachées**

**Reserve onderdelen**

**Repuestos**

**Reservdelar**

Replaces

Ersetzt

Remplace

Vervangt

Reemplaza

Ersätter

106 22 83-62

| PART NUMBER  | SQUARE | NOTE | PART NUMBER  | SQUARE | NOTE  | PART NUMBER  | SQUARE | NOTE | PART NUMBER | SQUARE | NOTE |
|--------------|--------|------|--------------|--------|-------|--------------|--------|------|-------------|--------|------|
| 501 45 16-01 | C      | G    | 503 16 31-01 | K      |       | 503 74 91-01 | F      | N    |             |        |      |
| 501 45 27-02 | J      |      | 503 16 77-01 | C      | N(51) | 503 74 97-01 | F      | N    |             |        |      |
| 501 45 41-01 | J      |      | 503 16 83-01 | C      | (51)  | 503 76 48-01 | D      | N    |             |        |      |
| 501 45 54-03 | H      |      | 503 20 02-10 | D      |       | 503 78 32-01 | K      | N    |             |        |      |
| 501 45 61-01 | H      |      | 503 20 02-16 | D H J  |       | 504 13 08-07 | M      | 3    |             |        |      |
| 501 45 74-02 | H      |      | 503 20 02-25 | C J    |       | 504 13 08-08 | M      | 3    |             |        |      |
| 501 46 69-01 | M      |      | 503 20 02-50 | J      |       | 504 13 09-06 | M      | 3    |             |        |      |
| 501 46 84-01 | M      |      | 503 20 25-20 | K      |       | 504 21 00-49 | M      |      |             |        |      |
| 501 46 87-01 | M      |      | 503 21 06-16 | EL     |       | 504 21 00-50 | M      |      |             |        |      |
| 501 48 54-02 | K      |      | 503 21 06-25 | E      |       | 504 35 09-05 | M      |      |             |        |      |
| 501 53 82-01 | F      |      | 503 21 07-45 | D      |       | 504 52 30-02 | H      |      |             |        |      |
| 501 54 63-01 | J      |      | 503 21 27-16 | J      | N     | 505 22 09-37 | J      |      |             |        |      |
| 501 63 06-01 | L      |      | 503 21 28-06 | K      |       | 505 27 57-19 | J      |      |             |        |      |
| 501 63 97-01 | D      |      | 503 21 28-10 | A      |       | 505 30 37-35 | L      |      |             |        |      |
| 501 66 61-01 | M      |      | 503 21 43-38 | B      |       | 505 30 51-25 | L      |      |             |        |      |
| 501 66 78-01 | M      |      | 503 21 82-02 | F      |       | 505 31 07-51 | D      |      |             |        |      |
| 501 69 17-01 | M      |      | 503 21 90-08 | F      | N     | 505 31 67-17 | M      |      |             |        |      |
| 501 76 13-10 | E      |      | 503 22 00-01 | A      |       | 505 31 67-54 | M      |      |             |        |      |
| 501 76 18-02 |        | 1    | 503 22 10-11 | K      |       | 505 31 67-82 | M      |      |             |        |      |
| 501 76 22-02 | J      |      | 503 22 24-01 | F      | N     | 505 52 01-10 | M      | 3    |             |        |      |
| 501 76 30-03 | J      |      | 503 22 62-01 | J      |       | 505 52 01-25 | M      |      |             |        |      |
| 501 76 31-01 | L      |      | 503 23 00-35 | L      |       | 505 52 01-27 | M      |      |             |        |      |
| 501 76 32-01 | H      |      | 503 23 00-42 | K      | N     | 506 02 72-07 | K      | N    |             |        |      |
| 501 76 37-01 | H      |      | 503 23 01-01 | K      |       | 506 02 80-01 | M      |      |             |        |      |
| 501 76 39-02 | E      |      | 503 23 01-05 | H      |       | 506 02 82-01 | M      |      |             |        |      |
| 501 76 44-03 | J      |      | 503 23 51-08 | C      |       | 720 12 33-00 | A      |      |             |        |      |
| 501 76 56-02 | J      |      | 503 25 34-01 | H      |       | 720 12 40-20 | E      | N    |             |        |      |
| 501 76 64-03 | J      |      | 503 26 30-17 | E      | N     | 720 13 14-20 | E      |      |             |        |      |
| 501 76 66-02 | F      |      | 503 28 15-04 | D M    |       | 721 12 10-40 | H      |      |             |        |      |
| 501 76 71-01 | F      |      | 503 28 90-11 | C      | (51)  | 721 42 30-50 | J      |      |             |        |      |
| 501 76 80-01 | A      |      | 503 28 90-28 | C      | (55)  | 721 42 52-50 | A      |      |             |        |      |
| 501 76 81-01 | A      |      | 503 40 47-01 | E      |       | 723 23 29-85 | L      |      |             |        |      |
| 501 76 83-01 | E      |      | 503 44 32-01 | E      |       | 724 33 25-56 | J      | N    |             |        |      |
| 501 76 88-01 | F      |      | 503 45 39-02 | H      | N     | 725 52 93-56 | A      |      |             |        |      |
| 501 77 00-02 | D      | 1    | 503 49 32-01 | A      |       | 735 31 08-20 | A      |      |             |        |      |
| 501 77 21-02 | O      |      | 503 49 34-01 | A      |       | 737 44 10-00 | C      |      |             |        |      |
| 501 77 76-01 | H      |      | 503 49 81-02 | A      | N     | 738 22 02-25 | G      |      |             |        |      |
| 501 77 80-02 | E      |      | 503 51 55-01 | M      |       | 740 44 05-00 | J      |      |             |        |      |
| 501 79 50-01 | J      |      | 503 52 18-01 | K      | N     |              |        |      |             |        |      |
| 501 81 96-02 | E      |      | 503 52 27-01 | M      |       |              |        |      |             |        |      |
| 501 81 99-03 | K      | N    | 503 54 39-01 | L      |       |              |        |      |             |        |      |
| 501 87 29-07 | E      |      | 503 55 22-01 | C      | N(55) |              |        |      |             |        |      |
| 501 87 31-01 | E      |      | 503 56 34-01 | M      |       |              |        |      |             |        |      |
| 501 87 42-02 | A      |      | 503 57 02-01 | M      |       |              |        |      |             |        |      |
| 501 87 47-01 | A      |      | 503 57 38-02 | G      |       |              |        |      |             |        |      |
| 501 87 49-01 | A      |      | 503 57 42-01 | M      |       |              |        |      |             |        |      |
| 501 87 53-01 | A      |      | 503 57 50-01 | E      |       |              |        |      |             |        |      |
| 501 87 54-01 | A      |      | 503 57 89-01 | E J    |       |              |        |      |             |        |      |
| 501 87 77-02 | E      |      | 503 60 81-01 | C      | (55)  |              |        |      |             |        |      |
| 501 87 84-04 | A      | N    | 503 60 82-01 | D      |       |              |        |      |             |        |      |
| 502 10 21-01 | M      |      | 503 60 83-01 | D      |       |              |        |      |             |        |      |
| 502 10 28-01 | M      |      | 503 60 83-02 | D O    |       |              |        |      |             |        |      |
| 502 10 29-01 | M      |      | 503 60 84-01 | D      |       |              |        |      |             |        |      |
| 502 10 30-01 | M      |      | 503 60 86-01 | L      |       |              |        |      |             |        |      |
| 502 10 32-01 | M      |      | 503 60 88-03 | L      |       |              |        |      |             |        |      |
| 502 10 35-01 | M      |      | 503 60 90-05 | B      | N     |              |        |      |             |        |      |
| 502 11 44-01 | M      |      | 503 60 90-06 | B      | N     |              |        |      |             |        |      |
| 502 11 96-01 | M      |      | 503 60 91-04 | C      | N(55) |              |        |      |             |        |      |
| 503 08 46-01 | E      |      | 503 61 97-04 | L      | N     |              |        |      |             |        |      |
| 503 08 87-02 | H      |      | 503 61 97-05 | L      | N     |              |        |      |             |        |      |
| 503 08 97-02 | K      |      | 503 66 01-02 | H      | N     |              |        |      |             |        |      |
| 503 09 79-04 | E      |      | 503 66 54-01 | C      | N(55) |              |        |      |             |        |      |
| 503 10 16-01 | H      |      | 503 66 84-01 | J      |       |              |        |      |             |        |      |
| 503 10 23-01 | C      | 1    | 503 71 02-01 | K      | N     |              |        |      |             |        |      |
| 503 10 47-01 | M      |      | 503 71 87-01 | A      | N     |              |        |      |             |        |      |
| 503 10 49-02 | H      |      | 503 72 98-01 | J      | N     |              |        |      |             |        |      |
| 503 10 87-01 | M      |      | 503 73 04-01 | J      | N     |              |        |      |             |        |      |
| 503 15 21-01 | A      |      | 503 73 08-01 | D      | N     |              |        |      |             |        |      |
| 503 16 16-02 | D      |      | 503 73 09-01 | D      | N     |              |        |      |             |        |      |
| 503 16 21-03 | C      | 1    | 503 74 54-01 | H      | N     |              |        |      |             |        |      |

1 = 501 76 18-02



Set of gaskets  
Dichtungssatz  
Jeu de joints  
Juego de juntas  
Packningssats

3 = 502 10 35-01


Set of gaskets(carb.)  
Dichtungssatz(Verg.)  
Jeu de joints(carb.)  
Juego de juntas(carb.)  
Packningssats(forg.)



N= New part  
Neues Teil  
Nouvelle piece  
Nueva pieza  
Ny detalj

**A** \* compl 503 49 81-02  
compl 501 87 84-04




**B** \* compl 503 60 90-05  
\* compl 503 60 90-06 (USA)







**E** \* compl 501 76 13-10




**F** \* compl 501 76 66-02  
\*\* compl 503 74 91-01 (USA)



**G** \* compl 503 57 38-02




**N** Accessories  
Accessoires  
Zubehöre  
Tillbehör






501 69 17-01

**H**



**K**






**M**

\* compl 503 28 15-04

## Walbro WT 170



**O**

\* compl 501 77 21-02

**Winter equipment**  
**Winterausrüstung**  
**Equipement d'hiver**  
**Vintersats**

