


For Husqvarna Parts Call 606-678-9623 or 606-561-4983




IPL, 322 C, 322 L, 322 R, 325 L-X, 325 R-X, 1999-03, 106 25 68-62


# **322 C, 322 L, 322 R, 325 L-X, 325 R-X**

**Spare parts  
Ersatzteile  
Pièces détachées  
Reserve onderdelen  
Repuestos  
Reservdelar**

**A** 322 C




**B** 322 L  
325 L-X




**C**

322 R  
325 R-X




**D**

322 C  
322 L  
325 L-X



**E**


322 R  
322 R-X



**F**


322 R  
325 R-X

\*compl 503 94 11-01




**G**


503 98 12-01 322 C  
503 98 12-02 322 L  
503 98 12-03 322 R  
503 98 12-04 325 L-X  
503 98 12-05 325 R-X



**H**




**J**






**M**




**N**



**P**


\*compl 503 85 24-73




**Q Accessories**  
**Zubehöre**  
**Accessoires**  
**Acessorios**  
**Tillbehör**




503 89 01-01




502 28 59-01




502 11 46-02



502 21 58-01





502 03 55-02




503 97 64-01

501 60 02-02




503 74 16-01  
 503 74 16-02 (USA)



501 78 33-01

503 21 83-16



503 99 78-01


503 21 75-16 (3x)

**\*compl 537 02 21-01**

725 23 68-71 (2x)



537 04 75-01



537 00 55-01




502 18 82-04




503 21 75-16 (4x)

**322 C \*compl 537 02 61-01**



530 05 22-87\*  
 503 21 75-16\*


**compl 503 73 63-03  
 compl 503 73 63-04 (USA)**



503 73 40-01

503 73 41-02

**322R  
 325 R-X**




503 21 07-16\*

503 79 88-01\*

**\*compl 503 93 42-02**


**322 L  
 325 L-X**



503 21 07-16\*

503 79 88-01\*

**\*compl 503 97 71-01**




502 26 12-01

**R**

Compl 503 28 31-10

ZAMA C1Q - EL 11

Repair Kit - 531 00 45-53 (RB-69)  
Gasket/Diaphragm Kit - 531 00 45-52 (GND-39)



# For Husqvarna Parts Call 606-678-9623 or 606-561-4983

| PART NUMBER  | SQUARE | NOTE | PART NUMBER  | SQUARE | NOTE | PART NUMBER  | SQUARE | NOTE | PART NUMBER | SQUARE | NOTE |
|--------------|--------|------|--------------|--------|------|--------------|--------|------|-------------|--------|------|
| 501 60 02-02 | Q      |      | 503 85 27-71 | M      | N    | 537 00 84-01 | J      | N    |             |        |      |
| 501 78 33-01 | Q      |      | 503 85 28-01 | J      | N    | 537 01 13-01 | D      | N    |             |        |      |
| 502 03 55-02 | Q      |      | 503 85 87-01 | J      | N    | 537 01 25-01 | R      | N    |             |        |      |
| 502 11 46-02 | Q      |      | 503 85 89-01 | J      |      | 537 01 26-01 | R      | N    |             |        |      |
| 502 19 71-01 | BC     |      | 503 86 45-01 | BC     |      | 537 01 30-01 | F      | N    |             |        |      |
| 502 19 90-01 | E      |      | 503 87 17-01 | M      | N    | 537 01 32-72 | M      | N    |             |        |      |
| 502 19 91-01 | E      |      | 503 87 18-01 | G      | N    | 537 01 32-74 | M      | N    |             |        |      |
| 502 19 92-01 | E      |      | 503 87 19-01 | B      |      | 537 01 41-01 | M      | N    |             |        |      |
| 502 19 94-01 | E      |      | 503 87 19-03 | B      | N    | 537 01 96-01 | R      | N    |             |        |      |
| 502 19 95-02 | C      | N    | 503 87 21-01 | G      | N    | 537 01 97-01 | R      | N    |             |        |      |
| 502 20 38-01 | C      |      | 503 87 26-01 | BC     | N    | 537 01 98-01 | R      | N    |             |        |      |
| 502 20 40-01 | H      |      | 503 87 28-01 | L      | N    | 537 01 99-01 | R      | N    |             |        |      |
| 502 20 65-03 | H      |      | 503 87 33-01 | J      | N    | 537 02 00-01 | R      | N    |             |        |      |
| 502 21 12-01 | C      |      | 503 87 35-01 | J      | N    | 537 02 01-01 | R      | N    |             |        |      |
| 502 21 58-01 | Q      |      | 503 87 36-01 | J      | N    | 537 02 02-01 | R      | N    |             |        |      |
| 502 26 12-01 | Q      |      | 503 87 79-01 | D      | N    | 537 02 03-01 | R      | N    |             |        |      |
| 502 28 59-01 | Q      |      | 503 87 80-01 | D      | N    | 537 02 04-01 | R      | N    |             |        |      |
| 503 20 02-16 | C      |      | 503 87 85-01 | D      | N    | 537 02 05-01 | R      | N    |             |        |      |
| 503 20 02-25 | F      |      | 503 87 86-01 | D      | N    | 537 02 06-01 | R      | N    |             |        |      |
| 503 20 03-25 | H      | N    | 503 87 90-01 | B      |      | 537 02 07-01 | R      | N    |             |        |      |
| 503 20 29-50 | M      |      | 503 88 23-01 | C      |      | 537 02 09-01 | R      | N    |             |        |      |
| 503 21 07-16 | Q      |      | 503 88 41-01 | A      | N    | 537 02 10-01 | R      | N    |             |        |      |
| 503 21 07-22 | E      |      | 503 88 80-01 | H      | N    | 537 02 11-01 | R      | N    |             |        |      |
| 503 21 07-38 | E      |      | 503 88 81-01 | H      | N    | 537 02 16-01 | R      | N    |             |        |      |
| 503 21 07-45 | C      |      | 503 88 88-01 | BC     | N    | 537 02 21-01 | Q      | N    |             |        |      |
| 503 21 71-20 | DJL    |      | 503 89 01-01 | Q      |      | 537 02 61-01 | Q      | N    |             |        |      |
| 503 21 75-16 | CQH    |      | 503 89 03-01 | H      | N    | 537 03 20-02 | M      | N    |             |        |      |
| 503 21 75-20 | GJN    |      | 503 91 08-01 | K      | N    | 537 03 20-04 | M      | N    |             |        |      |
| 503 21 75-25 | CN     |      | 503 91 09-01 | H      | N    | 537 03 23-01 | N      | N    |             |        |      |
| 503 21 75-30 | M      |      | 503 91 10-01 | K      | N    | 537 03 23-02 | N      | N    |             |        |      |
| 503 21 75-50 | H      |      | 503 91 18-02 | K      | N    | 537 03 24-01 | N      | N    |             |        |      |
| 503 21 77-16 | J      |      | 503 91 81-01 | D      | N    | 537 03 41-01 | J      | N    |             |        |      |
| 503 21 83-16 | Q      |      | 503 93 42-02 | Q      | N    | 537 04 10-01 | F      | N    |             |        |      |
| 503 22 65-01 | H      |      | 503 93 55-01 | F      | N    | 537 04 11-01 | N      | N    |             |        |      |
| 503 23 00-61 | B      |      | 503 93 66-01 | K      |      | 537 04 12-01 | N      | N    |             |        |      |
| 503 23 51-08 | L      |      | 503 93 79-01 | E      | N    | 537 04 23-01 | L      | N    |             |        |      |
| 503 23 51-11 | L      |      | 503 93 80-01 | E      | N    | 537 04 24-01 | K      | N    |             |        |      |
| 503 28 31-10 | HR     |      | 503 94 02-01 | P      | N    | 537 04 25-01 | A      |      |             |        |      |
| 503 28 90-30 | M      | N    | 503 94 03-01 | B      |      | 537 04 58-01 | L      | N    |             |        |      |
| 503 28 90-38 | M      | N    | 503 94 05-01 | P      | N    | 537 04 67-01 | L      | N    |             |        |      |
| 503 44 32-01 | K      |      | 503 94 10-01 | C      | N    | 537 04 68-01 | L      | N    |             |        |      |
| 503 47 89-01 | R      |      | 503 94 11-01 | F      | N    | 537 04 75-01 | Q      | N    |             |        |      |
| 503 47 90-01 | R      |      | 503 94 12-01 | F      | N    | 537 05 23-01 | K      | N    |             |        |      |
| 503 47 92-01 | R      |      | 503 94 14-01 | F      | N    | 725 23 68-71 | Q      |      |             |        |      |
| 503 47 96-01 | R      |      | 503 94 26-01 | H      |      | 725 23 70-51 | F      |      |             |        |      |
| 503 47 97-01 | R      |      | 503 95 97-01 | F      | N    | 725 23 78-51 | B      |      |             |        |      |
| 503 48 00-01 | R      |      | 503 96 13-01 | D      | N    | 725 23 80-51 | B      |      |             |        |      |
| 503 48 01-01 | R      |      | 503 96 13-01 | G      |      | 725 23 86-51 | C      |      |             |        |      |
| 503 48 02-01 | R      |      | 503 96 14-01 | D      | N    | 731 23 14-01 | CH     |      |             |        |      |
| 503 48 05-01 | R      |      | 503 96 25-01 | H      | N    | 731 71 16-51 | JL     |      |             |        |      |
| 503 48 08-01 | R      |      | 503 96 31-01 | C      | N    | 735 21 35-10 | F      |      |             |        |      |
| 503 48 11-01 | R      |      | 503 96 36-01 | A      | N    | 735 31 08-20 | J      |      |             |        |      |
| 503 48 16-01 | R      |      | 503 96 49-01 | J      | N    | 735 31 11-00 | F      |      |             |        |      |
| 503 48 18-01 | R      |      | 503 97 21-01 | G      | N    | 735 31 12-00 | A      |      |             |        |      |
| 503 48 19-01 | R      |      | 503 97 43-01 | R      |      | 735 31 28-10 | F      |      |             |        |      |
| 503 49 71-01 | H      |      | 503 97 64-01 | Q      |      | 737 44 08-00 | M      |      |             |        |      |
| 503 53 57-01 | R      |      | 503 97 71-01 | Q      | N    | 738 21 01-04 | F      |      |             |        |      |
| 503 66 59-01 | R      |      | 503 97 98-01 | J      | N    | 738 21 01-10 | P      |      |             |        |      |
| 503 71 22-01 | MP     |      | 503 97 98-02 | J      | N    | 738 21 99-00 | F      |      |             |        |      |
| 503 71 48-01 | F      |      | 503 97 98-03 | J      | N    | 738 22 96-15 | F      |      |             |        |      |
| 503 71 82-01 | DE     |      | 503 97 98-04 | J      | N    | 740 42 06-00 | D      | N    |             |        |      |
| 503 72 10-03 | C      |      | 503 97 98-05 | J      | N    |              |        |      |             |        |      |
| 503 72 43-03 | C      |      | 503 98 12-01 | G      | N    |              |        |      |             |        |      |
| 503 72 99-01 | C      |      | 503 98 12-02 | G      | N    |              |        |      |             |        |      |
| 503 73 40-01 | Q      |      | 503 98 12-03 | G      | N    |              |        |      |             |        |      |
| 503 73 41-02 | Q      |      | 503 98 12-04 | G      | N    |              |        |      |             |        |      |
| 503 73 63-03 | Q      |      | 503 98 12-05 | G      | N    |              |        |      |             |        |      |
| 503 73 63-04 | Q      |      | 503 99 55-01 | D      | N    |              |        |      |             |        |      |
| 503 74 16-01 | Q      |      | 503 99 55-02 | D      | N    |              |        |      |             |        |      |
| 503 74 16-02 | Q      |      | 503 99 56-01 | D      | N    |              |        |      |             |        |      |
| 503 75 00-01 | C      |      | 503 99 56-02 | D      | N    |              |        |      |             |        |      |
| 503 75 53-01 | R      |      | 503 99 78-01 | Q      | N    |              |        |      |             |        |      |
| 503 79 41-01 | E      |      | 530 01 58-20 | A      |      |              |        |      |             |        |      |
| 503 79 88-01 | Q      | N    | 530 01 61-18 | A      |      |              |        |      |             |        |      |
| 503 80 45-01 | C      |      | 530 05 22-87 | Q      | N    |              |        |      |             |        |      |
| 503 81 60-01 | L      |      | 530 05 38-00 | A      |      |              |        |      |             |        |      |
| 503 83 61-01 | P      | N    | 530 05 39-50 | A      | N    |              |        |      |             |        |      |
| 503 84 28-01 | L      | N    | 530 09 45-43 | A      |      |              |        |      |             |        |      |
| 503 84 29-01 | L      | N    | 530 09 52-21 | A      |      |              |        |      |             |        |      |
| 503 85 24-73 | P      | N    | 537 00 55-01 | Q      | N    |              |        |      |             |        |      |