



SERVICE	B0403002
BULLETIN	2004-03

Subject: New Consumer Z Neutral adjustment

Models Affected: New consumer Z, CZ4817,4217,3815

Service Information:

All units are set at factory and run tested before delivery, this is for reference only

Neutral adjustment is necessary to have the unit perform correctly, Raise the rear wheels of the unit off the ground and put on jack stands. Start unit and put the levers in the neutral position and release the brake. If the rear wheels don't turn, neutral is set correctly. If either wheel turns, loosen the locknut on the end piece coupler on the linkage. Remove the bolt holding the EZT control linkage in place at the motion control lever (this is indicated by an arrow). Turn the end piece about two turns to the right if the tire was rotating in reverse and two turn to the left if the tire was rotating forward. Reinsert the bolt to see if neutral has been established. Repeat the above step until neutral is achieved. Tighten bolt and tighten locknut to complete operation

