



Enclosure to spare parts list 106 20 31-98
Annexe 5 la liste de pièces détachées 106 20 31-98

SPARE PART CHANGES ON MODEL HUSQVARNA 50

Square	Denomination				
A	Chainbrake, new	501 76 12-02	replaces	501 76 12-01	
	Handguard, new	503 12 36-01	replaces	501 76 46-01	
	Clutch cover	501 76 46-02	replaces	501 76 75-01	
B	Cylinder cover, new	503 15 17-01	replaces	501 76 05-01	
	Choke control	501 77 07-02	replaces	501 77 07-01	
C	Exhaust gasket, alu	503 10 23-01	replaces	505 27 21-22	
	Cylinder base gasket	503 16 21-01	replaces	505 27 21-21	
D	No changes				
E	Valve plug	501 87 31-01	replaces	501 62 98-01	
	Fuel filter	501 87 76-01	replaces	501 82 23-01	
	Fuel tank	501 76 13-06	replaces	501 76 13-01	
	Throttle catch	501 77 20-02	replaces	501 77 20-01	
	Throttle trigger	501 76 36-02	replaces	501 76 36-01	
	Throttle rod	501 77 80-02	replaces	501 77 80-01	
	Handle	501 87 29-01	replaces	501 76 98-01	
F	Muffler compl.	501 76 66-03	replaces	501 76 66-01	
G	Crankshaft	503 11 21-01	replaces	505 30 08-50	
H	Clutch compl.	501 45 54-03	replaces	505 30 32-77	
	Clutch spring	501 45 61-01	new part		
J	Crankcase	501 76 22-02	replaces	501 76 22-60	
	Cover	501 76 44-03	replaces	501 76 44-02	
	Chain catcher	501 76 64-03	replaces	501 76 64-02	
	Tank vent	501 83 93-02	new part		
	Spiral pin	731 42 3050	new part		
	Air conductor	501 76 30-02	replaces	501 76 30-01	
K	Electronic module	506 02 72-01	replaces	506 01 00-01	
	Switch wire	503 16 31-01	new part		
	Flywheel	506 03 13-01	replaces	505 32 56-29	
L	Starter compl.	503 15 18-01	new part		
	Starter housing	503 12 29-01	new part		
	Cover	503 10 60-02	new part		