


# Clearing Saw Accessories








# Freischneider **Zubehöre**


# Débroussailleuse **Accessoires**

# Desbrozadora Accessories

# - **Röjsågstillbehör**




Saw blades 200 mm-8"	Saw blades 225 mm-9"	Saw blades 225 mm-9"
<p><b>Maxi 200 saw blade</b> no 502 04 13-02</p> 	<p><b>Maxi 225 saw blade</b> no 502 01 95-02</p> 	<p><b>Spets 225 pointed-tooth blade</b> no 502 14 25-01</p> 
<p><b>Scarlet 200 saw blade</b> no 501 91 34-01</p> 	<p><b>Scarlet 225 saw blade</b> no 501 91 35-01</p> 	
<p><b>Guard</b> no 502 03 93-01</p> 	<p><b>Guard</b> no 502 03 94-01</p> 	




**Brush blades 255 mm-10"**


**Multi 255-4 brush blade**  
no 501 91 05-02




**Multi 255-3 brush blade**  
no 501 31 64-01



**Plant protector (complete)**  
no 502 12 26-01




**Guard**  
no 502 03 95-01




**Brush blades 300 mm-12"**

**Multi 300 brush blade**  
no 502 04 68-01



**Guard**  
no 502 03 96-01




**Support cup** no 502 13 93-01




**Nylon cordheads**


**Trimmy Fix**  
no 502 13 87-01




**Trimmy H**  
no 501 91 28-03



**Trimmy Hit**  
no 501 95 40-01




**Trimmy S**  
no 508 01 01-02




**Guard**  
no 502 10 47-01

For Husqvarna Parts Call 606-678-9623 or 606-561-4983




**Spare cord  $\varnothing$  2,4 mm**

15 m, 45 feet  
no 508 01 51-49



98 m, 297 feet  
no 502 04 77-01



 **Husqvarna**  
SWEDEN  
**The Clearing Saw Professionals**

[www.mymowerparts.com](http://www.mymowerparts.com)