

Enclosure to spare parts list 10 62 082-98, 1 : 1987 (index 10: X 87.108)

DIFFERENCES BETWEEN THE MODELS 61 AND 66

Square	Description	Part Number 61	Part Number 66
B	Cylinder cover	501 68 60-04	501 68 60-05
	Cylinder cover, USA	501 68 60-07	501 68 60-09
C	Cylinder compl.	503 53 20-71	503 44 82-71
	Piston compl. class AB	503 53 22-02	503 44 83-71
	Piston ring	501 51 12-03	503 44 84-01
	Piston pin, lock ring	501 05 64-01	503 44 86-01
D	Carburettor	501 52 77-01	501 77 79-01
	Gasket, carburettor – manifold	501 25 09-02	501 29 64-03
	Manifold	501 53 38-02	503 49 24-01
	Gasket, manifold – cylinder	501 25 10-02	501 51 19-02
	Screw, manifold	—	503 20 21-12
	Screw, carburettor	503 20 21-09	503 49 69-02
	Clips, carburettor support	503 48 98-01	—
	Washer, carburettor support	—	503 23 00-01
K	Sticker	501 91 57-01	503 44 91-01
O	Carburettor	501 52 77-01	501 77 79-01
	Gasket kit, engine	501 52 26-02	501 52 26-05