

Clearing Saw Accessories


Freischneider **Zubehöre**

Débroussailleuse Accessoires

Desbrozadora Accessories


Röjsågstillbehör

For Husqvarna Parts Call 606-678-9623 or 606-561-4983




Saw blades 200 mm–8"

Maxi 200 saw blade
no 502 04 13-02



Scarlet 200 saw blade
no 501 91 34-01




Guard
no 502 03 93-03




Saw blades 225 mm–9"


Maxi 225 saw blade
no 502 01 95-02



Scarlet 225 saw blade
no 501 91 35-01





Guard
no 502 03 94-03



Saw blades 225 mm–9"


Spets 225 pointed-tooth blade
no 502 14 25-01






Brush blades 255 mm-10"


Multi 255-4 brush blade
no 501 91 05-02




Multi 255-3 brush blade
no 501 31 64-01



Plant protector (complete)
no 502 12 26-01




Guard
no 50 20 395-03




Brush blades 300 mm-12"

Multi 300 brush blade
no 502 04 68-01



Guard
no 502 03 96-03




Support cup no 502 13 93-01




Nylon cordheads


Trimmy Fix
no 502 13 87-01




Trimmy H
no 501 91 28-03




Trimmy Hit
no 501 95 40-01




Trimmy S
no 508 01 01-02



Guard
no 502 10 47-01




For Husqvarna Parts Call 606-678-9623 or 606-561-4983




Spare cord $\varnothing$ 2,4 mm

15 m, 45 feet
no 502 04 77-01



98 m, 297 feet
no 508 01 51-49



 **Husqvarna**
SWEDEN
The Clearing Saw Professionals