




1	747-1161A	Blade Control Handle	23	687-02099A	Height. Adj. Assy. Front - LH
2	749-1092A	Upper Handle		687-02100A	Height Adj. Assy. Front - RH
3	710-1205	Rope Guide	24	782-5002B	Front Baffle
4	720-0279	Wing Nut, 1/4-20	25	748-0377C	Blade Adapter
5	710-1174	Carriage Bolt, 5/16-18 x 2	26	742-0741	Blade
6	720-04072	Hand Star Knob	27	736-0524B	Blade Bell Support
7	749-0928A	Lower Handle	28	710-1257	Screw, 3/8-24 x 2.50
8	712-0397	Wing Nut, 1/4-20	29	712-04065	Flange Lock Nut, 3/8-16
9	746-0957	Control Cable - 37.25"	30	787-01290	Height Adjustment Plate
	746-1130	Control Cable - 40"	31	687-02076A	Pivot Arm Assembly - RH
	746-0554	Control Cable - 40.5"		687-02077A	Pivot Arm Assembly - LH
	746-1137	Control Cable - 53"	32	‡	Front Wheel
10	726-0240	Cable Tie	33	738-0507B	Shoulder Screw
11	664-04007A	Grass Bag Assembly	34	732-0404	Spring Lever
12	747-04080	Grass Bag Frame	35	720-0426	Height Adjustment Knob
13	732-0700	Trailshield Wire	36	687-02071A	Pivot Arm Assembly - RH
14	731-04998	Trailshield		687-02070A	Pivot Arm Assembly - LH
15	747-04035	Rear Door Pivot Rod	37	732-04175	Spring Lever
16	732-04089A	Torsion Spring LH	38	738-04136	Shoulder Screw
17	731-04134A	Rear Discharge Door	39	‡	Rear Wheel
18	750-04162	Spacer	40	710-1652	Screw, 1/4-20 x .625
19	732-04090A	Torsion Spring RH	41	714-0104	Hairpin Clip
20	710-04371	Screw, 1/4-15 x 1.25	42	787-01292	Rear Handle Bracket - RH
21	787-01276	Deck 21 inch		787-01291	Rear Handle Bracket - LH
22	687-02068	Handle Bracket Assy - RH	43	710-0703	Carriage Bolt, 1/4-20
	687-02069	Handle Bracket Assy - LH	44	731-04150C	Rear Baffle

† If equipped

‡ Refer to Wheel Chart

‡ Wheel Chart

Type	Part No.	Tread
Wheels w/o bearing	734-1781, 8 x 1.8 Slot Hub Gray	Bar
	734-1987, 8 x 1.8 Spoke Gray	Bar
	734-1988, 7 x 1.8 Spoke Gray	Bar
Wheels w/ BB	734-2004A, 8 x 2 Disc Hub	Zag
	734-2005A, 8 x 2	Zag

8

Parts List



To order replacement parts, contact
1-800-800-7310
or visit
www.mtdproducts.com