



1	747-04349	Clutch Bail
2	786-04258	Clutch Crank
3	649-04029	Handle Assembly: Lower
4	649-04030	Handle Assembly: Upper
5	710-0136	Hex Screw: 1/4-20:1.75:GR5:STD
6	710-0189	Hex Screw: 5/16-18:3.00:GR5:STD
7	710-04398	Flange Screw: 5/16-18:7.500:GR5
8	712-0324	Hex Lock Nut: 1/4-20:GR8:NYL
9	712-04063	Flange Lock Nut:5/16-18:GRF: NYL
10	716-0102	Snap Ring: 1.0 dia. shaft
11	720-0269	Handle Grip
12	720-0274	Grip: 1.0 ID x 5.0 LG
13	725-0157	Cable Tie
14	731-05095	Bail Holder LH
15	731-05096	Bail Holder RH
16	736-0242	Bell Washer: .340 x .872 x .060
17	736-0463	Flat Washer: .25 x .630 x .0515
18	731-05272	Snap Fitting
19	746-04215	Forward Clutch Cable
20	786-0340	Handle Adjustment Lever
21	786-0341	Retainer Bracket
22	710-0514	Hex Screw: 3/8-16:1.00:GR5:STD
23	710-1315	TT Screw: 3/8-16:1.250
24	712-04065	Flange Lock Nut: 3/8-16:GRF:NYL
25	786-04222	Frame
26	686-04054	Idler Assembly Forward
27	738-04171	Shoulder Screw: 3/8-16:1.25:GR5
28	710-04453	Socket Screw: 3/8-24:1.0
29	732-0418	Extension Spring
30	749-04185†	Front Bumper
31	738-04131	Shoulder Screw: .56 x 1.87:3/8-16
32	738-04139	Stud: .33 x 1.5:3/8-16

33	754-04061	Belt
34	756-04145	Flywheel Pulley
35	756-04163	Idler Pulley
36	786-04256	Tine Shield 24 inch
37	GW-9727	Pipe Plug: 3/8 NPT
38	756-04155	Pulley
39	710-04453	Socket Screw: 3/8-24:1.0
40	736-04184	Bell Washer: .382 x 1.500 x .109
41	748-04079	Pulley Adapter: .9875 dia. w/dd
42	710-0809	TT Screw: 1/4-20:1.250
43	642-0002	Inner Tine Assembly RH
44	642-0003	Inner Tine Assembly LH
45	642-0004	Outer Tine Assembly RH
46	642-0005	Outer Tine Assembly LH
47	711-0415	Clevis Pin
48	714-0149B	Internal Cotter Pin
49	710-0641	Hex Screw: 1/4-20:2.25:GR5:STD
50	710-0520	Hex Screw: 3/8-16:1.50:GR5:STD
51	710-3011	Hex Screw: 3/8-16:2.25:GR5:STD
52	710-3130	Hex Screw: 3/8-16:3.25:GR8:STD
53	714-3020	Internal Cotter Pin
54	732-0384	Extension Spring
55	734-1988	Wheel 7 x 1.8
56	749-04204	Tube Sleeve
57	750-04380	Spacer: .383 x .750 x .285
58	750-04432	Spacer: .525 x .775 x .835
59	786-04232	Front Wheel Bracket
60	786-04238	Tail Bracket RH
61	786-04239	Tail Bracket LH
62	686-04064	Depth Stake Stand
63	736-3010	Flat Washer: .407x.812x.135:HT
64	749-04240	Tube Sleeve

† If equipped



Parts List



To order replacement parts, call 1-800-800-7310 or visit www.mtdproducts.com

IMPORTANT

For a proper working machine, use Factory Approved Parts.

V-BELTS are specially designed to engage and disengage safely. A substitute (non OEM) V-Belt can be dangerous by not disengaging completely.