


**MODEL 8-3662
BODY SECTION**




MODEL 8-3662

1991 8-3662
A 9-1-1991

KEY NO.	PART NO.	DESCRIPTION
1	21970	Seat
2	1X45Z	Bolt 5/16"-18X5/8"
3	23325	Rear Shroud
4	17X47Z	Washer
5	21434	Grip
6	26X197	Screw 5/16X5/8 Type B
7	26X159	Screw #8X3/8" Type A
8	26X186	Screw #10X1/2" Type AB
9	21707	Steering Post Bearing
10	23299	Control Panel
11	23332PA	Remote Control
12	15X79	Flange Nut 5/16"-18
13	21792	Side Plate R.H.
14	21268	Grommet
15	21714	Rear Shroud Support
16	21934	Running Board R.H.
17	15X79	Flange Nut 5/16"-18
18	2X53	Carriage Bolt 5/16"-18X5/8"
19	21710	Rubber Mat
20	21547	Running Board Support
21	403040	Hood Latch R.H.
---	403041	Hood Latch L.H.
22	23146Z	Belt Guide
23	15X84Z	Lock Nut 3/8"-16
24	21441	Front Axle Ass'y.
25	21469	Pivot Pin
26	2X60	Carriage Bolt 3/8"-16X3"
27	21534	Front Axle Hanger
28	403026	Frame Ass'y.
30	21935	Running Board L.H.
31	21793	Side Plate L.H.
32	21713	Lower Grill
33	21794	Hood Ass'y.
34	21765	Edge Trim
35	14X79	Wing Nut
36	21761Z	Battery Clamp
37	21762Z	Battery Clamp Rod
38	400201	Upper Grill w/Light
39	21789	Edge Trim

MODEL 8-3662 STEERING SECTION




*HUB
CAP 29
21662*

MODEL 8-3662

KEY NO.	PART NO.	DESCRIPTION
1	21688	Steering Wheel
2	21303	Steering Wheel Cap
3	15X76	Keps Nut 5/16"-18
4	1X75	Bolt 5/16"-18X1 3/4"
5	21486C	Steering Post
6	1X45Z	Screw 5/16"-18X 7/8"
7	21493	Steering Gear & Coupling Ass'y.
8	15X84Z	Locknut 3/8"-16
9	20587	Bearing
10	21692	Steering Arm Gear & Brkt. Ass'y.
11	21426	Shoulder Bolt
12	15X77	Locknut 3/8"-24
13	21031	Ball Joint
14	15X61Z	Hex Nut 3/8"-24
15	21482	Drag Link Rod
16	30X49	Cotter Pin 1 1/4"
17	17X83Z	Washer
18	21401	Spindle Bearings
19	21476	Spindle Ass'y. L.H.
20	21475	Tie Rod Ass'y.
21	21479	Spindle Ass'y. R.H.
22	21527	Front Wheel & Tire
	403000	Rim Only
	403001	Tire Only
	400162	Valve Stem & Cap
23	403010	Front Wheel Bearing
24	15X43Z	Locknut 5/16"-18
25	15X79	Flange Nuts 5/16-18
26	21693	Steering Bracket
27	1X45Z	Bolt 5/16-18X 5/8"
28	17X115	Washer
29	21662	Hub Cap
	21747	Parts Bag Assy.


**MODEL 8-3662
DRIVE SECTION**



MODEL 8-3662

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	21651	Cap	35	21473	Transaxle Clamp
2	21749	Oil Drain Extension	36	15X88	Lock Nut 5/16"-18
3	----	Engine	37	21526	Wheel & Tire 18X9.50-8
8	403026	Frame Ass'y.		403004	Wheel Only
9	20062	Woodruff Key #6		403005	Tire 18X9.50-8
10	15X84Z	Lock Nut 3/8"-16		400162	Valve Stem & Cap
11	19X8	Lock Washer	39	11X3	E-Ring
12	20103	Engine Bolt 3/8"-16X1"	40	21521	Washer
13	23724	Drive Idler Spring	41	21553	Square Key
14	21681	Clutch Link Rod	42	21539	Woodruff Key
15	21428	Idler Bracket & Stud Ass'y.	43	----	Transaxle <i>66DA</i>
16	21409	Idler Pulley	44	20844	Knob
17	21426	Shoulder Bolt 3/8"-16X7/8"	45	21615	Drive Belt 1/2"X95"
18	20613	Idler Pulley	46	21447	Input Pulley
19	15X84Z	Flange Lock Nut 3/8-16	47	18X30	Lockwasher
20	17X47Z	Washer	48	1X38	Bolt 1/4"-20X5/8"
21	30X20	Cotter Pin 3/4"	49	18X15	Lock Washer
22	21415Z	Stack Pulley	50	1X91	Bolt 5/16"-18X3/4"
23	10851Z	Washer	51	2X57	Carriage Bolt 3/8"-16X7/8"
24	19X39	Shakeproof Washer	52	21440Z	Transaxle Support Bracket
25	1X20	Bolt 3/8"-24X1"	53	2X56	Carriage Bolt 3/8"-16X3/4"
26	21951	Clutch Lever Ass'y.	54	21683	Belt Guide
27	26X174	Screw	55	15X68	Lock Nut 3/8"-16
28	21948	Brake Lever Ass'y.	56	1X84Z	Bolt 5/16"-18X1"
29	21484Z	Parking Brake Arm	57	21678Z	Brake Rod Support
30	21434	Grip	58	26X185	Screw #10X1/2" Type AB
31	21544	Pedal	59	20682	Spring
32	21535	Cap	60	15X79	Lock Nut
33	21472Z	Brake Rod	61	20619	Belt Guide
34	21675	Spring	62	17X115	Washer
				21662	Hub Cap

**MODEL 8-3643
MODEL 8-3662
MODEL 8-3666
MODEL 8-3667
MODEL 8-3697
BLADE HOUSING**




36" BLADE HOUSING

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	21912Z	Pull Pin	41	21189	Torsion Spring
2	20692	Cotter Hair Pin	42	21154	Chute Deflector
3	17X57Z	Washer	43	28X23	Push-On-Cap
4	20661Z	Shoulder Bolt	44	21198Z	Deflector-Rod
5	21911	Support Arm L.H.	45	21953Z	Cable Guide
6	30X20	Cotter Pins	46	1X38	Bolt 1/4"-20X5/8"
7	17X47Z	Washer	47	20557	Cross Drive Belt 1/2"X46"
8	21914Z	Clevis	48	17X87Z	Washers
9	29X93	Clevis Pin	49	23126	Idler Spring
10	15X84Z	Flange Locknut 3/8"-16	50	21409	Idler Pulley
11	21426	Shoulder Bolt 3/8"-16X7/8"	51	21096	Jackshaft Pulley
12	20613	Idler Pulley <i>21622 20013</i>	52	21024	Jackshaft - Long
13	21649	Blade Drive Belt 1/2"X55" <i>37X12</i>	53	21504Z	Belt Guide
14	21503	Blade Drive Idler Ass'y.	54	21915Z	Adjusting Clevis
15	15X77	Locknut 3/8"-24	55	15X2	Hex Nut 5/16"-18
16	21496	Idler Support Bracket	56	21500	Lifter Bracket
17	20062	Woodruff Key #6	57	20476	Lifter Latch Grip
18	20616	Jackshaft - Short	58	6X46	Shoulder Screw
19	15X88Z	Flange Locknut 5/16"-18	59	23139Z	Torsion Spring
20	21022	Jackshaft Pulley	60	21591Z	Lifter Latch
21	20662Z	Shoulder Bolt	61	21249	Lifter Grip
22	21139Z	Twin Blade Idler Bracket Ass'y.	62	20101	Cotter Hair Pin
23	20682	Cross Drive Idler Spring	63	21920	Adjusting Nut
24	1X84Z	Bolt 5/16"-18X1"	64	23704Z	Adjusting Rod
25	21907	Blade Housing	65	17X53Z	Washer
26	21913	Lifter Cable	66	21031	Ball Joint
27	15X67	Hex Nut 1/4"-20	67	15X61Z	Hex Nut 3/8"-24
28	21917Z	Cable Guide	68	21517	Link Rod
29	21916	Nylon Pulley	69	17X67Z	Washer
30	20551	Jackshaft Housing Assembly	70	20934	Scissors Bracket R.H.
31	20617	Blade Adapter	71	21515C	Blade Drive Lever Ass'y.
32	21673Z	Washer	72	20739	Lever Knob
33	20930	Blade	73	15X66	Hex Nut 1/4"-20
34	20663Z	Blade Washer	74	404015	Skid Set
35	18X27	Lockwasher	75	26X159	Screw #8X3/8"
36	15X72	Hex Nut 1/2"-20	76	21549	Safety Switch
37	1X90	Bolt 1/4"-20X1-3/4"	77	21670	Safety Switch Protector
38	23169	Belt Guide	78	20682	Lifter Latch Spring
39	2X53	Carriage Bolt	79	23256	Support Arm Assembly R. H.
40	21906	Lifter Assembly	80	23705Z	Hanger Bracket Assembly
				(404036)	Complete Blade Housing Assy.

403131

**MODEL 8-3662
WIRING DIAGRAM**



PARTS LIST

KEY NO.	PART NO.	DESCRIPTION
2	20837	Seal Beam Light
3	26X159	Screw
4	21263	Battery Cable
5	26X186	Screw
6	15X66	Keys Nut
7	21261	Solenoid
8	1X38	Bolt 1/4-20
9	21549	Safety Switch
10	21075	Battery
	21079	Electrolyte
11	26X174	Screw
12	23752	Fuse 15 Amp.
13	21064PA	Switch & Key
14	21057PA	Ammeter Assy.
15	20899PA	Light Switch
16	23788	Wiring Harness
17	23834	Fuse Wire
18	23785	Battery Cable
	20729	Key Only