



**MODEL 8-3666
MODEL 8-3667
BODY SECTION**



MODEL 8-3666
MODEL 8-3667

KEY NO.	PART NO.	DESCRIPTION
1	21970	Seat
2	1X45Z	Bolt 5/16"-18X5/8"
3	23325	Rear Shroud
4	17X47Z	Washer
5	21434	Grip
6	26X197	Screw 5/16X5/8 Type B
7	26X159	Screw #8X3/8" Type A
8	26X186	Screw #10X1/2" Type AB
9	21707	Steering Post Bearing
10	23299	Control Panel
11	23332PA	Remote Control
12	15X79	Flange Nut 5/16"-18
13	21792	Side Plate R.H.
14	21268	Grommet
15	21714	Rear Shroud Support
16	21934	Running Board R.H.
17	15X43	Lock Nut 5/16"-18
18	2X53	Carriage Bolt 5/16"-18X5/8"
19	21710	Rubber Mat
20	21547	Running Board Support
21	403040	Hood Latch R.H.
---	403041	Hood Latch L.H.
22	23146Z	Belt Guide
23	15X84Z	Lock Nut 3/8"-16
24	21441	Front Axle Ass'y.
25	21469	Pivot Pin
26	2X60	Carriage Bolt 3/8"-16X3"
27	21534	Front Axle Hanger
28	403037	Frame Ass'y.
30	21935	Running Board L.H.
31	21793	Side Plate L.H.
32	21713	Lower Grill
33	21794	Hood Ass'y.
34	21765	Edge Trim
35	14X79	Wing Nut
36	21761Z	Battery Clamp
37	21762Z	Battery Clamp Rod
38	400201	Upper Grill w/Light
39	21789	Edge Trim


**MODEL 8-3667
MODEL 8-3666
STEERING SECTION**



MODEL 8-3667
MODEL 8-3666

KEY NO.	PART NO.	DESCRIPTION
1	21688	Steering Wheel
2	21303	Steering Wheel Cap
3	15X76	Keps Nut 5/16"-18
4	1X75	Bolt 5/16"-18X1 ³ / ₄ "
5	21486C	Steering Post
6	1X45Z	Screw 5/16"-18X ⁷ / ₈ "
7	21493	Steering Gear & Coupling Ass'y.
8	15X84	Locknut ³ / ₈ "-16
9	20587	Bearing
10	21692	Steering Arm Gear & Brkt. Ass'y.
11	21426	Shoulder Bolt
12	15X77	Locknut ³ / ₈ "-24
13	21031	Ball Joint
14	15X61Z	Hex Nut ³ / ₈ "-24
15	21482	Drag Link Rod
16	30X49	Cotter Pin 1 ¹ / ₄ "
17	17X115	Washer
18	21401	Spindle Bearings
19	21476	Spindle Ass'y. L.H.
20	21475	Tie Rod Ass'y.
21	21479	Spindle Ass'y. R.H.
22	21527	Front Wheel & Tire
	403000	Rim Only
	403001	Tire Only
	400162	Valve Stem & Cap
23	403010	Front Wheel Bearing
24	15X43Z	Locknut 5/16"-18
25	15X79	Flange Nuts 5/16-18
26	21693	Steering Bracket
27	1X45Z	Bolt 5/16-18X ⁵ / ₈ "
29	21662	Hub Cap
	21747	Parts Bag Assy.

MODEL 8-3667
MODEL 8-3666
DRIVE SECTION




MODEL 8-3667
MODEL 8-3666

PARTS LIST

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	21651	Cap	35	21473	Transaxle Clamp
2	21749	Oil Drain Extension	36	15X43Z	Lock Nut 5/16"-18
3	----	Engine	37	21526	Wheel & Tire 18X9.50-8
4	21616	Lock Nut		403004	Wheel Only
5	21664Z	Heat Shield (8-3667)		403005	Tire 18X9.50-8
6	23343	Muffler (8-3667)		400162	Valve Stem & Cap
6A	----	Muffler (8-3666)†	39	11X3	E-Ring
8	403037	Frame Ass'y.	40	21521	Washer
9	20062	Woodruff Key #6	41	21553	Square Key
10	15X84Z	Lock Nut 3/8"-16	42	21539	Woodruff Key
11	19X8	Lock Washer	43	----	Transaxle 646? 668A
12	20103	Engine Bolt 3/8"-16X1"	44	20844	Knob
13	20684	Drive Idler Spring	45	21615	Drive Belt 1/2"X95" 794283
14	21681	Clutch Link Rod	46	21447	Input Pulley
15	21428	Idler Bracket & Stud Ass'y.	47	18X30	Lockwasher
16	21409	Idler Pulley	48	1X38	Bolt 1/4"-20X5/8"
17	21426	Shoulder Bolt 3/8"-16X7/8"	49	18X15	Lock Washer
18	20613	Idler Pulley	50	1X84Z	Bolt 5/16"-18X1"
19	15X84Z	Flange Lock Nut 3/8-16	51	2X57	Carriage Bolt 3/8"-16X7/8"
20	17X47Z	Washer	52	21440Z	Transaxle Support Bracket
21	30X20	Cotter Pin 3/4"	53	2X56	Carriage Bolt 3/8"-16X3/4"
22	21415Z	Stack Pulley	54	21683	Belt Guide
23	10851Z	Washer	55	15X68Z	Lock Nut 3/8"-16
24	19X39	Shakeproof Washer	56	1X84Z	Bolt 5/16"-18X1"
25	1X20	Bolt 3/8"-24X1"	57	21678Z	Brake Rod Support
26	21951	Clutch Lever Ass'y.	58	26X185	Screw #10X1/2" Type AB
27	26X174	Screw	59	20682	Spring
28	21948	Brake Lever Ass'y.	60	15X79Z	Lock Nut
29	21484Z	Parking Brake Arm	61	20619	Belt Guide
30	21434	Grip	62	17X115	Washer
31	21544	Pedal	63	21662	Hub Cap
32	21535	Cap			
33	21472Z	Brake Rod			
34	21675	Spring			

†Note: Available through engine manufacturer only.

**MODEL 8-3643
MODEL 8-3662
MODEL 8-3666
MODEL 8-3667
MODEL 8-3697
BLADE HOUSING**




36" BLADE HOUSING

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	21912Z	Pull Pin	41	21189	Torsion Spring
2	20692	Cotter Hair Pin	42	21154	Chute Deflector
3	17X57Z	Washer	43	28X23	Push-On-Cap
4	20661Z	Shoulder Bolt	44	21198Z	Deflector Rod
5	21911	Support Arm L.H.	45	21953Z	Cable Guide
6	30X20	Cotter Pins	46	1X38	Bolt 1/4"-20X5/8"
7	17X47Z	Washer	47	20557	Cross Drive Belt 1/2"X46"
8	21914Z	Clevis	48	17X87Z	Washers
9	29X93	Clevis Pin	49	23126	Idler Spring
10	15X84Z	Flange Locknut 3/8"-16	50	21409	Idler Pulley
11	21426	Shoulder Bolt 3/8"-16X7/8"	51	21096	Jackshaft Pulley
12	20613	Idler Pulley → 21022 20013	52	21024	Jackshaft - Long
13	21649	Blade Drive Belt 1/2"X55" 37x12	53	21504Z	Belt Guide
14	21503	Blade Drive Idler Ass'y.	54	21915Z	Adjusting Clevis
15	15X77	Locknut 3/8"-24	55	15X2	Hex Nut 5/16"-18
16	21496	Idler Support Bracket	56	21500	Lifter Bracket
17	20062	Woodruff Key #6	57	20476	Lifter Latch Grip
18	20616	Jackshaft - Short	58	6X46	Shoulder Screw
19	15X88Z	Flange Locknut 5/16"-18	59	23139Z	Torsion Spring
20	21022	Jackshaft Pulley	60	21591Z	Lifter Latch
21	20662Z	Shoulder Bolt	61	21249	Lifter Grip
22	21139Z	Twin Blade Idler Bracket Ass'y.	62	20101	Cotter Hair Pin
23	20682	Cross Drive Idler Spring	63	21920	Adjusting Nut
24	1X84Z	Bolt 5/16"-18X1"	64	23704Z	Adjusting Rod
25	21907	Blade Housing	65	17X53Z	Washer
26	21913	Lifter Cable	66	21031	Ball Joint
27	15X67	Hex Nut 1/4"-20	67	15X61Z	Hex Nut 3/8"-24
28	21917Z	Cable Guide	68	21517	Link Rod
29	21916	Nylon Pulley	69	17X67Z	Washer
30	20551	Jackshaft Housing Assembly	70	20934	Scissors Bracket R.H.
31	20617	Blade Adapter	71	21515C	Blade Drive Lever Ass'y.
32	21673Z	Washer	72	20739	Lever Knob
33	20930	Blade	73	15X66	Hex Nut 1/4"-20
34	20663Z	Blade Washer	74	404015	Skid Set
35	18X27	Lockwasher	75	26X159	Screw #8X3/8"
36	15X72	Hex Nut 1/2"-20	76	21549	Safety Switch
37	1X90	Bolt 1/4"-20X1-3/4"	77	21670	Safety Switch Protector
38	23169	Belt Guide	78	20682	Lifter Latch Spring
39	2X53	Carriage Bolt	79	23256	Support Arm Assembly R. H.
40	21906	Lifter Assembly	80	23705Z	Hanger Bracket Assembly
				404036	Complete Blade Housing Assy.

↓
403131

**MODEL 8-3666
MODEL 8-3667
MODEL 8-3697
WIRING DIAGRAM**



PARTS LIST

KEY NO.	PART NO.	DESCRIPTION
1	20837	Seal Light Beam
2	26X186	Screw
3	21263	Battery Cable
4	21261	Solenoid
5	26X159	Screw #8X $\frac{3}{8}$ "
6	21549	Safety Switch
7	21075	Battery
	21079	Electrolyte
8	15X66	Keps Nut $\frac{1}{4}$ "-20
9	1X38	Bolt $\frac{1}{4}$ "-20X $\frac{5}{8}$ "
10	26X174	Screw
11	21686PA	Light Switch
12	21064PA	Switch & Key
13	21057PA	Ammeter Assembly
14	23336	Wiring Harness
15	23834	Fuse Wire
16	23752	Fuse
	20729	Key Only