


MODEL 9-3653

36" LAWN TRACTOR
BODY SECTION




MODEL 9-3653

Key No.	Part No.	Description
1	21970	Seat
2	1X45Z	Bolt 5/16"-18X5/8"
3	23345	Rear Shroud
4	17X47Z	Washer
5	21434	Grip
6	26X197	Screw 5/16"X5/8" Type B
7	26X159	Screw # 8X3/8" Type A
8	26X186	Screw # 10X1/2" Type AB
9	21707	Steering Post Bearing
10	23297	Control Panel
11	24011PA	Remote Control
12	15X79Z	Flange Nut 5/16"-18
13	21792	Side Plate R.H.
14	21268	Grommet
15	21714	Rear Shroud Support
16	21934	Running Board R.H.
17	15X79	Flange Nut 5/16"-18
18	2X53	Carriage Bolt 5/16"-18X5/8"
19	21710	Rubber Mat
20	21547	Running Board Support
21	403040	Hood Latch R.H.
---	403041	Hood Latch L.H.
22	23146Z	Belt Guide
23	15X84Z	Locknut 3/8"-16
24	21441	Front Axle Assembly
25	21469	Pivot Pin
26	2X60	Carriage Bolt 3/8"-16X3"
27	21534	Front Axle Hanger
28	404021	Frame Assembly
30	21935	Running Board L.H.
31	21793	Side Plate L.H.
32	21713	Lower Grill
33	21794	Hood Assembly
34	21765	Edge Trim
35	14X81	Wing Nut
36	21761Z	Battery Clamp
37	21762Z	Battery Clamp Rod
38	21712C	Upper Grill
39	21789	Edge Trim
40	26X49	Screw
41	23832	Running Board Support

MODEL 9-3653

STEERING SECTION




MODEL 9-3653

Key No.	Part No.	Description
1	21688	Steering Wheel
2	21303	Steering Wheel Cap
3	15X76	Keps Nut 5/16"-18
4	1X75	Bolt 5/16"-18X1-3/4"
5	21486C	Steering Post
6	1X45	Screw 5/16"-18X7/8"
7	21493	Steering Gear & Coupling Assembly
8	15X84	Locknut 3/8"-16
9	20587	Bearing
10	21692	Steering Arm Gear & Bracket Assembly
11	9X12	Shoulder Bolt
12	15X77	Locknut 3/8"-24
13	21031	Ball Joint
14	15X61	Hex Nut 3/8"-24
15	21482	Drag Link Rod
16	30X49	Cotter Pin 1-1/4"
17	17X83Z	Washer
18	23820	Spindle Bearings
19	24045	Spindle Assembly L.H.
20	21475	Tie Rod Assembly
21	24044	Spindle Assembly R.H.
22	21527	Wheel & Tire Assembly
	403000	Rim Only
	403001	Tire Only
	400162	Valve Stem & Cap
23	403010	Front Wheel Bearing
24	15X43	Locknut 5/16"-18
25	15X79	Flange Nuts 5/16"-18
26	21693	Steering Bracket
27	1X45	Bolt 5/16"-18X5/8"
28	17X115	Washer
	21747	Parts Bag Assembly

MODEL 9-3653

DRIVE SECTION



MODEL 9-3653

Key No.	Part No.	Description	Key No.	Part No.	Description
1	-----	Engine		403006	Rim Only
8	404021	Frame Assembly		403007	Tire Only 18X8.50-8
9	20062	Woodruff Key # 6		400162	Valve Stem & Cap
10	19X8	Shakeproof Washer	38	88X44Z	Spacer Tube
11	20103	Engine Bolt 3/8"-16X1"	39	21553	Square Key
12	23724	Drive Idler Spring	40	21402	Differential W/Disc*
13	21681	Clutch Link Rod	41	21471	Brake Rod
14	21428	Idler Bracket & Stud Assembly	42	20733	Roller Chain
15	21409	Idler Pulley	43	20730	Connecting Link
16	9X12	Shoulder Bolt 3/8"-16X7/8"	44	21567	Brake
17	20613	Idler Pulley	45	11X7	Retainer Ring
18	15X84Z	Locknut 3/8"-16	46	23347	Drive Belt
19	17X47	Washer	47	75073	Drive Input Pulley
20	30X20	Cotter Pin	48	1X91	Bolt 5/16"-18X3/4"
21	21415Z	Stack Pulley Assembly	49	19X6	Shakeproof Washer
22	10851Z	Washer	50	15X79	Flange Nut 5/16"-18
23	19X39	Shakeproof Washer	51	1X85Z	Bolt 3/8"-16X3/4"
24	1X20	Bolt 3/8"-24X1"	52	15X85	Flange Nut 3/8"-16
25	21951	Clutch Lever Assembly	53	21400	Rear Axle Bearing
26	26X174	Screw 5/16"X3/4"	54	21422Z	Bearing Adjustment Plate
27	21949	Brake Lever Assembly	55	20619	Guide Bolt
28	29X95	Clevis Pin	56	1X63	Bolt 5/16"-24X1-1/2"
29	17X46Z	Washer	57	20844	Knob
30	21484Z	Parking Brake Arm	58	24131PA	Transmission* *
31	21544	Clutch & Brake Pedal	59	20697	Woodruff Key # 9
32	21535	Push On Cap	60	21651	Pipe Cap
33	21662	Hub Cap	61	21749	Oil Drain Extension
34	11X4	E-Ring	62	15X84	Locknut 3/8"-16
35	17X114	Washer	63	21434	Brake Grip - Parking
36	61961Z	Washer	64	20692	Cotter Hair Pin
37	21525	Wheel & Tire Assembly	65	20682	Parking Brake Arm Spring


* Note: Complete illustration of Differential shown on page 98.

* * Note: Complete illustration of transmission shown on page 93.

MODEL 9-3653
MODEL 9-3666
MODEL 9-3667
MODEL 9-3697

36" BLADE HOUSING

9-3662




MODEL 9-3653
MODEL 9-3662
MODEL 9-3666
MODEL 9-3667
MODEL 9-3697

404036

PARTS LIST *DECK ASSY*

Key No.	Part No.	Description	Key No.	Part No.	Description
1	21912Z	Pull Pin	41	21189	Torsion Spring
2	20692	Cotter Hair Pin	42	21154	Chute Deflector
3	17X57Z	Washer	43	28X23	Push-On-Cap
4	9X14	Shoulder Bolt	44	21198Z	Deflector Rod
5	21911	Support Arm L.H.	45	21953Z	Cable Guide
6	30X20	Cotter Pins	46	1X38Z	Bolt 1/4"-20X5/8"
7	17X47Z	Washer	47	20557	Cross Drive Belt
8	24073Z	Clevis	48	17X87Z	Washers
9	29X93	Clevis Pin	49	24074	Idler Spring
10	15X84Z	Flange Locknut 3/8"-16	50	21409	Idler Pulley
11	9X12	Shoulder Bolt 3/8"-16X7/8"	51	21096	Jackshaft Pulley
12	20613	Idler Pulley	52	21024	Jackshaft - Long
13	21649	Blade Drive Belt	53	21504Z	Belt Guide
14	21503	Blade Drive Idler Assembly	54	21915Z	Adjusting Clevis
15	15X77	Locknut 3/8"-24	55	15X2	Hex Nut 5/16"-18
16	21496	Idler Support Bracket	56	21500	Lifter Bracket
17	20062	Woodruff Key # 6	57	20476	Lifter Latch Grip
18	20616	Jackshaft - Short	58	6X46	Shoulder Screw
19	15X88	Flange Locknut 5/16"-18	59	23139	Torsion Spring
20	21022	Jackshaft Pulley	60	21591Z	Lifter Latch
21	9X15	Shoulder Bolt	61	21249	Lifter Grip
22	21139Z	Twin Blade Idler Bracket Assembly	62	20692	Cotter Hair Pin
23	20682	Cross Drive Idler Spring	63	21920	Adjusting Nut
24	1X84Z	Bolt 5/16"-18X11"	64	23704Z	Adjusting Rod
25	21907	Blade Housing	65	17X53Z	Washer
26	21913	Lifter Cable	66	21031	Ball Joint
27	15X67	Hex Nut 1/4"-20	67	15X61	Hex Nut 3/8"-24
28	21917Z	Cable Guide	68	21517	Link Rod
29	21916	Nylon Pulley	69	17X67Z	Washer
30	20551	Jackshaft Housing Assembly	70	20934	Scissors Bracket R.H.
31	20617	Blade Adapter	71	23915C	Blade Drive Lever Assembly
32	21673Z	Washer	72	20739	Lever Knob
33	20930	Blade	73	15X66	Hex Nut 1/4"-20
34	20663Z	Blade Washer	74	404015	Skid Set
35	18X27	Lockwasher	75	26X211	Screw # 10X1" Type AB
36	15X72	Hex Nut 1/2"-20	76	24527	Limit Switch
37	1X90	Bolt 1/4"-20X1 3/4"	78	20682	Lifter Latch Spring
38	23169	Belt Guide	79	23256	Support Arm Assembly R.H.
39	2X53	Carriage Bolt	80	23705Z	Hanger Bracket Assembly
40	21906	Lifter Assembly			

**MODEL 9-3653
WIRING DIAGRAM**



Key No.	Part No.	Description
1	21263	Battery Wire - Short
2	21261	Solenoid
3	26X185	Screw
4	23834	Fuse Wire
5	21075	Battery
*	21079	Electrolyte - (Battery Acid)
6	1X38Z	Bolt 1/4"-20X5/8"
7	26X174	Screw
8	15X66	Keps Nut 1/4"-20
9	23752	Fuse - Slow Blowing
10	21064PA	Switch & Key
11	24068	Wiring Harness
12	24527	Limit Switch - Blade Housing
13	26X211	Screw
14	23984	Jumper Wire
15	21549	Limit Switch - Clutch
*	21980	Wire Clamp
	20729	Key Only

* Not Illustrated.