


MODEL 0-3656

BODY PARTS ASSEMBLY




MODEL 0-3656 (8 hp.)

Key No.	Part No.	Description
1	21970	Seat
2	1X45Z	Bolt 5/16"-18X5/8"
3	23325	Rear Shroud
4	17X47Z	Washer
5	21434	Grip
6	26X197	Screw 5/16"X5/8" Type B
7	26X159	Screw # 8X3/8" Type A
8	26X186	Screw # 10X1/2" Type AB
9	21707	Steering Post Bearing
10	23297	Control Panel
11	24011PA	Remote Control
12	15X79Z	Flange Nut 5/16"-18
13	21792	Side Plate R.H.
14	21268	Grommet
15	21714	Rear Shroud Support
16	21934	Running Board R.H.
17	15X88	Locknut 5/16"-18
18	2X53	Carriage Bolt 5/16"-18X5/8"
19	21710	Rubber Mat
20	21547	Running Board Support
21	403040	Hood Latch R.H.
---	403041	Hood Latch L.H.
22	23146Z	Belt Guide
23	15X84Z	Locknut 3/8"-16
24	21441	Front Axle Assembly
25	21469	Pivot Pin
26	2X60	Carriage Bolt 3/8"-16X3"
27	21534	Front Axle Hanger
28	403029	Frame Assembly
29	26X202	Screw 3/8"X5/8"
30	21935	Running Board L.H.
31	24238	Side Plate L.H.
32	21713	Lower Grill
33	24083	Hood Assembly
34	21765	Edge Trim
35	14X81	Wing Nut
36	21761Z	Battery Clamp
37	21762Z	Battery Clamp Rod
38	21712C	Upper Grill
39	21789	Edge Trim
40	24157	Battery Tray
41	23832	Deck Stop Assembly

MODEL 0-3656

STEERING ASSEMBLY




MODEL 0-3656

Key No.	Part No.	Description
1	21688	Steering Wheel
2	21303	Steering Wheel Cap
3	15X76	Keps Nut 5/16" - 18
4	1X75	Bolt 5/16" - 18X1-3/4"
5	21486C	Steering Post
6	1X45Z	Screw 5/16" - 18X7/8"
7	21493	Steering Gear & Coupling Assembly
8	15X84Z	Locknut 3/8" - 16
9	20587	Bearing
10	21692	Steering Arm Gear & Bracket Assembly
11	9X12	Shoulder Bolt
12	15X87Z	Locknut 3/8" - 24
13	21031	Ball Joint
14	15X61	Hex Nut 3/8" - 24
15	21482	Drag Link Rod
16	30X49	Cotter Pin 1-1/4"
17	17X83Z	Washer
18	23820	Spindle Bearings
19	24045	Spindle Assembly L.H.
20	21475	Tie Rod Assembly
21	24044	Spindle Assembly R.H.
22	21527	Wheel & Tire Assembly
	403000	Rim Only
	403001	Tire Only
	400162	Valve Stem & Cap
23	403010	Front Wheel Bearing
24	15X88	Locknut 5/16" - 18
25	15X79Z	Flange Nuts 5/16" - 18
26	21693	Steering Bracket
27	1X45Z	Bolt 5/16" - 18X5/8"
28	17X115	Washer
	21662	Hub Cap
	21747	Parts Bag Assembly
	F-4905	Owners Manual

MODEL 0-3656

DRIVE SECTION



MODEL 0-3656


PARTS LIST

Key No.	Part No.	Description	Key No.	Part No.	Description
1	21651	Cap	36	15X88	Locknut 5/16"-18
2	21749	Oil Drain Extension	37	21648	Wheel & Tire Assembly
3	-----	Engine		403004	Wheel Only
8	403029	Frame Assembly		403007	Tire 18X8.50-8
9	20062	Woodruff Key # 6		400162	Valve Stem & Cap
10	15X84Z	Locknut 3/8"-16	39	11X3	E-Ring
11	19X8	Lockwasher	40	21521	Washer
12	20103	Engine Bolt 3/8"-16X1"	41	21553	Square Key
13	23724	Drive Idler Spring	42	21539	Woodruff Key
14	21681	Clutch Link Rod	43	-----	Transaxle *
15	21428	Idler Bracket & Stud Assembly	44	20844	Knob
16	21409	Idler Pulley	45	21615	Drive Belt
17	9X12	Shoulder Bolt 3/8"-16X7/8"	46	21447	Input Pulley
18	20613	Idler Pulley	47	18X30	Lockwasher
19	15X84Z	Flange Locknut 3/8"-16	48	1X38Z	Bolt 1/4"-20X5/8"
20	17X47Z	Washer	49	18X15	Lockwasher
21	30X20	Cotter Pin 3/4"	50	1X84Z	Bolt 5/16"-18X1"
22	21415Z	Stack Pulley	51	2X57	Carriage Bolt 3/8"-16X7/8"
23	10851Z	Washer	52	21440Z	Transaxle Support Bracket
24	19X39	Shakeproof Washer	53	2X56	Carriage Bolt 3/8"-16X3/4"
25	1X20	Bolt 3/8"-24X1"	54	21683	Belt Guide
26	21951	Clutch Lever Assembly	55	15X84Z	Locknut 3/8"-16
27	26X49	Screw	56	1X84Z	Bolt 5/16"-18X1"
28	21948	Brake Lever Assembly	57	21678Z	Brake Rod Support
29	24202Z	Parking Brake Arm	58	26X185	Screw # 10X1/2" Type AB
31	21544	Pedal	59	20682	Spring
32	21535	Cap	60	15X79	Locknut
33	21472Z	Brake Rod	61	20619	Belt Guide
34	21675	Spring	62	17X115	Washer
35	21473	Transaxle Clamp	64	1X91	Bolt 5/16"-18X3/4"

* NOTE: Complete illustration of transaxle shown on pages 82 and 83.

MODEL 0-3656
MODEL 0-3666
MODEL 0-3667
MODEL 0-3697

BLADE HOUSING



MODEL 0-3656
MODEL 0-3666
MODEL 0-3667
MODEL 0-3697

BLADE HOUSING

PARTS LIST

Key No.	Part No.	Description	Key No.	Part No.	Description
1	21912Z	Pull Pin	42	21154	Chute Deflector
2	20692	Hair Pin	43	28X23	Push-On-Cap
3	17X57Z	Washer	44	21198Z	Deflector Rod
4	9X14Z	Shoulder Bolt	45	21953Z	Cable Guide
5	21911	Support Arm L.H.	46	1X38Z	Bolt 1/4"-20X5/8"
6	30X20	Cotter Pins	47	20557	Cross Drive Blet
7	17X47Z	Washer	48	17X87Z	Washers
8	24073Z	Clevis	49	24074	Idler Spring
9	29X93	Clevis Pin	50	21409	Idler Pulley
10	15X84Z	Flange Locknut 3/8"-16	51	21096	Jackshaft Pulley
11	9X12	Shoulder Bolt 3/8"-16X7/8"	52	21024	Jackshaft - Long
12	20613	Idler Pulley	53	21504Z	Belt Guide
13	21649	Blade Drive Belt	54	21915Z	Adjusting Clevis
14	21503	Blade Drive Idler Assembly	55	15X2	Hex Nut 5/16"-18
15	15X87Z	Locknut 3/8"-24	56	21500	Lifter Bracket
16	21496	Idler Support Bracket	57	20476	Lifter Latch Grip
17	20062	Woodruff Key # 6	58	6X46	Shoulder Screw
18	20616	Jackshaft - Short	59	23139	Torsion Spring
19	15X88Z	Flange Locknut 5/16"-18	60	21591Z	Lifter Latch
20	21022	Jackshaft Pulley	61	21249	Lifter Grip
21	9X15	Shoulder Bolt	62	20692	Hair Pin
22	21139Z	Twin Blade Idler Bracket Assembly	63	21920	Adjusting Nut
23	20682	Cross Drive Idler Spring	64	23704Z	Adjusting Rod
24	1X84Z	Bolt 5/16"-18X1"	65	17X53Z	Washer
25	21907	Blade Housing	66	21031	Ball Joint
26	21913	Lifter Cable	67	15X61Z	Hex Nut 3/8"-24
27	15X67	Hex Nut 1/4"-20	68	21517	Link Rod
28	21917Z	Cable Guide	69	17X67Z	Washer
29	21916	Nylon Pulley	70	20934	Scissors Bracket R.H.
30	20551	Jackshaft Housing Assembly	71	23915C	Blade Drive Lever Assembly
31	20617	Blade Adapter	72	20739	Lever Knob
32	21673Z	Washer	73	15X66	Hex Nut 1/4"-20
33	20930	Blade	74	404015	Skid Set
34	20663Z	Blade Washer	75	26X211	Screw # 10X1" Type AB
35	18X27	Lockwasher	76	24527	Limit Switch
36	15X72	Hex Nut 1/2"-20	77	15X79Z	Flange Nut
37	1X90	Bolt 1/4"-20X1-3/4"	78	20682	Lifter Latch Spring
38	23169	Belt Guide	79	23256	Support Arm Assembly R.H.
39	2X53	Carriage Bolt	80	23705Z	Hanger Bracket Assembly
40	21906	Lifter Assembly	81	17X124	Washer
41	21189	Torsion Spring		404036	Complete Blade Housing Assembly

WIRING DIAGRAM

MODEL 0-3656 (8 hp.)

PARTS LIST

Key No.	Part No.	Description
1	24X9	Battery Wire - Short
2	21261	Solenoid
3	26X185	Screw
4	23834	Fuse Wire
5	21075	Battery
*	21079	Electrolyte (Battery Acid)
6	1X38Z	Bolt 1/4''-20X5/8''
7	26X174	Screw
8	15X66	Keys Nut 1/4''-20
9	23752	Fuse - Slow Blowing
10	21064PA	Switch & Key
11	24068	Wiring Harness
12	24527	Limit Switch - Blade Housing
13	26X211	Screw
14	23984	Jumper Wire
15	21549	Limit Switch - Clutch
*	21980	Wire Clamp

* Not Illustrated

