


**MODEL 81-21820  
REAR BAGGER  
SELF-PROPELLED**



**MODEL 81-21820  
REAR BAGGER  
SELF-PROPELLED**


Key No.	Part No.	Description	Key No.	Part No.	Description
1	----	Engine	44	17X17Z	Washer
2	32X64	Spring Pir.	45	26X184	Screw
3	42086	Sprocket - Engine	46	42204	Rear Guard
4	42289	Primary Chain Cover	49	42011	Housing Assembly
5	26X159	Tapping Screw	50	20105	Wheel & Tire
6	20062	Woodruff Key # 6	51	400247	Wheel Adjuster Assembly*
7	42108	Roller Chain	52	15X82	Flange Nut 1/4"-20
8	42088	Pinion Guard	53	19X8	Shakeproof Washer
9	20066	Drive Pinion	54	20102	Bolt - Engine Mount
10	22974Z	Bearing Retainer Bracket	55	1X68	Bolt - Blade Mount
11	20048	Bearing	56	18X31	Spring Lockwasher
12	42063Z	Drive Arm	57	20094Z	Washer
13	22977	Spring - L.H.	58	22860	Blade - 21 Inch
14	22976	Spring - R.H.	59	42002	Blade Adapter
15	22970Z	Wheel Connecting Lever Assembly	60	42035	Grass Catcher Frame
16	15X84	Flange Locknut 3/8"-16	61	42037	Door Latch
17	17X53Z	Washer	62	42036	Upper Tube
18	1X38	Hex Bolt 1/4"-20X5/8"	63	42033	Grass Catcher Bag
19	42053Z	Drive Yoke Bracket - L.H.	64	22961C	Upper Handle
20	42054Z	Drive Yoke Bracket - R.H.	65	42039C	Lower Handle
21	4X20	Machine Screw # 10-24X1/2"	66	42029	Handle Bracket LH
23	15X51Z	Hex Nut # 10-24	67	1X85	Hex Bolt
24	42083Z	Sprocket & Drive Shaft Assembly	68	15X84Z	Hex Nut
25	9X8	Shoulder Bolt	69	42028	Handle Bracket R.H.
26	42018	Spring - Extension	70	22550	Cable Clip
27	42003	Spacer	71	20266	Knob - Folding Handle
28	42087	Sprocket	72	20129Z	Contour Head Bolt
29	42090Z	Axle Drive Yoke Support	73	42058	Throttle Control
30	1X45	Hex Bolt 5/16"-18X5/8"	74	3X136Z	Screw
31	11X8	Retainer Ring	75	15X66	Keps Nut
32	17X100Z	Washer	76	22975Z	Handle Stop
33	15X76	Keps Nut 5/16"-18	77	22957Z	Control Handle
34	15X88	Stover Nut 5/16"-18	78	22959	Clutch Cable Hook
35	22973	Bracket & Pulley Assembly	79	42069Z	Cable Bracket
36	9X1	Shoulder Bolt	80	42092	Control Cable Assembly
37	42050Z	Tie Rod Assembly	81	17X46Z	Washer
38	32X70	Spring Pin		42070	Parts Bag Assembly
41	42251E	Base Plate & Spacer Assembly		F-5418	Owners Manual
42	400249	Door & Bracket Assembly	82	32425	1" Cable Clip
43	42031	Knob - Door	83	42041	Catcher Support Hook

\*Note: See page 24 for Wheel Adjuster Replacement Parts.

### DELUXE WHEEL ADJUSTER ASSEMBLY

**MODEL 400245 - MULCHER**  
**400246 - SIDE BAGGER**  
**400247 - REAR BAGGER**

KEY NO.	MODEL 400245	MODEL 400246	MODEL 400247	DESCRIPTION
1	17X102Z	17X102Z	17X102Z	Washer
2	20101	20101	20101	Hair Pin
3	9X9	9X9	9X18	Shoulder Bolt
4	22956Z	22956Z	22956Z	Arm and Axle Assembly
5	20065	20065	20065	Lever Spring Knob
6	42007Z	20113Z	42007Z	Index Plate Assembly
7	15X12	15X12	15X12	Flange Locknut
8	15X84Z	15X84Z	15X84Z	Locknut
9	42205Z	-----	-----	Spacer



### STANDARD WHEEL ADJUSTER ASSEMBLY MODELS 400251 & 400252

Key No.	Part No.	Description
1	17X102Z	Washer
2	20101	Hair Pin
3	42102Z	Wheel Bracket Assembly - Right Front or Left Rear
	42103Z	Wheel Bracket Assembly - Left Front or Right Rear
4	42104Z	Index Plate Assembly
1-4	400251	Wheel Adjuster Assembly - Right Front or Left Rear
1-4	400252	Wheel Adjuster Assembly - Left Front or Right Rear
5	15X84Z	Flange Locknut

