


5-40700


**BODY PART
ILLUSTRATIO**



BODY PARTS

KEY NO.	DESCRIPTION	PART NO.
1	Seat	90368
2	Seat Support	90032
3	Flange Locknut 3/8"-16	15X84
4	Shoulder Bolt 3/8"-16X7/8"	9X15
5	Hex Bolt 5/16"-18X5/8"	1X45
9	Screw	26X49
10	Seat Pivot Bracket	90031
11	Seat Deck	90186
12	Spring	164X17
13	Spring Retainer	90014
14	Seat Deck Support	90633
15	Carriage Bolt	2X53
16	Keps Nut 5/16" 18	15X76
17	Battery Tray	24157
18	Battery Clamp	90632Z
19	Flange Locknut 5/16"-18	15X88
20	Dashboard Assembly	90737
21	Bearing - Steering Post	90081
22	Screw	26X186
23	Battery Clip	55149
24	Right Hood Latch*	90464Z
25	Left Hood Latch*	90465Z
26	Washer*	17X17Z
27	Hex Nut No. 10-24*	15X81
28	Machine Screw No. 10-24X½"*	4X20Z
29	Edge Trim*	90240
30	Hood & Grille Assembly-Complete No Hole	90471
30a	Hood & Grille Assembly - Complete With Hole	90470
32	Shoulder Bolt 3/8"-16X7/8"	9X14
33	Reflector, Headlight	90009C
34	Lens, Headlight	90082
36	Mat - Foot Rest	90148
37	Frame Channel	90001
40	Washer	17X47Z
42	Headlight Trim	90159C
43	Lock Washer	18X16


*NOTE: These numbers are included in with key no. 30

5-40700**STEERING REPLACEMENT PARTS**

KEY NO.	DESCRIPTION	PART NO.
1	Steering Wheel Cap	55367
2	Steering Wheel	55368
3	Hex Bolt 5/16"-18X1 1/2"	1X102
4	Keps Nut	15X88
5	Steering Post	90130C
6	Washer	17X47Z
7	Hex Bolt 5/16"-18X5/8"	1X45
8	Screw	26 X 49
9	Hex Bolt 3/8"-24X3 1/4"	1X101
10	Bearing	90035
11	Pinion Gear & Shaft	90132
12	Sector Gear Assembly	90025
13	Flange Locknut 3/8"-24	15X87
14	Axle Support - Front	90002
15	Cotter Pin	30X49
16	Bearing	90035
17	Axle Assembly	90034
18	Washer	17X113
19	Left Hand Spindle Assembly	90139
20	Ball Joint	21031
21	Washer	17X124
22	Tie Rod	21475
23	Drag Link Assembly	90041
24	Right Hand Spindle Assembly	90138
25	Bearing	55599
26	Tire Only	24376
--	Tire Tube	407047
27	Wheel Only	24488E
28	Washer-Hub Caps Only	17X115
--	Washer-Without Hub Caps	17X83Z
29	Valve Stem & Cap	24373
31	Hub Cap-Optional	21662
32	Hex Nut 3/8"-24	15X61

*NOTE: When ordering replacement parts specify the brand name of the tire to insure that tread patterns on tire match.

REPLACEMENT PARTS ENGINE MOUNT




KEY NO.	DESCRIPTION	PART NO.
1	Throttle Control (Complete)	90728
2	Screw	26X159
3	Fuel Cap	23711
3A	Fuel Cap with gauge	24064
4	Fuel Tank	23300
5	Hose Clamp	23713
6	Fuel Line	90671
7	Fuel Filter	24159
8	Screw	26X214
9	Engine †	-----
10	Woodruff Key No. 6	20062
11	Frame Channel	90001
13	Star Washer	19X8
14	Bolt - Engine Mount	20103
15	Stack Pulley Assembly	90329Z
16	Washer	10851Z
17	Star Washer	19X39
18	Hex Bolt 3/8"-24X1"	1X20
19	Belt Guide, Stack Pulley	90867Z
20	Muffler	90330PA
22	Hex Bolt 5/16"-18X3 1/4"	1X118
23	Muffler Heat Shield	90332
24	Exhaust Deflector	23740Z
25	Screw	26X203
26	Oil Drain Extension	24066
27	Oil Drain Cap	21651

†NOTE: The Engine Model, Type & Code Numbers are on the engine. All parts to the engine are available from a Briggs and Stratton Authorized Service Center. See the yellow pages under, "Engines, Gasoline "or" Gasoline Engines" in the telephone directory.

5-40700

DRIVE PART
ILLUSTRATIO



D-5283-5

REPLACEMENT PARTS

5-40700

DRIVE PARTS


KEY NO.	DESCRIPTION	PART NO.
1	Bolt, Belt Guide	20619
2	Flange Nut 5/16"-18	15X79Z
3	Flange Locknut 3/8"-18	15X84
4	Frame Channel	90001
5	Hex Bolt 5/16"-18X1 7/8"	1X98
6	Push Nut	28X44
7	Cap Retainer, Parking Brake	28X48
8	Retainer Ring	11X7
9	Drive Pulley	90190
10	Extension Spring	165X31
12	Idler Bracket Assembly	90011Z
13	Shoulder Bolt 3/8"-16X7/8"	9X12
14	Drive Belt	37X45
15	Washer	17X53Z
16	Idler Pulley	21409
17	Transaxle Support	90173Z
18	Knob - Shift Lever	20739
19	Shift Lever	90670Z
20	Shifter Yoke	90183Z
21	Hex Bolt 1/4"-28X1/2"	1X82
22	Lockwasher	18X32
23	Washer	17X32Z
24	Washer	17X134
25	Screw	26X207
26	Washer	17X102Z
27	Cotter Pin	30X20
28	Transaxle† (Peerless Model No. 834)	----
29	Clutch and Brake Pedal	21544
30	Lever Assembly	90027
31	Support Bracket	90013
32	Adjustable Nut	21920
33	Clutch Rod	90066Z
34	Brake Rod	90067Z
35	Brake Link Assembly	90068
36	Brake Spring	165X47
37	Flange Locknut 5/16"-18	15X88
38	Transaxle Washer	21521
39	Axle Spacer	87X63Z
40	Square Key 3/16"X2"	21553
41	Woodruff Key No. 9	20697
42	Spring, Brake Return	165X34
43	Tire Only	90807
--	Tire Tube	407049
44	Wheel Only	24351E
45	E-Ring	11X3
46	Valve Stem and Cap	24373
48	Carriage Bolt 5/16"-18X3/4"	2X53Z
49	Screw	26X49
50	Belt Guide	90694
51	Belt Guide	90691

*NOTE: For replacement parts, always give the name on the side of the tire so that the tire tread pattern will be the same.

†NOTE: Replacement parts for the transaxle are available from a Tecumseh Authorized Service Center. See the yellow pages under, "Engines, Gasoline "or" gasoline Engines" in the telephone directory.

5-40700

BLADE HOUSING SUSPENSION
REPLACEMENT PARTS



Q-5471-1

F-7542


**BLADE HOUSING SUSPENSION
REPLACEMENT PARTS**
5-40700

KEY NO.	DESCRIPTION	PART NO.
1	Grip, Blade Engagement Control	20476
2	Lever, Blade Engagement Control	90030Z
3	Hair Pin (*)	75336
4	Carriage Bolt	2X64
5	Screw	26X49
6	Adjuster Screw Assembly	90078Z
7	Washer (*)	17X53Z
8	Bracket Assembly, Adjuster	404063
9	Cotter Pin	30X20
10	Spring, Blade Engagement Control (*)	165X32
11	Rod, Adjuster (*)	23704Z
12	Nut, Adjustable (*)	21920
13	Lifter Assembly	90825
14	Link Assembly (*)	90754Z
15	Hex Nut 5/16"-18	15X79
16	Support, Channel	90028
17	Carriage Bolt	2X57
18	Locknut 3/8"-16	15X84
20	Grip, Lifter Handle	23340
21	Handle, Lifter	90801E
23	Rod, Chute-R.H. (*)	90888Z
24	Rod, Chute-L.H. (*)	90889Z
25	Hair Pin (*)	20692
26	Spring, Lifter Extension	165X60
27	Rod	90797Z

* NOTE: Parts that have an asterisk (*) in the description are included with the complete blade housing.

5-40700

BLADE HOUSING
REPLACEMENT PARTS



D-5472-1

**BLADE HOUSING
REPLACEMENT PARTS**
5-40700


KEY NO.	DESCRIPTION	PART NO.	KEY NO.	DESCRIPTION	PART NO.
1	Bracket, Rear Hanger (*)	90881	36	Shaft Assembly, Right Spline	90883
2	Adjusting Bar	90109	37	Pulley, Flat Idler	90865
3	Cotter Pin	30X20	38	Belt, 8mm HTD Cross Drive	37X54
4	Push Nut	28X54	39	Washer	17X53Z
5	Lever, Deck Pivot	90339Z	40	Guide, Left Belt	90893Z
6	Hair Pin	75336	41	Bracket, Lifter (*)	90103
7	Hex Nut 5/16"-18 (*)	15X79Z	42	Hex Bolt 3/8"-16X4"	1X123
8	Adjustable Nut	21920	43	Washer	17X158
9	Rod, Link	90108Z	44	Spring, Compression	164X18
10	Rod, Control	90885Z	45	Absorber	90895
11	Spring, Extension	165X63	46	Bracket, Idler & Deck Lift (*)	90894
12	Shoulder Bolt	9X12	47	Jam Nut 3/8"-16	15X73
13	Spring, Extension	165X61	48	Locknut, Flange 3/8"-16	15X68
14	Screw	26X214	49	Shoulder Bolt	9X14
15	Guard, Pulley	90858	50	Bracket Assembly, Idler	90880Z
16	Brake Assembly, Idler and	90887	51	Hex Bolt 5/16"-18X1"	1X84
17	Locknut 9/16"-18	15X101	52	Guide, Right Belt	90892Z
18	Lockwasher	18X33	53	Bracket Assembly, Idler (*)	90879
19	Pulley, Idler	23238	54	Blade Housing-See Note Below	90896
20	Bracket, Idler Support (*)	90859	55	Hanger Rod	90107Z
21	Locknut 3/8"-16	15X84	56	Washer	17X57Z
22	Pulley, V-Idler	90315	57	Bracket, Front Hanger (*)	90854
23	Pulley	90872	58	Pin, Pull	90827Z
24	Belt, Blade Drive	37X40	59	Washer	17X122Z
25	Cover, Blade Drive	90856	60	Front Hanger	90106
26	Pin, Deflector Pivot	90862Z	61	Carriage Bolt (*)	2X53Z
27	Deflector	90857	62	Mandrell Housing	24384
28	Hair Pin	20692	63	Adapter, Blade	90891
29	Bracket, Right Chute (*)	90863	64	Baffle, Center (*)	90868
30	Locknut 5/16"-18 (*)	15X88	65	Blade, Left	90877
31	Bracket, Left Chute (*)	90864	66	Washer	20663Z
32	Shaft Assembly, Left Spline	90882	67	Blade, Right	90878
33	Sprocket, HTD	90875	--	Blade Housing-complete (†)	403205
34	Washer	17X157			
35	Washer	17X149			

* NOTE: Parts that have an asterisk (*) in the description are included with key number 54.

† NOTE: The blade housing complete includes this page

5-40700

REPLACEMENT PARTS WIRING DIAGRAM



D-5281-4

KEY NO.	DESCRIPTION	PART NO.
1	Battery	21075
--	Electrolyte (Battery Acid)	90665
--	Battery Caps	400262
2	Hex Bolt 1/4"-20X5/8"	1X38
3	Keps Nut 1/4"-20	15X66
4	Battery Cable - (Black)	24X9
5	Screw	26X49
6	Fuse	54212
7	Ammeter Assembly	90729
8	Ignition Switch and Key	21064PA
8a	Key and Ring Only	20729
9	Light Switch	90647
11	Battery Cable - (Red)	24X17
12	Screw	26X233
13	Solenoid	24285
13a	Cover, Solenoid	90565
14	Limit Switch	24273
15	Light Socket Assembly	90155
16	Washer, Light Socket	90228
17	Headlight Bulb	90084
18	Wiring Harness	90730
--	Tie Strap	32618