


MODEL NO. 7-30502X92

FRAME & BODY



D-5338-7

D-4351-10


FRAME & BODY

MODEL NO. 7-30502X92

KEY NO.	DESCRIPTION	PART NO.
1	Seat	91039
2	Seat Mount	55765
3	Locknut, Flange 3/8"-16	15X84
4	Seat Spring	164X17
5	Screw	26X49
6	Spring Retainer	90014
7	Spring Hanger	55062
8	Seat Support	55741
9	Washer	17X47Z
10	Hex Bolt 5/16"-18x5/8"	1X45
11	Shoulder Bolt 3/8"-16X7/8"	9X30
12	Seat Hinge	55061
13	Engine	+
14	Muffler	90331PA
15	Hex Bolt 1/4"-20X3 1/4"	1X117
16	Washer, Shakeproof	19X8
17	Bolt, Engine Mount	25X6
19	Control & Cable	55330PA
20	Rear Body Assembly, For Light	55678
21	Nut, Tinnerman 1/4"-20	28X18
22	Frame Channel	55941
23	Nuts, Keps 1/4"-20	15X66
24	Screw, Tapping	26X201
25	Bolt, Carriage	2X67
26	Clamp, Battery	55210Z
27	Screw, Tapping	26X159
28	Screw, Tapping	26X214
29	Battery Clip	55149Z
30	Bushing	21268
31	Bolt, Hex 1/4"-20X5/8"	6X74
32	Mat, Running Board (R.H.)	55102
33	Mat, Running Board (L.H.)	55103
34	Console Plate	55023
35	Bearing, Steering Post	56022
36	Console Assembly, with light	55932
37	Reflector	90009C
38	Lens	90082
39	Screw, Machine 1/4"-20X1/2"	4X24
40	Washer	19X6
41	Lockwasher	18X16
42	Hex Bolt	1X91
43	Locknut, Flange	15X88
44	Engine Strap, right	55205
45	Engine Strap, left	55206
46	Rear Body Support	55017Z
47	Tank, Fuel	55805
48	Cap, Fuel	55990
49	Clamp, Hose	23713
50	Fuel Line	91022
51	Bracket, Tank	55806E
52	Screw	26X213
53	Filter	+
	Parts Bag	55964
	Owners Manual	F-87520
	Parts List	F-87521
	Decal Console Front	58X939
	Decal RH Console	58X854
	Decal LH Console	58X855
	Decal RH Shroud	58X852
	Decal LH Shroud	58X853

MODEL NO. 7-30502X92

**BLADE HOUSING
TOP HALF**




*D-4595-3

**BLADE HOUSING
TOP HALF****MODEL NO. 7-30502X92**

KEY NO.	DESCRIPTION	PART NO.
1	Grip, Blade Control Lever	55449
2	Lever, Blade Control	55927Z
3	Locknut, Flange ¼"-20	15X89
4	Bolt, Hex ¼"-20	1X76
5	Washer	17X122Z
6	Washer	17X67Z
7	Cam, PTO	55853
8	Grip, Lifter	21249
9	Lever Assembly, Lifter	56031
10	Bolt, Hex ¼"-20X5/8"	1X38
11	Strut	55348
12	Locknut, Flange 3/8"-16	15X84
13	Plate, Index	55365
14	Screw	26X49
15	Bolt, Shoulder 3/8"-16	9X9
16	Nut, Adjuster	21920
17	Washer	17X53Z
18	Pin, Cotter	30X20
19	Nut, Hex Flange 5/16"-18	15X88
20	Washer	17X48
21	Lever Assembly	55656
22	Rod & Arm Assembly	55930
23	Spring, Extension	165X67
24	Link, Front Deck	55179
25	Bracket, Front Suspension	55139
26	Clevis	55298
27	Bolt, Shoulder 3/8"-16	9X17
28	Nut, Hex Jam 3/8"-16	15X73
29	Rod Assembly	55957
30	Link	55271Z
31	Bolt, Shoulder	9X4
32	Clevis, Adjuster	24471Z
33	Nut, Hex 5/16"-18	15X2
34	Hairpin	31X4
35	Plate, Adjuster	55344
36	Plate, Mounting	55270
37	Rod Assembly, Suspension	55346
38	Bolt Carriage	2X537
39	Rod Blade Brake	24839

MODEL NO. 7-30502X92

BLADE HOUSING
BOTTOM HALF



D-4745


BLADE HOUSING BOTTOM HALF

MODEL NO. 7-30502X92

KEY NO.	DESCRIPTION	PART NO.
1	Belt, Mower Drive	37X57
2	Pulley, Splined	55452
3	Lockwasher	18X33
4	Locknut 9/16x18	15X101
5	Nut, Hex	15X41
6	Pulley, Idler	91178
7	Bracket, Upper Idler	55921
8	Spacer	55895
9	Assembly, Blade Idler	55979
10	Locknut, Flange	15X88
11	Pin, Clevis	29X99
12	Clevis	24471
13	Bolt, Hex	1X45
14	Pin, Hair	31X6
15	Guide, Belt	55977
16	Bracket, Lower Idler	55920
17	Bolt, Carriage	2X53Z
18	Nut, Flange	15X79Z
19	Guide, Belt	55894
20	Spacer	55273Z
21	Bolt, Hex	1X127
22	Housing, Mandrel	55962
23	Guide, Belt	55956Z
24	Bracket, Hanger	55974
25	Spring, Compression	164X1
26	Nut, Hex	15X43Z
27	Spring, Torsional	166X4
28	Push On Cap	28X23
29	Rod	21197Z
30	Bracket, Chute Deflector	55963
32	Spring, Extension	165X68
33	Housing, Blade	55904 55973
34	Bracket, Front	55916
35	Screw	26X216
36	Bolt, Hex 5/16"-18x7/8"	1X75
37	Deflector, Chute Assembly	55971
38	Jackshaft Splined	55445
39	Blade	55969HT
40	Washer, Belleville	17X155
41	Washer, Hardened	17X154
42	Nut, Hex 9/16"-18	15X100
43	Pin, Pull	90828Z
44	Washer	17X67Z
45	Pin, Hair	31X4
—	Mower Housing, Complete	403215

MODEL NO. 7-30502X92

MOTION DRIVE



MOTION DRIVE

MODEL NO. 7-30502X92

KEY NO.	DESCRIPTION	PART NO.	KEY NO.	DESCRIPTION	PART NO.
1	Nut 5/16''-18	15X2	36	Belt Guide Assembly	55281Z
2	Spring Lockwasher	18X15	37	Drive Belt, Traction	37X38
3	Washer	17X47	38	Stack Pulley Assembly	55437Z
4	Transmission Yoke	55262Z	39	Washer	17X103
5	Cotter Pin	30X20	40	Washer	19X35
6	Extension Spring, Brake Return	165X28	41	Hex Bolt 7/16''-20X1''	1X80
7	Washer	17X148	42	Idler Pulley	20613
8	Screw, Tapping	26X207	43	Pulley, Transmission	55101
9	Grip	55321	44	Retainer Ring	11X7
10	Shift Lever	55121Z	45	Axle Bearing, Flange	55597
11	Transmission Gate	55262Z	46	Bracket, Rear Axle	55065
12	Transmission, JB Foote	***	47	Differential, Peerless 100	+
13	Woodruff Key #9	20697	48	Roller Chain	55115
14	Guide Screw	20619	49	Roller**	90176
15	Locknut, Flange 3/8''-16	15X84	50	Locknut, Flange 5/16''-18**	15X88
16	Carriage Bolt 3/8''-16X3/4''	2X56	51	Chain Adjustment Bracket	55194
17	Carriage Bolt 5/16''-18X5/8''	2X53Z	52	Hex Nut, Flange 3/8''-16	15X68
18	Screw, Tapping	26X49	53	Shoulder Bolt 5/16'' -18X17.2''***	9X22
19	Chain Clamp	55264Z	54	Sprocket & Chain Guard, 50 Tooth	55621
20	Pedal, Clutch/Brake	55395	55	Connecting Link	407059
21	Torsional Spring, Pedal	166X18	56	Key, Square 3/16''	21553
22	Hex Nut	15X2	57	Washer	21521
23	Lever Assembly, Brake/Clutch	55656	58	E-Ring	11X3
24	Washer	17X67Z	60	Valve Stem & Cap	24373
25	Adjustable Nut	55002	61	Tire Only*	24393
26	Rod, Brake/Clutch	55737Z	62	Wheel Only	24391E
27	Extension Spring, Brake	165X51	64	Guide Block**	23403
28	Shoulder Bolt 3/8''-16X7/8''	9X30	66	Screw, Tapping**	26X214
30	Extension Spring, Clutch	165X39	67	Clevis	21915Z
31	Hex Nut, Flange 5/16''-18	15X79	68	Clevis Pin	29X99
33	Hex Bolt	1X45			
34	Idler Arm Assembly	55067Z			

+ NOTE: Replacement parts for the transmission or differential are available from a Tecumseh Authorized Service Center. See "Engines, Gasoline" or "Gasoline Engines" in the yellow pages of the telephone directory.

*NOTE: For replacement parts, always give the name on the side of the tire so that the tire pattern will be the same.


**NOTE: These parts are included with the chain adjusting bracket, key no. 51.

***NOTE: Replacement parts for the transmission are available from a J.B. Foote Distributor listed on the warranty or contract: The J.B. Foote Foundry Co., P.O. Box 236, Fredericktown, Ohio, 43019, C/O Parts Service Manager.

*may have 4100-11 - 3spd
4100-12 5spd*

MODEL NO. 7-30502X92

STEERING




STEERING**MODEL NO. 7-30502X92**

KEY NO.	DESCRIPTION	PART NO.
1	Steering Wheel	90576
3	Hex Bolt 5/16''-18X1 1/2''	1X102
4	Locknut, Flange 5/16''-13	15X88
5	Steering Post	90130C
6	Washer	17X47Z
7	Carriage Bolt 5/16''-18X5/8''	2X53Z
8	Screw, Tapping	26X49
9	Suspension Plate, Left	55384
10	Hex Nut, Flange	15X79Z
11	Suspension Plate, Right	56023
12	Locknut, Flange 3/8''-24	15X87Z
13	Front Axle Support Assembly	55937
14	Cotter Pin	30X49
15	Spindle Bearing	55003
16	Front Axle Hanger Assembly	55655
17	Front Axle Assembly	55024
18	Pinion Gear	55001
19	Sector Assembly	55746
20	Drag Link	55046
21	Hex Nut 3/8''-24	15X61Z
22	Steering Ball Joint	21031
23	Washer	17X53Z
24	Cotter Pin	30X20
25	Hex Bolt 3/8''-24X2 3/8''	1X69
26	Left Spindle Assembly	55381 400301
27	Tie Rod	55026
28	Right Spindle Assembly	55380 400302
30	Bearing	55598
31	Tire Only*	24394
32	Valve Stem & Cap	24373
33	Wheel Only	24364E
34	Washer	24583
36	Bearing	55168
37	Washer	17X100Z
38	Bushing, Nylon	55547

*When ordering replacement parts, specify the brand name of the tire to insure that tread patterns on the tire match.

MODEL NO. 7-30502X92

WIRING DIAGRAM



KEY NO.	DESCRIPTION	PART NO.	KEY NO.	DESCRIPTION	PART NO.
1	Cable, Battery	24X12	14	Wiring Harness, with light	250X5
2	Solenoid	24285	15	Switch	21064
3	Screw	26X233	16	Key Only	20729
4	Nut, Locknut 1/4"-20	15X66	17	Light Switch	90647
5	Battery	23581	18	Light Socket	90155
—	Electrolyte (Battery Acid)	55320	19	Light Bulb	90084
6	Hardware, Battery	402012	20	Solenoid Cap	90565
7	Cover, Battery Terminal	24196	21	Washer, Shakeproof	19X40
8	Cable, Ground Battery	24X9	22	Nut, Hex	15X105
9	Screw	26X49	23	Switch, Seat Sensor	91031
10	Limit Switch, Transmission	23479	—	Tie, Wire Seat*	55938
11	Fuse, 15 AMP	54212	—	Clip, Wire Adhesive*	55939
12	Fuse Holder	407078	—	Clamp, Wire*	21980
13	Limit Switch	91032			

*Part is not shown.