


**ROTARY LAWN MOWER -- MODEL NUMBER PR55N21CHE**



## ROTARY LAWN MOWER - - MODEL NUMBER PR55N21CHE

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	180426	Control Bar	38	160828	Bolt, Shoulder
2	166860X479	Upper Handle	39	83923	Flanged Locknut
3	161105X479	Lower Handle	40	180624	Hubcap
4	179585	Rope Guide	41	88652	Hinge Screw
5	<b>73800400</b>	Locknut 1/4-20	42	165766	Spring (LH)
6	131959	Handle Bolt	43	165767	Spring (RH)
7	66426	Wire Tie	44	<b>185819</b>	Rod
8	161551	Bolt	45	150406	Hex Head Thread Rolling Screw 3/8-16 x 1
9	154132	Hinge Bracket	46	107339X	Danger Decal
10	165754	Mulcher Door	48	180410X004	Axle Arm Assembly - RR
11	130861	Engine Zone Control Cable	52	174161	Housing Assembly (Includes Key Numbers 17, 18 and 46)
12	750634	Hex Washer Head Screw #10-24 x 1/2	53	851084	Hex Head Screw 3/8-24 x 1-3/8 Grade 8
13	850733X004	Up-Stop Bracket	54	850263	Helical Lockwasher
14	170146	Handle Knob	55	851074	Hardened Washer
15	51793	Hairpin Cotter	56	175064	21" Blade
16	147286	Hinge Rod	57	<b>184590</b>	Blade Adapter
17	165946X479	Support Bracket	58	<b>88652</b>	Hinge Screw
18	17600406	Screw	59	<b>751152</b>	Nut, Hex
19	<b>186577X004</b>	Axle Arm Assembly - LF	67	184781	Grass Bag
20	<b>186578X004</b>	Axle Arm Assembly - RF	68	180332	Grass Bag Frame
21	165858	Rear Skirt	70	---	Engine, Honda, Model Number GCV160 (Order parts from Engine Manufacturer)
22	168360X004	Selector Spring - Front	71	185496	Throttle Control
23	<b>186612</b>	Rear Door Assembly Kit (Includes Springs, Key Numbers 42 and 43)	72	<b>183365</b>	Screw
24	<b>73800500</b>	Locknut 5/16-18	73	132004	Nut, Hex
25	<b>186212X479</b>	Handle Bracket Assembly (Left)	74	166785	Nut, Hex
26	<b>186213X479</b>	Handle Bracket Assembly (Right)	75	851856	Screw
27	74780512	Screw 1/4-20 x 3/8	76	57143	Washer
28	152124	Hinge Spring	77	73930500	Nut, Hex
29	160835X007	Wheel Adjusting Bracket - Front	78	157178	Wheel Assembly
30	183901	Washer	79	180660	Hubcap
31	165760	Clip on Discharge Guard	--	162300	Warning Decal (Not Shown)
32	168360X004	Selector Spring - Rear	--	172782	Operator's Manual, English
33	170143	Selector Knob	--	172783	Operator's Manual, French
34	180409X004	Axle Arm Assembly - LR	--	<b>187140</b>	Repair Parts Manual, English/French
35	73990500	Nut, Hex			
36	164362	Shoulder Bolt 5/16-18			
37	180203	Wheel Assembly			

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm