


ROTARY LAWN MOWER -- MODEL NUMBER PR675R21AA




ROTARY LAWN MOWER - - MODEL NUMBER PR675R21AA

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	182724	Handle, Upper, with Grip	40	180026	Grass Catcher Frame
2	161105X479	Handle, Lower	41	107339X	Danger Decal
3	182748	Grip, Foam	57	179783X004	Bracket Assembly
4	179585	Guide, Rope, Side	58	57808	Screw
5	132004	Nut, Hex Lockwasher 1/4-20	59	166042	V-Groove Pulley
6	66426	Wire, Tie	60	166050	Idle Arm Spacer
7	131959	Bolt, Handle 5/16-18 x 2-5/8	61	145212	Flange Nut
8	170176	Knob, Handle	62	155552	Locknut
9	186089	Bail, Wire	63	179719X004	Idle Arm
10	161551	Bolt, Sq. Neck	64	166043	Idle Pulley
11	73990500	Nut, Hex Lockwasher Ins. 5/16-18 UNC	65	160829	Shoulder Bolt
12	51793	Cotter, Hairpin	66	183058	Door Assembly
13	186844	Throttle Control	67	169699	Multi Cut Guard
14	144929	Screw	68	88349	Nut
16	162085	Kit, Door Rear	73	182003	Clip
17	179885	Seal, Door	76	850733X004	Bracket, Upstop
18	182779	Plug, Mulcher	77	750634	Screw
19	181763	Kit, Housing	84	54583	Screw
20	181021X479	Handle, Bracket Asm. Left	85	850848	Key
21	181020X479	Handle, Bracket Asm. Right	86	184941	Pulley
22	150078	Screw, Hex Wshd	87	851074	Washer
23	163183	Bolt, Hex Head 5/16-18 x 5/8	88	850263	Washer, Lock
24	63124	Nut, Hex Lock Wshr 5/16-18	89	184590	Blade Adapter
25	161333	Baffle, Side	90	186063	Debris Shield
26	163409	Screw 12 x 5/8	91	182227	Bolt
27	161550	Skirt	92	182001	Belt Keeper
28	88652	Screw, Hinge 1/4-20 x 1.25	93	182228	Nut, Hex
29	182837	Cable, MZR	--	162300	Warning Decal (Not Shown)
31	175064	Blade, 21"	--	172787	Operator's Manual, English
34	851084	Bolt, Hex Head	--	172788	Operator's Manual, French
37	150406	Bolt, Engine	--	186727	Repair Parts Manual, English / French
38	---	Engine, Briggs & Stratton, Model Number 121602 (Order parts from Engine manufacturer)			
39	182116	Grass Catcher Bag			

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm

ROTARY LAWN MOWER -- MODEL NUMBER PR675R21AA



ROTARY LAWN MOWER - - MODEL NUMBER PR675R21AA

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	181069	EZ Walk Drive Control Assembly	34	180660	Hubcap, Mag Platinum
2	180612	Cable, Drive	35	160785 X004	Shaft Asm. Rear
3	54583	Screw	36	160786X004	Shaft Asm. Front
5	161537	Cover Drive	37	161463	Retainer Front Shaft
6	750634	Screw Thdrol 10-25 x .50	38	163409	Screw 12 x 5/8
7	182212	V-Belt	39	700279	Clip Retainer
8	132010	Nut Lock Flanged 3/8-16 Zinc	40	172323	Wheel 8 x 2
9	184749	Pulley Halves	41	181609	Connector, Lever/Pulley
10	166021X004	Belt Keeper Bracket	42	83923	Nut, Hex Flange Lock 3/8-16
11	17541011	Screw Hex Wash Head 10-24 X .668	43	19572216	Washer
12	181045	Spring, Return, Lever	44	180601	Cover, Top, EZ Walk Drive Control
13	180868	Transmission Assembly	45	181047	Lever, EZ Walk Drive Control
14	145354	Pin Spring Thrust	46	180602	Cover, Bottom, EZ Walk Drive Control
15	57079	Washer Hardened	47	181363X479	Plate, Trigger, EZ Walk Drive Control
16	161584	Rod Connecting	48	181698	Screw, Phillips Head #10-5/8
17	161602	Spring Extension	49	175103	Pinion, Gear
18	160477X004	Spring Selector	50	175102	Retainer, Drive, RH
19	170203	Knob Selector Spring	51	175098	Pawl
20	12000022	E-Ring 7/8	52	175267	Spring, Torsion
21	163365	Bearing Support	53	175104	Disc, Drive
22	169911	Bearing Ball	54	175101	Seal, Friction
23	161118X004	Retainer Drive Asm. Stimp.	55	176412	Pinion/Pawl Assembly, RH
24	57808	Screw Hex Head Tapping 1/4-20 x .75	56	176413	Pinion/Pawl Assembly, LH
25	180604	Pulley, Split, Upper	57	67725	Washer
26	180603	Pulley, Split, Lower	58	175105	Retainer, Drive, LH
27	52160	Washer	59	180606	Screw
28	12000058	E-Ring 7/16	60	52160	Washer
29	180504	Cover, Dust Wheel	61	57079	Washer
31	180607	Spring, Pulley Adjuster			
32	180763	Wheel 9 x 2			
33	145212	Nut Hex Flange Lock			

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm