


ROTARY LAWN MOWER - - MODEL NUMBER PR6N22SHC



ROTARY LAWN MOWER - - MODEL NUMBER PR6N22SHC

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	63601	Locknut 1/4-20	46	83923	Locknut 1/16-18
2	170285	Control Bar	47	143593	Wheel Assembly (Front)
3	179585	Rope Guide	48	57143	Washer
4	172139X479	Upper Handle	50	180660	Hubcap
5	169708X479	Lower Handle	51	74760514	Hex Head Bolt 5/16-18x
6	63601	Locknut 1/4-20	52	150406	Hex Head Thread Rolling Screw 3/8-16 x 1
7	131959	Handle Bolt 5/16-18	55	107339X	Danger Decal
8	144929	Hex Washer Head Screw 1/4-20 x 2-1/8	59	172820	Lawn Mower Housing (Incl. Key Nos. 55)
9	170297	Throttle Control	61	851514	Blade Adapter
11	133107	Engine Zone Control Cable	62	141114	22" Blade
12	750097	Hex Washer Head Screw #10-24 x 1/2	63	851074	Hardened Washer
13	850733X004	Up-Stop Bracket	64	850263	Helical Lockwasher 3/8
14	213146	Cable Clamp	65	851084	Screw Hex Head 3/8-24 x 1-3/8 (Grd. 8)
15	83816	Screw #10 x 5/8	67	---	Engine - Briggs & Stratton (Order parts from engine manufacturer)
16	170146	Handle Knob	70	180409X004	Axle Arm Assembly (LR)
19	51793	Hairpin Cotter	72	167132X004	Axle Arm Assembly (LF)
21	165858	Rear Deflector	73	167133X004	Axle Arm Assembly (RF)
22	66426	Wire Tie	74	751153	Nut
23	160831	Discharge Guard	75	160830	Plate, Mulcher
27	160832	Torsion Spring	76	161622	Clip, Closeout
30	160833	Hinge Rod	77	74760412	Screw
33	63124	Locknut 5/16-18	78	61537	Washer
34	170373X479	Wheel Bracket Support (Left)	79	132004	Nut, Hex
35	170374X479	Wheel Bracket Support (Right)	80	180624	Hubcap
36	160835X007	Wheel Bracket Adjuster	--	172782	Operator's Manual (English)
39	168360X004	Selector Spring	--	172783	Operator's Manual (French)
40	170143	Selector Knob	--	162300	Warning Decal(Not Shown)
41	180410X004	Axle Arm Assembly (RR)	--	181461	Replacement Parts Manua
43	19112222	Washer			
44	160828	Shoulder Bolt			
45	180203	Wheel Assembly (Rear)			

NOTE: All component dimensions given in U.S. inches.
1 inch = 25.4 mm

|