


**ROTARY LAWN MOWER -- MODEL NUMBER SR65N22SHA**



## ROTARY LAWN MOWER -- MODEL NUMBER SR65N22SHA

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	73800400	Locknut 1/4-20	51	74760514	Hex Head Bolt 5/16-18
2	86902	Control Bar	52	150406	Hex Head Thread Rolling Screw 3/8-16 x 1
3	179585	Rope Guide	55	141846	Danger Decal
4	169709X479	Upper Handle	59	<b>164865</b>	Lawn Mower Housing (Includes Key Number 55)
5	169708X479	Lower Handle	61	<b>184590</b>	Blade Adapter
6	132004	Nut, Hex	62	141114	22" Blade
7	131959	Handle Bolt 5/16-18	63	851074	Hardened Washer
11	<b>130861</b>	Engine Zone Control Cable	64	850263	Helical Lockwasher 3/8
12	750634	Hex Washer Head Screw #10-24 x 1/2	65	851084	Screw Hex Head 3/8-24 x 1-3/8 (Grade 8)
13	850733X004	Up-Stop Bracket	67	---	Engine, Briggs & Stratton, Model Number 123K02 (For engine service and replacement parts, call Briggs & Stratton at 1-800-233-3723)
16	136376	Knob			
19	51793	Hairpin Cotter			
21	188987	Rear Deflector	70	180409X004	Axle Arm Assembly, LR
22	66426	Wire Tie	72	186577X004	Axle Arm Assembly, LF
23	160831	Discharge Guard	73	186578X004	Axle Arm Assembly, RF
27	160832	Torsion Spring	74	166785	Nut
30	160833	Hinge Rod	76	161622	Clip, Closeout
33	73800500	Locknut 5/16-18	77	74760412	Screw
34	170373X479	Wheel Bracket Support, LH	79	160830	Mulcher Plate
35	170374X479	Wheel Bracket Support, RH	80	<b>182157</b>	Throttle Control
36	160835X007	Wheel Bracket Adjuster	81	183365	Screw
39	168360X004	Selector Spring	82	111190X	Clamp
40	87877	Selector Knob	83	83816	Screw
41	180410X004	Axle Arm Assembly, RR	85	132004	Nut, Hex
43	183901	Spacer	--	161058	Warning Decal (not shown)
44	160828	Shoulder Bolt	--	172782	Operator's Manual, English
45	<b>190013</b>	Wheel Assembly, Rear	--	172784	Operator's Manual, Spanish
46	83923	Locknut 1/16-18	--	<b>190330</b>	Replacement Parts Manual
47	<b>146247</b>	Wheel Assembly, Front			
50	77400	Hubcap			

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm