


**ROTARY LAWN MOWER -- MODEL NUMBER W4QN22SHD**



**ROTARY LAWN MOWER - - MODEL NUMBER W4QN22SHD**

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	73800400	Locknut 1/4-20	50	77400	Hubcap
2	86902	Control Bar	51	74760514	Hex Head Bolt 5/16-18
3	179585	Rope Guide	52	150406	Hex Head Thread Rolling Screw 3/8-16 x 1
4	169709X479	Upper Handle	55	141846	Danger Decal
5	169708X479	Lower Handle	59	163326	Lawn Mower Housing (Includes Key Number 55)
6	132004	Nut, Hex	61	851514	Blade Adapter
7	131959	Handle Bolt 5/16-18	62	141114	22" Blade
8	<b>188152</b>	O-Ring	63	851074	Hardened Washer
11	851671	Engine Zone Control Cable	64	850263	Helical Lockwasher 3/8
12	750634	Hex Washer Head Screw #10-24 x 1/2	65	851084	Screw Hex Head 3/8-24 x 1-3/8 (Grade 8)
13	850733X004	Up-Stop Bracket	67	- - -	Engine, Briggs & Stratton, Model Number 10K902 (For engine service and replacement parts, call Briggs & Stratton at 1-800-233-3723)
16	136376	Knob	70	180409X004	Axle Arm Assembly, LR
19	51793	Hairpin Cotter	72	186577X004	Axle Arm Assembly, LF
21	<b>188987</b>	Rear Deflector	73	186578X004	Axle Arm Assembly, RF
22	66426	Wire Tie	74	166785	Nut
23	160831	Discharge Guard	76	161622	Clip, Closeout
27	160832	Torsion Spring	77	74760412	Screw
30	160833	Hinge Rod	79	160830	Mulch Plate
33	73800500	Locknut 5/16-18	80	700644	Throttle Control
34	170373X479	Wheel Bracket Support, LH	81	183365	Screw
35	170374X479	Wheel Bracket Support, RH	82	111190X	Clamp
36	160835X007	Wheel Bracket Adjuster	83	83816	Screw
39	168360X004	Selector Spring	85	132004	Nut, Hex
40	87877	Selector Knob	- -	161058	Warning Decal (Not Shown)
41	180410X004	Axle Arm Assembly, RR	- -	172782	Operator's Manual, English
43	183901	Spacer	- -	172784	Operator's Manual, Spanish
44	160828	Shoulder Bolt	- -	<b>190220</b>	Replacement Parts Manual
45	180206	Wheel Assembly, Rear			
46	83923	Locknut 1/16-18			
47	86984	Wheel Assembly, Front			
48	<b>88348</b>	Washer, Flat 3/8			

**NOTE:** All component dimensions given in U.S. inches.  
1 inch = 25.4 mm