


| Ref # | Part Number | Qty | Description                              |
|-------|-------------|-----|--|
|       | 1 36866     | 1   | Cylinder (Incl. 2 & 20)                  |
|       | 2 26727     | 2   | Dowel Pin                                |
|       | 4 31857     | 1   | Oil Drain Extension                      |
|       | 5 30969     | 1   | Extension Cap                            |
|       | 14 28277    | 1   | Washer                                   |
|       | 15 30589    | 1   | Governor Rod                             |
|       | 16 36618    | 1   | Governor Lever                           |
|       | 17 36700    | 1   | Governor Lever Clamp                     |
|       | 18 651028   | 1   | Screw, Torx T-15, 8-32 x 3/8"            |
|       | 30 35975    | 1   | Crankshaft                               |
|       | 35 29826    | 1   | Screw, 10-32 x 3/4"                      |
|       | 36 29918    | 1   | Lock Washer                              |
|       | 37 29216    | 1   | Lock Nut, 10-32                          |
|       | 38 29642    | 1   | Retaining Ring                           |
|       | 40 40004    | 1   | Piston, Pin & Ring Set (Std.)            |
|       | 40 40005    | 1   | Piston, Pin & Ring Set (.010" OS)        |
|       | 41 36070    | 1   | Piston & Pin Ass'y (Std.) (Incl. 43)     |
|       | 41 36071    | 1   | Piston & Pin Ass'y (.010" OS) (Incl. 43) |
|       | 42 40006    | 1   | Ring Set (Std.)                          |
|       | 42 40007    | 1   | Ring Set (.010" OS)                      |
|       | 43 20381    | 2   | Piston Pin Retaining Ring                |
|       | 45 32875A   | 1   | Connecting Rod Ass'y (Incl. 46 & 49)     |
|       | 46 32610A   | 2   | Connecting Rod Bolt                      |
|       | 48 35616    | 2   | Valve Lifter                             |
|       | 49 36611    | 1   | Oil Dipper                               |
|       | 50 36903    | 1   | Camshaft (Incl. 253 & 254)               |
|       | 64 651027   | 1   | Screw, 1/4-20 x 27/32"                   |
|       | 69 36624    | 1   | * Cylinder Cover Gasket                  |
|       | 70 36724    | 1   | Cylinder Cover (Incl. 75 thru 83)        |
|       | 75 27897    | 1   | Oil Seal                                 |
|       | 76 30318    | 1   | Camshaft Seal                            |
|       | 80 30574A   | 1   | Governor Shaft                           |
|       | 81 30590A   | 1   | Washer                                   |
|       | 82 30591    | 1   | Governor Gear Ass'y (Incl. 81)           |
|       | 83 36057    | 1   | Governor Spool                           |
|       | 86 650488   | 8   | Screw, 1/4-20 x 1-1/4"                   |
|       | 89 610961   | 1   | Flywheel Key                             |
| 110B  | 36874       | 1   | Ground Wire                              |
| 119   | 36719       | 1   | * Cylinder Head Gasket                   |
| 120   | 36721       | 1   | Cylinder Head                            |
| 125   | 36471       | 1   | Exhaust Valve (Std.) (Incl. 151)         |
| 125   | 36472       | 1   | Exhaust Valve (1/32" OS) (Incl. 151)     |
| 126   | 37711       | 1   | Intake Valve (Std.) (Incl. 151)          |
| 126   | 29315C      | 1   | Intake Valve (1/32" OS) (Incl. 151)      |
| 130A  | 650999      | 1   | Screw, 5/16-18 x 2-41/64"                |
| 130   | 650912      | 4   | Screw, 5/16-18 x 1-1/2"                  |
| 135   | 34645       | 1   | Resistor Spark Plug (N4C)                |
| 150   | 31672       | 2   | Valve Spring                             |
| 151   | 31673       | 2   | Valve Spring Cap                         |
| 153   | 36649       | 1   | Push Rod Guide                           |
| 154   | 650913      | 2   | Rocker Arm Stud                          |
| 155   | 35624A      | 2   | Rocker Arm                               |
| 157   | 650914      | 2   | Nut, 1/4-28                              |
| 158   | 36629       | 2   | Push Rod                                 |
| 159   | 35626       | 1   | * Rocker Arm Cover Gasket                |
| 160   | 36630A      | 1   | Rocker Arm Cover                         |
| 161A  | 651034      | 1   | Stud                                     |
| 161   | 651008      | 3   | Screw, 1/4-20 x 31/64"                   |

| Ref # | Part Number | Qty | Description                               |
|-------|-------------|-----|---|
| 173   | 37676       | 1   | Breather Tube                             |
| 178   | 650852      | 2   | Nut, 1/4-20                               |
| 182   | 650451      | 2   | Screw, 1/4-20 x 1"                        |
| 183   | 36867       | 1   | Choke Bracket                             |
| 184   | 26756       | 1   | * Carburetor To Intake Pipe Gasket        |
| 185   | 36631       | 1   | Intake Pipe                               |
| 186B  | 36652       | 1   | Choke Spring                              |
| 207   | 36632       | 1   | Throttle Link                             |
| 219   | 36868       | 1   | Choke Rod                                 |
| 220   | 35438       | 1   | Choke Knob                                |
| 222   | 28820       | 2   | Screw, 10-32 x 1/2"                       |
| 223   | 650451      | 2   | Screw, 1/4-20 x 1"                        |
| 224   | 36581       | 1   | * Intake Pipe Gasket                      |
| 253   | 36701       | 1   | Compression Release Weight                |
| 254   | 36702       | 1   | Compression Release Spring                |
| 275   | 36722       | 1   | Muffler                                   |
| 277   | 650988      | 2   | Screw, 1/4-20 x 2-9/32"                   |
| 305   | 35554       | 1   | Oil Fill Tube                             |
| 307   | 35499       | 1   | "O" Ring                                  |
| 308   | 36651       | 1   | Fill Tube Clip                            |
| 309   | 651011      | 1   | Screw, 10-32 x 5/16"                      |
| 310   | 36902       | 1   | Dipstick                                  |
| 328   | 35062       | 2   | Ignition Key                              |
| 329   | 610973      | 1   | Terminal                                  |
| 335   | 36873       | 1   | Carburetor Cover                          |
| 338   | 650821      | 2   | Screw, 10-32 x 1/2"                       |
| 361   | 650738      | 3   | Screw, 1/4-20 x 5/8"                      |
| 364   | 36872       | 1   | Carburetor Cover Bracket                  |
| 365   | 650821      | 2   | Screw, 10-32 x 1/2"                       |
| 370C  | 36501       | 1   | Primer Decal                              |
| 370I  | 34414       | 1   | Warning Decal                             |
| 380   | 640058      | 1   | Carburetor (Incl. 184)                    |
| 396   | 33290E      | 1   | Electric Starter Motor (110 Volt)         |
| 416   | 36085       | 1   | Spark Arrestor Kit (Incl. 417) (Optional) |
| 417   | 650760      | 1   | Screw, 8-32 x 3/8"                        |
| 600   | 651013      | 1   | Washer                                    |



| Ref # | Part Number | Qty | Description  |
|-------|-------------|-----|--|
| 19    | 36710       | 1   | Extension Spring   |
| 20    | 32600       | 1   | Oil Seal   |
| 25A   | 36869       | 1   | Air Baffle (Right)   |
| 25    | 36621       | 1   | Air Baffle (Left)  |
| 26    | 30200       | 1   | Screw, 10-24 x 9/16"   |
| 60    | 36623       | 1   | Blower Housing Extension   |
| 65    | 30200       | 1   | Screw, 10-24 x 9/16"   |
| 90    | 611216      | 1   | Flywheel   |
| 92    | 650815      | 1   | Belleville Washer  |
| 93    | 650816      | 1   | Flywheel Nut   |
| 100   | 34443A      | 1   | Solid State Ignition   |
| 101   | 610118      | 1   | Spark Plug Cover   |
| 103   | 651007      | 2   | Screw, Torx T-15, 10-24 x 15/16"   |
| 110   | 36230       | 1   | Ground Wire  |
| 186   | 36711       | 1   | Governor Link  |
| 200   | 36824       | 1   | Control Bracket (Incl. 206)  |
| 206   | 610973      | 1   | Terminal   |
| 209   | 650821      | 2   | Screw, 10-32 x 1/2"  |
| 215   | 32410       | 1   | Control Knob   |
| 260   | 36901       | 1   | Blower Housing   |
| 261A  | 650821      | 1   | Screw, 10-32 x 1/2"  |
| 261   | 651008      | 1   | Screw, 1/4-20 x 31/64"   |
| 262   | 651008      | 2   | Screw, 1/4-20 x 31/64"   |
| 285   | 35985B      | 1   | Starter Cup  |
| 287   | 651008      | 4   | Screw, 1/4-20 x 31/64"   |
| 290   | 30705       | 1   | Fuel Line  |
| 291   | 29774       | 1   | Fuel Line  |
| 292   | 26460       | 4   | Fuel Line Clamp  |
| 295   | 35857       | 1   | Fuel Shut-Off Valve  |
| 300   | 36863       | 1   | Fuel Tank (Incl. 292 & 301)  |
| 301   | 35355       | 1   | Fuel Cap   |
| 313   | 34080       | 1   | Spacer   |
| 314   | 650873      | 1   | Screw, 1/4-20 x 3/4"   |
| 315   | 611111      | 1   | Alternator Coil (18 Watt) (Incl. 323)  |
| 323   | 611118      | 1   | Terminal   |
| 325   | 29443       | 1   | Wire Clip  |
| 327   | 35392       | 1   | Starter Plug   |
| 341   | 36644       | 1   | Fuel Tank Bracket (Lower)  |
| 342   | 651010      | 2   | Screw, 1/4-20 x 7/8"   |
| 350   | 570682      | 1   | Primer Assembly  |
| 351   | 32180C      | 1   | Primer Line  |
| 355   | 590574      | 1   | Starter Handle (Mitten Grip)   |
| 370A  | 36261       | 1   | Lubrication Decal  |
| 370B  | 36899       | 1   | Control Decal  |
| 390   | 590733      | 1   | Rewind Starter   |
| 400   | 36720       | 1   | * Gasket Set (Incl. items marked PK in notes) Incl. (1) each of 26756, 27272A, 29673, 35626, 36581, 36624, 36719 |