


Engine Parts List #1

Ref #	Part Number	Qty	Description
1	35010	1	Cylinder Ass'y. (Incl. 2 & 20)
2	26727	2	Dowel Pin
6	33734	1	Breather Element
7	34214A	1	Breather Ass'y. (Incl. 6, 8, 9 & 12A)
8	33735	1	Breather Gasket
9	30200	2	Screw & Lockwasher, 10-24 x 9/16"
12A	33886	1	Breather Tube
14	28277	1	Flat Washer
15	30589	1	Governor Rod (Incl. 14)
16	31383A	1	Governor Lever
17	31335	1	Governor Lever Clamp
18	650548	1	Screw, 8-32 x 5/16"
19	31361	1	Extension Spring
20	32600	1	Oil Seal
30	34473A	1	Crankshaft Ass'y.
40	35544A	1	Piston, Pin & Ring Set (Std.)
40	35545A	1	Piston, Pin & Ring Set (.010 OS)
40	35546	1	Piston, Pin & Ring Set (.020 OS)
41	35541	1	Piston & Pin (Std.) (Incl. 43)
41	35542	1	Piston & Pin (.010 OS) (Incl. 43)
41	35543	1	Piston & Pin (.020 OS) (Incl. 43)
42	35547A	1	Ring Set (Std.)
42	35548A	1	Ring Set (.010 OS)
42	35549	1	Ring Set (.020 OS)
43	20381	2	Piston Pin Retaining Ring
45	30963B	1	Connecting Rod Ass'y (Incl. 46)
46	32610A	2	Connecting Rod Screw
48	27241	2	Valve Lifter
50	33148A	1	Camshaft
52	29914	1	Oil Pump Ass'y.
69	35261	1	Mounting Flange Gasket
70	30571A		Mounting Flange (Incl. 72, 75, 80 & 311)
72	30572	1	Oil Drain Plug
75	26208	1	Oil Seal
80	30574	1	Governor Shaft
81	30590A	1	Flat Washer
82	30591	1	Governor Gear Ass'y. (Incl. 81)
83	30588A	1	Governor Spool
84	29193	2	Retaining Ring
86	650488	6	Screw & Lockwasher, 1/4-20 x 1-1/4"
89	611004	1	Flywheel Key
90	611112	1	Flywheel
92	650815	1	Belleville Washer
93	650816	1	Flywheel Nut
100	34443A	1	Solid State Ignition
101	610118	1	Spark Plug Cover
103	650814	2	Screw, Torx T-15, 10-24 x 1"
110	34961	1	Ground Wire
119	33015A	1	Cylinder Head Gasket
120	34342	1	Cylinder Head
125	29313C	1	Exhaust Valve (Std.) (Incl. 151)
125	29315C	1	Exhaust Valve (1/32" OS) (Incl. 151)
126	29314B	1	Intake Valve (Std.) (Incl. 151)
126	29315C	1	Intake Valve (1/32" OS) (Incl. 151)
130	6021A	6	Screw, 5/16-18 x 1-1/2"
130	6021A	2	Screw, 5/16-18 x 1-1/2"
135	35395	1	Spark Plug (RJ19LM/458)
150	31672	2	Valve Spring

Ref #	Part Number	Qty	Description
151	31673	2	Lower Valve Spring Cap
169	27234A	1	Valve Spring Box Gasket
172	32755	1	Valve Spring Box Cover
174	650128	2	Screw & Lockwasher, 10-24 x 1/2"
178	29752	2	Nut & Lockwasher
182	6201	2	Screw, 1/4-28 x 7/8"
184	26756	1	Intake Pipe Gasket
185	31384A	1	Intake Pipe (Incl. 224)
186	34337	1	Governor Spring Link
189	650839	2	Screw, 1/4-20 x 3/8"
190	35831	1	Brake Lever
191	35040B	1	S.E. Brake Bracket (Incl. 195)
192	34966	1	Control Link
193	34965	1	Brake Spring
194	32309	1	Retaining Ring
195	610973	1	Terminal
200	33131A		Control Bracket Ass'y. (Incl. 202 thru 205)
202	33802	1	Compression Spring
203	31342	1	Compression Spring
204	650549	1	Screw, 5-40 x 7/16"
205	650777	1	Screw, 6-32 x 21/32"
207	34336	1	Throttle Link
209	30200	2	Screw & Lockwasher, 10-24 x 9/16"
210	27793	1	Conduit Clip
211	28942	1	Screw & Lockwasher, 10-32 x 3/8"
223	650451	2	Screw & Lockwasher, 1/4-20 x 1"
224	34690A	1	Intake Pipe Gasket
239	34338	1	Air Cleaner Gasket
240	34858	1	Air Cleaner Body
246	34340	1	Air Cleaner Filter
261	30200	2	Screw & Lockwasher, 10-24 x 9/16"
262	650831	2	Screw, 1/4-20 x 1/2"
275	35708	1	Muffler (Incl. 277)
277	650795	2	Screw, 1/4-20 x 2-1/4"
285	35000	1	Starter Hub
290	34357	1	Fuel Line (4.75")
292	26460	1	Fuel Line Clamp
292	26460	1	Fuel Line Clamp
300	32170B	1	Fuel Tank (black) (Incl. 292)
311	27625	1	Oil Filler Plug Ass'y. (Incl. 312)
312	29673	1	Oil Fill Plug Gasket
313	34080	1	Flywheel Key Spacer
327	35392	1	Plug
380	632046A	1	Carburetor (Incl. 184)
400	36207	1	* Gasket Set(Incl. Items Marked PK in Notes.) (Includes Part Nos. 26756(1), 27234A (1), 33015A (1), 33735 (1), 34265 (1), 34338 (1), 34690A (1), 35261 (1).



ILLUSTRATION SHOWS TYPICAL PARTS ONLY. ORDER BY PART NUMBER. PARTS NOT LISTED ARE SUPPLIED BY OEM.



Ref #	Part Number	Qty	Description
260	36212	1	Blower Housing
262	650831	2	Screw, 1/4-20 x 1/2"
287	650884	2	Screw, 8-32 x 1/2"
301	33032	1	Fuel Cap
327	35392	1	Plug
370D	34144	1	Primer Decal
370	34346	1	Lubrication Decal
390	590686	1	Recoil Starter



Ref #	Part Number	Qty	Description
189	650839	2	Screw, 1/4-20 x 3/8"
190	35831	1	Brake Lever
191	35040B	1	S.E. Brake Bracket (Incl. 195)
194	32309	1	Retaining Ring
195	610973	1	Terminal
210	27793	1	Conduit Clip
211	28942	1	Screw & Lockwasher, 10-32 x 3/8"
277	650795	2	Screw, 1/4-20 x 2-1/4"



Ref #	Part Number	Qty	Description
19	31361	1	Extension Spring
69	35261	1	Mounting Flange Gasket
182	6201	2	Screw, 1/4-28 x 7/8"
185	31384A	1	Intake Pipe (Incl. 224)
186	34337	1	Governor Spring Link
209	30200	2	Screw & Lockwasher, 10-24 x 9/16"
223	650451	2	Screw & Lockwasher, 1/4-20 x 1"
243	650806	2	Screw, 10-32 x 5/8"
250	36213	1	Air Cleaner Cover