















Ref #	Part Number	Qty	Description
1	772040		Cover Assembly (Incl. 107, 112, 114 & 117)
3	770045		Case Assembly (Incl. 107, 108, 112 & 117)
5	776065		Output Pinion
6	778036		Output Gear
13A	778079		Side Gear
14A	778078		Pinion Gear
15A	778080		Ring Gear
25	792007		Screw, 1/4-20 x 3/4"
26	792018		Snap Ring
29	780042		Thrust Washer
31	780052		Thrust Washer
31A	780075		Thrust Race
34	786039	2400-2408	Spacer
39	786026	Peerless #1	Dowel Pin
47D	774162		Axle (23" long)
48D	774161		Axle (22-1/8" long)
66	776130		Input Shaft & Pinion
67	776064		Brake Shaft & Gear
69	780007		Thrust Washer
85B	792019		Magnetic Drain Plug
85A	792010		Pipe Plug, 3/8" sq hd.
87	788008		Oil Seal
88	788005		Oil Seal
89	780050		Ball Bearing
96	780039		Thrust Bearing
101A	774142		Differential Carrier (Incl. 139)
102A	774141		Differential Carrier (Incl. 139)
103	792056		Screw, 1/4-20 x 3-1/4"
104	792006		Lockwasher, 1/4"
107	780049		Needle Bearing (capped)
108	780074		Needle Bearing
112	780047		Needle Bearing (capped)
114	780046		Needle Bearing
117	780048		Needle Bearing
124	788023		Case & Cover Gasket
132	778083		Idler Gear
136	XXXXX		Axle Housing (Supplied by OEM)
138	XXXXX		Axle Housing (Supplied by OEM)
139	780041		Bushing
151	786053		Cylindrical Spring (NOTE: This spring is obsolete. It is not required as a replacement part.)
152	786052		Body Core
154	788021		Oil Seal & Retainer (Incl. 87)
155	792037		Screw, 5/16-18 x 1"
155A	792037		Screw, 5/16-18 x 1"
157	786038		Coupling
163	788024		Square Cut Seal
180	730229A		Gear Oil SAE 80W90

6 	VIEW 2 of 2	7 
6A 		7A 
6B 		7B 
6C 		7C 
6D 		7D 
6E 		7E 
6F 		7F 

Ref #	Part Number	Qty	Description
6	778036		Output Gear
13A	778079		Side Gear
14A	778078		Pinion Gear
15A	778080		Ring Gear
31A	780075		Thrust Race
47D	774162		Axle (23" long)
48D	774161		Axle (22-1/8" long)
66	776130		Input Shaft & Pinion
67	776064		Brake Shaft & Gear
69	780007		Thrust Washer
85A	792010		Pipe Plug, 3/8" sq hd.
85B	792019		Magnetic Drain Plug
87	788008	2400-2408	Oil Seal Page 4 of 4
88	788005	Peerless #2	Oil Seal
89	780050		Ball Bearing
96	780039		Thrust Bearing
101A	774142		Differential Carrier (Incl. 139)
102A	774141		Differential Carrier (Incl. 139)
103	792056		Screw, 1/4-20 x 3-1/4"
104	792006		Lockwasher, 1/4"
107	780049		Needle Bearing (capped)
108	780074		Needle Bearing
112	780047		Needle Bearing (capped)
114	780046		Needle Bearing
117	780048		Needle Bearing
124	788023		Case & Cover Gasket
132	778083		Idler Gear
136	XXXXX		Axle Housing (Supplied by OEM)
138	XXXXX		Axle Housing (Supplied by OEM)
139	780041		Bushing
151	786053		Cylindrical Spring (NOTE: This spring is obsolete. It is not required as a replacement part.)
152	786052		Body Core
154	788021		Oil Seal & Retainer (Incl. 87)
155A	792037		Screw, 5/16-18 x 1"
155	792037		Screw, 5/16-18 x 1"
157	786038		Coupling
163	788024		Square Cut Seal
180	730229A		Gear Oil SAE 80W90